

FUSO V14.6 Function list

Note:

√ Functions marked with √ is fully supported and already existed in former software version.

Number Index number of the special function , you can find the name from the special function table.

System	ECU Info.	Read Fault Code	Clear Fault Code	Live Data	Active Test	Special Func
FUSO\Benz FUSO\TRUCK\Super Great\ACM	√	√	√	√	√	0067
FUSO\Benz FUSO\TRUCK\Super Great\CPC	√	√	√	√	√	
FUSO\Benz FUSO\TRUCK\Super Great\MCM	√	√	√	√	√	0028, 0032, 0037, 0038, 0041, 0046, 0047, 0065, 0070, 0071
FUSO\Benz FUSO\TRUCK\Super Great\MCM	√	√	√	√	√	0036, 0042, 0043, 0045, 0068, 0069
FUSO\Benz FUSO\TRUCK\Super Great\MCM	√	√	√	√	√	0001, 0003, 0004, 0006, 0007, 0009, 0011, 0012, 0013, 0014, 0015, 0016, 0017, 0018, 0020, 0021, 0022, 0023, 0024, 0025, 0026, 0027
FUSO\Benz FUSO\TRUCK\Super Great\MCM	√	√	√	√	√	
FUSO\Benz FUSO\TRUCK\Super Great\MCM	√	√	√	√	√	0028, 0037, 0039, 0064
FUSO\Benz FUSO\TRUCK\Super Great\TCM	√	√	√	√		
FUSO\Benz FUSO\TRUCK\Super Great\TCM	√	√	√	√	√	0033, 0044, 0063
FUSO\Benz FUSO\TRUCK\Super Great\TCM	√	√	√	√	√	
FUSO\Benz FUSO\TRUCK\Super Great\ABS	√	√	√	√	√	0044, 0063
FUSO\Benz FUSO\TRUCK\Super Great\ABS	√	√	√	√	√	
FUSO\Benz FUSO\TRUCK\Super Great\ABS	√	√	√	√	√	0040
FUSO\Benz FUSO\TRUCK\Super Great\Retarder	√	√	√			
FUSO\Benz FUSO\TRUCK\Super Great\Retarder	√	√	√	√	√	
FUSO\Benz FUSO\TRUCK\FX\CPC	√	√	√	√	√	
FUSO\Benz FUSO\TRUCK\FX\MCM	√	√	√	√	√	0028, 0032, 0037, 0038, 0041, 0046, 0047, 0065, 0070, 0071
FUSO\Benz FUSO\TRUCK\FX\MCM	√	√	√	√	√	0036, 0042, 0043, 0045, 0068, 0069
FUSO\Benz FUSO\TRUCK\FX\MCM	√	√	√	√	√	0001, 0003, 0004, 0006, 0007, 0009, 0011, 0012, 0013, 0014, 0015, 0016, 0017, 0018, 0020, 0021, 0022, 0023, 0024, 0025, 0026, 0027
FUSO\Benz FUSO\TRUCK\FX\MCM	√	√	√	√	√	
FUSO\Benz FUSO\TRUCK\FX\MCM	√	√	√	√	√	0028, 0037, 0039, 0064
FUSO\Benz FUSO\TRUCK\Fighter\ACM-AdBlue exhaust aftertreatment unit	√	√	√	√	√	0067
FUSO\Benz FUSO\TRUCK\Canter\EEC-Combustion engine Control unit	√	√	√	√	√	0028, 0032, 0037, 0038, 0041, 0046, 0047, 0065, 0070, 0071
FUSO\Benz FUSO\TRUCK\Canter\EEC-Combustion engine Control unit	√	√	√	√	√	0036, 0042, 0043, 0045, 0068, 0069

FUSO\Benz FUSO\TRUCK\Canter\EEC-Combustion engine Control unit	√	√	√	√	√	0001, 0003, 0004, 0006, 0007, 0009, 0011, 0012, 0013, 0014, 0015, 0016, 0017, 0018, 0020, 0021, 0022, 0023, 0024, 0025, 0026, 0027
FUSO\Benz FUSO\TRUCK\Canter\EEC-Combustion engine Control unit	√	√	√	√	√	
FUSO\Benz FUSO\TRUCK\Canter\EEC-Combustion engine Control unit	√	√	√	√	√	0028, 0037, 0039, 0064
FUSO\Benz FUSO\TRUCK\Canter\ABS-Antilock brake system Control unit	√	√	√	√	√	0044, 0063
FUSO\Benz FUSO\TRUCK\Canter\ABS-Antilock brake system Control unit	√	√	√	√	√	
FUSO\Benz FUSO\TRUCK\Canter\ABS-Antilock brake system Control unit	√	√	√	√	√	0040
FUSO\Benz FUSO\TRUCK\Canter\Transmission control module	√	√	√	√		
FUSO\Benz FUSO\TRUCK\Canter\Transmission control module	√	√	√	√	√	0033, 0044, 0063
FUSO\Benz FUSO\TRUCK\Canter\Transmission control module	√	√	√	√	√	
FUSO\Benz FUSO\TRUCK\Canter\Battery control	√	√	√	√		
FUSO\Benz FUSO\TRUCK\Canter\SRS-Supplemental restraint system Control unit	√	√	√			
FUSO\Benz FUSO\TRUCK\Canter\Motor control	√	√	√	√		
FUSO\Benz FUSO\TRUCK\Canter\EZGO-Hill Start Assist Control unit	√	√	√	√	√	
FUSO\Benz FUSO\TRUCK\Canter\HLAL-Control unit 'Automatic headlamp adjustment'	√	√	√	√	√	0044, 0063
FUSO\Benz FUSO\TRUCK\Canter\HVAC-Control and operating unit 'Automotive air conditioning'	√			√	√	
FUSO\Benz FUSO\TRUCK\Canter\ICUC-Instrument panel	√	√	√	√	√	0063
FUSO\Benz FUSO\TRUCK\Canter\IMMO-Immobilizer Control unit	√	√	√	√	√	
FUSO\Benz FUSO\TRUCK\Canter\ISS-Automatic engine start-stop Control unit	√	√	√	√	√	0033, 0067
FUSO\Benz FUSO\TRUCK\Canter\SSAM-Signal Actuator Module	√	√	√	√	√	0063
FUSO\Benz FUSO\TRUCK\Canter\MPC-Multifunction camera	√	√	√	√		
FUSO\Benz FUSO\TRUCK\Canter\Special functions						0034, 0035
FUSO\Benz FUSO\TRUCK\HDT Euro V\CPC-Common powertrain controller(CPC)Control unit(A3)	√	√	√	√	√	
FUSO\Benz FUSO\TRUCK\HDT Euro V\MR2-Combustion engine Control unit(A6)	√	√	√	√	√	0002, 0005, 0008, 0010
FUSO\Benz FUSO\TRUCK\CANTER ECO\EEC-Combustion engine Control unit	√	√	√	√	√	0028, 0032, 0037, 0038, 0041, 0046, 0047, 0065, 0070, 0071
FUSO\Benz FUSO\TRUCK\CANTER ECO\EEC-Combustion engine Control unit	√	√	√	√	√	0036, 0042, 0043, 0045, 0068, 0069
FUSO\Benz FUSO\TRUCK\CANTER ECO\EEC-Combustion engine Control unit	√	√	√	√	√	0001, 0003, 0004, 0006, 0007, 0009, 0011, 0012, 0013, 0014, 0015, 0016, 0017, 0018, 0020, 0021, 0022, 0023, 0024, 0025, 0026, 0027
FUSO\Benz FUSO\TRUCK\CANTER ECO\EEC-Combustion engine Control unit	√	√	√	√	√	
FUSO\Benz FUSO\TRUCK\CANTER ECO\EEC-Combustion engine Control unit	√	√	√	√	√	0028, 0037, 0039, 0064
FUSO\Benz FUSO\TRUCK\CANTER ECO\ABS-Antilock brake system Control unit	√	√	√	√	√	0044, 0063
FUSO\Benz FUSO\TRUCK\CANTER ECO\ABS-Antilock brake system Control unit	√	√	√	√	√	
FUSO\Benz FUSO\TRUCK\CANTER ECO\ABS-Antilock brake system Control unit	√	√	√	√	√	0040
FUSO\Benz FUSO\TRUCK\CANTER ECO\Battery control	√	√	√	√		
FUSO\Benz FUSO\TRUCK\CANTER ECO\Motor control	√	√	√	√		
FUSO\Benz FUSO\TRUCK\CANTER ECO\EZGO-Hill Start Assist Control unit	√	√	√	√	√	
FUSO\Benz FUSO\TRUCK\CANTER ECO\HLAL-Control unit 'Automatic headlamp adjustment'	√	√	√	√	√	0044, 0063
FUSO\Benz FUSO\TRUCK\CANTER ECO\HVAC-Control and operating unit 'Automotive air conditioning'	√			√	√	
FUSO\Benz FUSO\TRUCK\CANTER ECO\ICUC-Instrument panel	√	√	√	√	√	0063

FUSO\Benz FUSO\TRUCK\CANTER ECO\IMMO-Immobilizer Control unit	√	√	√	√	√	
FUSO\Benz FUSO\TRUCK\CANTER ECO\ISS-Automatic engine start-stop Control unit	√	√	√	√	√	0033, 0067
FUSO\Benz FUSO\TRUCK\CANTER ECO\MPC-Multifunction camera	√	√	√	√		
FUSO\Benz FUSO\TRUCK\CANTER ECO\SSAM-Signal Actuator Module	√	√	√	√	√	0063
FUSO\Benz FUSO\TRUCK\CANTER ECO\SRS Airbag	√	√	√	√		
FUSO\Benz FUSO\TRUCK\CANTER ECO\Transmission control module	√	√	√	√		
FUSO\Benz FUSO\TRUCK\CANTER ECO\Transmission control module	√	√	√	√	√	0033, 0044, 0063
FUSO\Benz FUSO\TRUCK\CANTER ECO\Transmission control module	√	√	√	√	√	
FUSO\Benz FUSO\BUS\Aero Ace-Aero Queen\ACM-AdBlue exhaust aftertreatment unit	√	√	√	√	√	0067
FUSO\Benz FUSO\BUS\Aero Ace-Aero Queen\CPC	√	√	√	√	√	
FUSO\Benz FUSO\BUS\Aero Ace-Aero Queen\MCM	√	√	√	√	√	0028, 0032, 0037, 0038, 0041, 0046, 0047, 0065, 0070, 0071
FUSO\Benz FUSO\BUS\Aero Ace-Aero Queen\MCM	√	√	√	√	√	0036, 0042, 0043, 0045, 0068, 0069
FUSO\Benz FUSO\BUS\Aero Ace-Aero Queen\MCM	√	√	√	√	√	0001, 0003, 0004, 0006, 0007, 0009, 0011, 0012, 0013, 0014, 0015, 0016, 0017, 0018, 0020, 0021, 0022, 0023, 0024, 0025, 0026, 0027
FUSO\Benz FUSO\BUS\Aero Ace-Aero Queen\MCM	√	√	√	√	√	
FUSO\Benz FUSO\BUS\Aero Ace-Aero Queen\MCM	√	√	√	√	√	0028, 0037, 0039, 0064
FUSO\Benz FUSO\BUS\Aero Ace MM\ACM-AdBlue exhaust aftertreatment unit	√	√	√	√	√	0067
FUSO\Benz FUSO\BUS\Aero Star\ACM-AdBlue exhaust aftertreatment unit	√	√	√	√	√	0067
FUSO\Benz FUSO\BUS\Aero Midi\ACM-AdBlue exhaust aftertreatment unit	√	√	√	√	√	0067
FUSO\Benz FUSO\BUS\Rosa\Engine control module	√	√	√	√	√	0028, 0032, 0037, 0038, 0041, 0046, 0047, 0065, 0070, 0071
FUSO\Benz FUSO\BUS\Rosa\Engine control module	√	√	√	√	√	0036, 0042, 0043, 0045, 0068, 0069
FUSO\Benz FUSO\BUS\Rosa\Engine control module	√	√	√	√	√	0001, 0003, 0004, 0006, 0007, 0009, 0011, 0012, 0013, 0014, 0015, 0016, 0017, 0018, 0020, 0021, 0022, 0023, 0024, 0025, 0026, 0027
FUSO\Benz FUSO\BUS\Rosa\Engine control module	√	√	√	√	√	
FUSO\Benz FUSO\BUS\Rosa\Engine control module	√	√	√	√	√	0028, 0037, 0039, 0064
FUSO\Benz FUSO\BUS\Rosa\Transmission control module	√	√	√	√		
FUSO\Benz FUSO\BUS\Rosa\Transmission control module	√	√	√	√	√	0033, 0044, 0063
FUSO\Benz FUSO\BUS\Rosa\Transmission control module	√	√	√	√	√	
FUSO\Benz FUSO\BUS\RM\ACM-AdBlue exhaust aftertreatment unit	√	√	√	√	√	0067
FUSO\Mitsubishi FUSO\Engine control module	√	√	√	√	√	0028, 0032, 0037, 0038, 0041, 0046, 0047, 0065, 0070, 0071
FUSO\Mitsubishi FUSO\Engine control module	√	√	√	√	√	0036, 0042, 0043, 0045, 0068, 0069
FUSO\Mitsubishi FUSO\Engine control module	√	√	√	√	√	0001, 0003, 0004, 0006, 0007, 0009, 0011, 0012, 0013, 0014, 0015, 0016, 0017, 0018, 0020, 0021, 0022, 0023, 0024, 0025, 0026, 0027
FUSO\Mitsubishi FUSO\Engine control module	√	√	√	√	√	
FUSO\Mitsubishi FUSO\Engine control module	√	√	√	√	√	0028, 0037, 0039, 0064
FUSO\Mitsubishi FUSO\Transmission control module	√	√	√	√		

FUSO\Mitsubishi FUSO\Transmission control module	√	√	√	√	√	0033, 0044, 0063
FUSO\Mitsubishi FUSO\Transmission control module	√	√	√	√	√	
FUSO\Mitsubishi FUSO\Retarder	√	√	√			
FUSO\Mitsubishi FUSO\Retarder	√	√	√	√	√	
FUSO\Mitsubishi FUSO\SRS Airbag	√	√	√	√		
FUSO\Mitsubishi FUSO\Motor control	√	√	√	√		
FUSO\Mitsubishi FUSO\Battery control	√	√	√	√		
FUSO\Mitsubishi FUSO\Air Suspension	√	√	√	√	√	
FUSO\Mitsubishi FUSO\Integrated control	√	√	√	√	√	
FUSO\Mitsubishi FUSO\Distance Warning	√	√	√	√		
FUSO\Mitsubishi FUSO\ICUC-Instrument panel	√	√	√	√	√	0063
FUSO\Mitsubishi FUSO\Headlamp Auto-Leveling	√	√	√	√		
FUSO\Mitsubishi FUSO\SWS(Smart Writing System)	√	√	√	√		
FUSO\Mitsubishi FUSO\IMMO-Immobilizer Control unit	√	√	√	√	√	
FUSO\Mitsubishi FUSO\EZGO(WHEEL BRAKE SPECIAL SYSTEM)	√	√	√	√	√	
FUSO\Mitsubishi FUSO\EZGO(WHEEL BRAKE SPECIAL SYSTEM)	√	√	√		√	
FUSO\Mitsubishi FUSO\EZGO(WHEEL BRAKE SPECIAL SYSTEM)	√	√	√	√		
FUSO\Mitsubishi FUSO\ISS(Idling Stop and Start System)	√	√	√	√	√	
FUSO\Mitsubishi FUSO\ABS-Antilock brake system Control unit	√	√	√	√	√	0044, 0063
FUSO\Mitsubishi FUSO\ABS-Antilock brake system Control unit	√	√	√	√	√	
FUSO\Mitsubishi FUSO\ABS-Antilock brake system Control unit	√	√	√	√	√	0040
FUSO\Mitsubishi FUSO\BlueTec-SCR(Selective Catalytic Reduction)	√	√	√	√		
FUSO\Mitsubishi FUSO\ISS-Automatic engine start-stop Control unit	√	√	√	√	√	0033, 0067
FUSO\Mitsubishi FUSO\MBECS(Moter vehicle Brake Energy Conservation System)	√	√	√	√		
FUSO\Mitsubishi FUSO\MDAS(Mitsubishi Driver's Attention monitoring System)	√	√	√	√		
FUSO\Mitsubishi FUSO\MILS(Mitsubishi Intelligent Load monitoring System)	√	√	√			
FUSO\Euro 6\EEC-Combustion engine Control unit	√	√	√	√	√	0048, 0049, 0050, 0051, 0052, 0053, 0054, 0055, 0056, 0057, 0058, 0059, 0060, 0061
FUSO\Euro 6\TCM-DUONIC Control unit	√	√	√	√	√	
FUSO\Euro 6\ABS-Antilock brake system Control unit	√	√	√	√	√	
FUSO\Euro 6\SRS-Supplemental restraint system Control unit	√	√	√			
FUSO\Euro 6\ICUC-Instrument panel	√	√	√	√	√	
FUSO\Euro 6\IMMO-Immobilizer Control unit	√	√	√	√		
FUSO\Euro 6\EZGO-Hill Start Assist Control unit	√	√	√	√	√	
FUSO\Euro 6\HLAL-Control unit 'Automatic headlamp adjustment'	√	√	√	√		
FUSO\Euro 6\HVAC-Control and operating unit 'Automotive air conditioning'	√	√	√	√	√	
FUSO\Euro 6\ISS-Automatic engine start-stop Control unit	√	√	√	√	√	
FUSO\Euro 6\SSAM-Signal Actuator Module	√	√	√	√	√	
FUSO\Euro 6\MPC-Multifunction camera	√	√	√			
FUSO\India Bus\India bus(CAN)	√	√	√	√	√	
FUSO\India Bus\India bus(KWP)	√	√	√	√		

Special Function Table

0001	000 Engine oil
0002	000 Injection value unit pumps
0003	000-1 Engine oil Reset
0004	000-2 Fix oil change interval Setting
0005	001 Ignition angle
0006	001 Injection valve (Reset)
0007	002 Pressure limiting valve in rail
0008	002 SCR Calibration
0009	003 Rail pressure sensor
0010	003 SCR Calibration 2
0011	004 Lambda control tester
0012	005 Air mass flow rate / Intake air temperature sensor
0013	006 Turbocharger (Reset)
0014	007 Turbocharger (Learned value)
0015	008 Exhaust gas recirculation valve
0016	009 Starter
0017	010 BlueTec
0018	011 Diesel particulate filter
0019	011 Regeneration of diesel particulate filter
0020	012 Differential pressure sensor of diesel particular filter
0021	013 Data transfer
0022	014 Cancellation of limitation of engine starts
0023	015 Resetting of learned values of Combustion engine Control unit(AdBlue system Error and Scr Group Fault)
0024	016 Injection valve (Learned value)
0025	017 Status of exhaust aftertreamnet
0026	018 Flight recorder
0027	019 Boost pressure/Temperature sensor
0028	A/T Communication Record Reset
0029	AdBlue metering Device
0030	AdBlue quality
0031	AdBlue system
0032	Coding
0033	Coding Tool
0034	Coding_Tools
0035	Coding_Tools2
0036	DPF RESET
0037	DPF Regeneration(Manual)
0038	DPF Related Information Reset
0039	Diesel Particulate filter (DPF) reset
0040	ECU RESET
0041	ECU Reset

0042	EGR RESET
0043	High pressure line RESET
0044	Manual settings
0045	NOx RESET
0046	Program
0047	Reset ECU
0048	Reset of AdBlue metering device value
0049	Reset of DPF learned value
0050	Reset of EGR valve learned value
0051	Reset of air mass flow rate/intake air temperature sensor learned value
0052	Reset of differential pressure sensor of DPF learned value
0053	Reset of fuel injector learned value
0054	Reset of lambda control tester learned value
0055	Reset of learned values of combustion engine control unit(Fault in AdBlue system)
0056	Reset of oil monitoring
0057	Reset of pressure limiting valve in rail learned value
0058	Reset of rail pressure sensor learned value
0059	Reset of starter learned value
0060	Reset of turbocharger learned value
0061	Resetting of learned values of component'SCR catalytic converter'
0062	SCR Catalytic Converter
0063	Sachunmmer Mitsubishi
0064	Supply Pump Initialization
0065	Supply Pump Learned Value -Initialization
0066	Supply Pump Learned Value-Initialization
0067	Teach-in processes
0068	VGT RESET
0069	VIN
0070	VIN information
0071	Write VIN