

ISUZU V13.65 Function list

Note:

√ Functions marked with √ is fully supported and already existed in former software version.

Number Index number of the special function , you can find the name from the special function table.

System	ECU Info.	Read Fault Code	Clear Fault Code	Live Data	Active Test	Special Func
ISUZU\ISUZU series\CANBUS engine default system	√	√	√	√		
ISUZU\ISUZU series\N Series Truck\Engine\4HK1-TC(C-Rail)	√	√	√	√		
ISUZU\ISUZU series\N Series Truck\Engine\4JJ1-TC(C-Rail)	√	√	√	√		
ISUZU\ISUZU series\N Series Truck\Engine\4JH1-4KH1	√	√	√	√		0401, 0405, 0409, 0413, 0514
ISUZU\ISUZU series\N Series Truck\Engine\4HK1-TC <C-Rail_NLT>	√	√	√	√	√	0108, 0119, 0129, 0139, 0149, 0208, 0209, 0275, 0300, 0313, 0337, 0357, 0387, 0392, 0596, 0683
ISUZU\ISUZU series\N Series Truck\Engine\4HK1-4JJ1 <C-Rail_Euro2>	√	√	√	√		0209, 0275, 0313, 0337, 0392, 0582, 0683
ISUZU\ISUZU series\N Series Truck\Engine\4HK1-4JJ1 <C-Rail_Euro3>	√	√	√	√		0209, 0275, 0313, 0337, 0392, 0582, 0683
ISUZU\ISUZU series\N Series Truck\Engine\4HV1 CNG	√	√	√	√	√	0009, 0272, 0280, 0694
ISUZU\ISUZU series\N Series Truck\Engine\4JH1-TC Bosch 2008	√	√	√	√	√	0236, 0392, 0559
ISUZU\ISUZU series\N Series Truck\Engine\4JJ1-TC C,Rail_NLT	√	√	√	√	√	0108, 0119, 0129, 0139, 0149, 0208, 0209, 0275, 0300, 0313, 0337, 0357, 0387, 0392, 0596, 0683
ISUZU\ISUZU series\N Series Truck\Engine\Idle stop BCM				√	√	
ISUZU\ISUZU series\N Series Truck\Engine\Hybrid system		√	√	√		
ISUZU\ISUZU series\N Series Truck\Engine\4HL1-4HJ1	√	√	√	√		
ISUZU\ISUZU series\N Series Truck\Engine\4JG2<LPG>	√	√	√	√		0079, 0080, 0085, 0328
ISUZU\ISUZU series\N Series Truck\Engine\4JG2	√	√	√	√		0223
ISUZU\ISUZU series\N Series Truck\Engine\4HG1<LPG>	√	√	√	√		0079, 0080, 0085, 0328
ISUZU\ISUZU series\N Series Truck\Engine\Denso 4HG1 (ECD-V4)\Denso 4HG1 (ECD-V4) ENG	√	√	√	√		
ISUZU\ISUZU series\N Series Truck\Engine\Denso 4HG1 (ECD-V4)\Denso 4HG1 (ECD-V4) HSA	√	√	√	√		
ISUZU\ISUZU series\N Series Truck\Engine\MIMAMORI		√	√	√		0073, 0083, 0098, 0619, 0679, 0680, 0681
ISUZU\ISUZU series\N Series Truck\Engine\4HF1<CNG>	√	√	√	√	√	0079, 0080, 0085, 0328
ISUZU\ISUZU series\N Series Truck\Engine\4HL1-4HJ1 (Vehicle Interface Module)	√			√		
ISUZU\ISUZU series\N Series Truck\Body\Immobiliser	√	√	√	√		
ISUZU\ISUZU series\N Series Truck\Body\SRS		√	√	√		
ISUZU\ISUZU series\N Series Truck\Body\Body control module		√	√	√		0041, 0106, 0206, 0207, 0440, 0593, 0696
ISUZU\ISUZU series\N Series Truck\Body\Driving Safety Reference	√			√		0006
ISUZU\ISUZU series\N Series Truck\Transmission\AT A460	√	√	√	√		0028, 0053, 0268, 0467, 0468, 0469, 0470, 0536, 0625, 0636, 0637, 0638
ISUZU\ISUZU series\N Series Truck\Transmission\Smother - Smother-Ex		√	√	√		
ISUZU\ISUZU series\N Series Truck\Transmission\Smother -Smother-Fx		√	√	√		

ISUZU\ISUZU series\N Series Truck\Transmission\Smother-E		√	√	√		
ISUZU\ISUZU series\N Series Truck\Transmission\Smother-Smother-E Auto Shift		√	√	√		
ISUZU\ISUZU series\N Series Truck\Chassis\ABS-ASR		√	√	√		
ISUZU\ISUZU series\N Series Truck\Information System\MIMAMORI		√	√	√		0086, 0087, 0088, 0089, 0173, 0310, 0311, 0679, 0680
ISUZU\ISUZU series\F&G Series Truck\Engine_F4HK1_TC_C_Rail_F	√	√	√	√		
ISUZU\ISUZU series\F&G Series Truck\Engine_F6HK1-TC(C-Rail)	√	√	√	√		
ISUZU\ISUZU series\F&G Series Truck\Engine_F6HK1-TC	√	√	√	√		
ISUZU\ISUZU series\F&G Series Truck\Engine_F6HK1_TC(Europe V)	√	√	√	√		
ISUZU\ISUZU series\F&G Series Truck\Engine_F6HK1_TC_C_Rail_2	√	√	√	√		
ISUZU\ISUZU series\F&G Series Truck\Engine_F4HK1-TC <C-Rail_NLT>	√	√	√	√	√	0108, 0119, 0129, 0139, 0149, 0208, 0209, 0275, 0300, 0313, 0337, 0357, 0387, 0392, 0596, 0683
ISUZU\ISUZU series\F&G Series Truck\Engine_F4HK1-6HK1 <C-Rail_Euro2>	√	√	√	√	√	0119, 0129, 0139, 0149, 0209, 0275, 0313, 0337, 0357, 0392, 0683
ISUZU\ISUZU series\F&G Series Truck\Engine_F4HK1-6HK1 <C-Rail_Euro3>	√	√	√	√	√	0209, 0275, 0313, 0337, 0357, 0392, 0683
ISUZU\ISUZU series\F&G Series Truck\Engine_F\Idle stop BCM				√	√	
ISUZU\ISUZU series\F&G Series Truck\Engine_F6UZ1-TC <C-Rail_Euro3>	√	√	√	√	√	0209, 0275, 0313, 0337, 0357, 0392, 0683
ISUZU\ISUZU series\F&G Series Truck\Engine_F6HK1-TC <C-Rail_NLT>	√	√	√	√	√	0108, 0119, 0129, 0139, 0149, 0208, 0209, 0275, 0300, 0313, 0337, 0357, 0387, 0392, 0596, 0599, 0683
ISUZU\ISUZU series\F&G Series Truck\Engine_F6UZ1-TC (Common rail) engine	√	√	√	√		0119, 0129, 0139, 0149, 0159, 0162, 0184, 0185, 0186, 0204, 0344
ISUZU\ISUZU series\F&G Series Truck\Engine_F6UZ1-TC (Common rail)	√	√	√	√		
ISUZU\ISUZU series\F&G Series Truck\Body\Immobliser	√	√	√	√		
ISUZU\ISUZU series\F&G Series Truck\Body\SRS		√	√	√		
ISUZU\ISUZU series\F&G Series Truck\Body\Body control module		√	√	√		0041, 0106, 0206, 0207, 0440, 0593, 0696
ISUZU\ISUZU series\F&G Series Truck\Transmission\Automatic Transmission	√	√	√	√		
ISUZU\ISUZU series\F&G Series Truck\Information System\Speedometer Control Equipment				√		
ISUZU\ISUZU series\F&G Series Truck\Information System\MIMAMORI		√	√	√		0086, 0087, 0088, 0089, 0173, 0310, 0311, 0679, 0680
ISUZU\ISUZU series\C&E Series Truck\Engine\6WG1-TC(C-Rail)	√	√	√	√		
ISUZU\ISUZU series\C&E Series Truck\Engine\6WG1-TC2 (Common rail)	√	√	√	√		
ISUZU\ISUZU series\C&E Series Truck\Engine\6UZ1-TC <C-Rail_NLT>	√	√	√	√	√	0119, 0129, 0139, 0149, 0208, 0209, 0300, 0313, 0337, 0357, 0387, 0392, 0596, 0599, 0683
ISUZU\ISUZU series\C&E Series Truck\Body\Driving Safety Reference	√			√		0006
ISUZU\ISUZU series\C&E Series Truck\Chassis\Air Suspension	√	√	√	√		0045, 0046, 0308, 0309, 0367, 0451
ISUZU\ISUZU series\C&E Series Truck\Chassis\Millimeter Wavelength Radar Cruise		√	√	√		0019, 0020, 0043, 0044, 0047, 0196, 0205, 0210, 0246, 0253, 0447, 0533, 0534, 0579, 0648, 0649, 0650, 0651, 0668, 0678, 0689, 0690

ISUZU\ISUZU series\C&E Series Truck\Chassis\Hydraulic pressure retarder	√			√		
ISUZU\ISUZU series\C&E Series Truck\Information System\MIMAMORI		√	√	√		0021, 0074, 0083, 0098, 0263, 0619, 0641, 0679, 0681
ISUZU\ISUZU series\LT-LV Series Bus\Engine\6HK1-TC(C-Rail)	√	√	√	√		
ISUZU\ISUZU series\LT-LV Series Bus\Engine\6UZ1-TC <C-Rail_Euro3>	√	√	√	√	√	0209, 0275, 0313, 0337, 0357, 0392, 0683
ISUZU\ISUZU series\LT-LV Series Bus\Engine\6HK1-TC <C-Rail_Euro3>	√	√	√	√	√	0209, 0275, 0313, 0337, 0357, 0392, 0683
ISUZU\ISUZU series\LT-LV Series Bus\Transmission\Automatic Transmission	√	√	√	√		
ISUZU\ISUZU series\ (C*,E*,L*,F*)Heavy-Medium Duty\Engine\6WF1-TC(C-Rail)	√	√	√	√		
ISUZU\ISUZU series\ (C*,E*,L*,F*)Heavy-Medium Duty\Chassis\ESC(with EBS)	√	√	√	√		
ISUZU\ISUZU series\ (C*,E*,L*,F*)Heavy-Medium Duty\Chassis\ABS 6	√	√	√	√		0022, 0025, 0026, 0294, 0379, 0460, 0462, 0605, 0607
ISUZU\ISUZU series\ (C*,E*,L*,F*)Heavy-Medium Duty\Chassis\ABS-ASR ADVICS		√	√	√		
ISUZU\ISUZU series\ (C*,E*,L*,F*)Heavy-Medium Duty\Chassis\ABS-ASR		√	√	√		
ISUZU\ISUZU series\ (C*,E*,L*,F*)Heavy-Medium Duty\Transmission\AT Allison Lct		√	√	√		
ISUZU\ISUZU series\KV-KR Bus Series\Chassis\ABS 6	√	√	√	√		0022, 0025, 0026, 0294, 0379, 0460, 0462, 0605, 0607
ISUZU\ISUZU series\Off-Road Industrial Engine\Engine\4JJ1-TC <C-Rail_Tier3>	√	√	√	√	√	0093, 0209, 0337, 0357, 0392, 0431, 0683
ISUZU\ISUZU series\Off-Road Industrial Engine\Engine\4HK1-TC <C-Rail_Tier3>	√	√	√	√	√	0093, 0209, 0337, 0357, 0392, 0431, 0683
ISUZU\ISUZU series\Off-Road Industrial Engine\Engine\6HK1-TC <C-Rail_Tier3>	√	√	√	√	√	0093, 0209, 0337, 0357, 0392, 0431, 0683
ISUZU\ISUZU series\Off-Road Industrial Engine\Engine\6UZ1-TC <C-Rail_Tier3>	√	√	√	√	√	0093, 0209, 0337, 0357, 0392, 0431, 0683
ISUZU\ISUZU series\Off-Road Industrial Engine\Engine\6WG1-TC <C-Rail_Tier3>	√	√	√	√	√	0093, 0209, 0337, 0357, 0392, 0431, 0683
ISUZU\QingLing ISUZU series\Engine System\Euro IV	√	√	√	√		
ISUZU\QingLing ISUZU series\Engine System\6HK1-TC	√	√	√	√		0236, 0260, 0559, 0562, 0645
ISUZU\QingLing ISUZU series\Engine System\6HK1-TC(as of 2007)		√	√	√		0121, 0131, 0141, 0151, 0160, 0163, 0200, 0201, 0232, 0276, 0296, 0339, 0395, 0401, 0403, 0405, 0407, 0409, 0411, 0413, 0415, 0417, 0418, 0419, 0420, 0432, 0442, 0495, 0496, 0514, 0551, 0565, 0675
ISUZU\QingLing ISUZU series\Engine System\6HL1	√	√	√	√		0296, 0314, 0398, 0434, 0489, 0557, 0598
ISUZU\QingLing ISUZU series\Engine System\6UZ1 Engine(Euro 5)	√	√	√	√		0121, 0131, 0141, 0151, 0200, 0201, 0215, 0276, 0296, 0339, 0401, 0404, 0405, 0408, 0409, 0412, 0413, 0416, 0439, 0495, 0496, 0514, 0515, 0547, 0551, 0676
ISUZU\QingLing ISUZU series\Engine System\6W*1-TC<C-Rail_DLT 3pin>	√	√	√	√	√	0199, 0224, 0286, 0437, 0698, 0699, 0700, 0701, 0702
ISUZU\QingLing ISUZU series\Engine System\6WF1-TC Engine System	√	√	√	√		0127, 0137, 0147, 0157, 0161, 0164, 0226, 0227, 0228, 0229, 0286, 0600

ISUZU\QingLing ISUZU series\Engine System\6WF1-TC	√	√	√	√		0288, 0314, 0343, 0398, 0434, 0489, 0557, 0598
ISUZU\QingLing ISUZU series\Engine System\6WG1-TC	√	√	√	√		0198, 0287, 0299, 0430, 0435, 0548, 0553, 0677
ISUZU\QingLing ISUZU series\Engine System\6WG1-TC(as of 2007)		√	√	√		0197, 0270, 0299, 0356, 0429, 0434, 0552, 0677
ISUZU\QingLing ISUZU series\Engine System\4JB1-TC engine(100P)		√	√	√		
ISUZU\QingLing ISUZU series\Engine System\4JB1-TCT-TC1 (100P)	√	√	√	√		
ISUZU\QingLing ISUZU series\Engine System\ISUZU 4JB1_100P National IV	√	√	√	√		0008, 0042, 0109, 0110, 0111, 0231, 0261, 0336, 0492, 0513, 0563, 0566
ISUZU\QingLing ISUZU series\Engine System\4JB1IT Engine (Bosch Diesel)		√	√	√		0008, 0030, 0104, 0105, 0170, 0230, 0262, 0301, 0302, 0315, 0370, 0464, 0465, 0511, 0571, 0654, 0663, 0665
ISUZU\QingLing ISUZU series\Engine System\4KH1_TCG40	√	√	√	√		0401, 0405, 0409, 0413, 0514
ISUZU\QingLing ISUZU series\Engine System\600P 4KH1-TC engine	√	√	√	√		0239
ISUZU\QingLing ISUZU series\Engine System\4HK1 Euro IV (2011 N series)	√	√	√	√		
ISUZU\QingLing ISUZU series\Engine System\4HK1-TC (C-Rail_NLT) 700P		√	√	√	√	0108, 0119, 0129, 0139, 0149, 0208, 0209, 0275, 0300, 0313, 0337, 0357, 0387, 0392, 0596, 0683
ISUZU\QingLing ISUZU series\Engine System\4HK1-TC (Euro IV)	√	√	√	√		0119, 0129, 0139, 0149, 0184, 0185, 0186, 0235, 0276, 0297, 0339, 0395, 0401, 0405, 0409, 0413, 0514, 0547, 0551, 0662, 0676
ISUZU\QingLing ISUZU series\Engine System\4HK1-TC(Euro 5)	√	√	√	√		0121, 0131, 0141, 0151, 0200, 0201, 0215, 0276, 0296, 0339, 0401, 0404, 0405, 0408, 0409, 0412, 0413, 0416, 0439, 0495, 0496, 0514, 0515, 0547, 0551, 0676
ISUZU\QingLing ISUZU series\Engine System\4HK1-TC (North America)\Engine system	√	√	√	√		0107, 0114, 0116, 0122, 0132, 0142, 0152, 0276, 0356, 0485, 0537, 0576, 0660, 0692
ISUZU\QingLing ISUZU series\Engine System\4HK1-TC (North America)\ABS	√	√	√	√		
ISUZU\QingLing ISUZU series\Engine System\4HK1-TC (North America)\AT	√	√	√	√		0055, 0630, 0631, 0639, 0658
ISUZU\QingLing ISUZU series\Engine System\4HK1-6HK1 Crail_Euro2	√	√	√	√		0275, 0314, 0342, 0438, 0557
ISUZU\QingLing ISUZU series\Engine System\4HK1-6HK1 Crail_Euro3	√	√	√	√		0275, 0314, 0342, 0438, 0557
ISUZU\QingLing ISUZU series\Engine System\DISEL_CR_EDC_4HK1	√	√	√	√		
ISUZU\QingLing ISUZU series\Engine System\DISEL_CR_EDC_4JJ1	√	√	√	√		
ISUZU\QingLing ISUZU series\Engine System\N series trucks\4HK1-4JJ1 CRail_Euro2	√	√	√	√		0119, 0129, 0139, 0149, 0275, 0340, 0357, 0397, 0446, 0488, 0552, 0581, 0674
ISUZU\QingLing ISUZU series\Engine System\N series trucks\4HK1-4JJ1 CRail_Euro3	√	√	√	√		0119, 0129, 0139, 0149, 0224, 0275, 0340, 0357, 0397, 0446, 0488, 0552, 0581, 0674
ISUZU\QingLing ISUZU series\Engine System\N series trucks\4HV1 CNG	√	√	√	√		0009, 0070, 0091, 0097, 0102, 0250, 0280, 0281, 0333, 0334, 0393, 0400, 0594, 0694
ISUZU\QingLing ISUZU series\Engine System\4JH1 diesel engine	√	√	√	√		0239
ISUZU\QingLing ISUZU series\Engine System\4JH1_TC (as of 2011)		√	√	√		0051, 0321, 0491
ISUZU\QingLing ISUZU series\Engine System\4JH1_TC	√	√	√	√		0217, 0256, 0479, 0558, 0559, 0645

ISUZU\QingLing ISUZU series\Engine System\4JH1-TC1		√	√	√		
ISUZU\QingLing ISUZU series\Engine System\4JH1-Tds		√	√	√		0123, 0133
ISUZU\QingLing ISUZU series\Engine System\4JH1-T DENSO	√	√	√	√	√	0199, 0224, 0286, 0437, 0698, 0699, 0700, 0701, 0702
ISUZU\QingLing ISUZU series\Engine System\4JJ1-TC 3.0L		√	√	√	√	0356, 0492, 0554, 0686, 0698, 0699, 0700
ISUZU\QingLing ISUZU series\Engine System\4JJ1-TC 3.0 (Delphi)	√	√	√	√		0354, 0358, 0401, 0405, 0409, 0413, 0486, 0551, 0616, 0676
ISUZU\QingLing ISUZU series\Engine System\4JJ1-TC(Euro 4)	√	√	√	√		0121, 0131, 0141, 0151, 0200, 0201, 0215, 0276, 0296, 0339, 0401, 0404, 0405, 0408, 0409, 0412, 0413, 0416, 0439, 0495, 0496, 0514, 0515, 0547, 0551, 0676
ISUZU\QingLing ISUZU series\Engine System\4JK1-TC 2.5L		√	√	√	√	0356, 0492, 0554, 0686, 0698, 0699, 0700
ISUZU\QingLing ISUZU series\Engine System\4JX1(3.0 L4)	√	√	√	√		
ISUZU\QingLing ISUZU series\Engine System\4JG2 (LPG)	√	√	√	√		0081, 0092, 0099, 0335
ISUZU\QingLing ISUZU series\Engine System\4HG1 (LPG)	√	√	√	√		0081, 0092, 0099, 0307, 0335, 0379, 0384
ISUZU\QingLing ISUZU series\Engine System\4HL_TC	√	√	√	√		0124, 0125, 0134, 0135, 0144, 0145, 0154, 0155, 0216, 0287, 0359, 0553
ISUZU\QingLing ISUZU series\Engine System\4HL1	√	√	√	√		
ISUZU\QingLing ISUZU series\Engine System\4HL1-NA		√	√	√		0270, 0356, 0433, 0436, 0554
ISUZU\QingLing ISUZU series\Engine System\4HJ1-TC		√	√	√		0123, 0133, 0143, 0153, 0550
ISUZU\QingLing ISUZU series\Engine System\4HJ1	√	√	√	√		0238, 0425, 0426, 0427, 0428
ISUZU\QingLing ISUZU series\Engine System\Perkins		√	√	√		0008, 0104, 0105, 0169, 0170, 0230, 0262, 0301, 0302, 0315, 0370, 0464, 0465, 0511, 0571, 0654, 0663, 0665
ISUZU\QingLing ISUZU series\Engine System\Qingling 100P BOSCH EDC17C55 system_national IV	√	√	√	√		0233, 0292, 0380, 0389, 0546, 0549, 0590, 0618
ISUZU\QingLing ISUZU series\Engine System\4ZE3-4ZE4 Engine	√	√	√	√		0007, 0038, 0039, 0052, 0126, 0136, 0146, 0156, 0303, 0304, 0321, 0338, 0377, 0491, 0524, 0659, 0684
ISUZU\QingLing ISUZU series\Engine System\4HF1(CNG)	√	√	√	√		0084, 0090, 0095, 0331, 0332
ISUZU\QingLing ISUZU series\Engine System\BOSCH Diesel Engine		√	√	√		0008, 0030, 0104, 0105, 0169, 0230, 0262, 0301, 0302, 0370, 0385, 0386, 0512, 0555, 0570, 0654, 0663, 0664
ISUZU\QingLing ISUZU series\Transmission System\4HK1-TC Transmission		√	√	√		0029, 0057, 0271, 0471, 0472, 0473, 0474, 0539, 0632, 0633, 0634, 0635
ISUZU\QingLing ISUZU series\Transmission System\4HK1_TC(AT)		√	√	√		
ISUZU\QingLing ISUZU series\Transmission System\ELF truck Smoother (Ex) Transmission		√	√	√		0538
ISUZU\QingLing ISUZU series\Transmission System\Smoother		√	√	√		0028, 0053, 0268, 0467, 0468, 0469, 0470, 0536, 0538, 0625, 0636, 0637, 0638
ISUZU\QingLing ISUZU series\Chassis\6WF1 ABS system	√	√	√	√		0023, 0024, 0027, 0290, 0378, 0517, 0518, 0519, 0520
ISUZU\QingLing ISUZU series\Chassis\4HK1-TC ABS		√	√	√		0022, 0025, 0026, 0294, 0379, 0460, 0462, 0605, 0607
ISUZU\QingLing ISUZU series\Chassis\ABS2	√	√	√	√		

ISUZU\QingLing ISUZU series\Chassis\Chassis electronic suspension control (With electronic brake system)		√	√	√		
ISUZU\QingLing ISUZU series\Chassis\Hill Start Assist-fuel shutoff at forced idle conditions	√	√	√	√		
ISUZU\QingLing ISUZU series\Body\Immobilizer	√	√	√	√		
ISUZU\QingLing ISUZU series\Body\Airbag	√	√	√	√		
ISUZU\ELF series\Engine System\4HK1-TC (Euro 2-3)	√	√	√	√		0033, 0270, 0295, 0356, 0429, 0436, 0554
ISUZU\ELF series\Engine System\4JJ1-TC(Euro 4)	√	√	√	√		0121, 0131, 0141, 0151, 0200, 0201, 0215, 0276, 0296, 0339, 0401, 0404, 0405, 0408, 0409, 0412, 0413, 0416, 0439, 0495, 0496, 0514, 0515, 0547, 0551, 0676
ISUZU\ELF series\Engine System\4JJ1-TC (Euro 5)	√	√	√	√		0121, 0131, 0141, 0151, 0200, 0201, 0215, 0276, 0296, 0339, 0401, 0404, 0405, 0408, 0409, 0412, 0413, 0416, 0439, 0495, 0496, 0514, 0515, 0547, 0551, 0676
ISUZU\ELF series\Engine System\4HK1-TC (Euro IV)	√	√	√	√		0119, 0129, 0139, 0149, 0184, 0185, 0186, 0235, 0276, 0297, 0339, 0395, 0401, 0405, 0409, 0413, 0514, 0547, 0551, 0662, 0676
ISUZU\ELF series\Engine System\4HK1-TC(Euro 5)	√	√	√	√		0121, 0131, 0141, 0151, 0200, 0201, 0215, 0276, 0296, 0339, 0401, 0404, 0405, 0408, 0409, 0412, 0413, 0416, 0439, 0495, 0496, 0514, 0515, 0547, 0551, 0676
ISUZU\ELF series\Engine System\4HK1-TC (North America)	√	√	√	√		0107, 0114, 0116, 0122, 0132, 0142, 0152, 0276, 0356, 0485, 0537, 0576, 0660, 0692
ISUZU\ELF series\Engine System\4JB1CN(national IV 100P)	√	√	√	√		0008, 0042, 0109, 0110, 0111, 0231, 0261, 0336, 0492, 0513, 0563, 0566
ISUZU\ELF series\ABS(North America)	√	√	√	√		
ISUZU\North American ISUZU series\2017\N-Series w-5.2L Diesel (4HK1)\Engine	√	√	√	√		0075, 0082, 0112, 0113, 0189, 0191, 0242, 0264, 0269, 0349, 0351, 0375, 0401, 0405, 0409, 0413, 0490, 0535, 0617, 0652
ISUZU\North American ISUZU series\2017\N-Series w-5.2L Diesel (4HK1)\Transmission	√	√	√	√		0054, 0467, 0468, 0469, 0470, 0521, 0620, 0622, 0624, 0625, 0667
ISUZU\North American ISUZU series\2017\N-Series w-5.2L Diesel (4HK1)\ABS	√	√	√	√		
ISUZU\North American ISUZU series\2017\N-Series w-5.2L Diesel (4HK1)\Diesel Exhaust Fluid Control Module	√	√	√	√		0174, 0175, 0176, 0177, 0178, 0187, 0240, 0497, 0498, 0522, 0610
ISUZU\North American ISUZU series\2017\N-Series w-5.2L Diesel (4HK1)\Mimanori ECU	√	√	√	√		
ISUZU\North American ISUZU series\2017\N-Series w-5.2L Diesel (4HK1)\FMS CAN converter(if equipped)	√	√	√	√		
ISUZU\North American ISUZU series\2017\Stripped Chassis w-3.0L Diesel(4JJ1)\Engine	√	√	√	√		0075, 0077, 0112, 0113, 0189, 0191, 0219, 0264, 0269, 0349, 0351, 0375, 0401, 0405, 0409, 0413, 0490, 0535, 0617
ISUZU\North American ISUZU series\2017\Stripped Chassis w-3.0L Diesel(4JJ1)\Transmission	√	√	√	√		0054, 0467, 0468, 0469, 0470, 0521, 0620, 0622, 0624, 0625, 0667

ISUZU\North American ISUZU series\2017\Stripped Chassis w-3.0L Diesel(4JJ1)\ABS	√	√	√	√		
ISUZU\North American ISUZU series\2017\Stripped Chassis w-3.0L Diesel(4JJ1)\Diesel Exhaust Fluid Control Module	√	√	√	√		0174, 0175, 0176, 0177, 0178, 0187, 0240, 0497, 0498, 0522, 0610
ISUZU\North American ISUZU series\2017\Stripped Chassis w-3.0L Diesel(4JJ1)\Mimanori ECU	√	√	√	√		
ISUZU\North American ISUZU series\2017\Stripped Chassis w-3.0L Diesel(4JJ1)\FMS CAN converter(if equipped)	√	√	√	√		
ISUZU\North American ISUZU series\2017\N-Series w-3.0L Diesel (4JJ1)\Engine	√	√	√	√		0075, 0077, 0112, 0113, 0189, 0191, 0219, 0264, 0269, 0349, 0351, 0375, 0401, 0405, 0409, 0413, 0490, 0535, 0617
ISUZU\North American ISUZU series\2017\N-Series w-3.0L Diesel (4JJ1)\Transmission	√	√	√	√		0054, 0467, 0468, 0469, 0470, 0521, 0620, 0622, 0624, 0625, 0667
ISUZU\North American ISUZU series\2017\N-Series w-3.0L Diesel (4JJ1)\ABS	√	√	√	√		
ISUZU\North American ISUZU series\2017\N-Series w-3.0L Diesel (4JJ1)\Diesel Exhaust Fluid Control Module	√	√	√	√		0174, 0175, 0176, 0177, 0178, 0187, 0240, 0497, 0498, 0522, 0610
ISUZU\North American ISUZU series\2017\N-Series w-3.0L Diesel (4JJ1)\Mimanori ECU	√	√	√	√		
ISUZU\North American ISUZU series\2017\N-Series w-3.0L Diesel (4JJ1)\FMS CAN converter(if equipped)	√	√	√	√		
ISUZU\North American ISUZU series\2016\N-Series w-5.2L Diesel (4HK1)\Engine	√	√	√	√		0075, 0082, 0112, 0113, 0189, 0191, 0242, 0264, 0269, 0349, 0351, 0375, 0401, 0405, 0409, 0413, 0490, 0535, 0617, 0652
ISUZU\North American ISUZU series\2016\N-Series w-5.2L Diesel (4HK1)\Transmission	√	√	√	√		0054, 0467, 0468, 0469, 0470, 0521, 0620, 0622, 0624, 0625, 0667
ISUZU\North American ISUZU series\2016\N-Series w-5.2L Diesel (4HK1)\ABS	√	√	√	√		
ISUZU\North American ISUZU series\2016\N-Series w-5.2L Diesel (4HK1)\Diesel Exhaust Fluid Control Module	√	√	√	√		0174, 0175, 0176, 0177, 0178, 0187, 0240, 0497, 0498, 0522, 0610
ISUZU\North American ISUZU series\2016\N-Series w-5.2L Diesel (4HK1)\Mimanori ECU	√	√	√	√		
ISUZU\North American ISUZU series\2016\N-Series w-5.2L Diesel (4HK1)\FMS CAN converter(if equipped)	√	√	√	√		
ISUZU\North American ISUZU series\2016\Stripped Chassis w-3.0L Diesel(4JJ1)\Engine	√	√	√	√		0075, 0077, 0112, 0113, 0189, 0191, 0219, 0264, 0269, 0349, 0351, 0375, 0401, 0405, 0409, 0413, 0490, 0535, 0617
ISUZU\North American ISUZU series\2016\Stripped Chassis w-3.0L Diesel(4JJ1)\Transmission	√	√	√	√		0054, 0467, 0468, 0469, 0470, 0521, 0620, 0622, 0624, 0625, 0667
ISUZU\North American ISUZU series\2016\Stripped Chassis w-3.0L Diesel(4JJ1)\ABS	√	√	√	√		
ISUZU\North American ISUZU series\2016\Stripped Chassis w-3.0L Diesel(4JJ1)\Diesel Exhaust Fluid Control Module	√	√	√	√		0174, 0175, 0176, 0177, 0178, 0187, 0240, 0497, 0498, 0522, 0610
ISUZU\North American ISUZU series\2016\Stripped Chassis w-3.0L Diesel(4JJ1)\Mimanori ECU	√	√	√	√		
ISUZU\North American ISUZU series\2016\Stripped Chassis w-3.0L Diesel(4JJ1)\FMS CAN converter(if equipped)	√	√	√	√		
ISUZU\North American ISUZU series\2016\N-Series w-3.0L Diesel (4JJ1)\Engine	√	√	√	√		0075, 0077, 0112, 0113, 0189, 0191, 0219, 0264, 0269, 0349, 0351, 0375, 0401, 0405, 0409, 0413, 0490, 0535, 0617
ISUZU\North American ISUZU series\2016\N-Series w-3.0L Diesel (4JJ1)\Transmission	√	√	√	√		0054, 0467, 0468, 0469, 0470, 0521, 0620, 0622, 0624, 0625, 0667
ISUZU\North American ISUZU series\2016\N-Series w-3.0L Diesel (4JJ1)\ABS	√	√	√	√		

ISUZU\North American ISUZU series\2016\N-Series w-3.0L Diesel (4JJ1)\Diesel Exhaust Fluid Control Module	√	√	√	√		0174, 0175, 0176, 0177, 0178, 0187, 0240, 0497, 0498, 0522, 0610
ISUZU\North American ISUZU series\2016\N-Series w-3.0L Diesel (4JJ1)\Mimanori ECU	√	√	√	√		
ISUZU\North American ISUZU series\2016\N-Series w-3.0L Diesel (4JJ1)\FMS CAN converter(if equipped)	√	√	√	√		
ISUZU\North American ISUZU series\2016\N-Series w-6.0L Gas\Engine	√	√	√	√		0005, 0048, 0049, 0167, 0211, 0244, 0245, 0322, 0324, 0325, 0348, 0362, 0363, 0364, 0365, 0376, 0401, 0405, 0409, 0413, 0417, 0419, 0421, 0422, 0482, 0490, 0647
ISUZU\North American ISUZU series\2016\N-Series w-6.0L Gas\Transmission	√	√	√	√		0368, 0525, 0526, 0527, 0528, 0529, 0530, 0531, 0532, 0597, 0620, 0621, 0622, 0623, 0656, 0657
ISUZU\North American ISUZU series\2016\N-Series w-6.0L Gas\ABS		√	√	√		0014, 0015, 0016, 0452, 0453, 0454, 0455, 0574, 0575, 0577, 0578
ISUZU\North American ISUZU series\2016\N-Series w-6.0L Gas\PIM Data Display		√	√			
ISUZU\North American ISUZU series\2015\N-Series w-5.2L Diesel (4HK1)\Engine	√	√	√	√		0075, 0082, 0112, 0113, 0189, 0191, 0242, 0264, 0269, 0349, 0351, 0375, 0401, 0405, 0409, 0413, 0490, 0535, 0617, 0652
ISUZU\North American ISUZU series\2015\N-Series w-5.2L Diesel (4HK1)\Transmission	√	√	√	√		0054, 0467, 0468, 0469, 0470, 0521, 0620, 0622, 0624, 0625, 0667
ISUZU\North American ISUZU series\2015\N-Series w-5.2L Diesel (4HK1)\ABS	√	√	√	√		
ISUZU\North American ISUZU series\2015\N-Series w-5.2L Diesel (4HK1)\Diesel Exhaust Fluid Control Module		√	√	√		0174, 0175, 0176, 0177, 0178, 0187, 0240, 0497, 0498, 0522, 0610
ISUZU\North American ISUZU series\2015\N-Series w-5.2L Diesel (4HK1)\Mimanori ECU	√	√	√	√		
ISUZU\North American ISUZU series\2015\N-Series w-5.2L Diesel (4HK1)\FMS CAN converter(if equipped)	√	√	√	√		
ISUZU\North American ISUZU series\2015\Stripped Chassis w-3.0L Diesel(4JJ1)\Engine	√	√	√	√		0075, 0077, 0112, 0113, 0189, 0191, 0219, 0264, 0269, 0349, 0351, 0375, 0401, 0405, 0409, 0413, 0490, 0535, 0617
ISUZU\North American ISUZU series\2015\Stripped Chassis w-3.0L Diesel(4JJ1)\Transmission	√	√	√	√		0054, 0467, 0468, 0469, 0470, 0521, 0620, 0622, 0624, 0625, 0667
ISUZU\North American ISUZU series\2015\Stripped Chassis w-3.0L Diesel(4JJ1)\ABS	√	√	√	√		
ISUZU\North American ISUZU series\2015\Stripped Chassis w-3.0L Diesel(4JJ1)\Diesel Exhaust Fluid Control Module	√	√	√	√		0174, 0175, 0176, 0177, 0178, 0187, 0240, 0497, 0498, 0522, 0610
ISUZU\North American ISUZU series\2015\Stripped Chassis w-3.0L Diesel(4JJ1)\Mimanori ECU	√	√	√	√		
ISUZU\North American ISUZU series\2015\Stripped Chassis w-3.0L Diesel(4JJ1)\FMS CAN converter(if equipped)	√	√	√	√		
ISUZU\North American ISUZU series\2015\N-Series w-3.0L Diesel (4JJ1)\Engine	√	√	√	√		0075, 0077, 0112, 0113, 0189, 0191, 0219, 0264, 0269, 0349, 0351, 0375, 0401, 0405, 0409, 0413, 0490, 0535, 0617
ISUZU\North American ISUZU series\2015\N-Series w-3.0L Diesel (4JJ1)\Transmission	√	√	√	√		0054, 0467, 0468, 0469, 0470, 0521, 0620, 0622, 0624, 0625, 0667
ISUZU\North American ISUZU series\2015\N-Series w-3.0L Diesel (4JJ1)\ABS	√	√	√	√		
ISUZU\North American ISUZU series\2015\N-Series w-3.0L Diesel (4JJ1)\Diesel Exhaust Fluid Control Module	√	√	√	√		0174, 0175, 0176, 0177, 0178, 0187, 0240, 0497, 0498, 0522, 0610
ISUZU\North American ISUZU series\2015\N-Series w-3.0L Diesel (4JJ1)\Mimanori ECU	√	√	√	√		

ISUZU\North American ISUZU series\2015\N-Series w-3.0L Diesel (4JJ1)\FMS CAN converter(if equipped)	√	√	√	√		
ISUZU\North American ISUZU series\2015\N-Series w-6.0L Gas\Engine	√	√	√	√		0005, 0048, 0049, 0167, 0211, 0244, 0245, 0322, 0324, 0325, 0348, 0362, 0363, 0364, 0365, 0376, 0401, 0405, 0409, 0413, 0417, 0419, 0421, 0422, 0482, 0490, 0647
ISUZU\North American ISUZU series\2015\N-Series w-6.0L Gas\Transmission	√	√	√	√		0368, 0525, 0526, 0527, 0528, 0529, 0530, 0531, 0532, 0597, 0620, 0621, 0622, 0623, 0656, 0657
ISUZU\North American ISUZU series\2015\N-Series w-6.0L Gas\ABS		√	√	√		0014, 0015, 0016, 0452, 0453, 0454, 0455, 0574, 0575, 0577, 0578
ISUZU\North American ISUZU series\2015\N-Series w-6.0L Gas\PIM Data Display		√	√			
ISUZU\North American ISUZU series\2014\N-Series w-5.2L Diesel (4HK1)\Engine	√	√	√	√		0075, 0082, 0112, 0113, 0189, 0191, 0242, 0264, 0269, 0349, 0351, 0375, 0401, 0405, 0409, 0413, 0490, 0535, 0617, 0652
ISUZU\North American ISUZU series\2014\N-Series w-5.2L Diesel (4HK1)\Transmission	√	√	√	√		0054, 0467, 0468, 0469, 0470, 0521, 0620, 0622, 0624, 0625, 0667
ISUZU\North American ISUZU series\2014\N-Series w-5.2L Diesel (4HK1)\ABS	√	√	√	√		
ISUZU\North American ISUZU series\2014\N-Series w-5.2L Diesel (4HK1)\Diesel Exhaust Fluid Control Module		√	√	√		0174, 0175, 0176, 0177, 0178, 0187, 0240, 0497, 0498, 0522, 0610
ISUZU\North American ISUZU series\2014\N-Series w-5.2L Diesel (4HK1)\Mimanori ECU	√	√	√	√		
ISUZU\North American ISUZU series\2014\N-Series w-5.2L Diesel (4HK1)\FMS CAN converter(if equipped)	√	√	√	√		
ISUZU\North American ISUZU series\2014\Stripped Chassis w-3.0L Diesel(4JJ1)\Engine	√	√	√	√		0075, 0077, 0112, 0113, 0189, 0191, 0219, 0264, 0269, 0349, 0351, 0375, 0401, 0405, 0409, 0413, 0490, 0535, 0617
ISUZU\North American ISUZU series\2014\Stripped Chassis w-3.0L Diesel(4JJ1)\Transmission	√	√	√	√		0054, 0467, 0468, 0469, 0470, 0521, 0620, 0622, 0624, 0625, 0667
ISUZU\North American ISUZU series\2014\Stripped Chassis w-3.0L Diesel(4JJ1)\ABS	√	√	√	√		
ISUZU\North American ISUZU series\2014\Stripped Chassis w-3.0L Diesel(4JJ1)\Diesel Exhaust Fluid Control Module		√	√	√		0174, 0175, 0176, 0177, 0178, 0187, 0240, 0497, 0498, 0522, 0610
ISUZU\North American ISUZU series\2014\Stripped Chassis w-3.0L Diesel(4JJ1)\Mimanori ECU	√	√	√	√		
ISUZU\North American ISUZU series\2014\Stripped Chassis w-3.0L Diesel(4JJ1)\FMS CAN converter(if equipped)	√	√	√	√		
ISUZU\North American ISUZU series\2014\N-Series w-3.0L Diesel (4JJ1)\Engine	√	√	√	√		0075, 0077, 0112, 0113, 0189, 0191, 0219, 0264, 0269, 0349, 0351, 0375, 0401, 0405, 0409, 0413, 0490, 0535, 0617
ISUZU\North American ISUZU series\2014\N-Series w-3.0L Diesel (4JJ1)\Transmission	√	√	√	√		0054, 0467, 0468, 0469, 0470, 0521, 0620, 0622, 0624, 0625, 0667
ISUZU\North American ISUZU series\2014\N-Series w-3.0L Diesel (4JJ1)\ABS	√	√	√	√		
ISUZU\North American ISUZU series\2014\N-Series w-3.0L Diesel (4JJ1)\Diesel Exhaust Fluid Control Module		√	√	√		0174, 0175, 0176, 0177, 0178, 0187, 0240, 0497, 0498, 0522, 0610
ISUZU\North American ISUZU series\2014\N-Series w-3.0L Diesel (4JJ1)\Mimanori ECU	√	√	√	√		
ISUZU\North American ISUZU series\2014\N-Series w-3.0L Diesel (4JJ1)\FMS CAN converter(if equipped)	√	√	√	√		

ISUZU\North American ISUZU series\2014\N-Series w-6.0L Gas\Engine	√	√	√	√		0005, 0048, 0049, 0167, 0211, 0244, 0245, 0322, 0324, 0325, 0348, 0362, 0363, 0364, 0365, 0376, 0401, 0405, 0409, 0413, 0417, 0419, 0421, 0422, 0482, 0490, 0647
ISUZU\North American ISUZU series\2014\N-Series w-6.0L Gas\Transmission	√	√	√	√		0368, 0525, 0526, 0527, 0528, 0529, 0530, 0531, 0532, 0597, 0620, 0621, 0622, 0623, 0656, 0657
ISUZU\North American ISUZU series\2014\N-Series w-6.0L Gas\ABS		√	√	√		0014, 0015, 0016, 0452, 0453, 0454, 0455, 0574, 0575, 0577, 0578
ISUZU\North American ISUZU series\2014\N-Series w-6.0L Gas\PIM Data Display		√	√			
ISUZU\North American ISUZU series\2013\N-Series w-5.2L Diesel (4HK1)\Engine	√	√	√	√		0075, 0082, 0112, 0113, 0189, 0191, 0242, 0264, 0269, 0349, 0351, 0375, 0401, 0405, 0409, 0413, 0490, 0535, 0617, 0652
ISUZU\North American ISUZU series\2013\N-Series w-5.2L Diesel (4HK1)\Transmission	√	√	√	√		0054, 0467, 0468, 0469, 0470, 0620, 0622, 0624, 0625, 0667
ISUZU\North American ISUZU series\2013\N-Series w-5.2L Diesel (4HK1)\ABS		√	√	√		0014, 0015, 0016, 0267, 0452, 0453, 0454, 0455, 0574, 0575, 0577, 0578
ISUZU\North American ISUZU series\2013\N-Series w-5.2L Diesel (4HK1)\Diesel Exhaust Fluid Control Module		√	√	√		0174, 0175, 0176, 0177, 0178, 0187, 0240, 0497, 0498, 0522, 0610
ISUZU\North American ISUZU series\2013\N-Series w-5.2L Diesel (4HK1)\Mimanori ECU	√	√	√	√		
ISUZU\North American ISUZU series\2013\Stripped Chassis w-3.0L Diesel(4JJ1)\Engine	√	√	√	√		0075, 0077, 0112, 0113, 0189, 0191, 0219, 0264, 0269, 0349, 0351, 0375, 0401, 0405, 0409, 0413, 0490, 0535, 0617
ISUZU\North American ISUZU series\2013\Stripped Chassis w-3.0L Diesel(4JJ1)\Transmission	√	√	√	√		0054, 0467, 0468, 0469, 0470, 0521, 0620, 0622, 0624, 0625, 0667
ISUZU\North American ISUZU series\2013\Stripped Chassis w-3.0L Diesel(4JJ1)\ABS	√	√	√	√		
ISUZU\North American ISUZU series\2013\Stripped Chassis w-3.0L Diesel(4JJ1)\Diesel Exhaust Fluid Control Module		√	√	√		0174, 0175, 0176, 0177, 0178, 0187, 0240, 0497, 0498, 0522, 0610
ISUZU\North American ISUZU series\2013\Stripped Chassis w-3.0L Diesel(4JJ1)\Mimanori ECU	√	√	√	√		
ISUZU\North American ISUZU series\2013\Stripped Chassis w-3.0L Diesel(4JJ1)\FMS CAN converter(if equipped)	√	√	√	√		
ISUZU\North American ISUZU series\2013\N-Series w-3.0L Diesel (4JJ1)\Engine	√	√	√	√		0075, 0077, 0112, 0113, 0189, 0191, 0219, 0264, 0269, 0349, 0351, 0375, 0401, 0405, 0409, 0413, 0490, 0535, 0617
ISUZU\North American ISUZU series\2013\N-Series w-3.0L Diesel (4JJ1)\Transmission	√	√	√	√		0054, 0467, 0468, 0469, 0470, 0521, 0620, 0622, 0624, 0625, 0667
ISUZU\North American ISUZU series\2013\N-Series w-3.0L Diesel (4JJ1)\ABS	√	√	√	√		
ISUZU\North American ISUZU series\2013\N-Series w-3.0L Diesel (4JJ1)\Diesel Exhaust Fluid Control Module		√	√	√		0174, 0175, 0176, 0177, 0178, 0187, 0240, 0497, 0498, 0522, 0610
ISUZU\North American ISUZU series\2013\N-Series w-3.0L Diesel (4JJ1)\Mimanori ECU	√	√	√	√		
ISUZU\North American ISUZU series\2013\N-Series w-3.0L Diesel (4JJ1)\FMS CAN converter(if equipped)	√	√	√	√		
ISUZU\North American ISUZU series\2013\N-Series w-6.0L Gas\Engine	√	√	√	√		0005, 0048, 0049, 0167, 0211, 0244, 0245, 0322, 0324, 0325, 0348, 0362, 0363, 0364, 0365, 0376, 0401, 0405, 0409, 0413, 0417, 0419, 0421, 0422, 0482, 0490, 0647

ISUZU\North American ISUZU series\2013\N-Series w-6.0L Gas\Transmission	√	√	√	√		0368, 0525, 0526, 0527, 0528, 0529, 0530, 0531, 0532, 0597, 0620, 0621, 0622, 0623, 0656, 0657
ISUZU\North American ISUZU series\2013\N-Series w-6.0L Gas\ABS		√	√	√		0014, 0015, 0016, 0452, 0453, 0454, 0455, 0574, 0575, 0577, 0578
ISUZU\North American ISUZU series\2013\N-Series w-6.0L Gas\PIM Data Display		√	√			
ISUZU\North American ISUZU series\2012\N-Series w-5.2L Diesel (4HK1)\Engine	√	√	√	√		0075, 0082, 0112, 0113, 0189, 0191, 0242, 0264, 0269, 0349, 0351, 0375, 0401, 0405, 0409, 0413, 0490, 0535, 0617, 0652
ISUZU\North American ISUZU series\2012\N-Series w-5.2L Diesel (4HK1)\Transmission	√	√	√	√		0054, 0467, 0468, 0469, 0470, 0620, 0622, 0624, 0625, 0667
ISUZU\North American ISUZU series\2012\N-Series w-5.2L Diesel (4HK1)\ABS		√	√	√		0014, 0015, 0016, 0267, 0452, 0453, 0454, 0455, 0574, 0575, 0577, 0578
ISUZU\North American ISUZU series\2012\N-Series w-5.2L Diesel (4HK1)\Diesel Exhaust Fluid Control Module		√	√	√		0174, 0175, 0176, 0177, 0178, 0187, 0240, 0497, 0498, 0522, 0610
ISUZU\North American ISUZU series\2012\N-Series w-5.2L Diesel (4HK1)\Mimanori ECU	√	√	√	√		
ISUZU\North American ISUZU series\2012\Stripped Chassis w-3.0L Diesel(4JJ1)\Engine	√	√	√	√		0075, 0077, 0112, 0113, 0189, 0191, 0219, 0264, 0269, 0349, 0351, 0375, 0401, 0405, 0409, 0413, 0490, 0535, 0617
ISUZU\North American ISUZU series\2012\Stripped Chassis w-3.0L Diesel(4JJ1)\Transmission	√	√	√	√		0054, 0467, 0468, 0469, 0470, 0620, 0622, 0624, 0625, 0667
ISUZU\North American ISUZU series\2012\Stripped Chassis w-3.0L Diesel(4JJ1)\ABS		√	√	√		0014, 0015, 0016, 0267, 0452, 0453, 0454, 0455, 0574, 0575, 0577, 0578
ISUZU\North American ISUZU series\2012\Stripped Chassis w-3.0L Diesel(4JJ1)\Diesel Exhaust Fluid Control Module		√	√	√		0174, 0175, 0176, 0177, 0178, 0187, 0240, 0497, 0498, 0522, 0610
ISUZU\North American ISUZU series\2012\Stripped Chassis w-3.0L Diesel(4JJ1)\Mimanori ECU	√	√	√	√		
ISUZU\North American ISUZU series\2012\N-Series w-3.0L Diesel (4JJ1)\Engine	√	√	√	√		0075, 0077, 0112, 0113, 0189, 0191, 0219, 0264, 0269, 0349, 0351, 0375, 0401, 0405, 0409, 0413, 0490, 0535, 0617
ISUZU\North American ISUZU series\2012\N-Series w-3.0L Diesel (4JJ1)\Transmission	√	√	√	√		0054, 0467, 0468, 0469, 0470, 0620, 0622, 0624, 0625, 0667
ISUZU\North American ISUZU series\2012\N-Series w-3.0L Diesel (4JJ1)\ABS		√	√	√		0014, 0015, 0016, 0267, 0452, 0453, 0454, 0455, 0574, 0575, 0577, 0578
ISUZU\North American ISUZU series\2012\N-Series w-3.0L Diesel (4JJ1)\Diesel Exhaust Fluid Control Module		√	√	√		0174, 0175, 0176, 0177, 0178, 0187, 0240, 0497, 0498, 0522, 0610
ISUZU\North American ISUZU series\2012\N-Series w-3.0L Diesel (4JJ1)\Mimanori ECU	√	√	√	√		
ISUZU\North American ISUZU series\2012\N-Series w-6.0L Gas\Engine	√	√	√	√		0005, 0048, 0049, 0167, 0211, 0244, 0245, 0322, 0324, 0325, 0348, 0362, 0363, 0364, 0365, 0366, 0376, 0401, 0405, 0409, 0413, 0417, 0419, 0421, 0422, 0482, 0490, 0647, 0655
ISUZU\North American ISUZU series\2012\N-Series w-6.0L Gas\Transmission	√	√	√	√		0368, 0525, 0526, 0527, 0528, 0529, 0530, 0531, 0532, 0597, 0620, 0621, 0622, 0623, 0656, 0657
ISUZU\North American ISUZU series\2012\N-Series w-6.0L Gas\ABS		√	√	√		0014, 0015, 0016, 0452, 0453, 0454, 0455, 0574, 0575, 0577, 0578
ISUZU\North American ISUZU series\2012\N-Series w-6.0L Gas\PIM Data Display		√	√			

ISUZU\North American ISUZU series\2011\N-Series w-5.2L Diesel (4HK1)\Engine	√	√	√	√		0075, 0082, 0112, 0113, 0189, 0191, 0242, 0264, 0269, 0349, 0351, 0375, 0401, 0405, 0409, 0413, 0490, 0535, 0617, 0652
ISUZU\North American ISUZU series\2011\N-Series w-5.2L Diesel (4HK1)\Transmission	√	√	√	√		0054, 0467, 0468, 0469, 0470, 0620, 0622, 0624, 0625, 0667
ISUZU\North American ISUZU series\2011\N-Series w-5.2L Diesel (4HK1)\ABS		√	√	√		0014, 0015, 0016, 0267, 0452, 0453, 0454, 0455, 0574, 0575, 0577, 0578
ISUZU\North American ISUZU series\2011\N-Series w-5.2L Diesel (4HK1)\Diesel Exhaust Fluid Control Module		√	√	√		0174, 0175, 0176, 0177, 0178, 0187, 0240, 0497, 0498, 0522, 0610
ISUZU\North American ISUZU series\2011\N-Series w-5.2L Diesel (4HK1)\Mimanori ECU	√	√	√	√		
ISUZU\North American ISUZU series\2011\N-Series w-3.0L Diesel (4JJ1)\Engine	√	√	√	√		0075, 0077, 0112, 0113, 0189, 0191, 0219, 0264, 0269, 0349, 0351, 0375, 0401, 0405, 0409, 0413, 0490, 0535, 0617
ISUZU\North American ISUZU series\2011\N-Series w-3.0L Diesel (4JJ1)\Transmission	√	√	√	√		0054, 0467, 0468, 0469, 0470, 0620, 0622, 0624, 0625, 0667
ISUZU\North American ISUZU series\2011\N-Series w-3.0L Diesel (4JJ1)\ABS		√	√	√		0014, 0015, 0016, 0267, 0452, 0453, 0454, 0455, 0574, 0575, 0577, 0578
ISUZU\North American ISUZU series\2011\N-Series w-3.0L Diesel (4JJ1)\Diesel Exhaust Fluid Control Module		√	√	√		0174, 0175, 0176, 0177, 0178, 0187, 0240, 0497, 0498, 0522, 0610
ISUZU\North American ISUZU series\2011\N-Series w-3.0L Diesel (4JJ1)\Mimanori ECU	√	√	√	√		
ISUZU\North American ISUZU series\2010\N-W Series w-5.2L Diesel(4HK1)\Engine	√	√	√	√		0034, 0075, 0112, 0113, 0189, 0191, 0264, 0349, 0351, 0401, 0405, 0409, 0413, 0490, 0535, 0617
ISUZU\North American ISUZU series\2010\N-W Series w-5.2L Diesel(4HK1)\Transmission	√	√	√	√		0054, 0467, 0468, 0469, 0470, 0620, 0622, 0624, 0625, 0667
ISUZU\North American ISUZU series\2010\N-W Series w-5.2L Diesel(4HK1)\ABS		√	√	√		0014, 0015, 0016, 0267, 0452, 0453, 0454, 0455, 0574, 0575, 0577, 0578
ISUZU\North American ISUZU series\2009\N-W Series w-5.2L Diesel(4HK1)\Engine	√	√	√	√		0034, 0075, 0112, 0113, 0189, 0191, 0264, 0349, 0351, 0401, 0405, 0409, 0413, 0490, 0535, 0617
ISUZU\North American ISUZU series\2009\N-W Series w-5.2L Diesel(4HK1)\Transmission	√	√	√	√		0054, 0467, 0468, 0469, 0470, 0620, 0622, 0624, 0625, 0667
ISUZU\North American ISUZU series\2009\N-W Series w-5.2L Diesel(4HK1)\ABS		√	√	√		0014, 0015, 0016, 0267, 0452, 0453, 0454, 0455, 0574, 0575, 0577, 0578
ISUZU\North American ISUZU series\2009\N-W Series w-6.0L Gas\Engine	√	√	√	√		0005, 0048, 0049, 0167, 0211, 0244, 0245, 0322, 0324, 0325, 0348, 0362, 0363, 0364, 0365, 0366, 0376, 0401, 0405, 0409, 0413, 0417, 0419, 0421, 0422, 0482, 0490, 0647, 0655
ISUZU\North American ISUZU series\2009\N-W Series w-6.0L Gas\Transmission	√	√	√	√		0002, 0003, 0597, 0656
ISUZU\North American ISUZU series\2009\N-W Series w-6.0L Gas\ABS		√	√	√		0014, 0015, 0016, 0452, 0453, 0454, 0455, 0574, 0575, 0577, 0578
ISUZU\North American ISUZU series\2009\N-W Series w-6.0L Gas\PIM Data Display		√	√			
ISUZU\North American ISUZU series\2009\F-T Series w-7.8L Diesel (6HK1)\F-T Series w-7.8L Diesel (6HK1) AUTO\Engine	√	√	√	√		0035, 0075, 0119, 0129, 0139, 0149, 0159, 0162, 0188, 0190, 0264, 0349, 0350, 0490, 0535
ISUZU\North American ISUZU series\2009\F-T Series w-7.8L Diesel (6HK1)\F-T Series w-7.8L Diesel (6HK1) AUTO\Transmission		√	√	√		

ISUZU\North American ISUZU series\2009\F-T Series w-7.8L Diesel (6HK1)\F-T Series w-7.8L Diesel (6HK1) AUTO\ABS		√	√	√		0014, 0265, 0456, 0457, 0458, 0459, 0483, 0601, 0602, 0603, 0604, 0615, 0666
ISUZU\North American ISUZU series\2009\F-T Series w-7.8L Diesel (6HK1)\F-T Series w-7.8L Diesel (6HK1) AUTO\IPC Data Display		√	√	√		
ISUZU\North American ISUZU series\2009\F-T Series w-7.8L Diesel (6HK1)\F-T Series w-7.8L Diesel (6HK1) AUTO\Chime Data Display		√	√	√		
ISUZU\North American ISUZU series\2009\F-T Series w-7.8L Diesel (6HK1)\F-T Series w-7.8L Diesel (6HK1) AUTO\SDGM Data Display(If Equipped)		√	√	√		
ISUZU\North American ISUZU series\2009\F-T Series w-7.8L Diesel (6HK1)\F-T Series w-7.8L Diesel (6HK1) Manual\Engine	√	√	√	√		0035, 0075, 0119, 0129, 0139, 0149, 0159, 0162, 0188, 0190, 0264, 0349, 0350, 0490, 0535
ISUZU\North American ISUZU series\2009\F-T Series w-7.8L Diesel (6HK1)\F-T Series w-7.8L Diesel (6HK1) Manual\ABS		√	√	√		0014, 0265, 0456, 0457, 0458, 0459, 0483, 0601, 0602, 0603, 0604, 0615, 0666
ISUZU\North American ISUZU series\2009\F-T Series w-7.8L Diesel (6HK1)\F-T Series w-7.8L Diesel (6HK1) Manual\IPC Data Display		√	√	√		
ISUZU\North American ISUZU series\2009\F-T Series w-7.8L Diesel (6HK1)\F-T Series w-7.8L Diesel (6HK1) Manual\Chime Data Display		√	√	√		
ISUZU\North American ISUZU series\2009\F-T Series w-7.8L Diesel (6HK1)\F-T Series w-7.8L Diesel (6HK1) Manual\SDGM Data Display(If Equipped)		√	√	√		
ISUZU\North American ISUZU series\2009\C-Series w-7.8L Diesel (6HK1)\C-Series w-7.8L Diesel (6HK1) AUTO\Engine	√	√	√	√		0035, 0075, 0119, 0129, 0139, 0149, 0159, 0162, 0188, 0190, 0264, 0349, 0350, 0490, 0535
ISUZU\North American ISUZU series\2009\C-Series w-7.8L Diesel (6HK1)\C-Series w-7.8L Diesel (6HK1) AUTO\ABS		√	√	√		0014, 0265, 0456, 0457, 0458, 0459, 0483, 0601, 0602, 0603, 0604, 0615, 0666
ISUZU\North American ISUZU series\2009\C-Series w-7.8L Diesel (6HK1)\C-Series w-7.8L Diesel (6HK1) AUTO\IPC Data Display		√	√	√		
ISUZU\North American ISUZU series\2009\C-Series w-7.8L Diesel (6HK1)\C-Series w-7.8L Diesel (6HK1) AUTO\Chime Data Display		√	√	√		
ISUZU\North American ISUZU series\2009\C-Series w-7.8L Diesel (6HK1)\C-Series w-7.8L Diesel (6HK1) AUTO\SDGM Data Display(If Equipped)		√	√	√		
ISUZU\North American ISUZU series\2009\C-Series w-7.8L Diesel (6HK1)\C-Series w-7.8L Diesel (6HK1) AUTO\Radio Data Display		√	√	√		
ISUZU\North American ISUZU series\2009\C-Series w-7.8L Diesel (6HK1)\C-Series w-7.8L Diesel (6HK1) Manual\Engine	√	√	√	√		0035, 0075, 0119, 0129, 0139, 0149, 0159, 0162, 0188, 0190, 0264, 0349, 0350, 0490, 0535
ISUZU\North American ISUZU series\2009\C-Series w-7.8L Diesel (6HK1)\C-Series w-7.8L Diesel (6HK1) Manual\ABS		√	√	√		0014, 0265, 0456, 0457, 0458, 0459, 0483, 0601, 0602, 0603, 0604, 0615, 0666
ISUZU\North American ISUZU series\2009\C-Series w-7.8L Diesel (6HK1)\C-Series w-7.8L Diesel (6HK1) Manual\IPC Data Display		√	√	√		
ISUZU\North American ISUZU series\2009\C-Series w-7.8L Diesel (6HK1)\C-Series w-7.8L Diesel (6HK1) Manual\Chime Data Display		√	√	√		
ISUZU\North American ISUZU series\2009\C-Series w-7.8L Diesel (6HK1)\C-Series w-7.8L Diesel (6HK1) Manual\SDGM Data Display(If Equipped)		√	√	√		
ISUZU\North American ISUZU series\2009\C-Series w-7.8L Diesel (6HK1)\C-Series w-7.8L Diesel (6HK1) Manual\Radio Data Display		√	√	√		
ISUZU\North American ISUZU series\2008\N-W Series w-5.2L Diesel(4HK1)\Engine	√	√	√	√		0034, 0075, 0112, 0113, 0189, 0191, 0264, 0349, 0351, 0401, 0405, 0409, 0413, 0490, 0535, 0617
ISUZU\North American ISUZU series\2008\N-W Series w-5.2L Diesel(4HK1)\Transmission	√	√	√	√		0054, 0467, 0468, 0469, 0470, 0620, 0622, 0624, 0625, 0667
ISUZU\North American ISUZU series\2008\N-W Series w-5.2L Diesel(4HK1)\ABS		√	√	√		0014, 0015, 0016, 0267, 0452, 0453, 0454, 0455, 0574, 0575, 0577, 0578

ISUZU\North American ISUZU series\2008\N-W Series w-6.0L Gas\Engine	√	√	√	√		0005, 0048, 0049, 0167, 0211, 0244, 0245, 0322, 0324, 0325, 0348, 0362, 0363, 0364, 0365, 0366, 0376, 0401, 0405, 0409, 0413, 0417, 0419, 0421, 0422, 0482, 0490, 0647, 0655
ISUZU\North American ISUZU series\2008\N-W Series w-6.0L Gas\Transmission	√	√	√	√		0002, 0003, 0597, 0656
ISUZU\North American ISUZU series\2008\N-W Series w-6.0L Gas\ABS		√	√	√		0014, 0015, 0016, 0452, 0453, 0454, 0455, 0574, 0575, 0577, 0578
ISUZU\North American ISUZU series\2008\N-W Series w-6.0L Gas\PIM Data Display		√	√			
ISUZU\North American ISUZU series\2008\F-T Series w-7.8L Diesel (6HK1)\F-T Series w-7.8L Diesel (6HK1) AUTO\Engine	√	√	√	√		0035, 0075, 0119, 0129, 0139, 0149, 0159, 0162, 0188, 0190, 0264, 0349, 0350, 0490, 0535
ISUZU\North American ISUZU series\2008\F-T Series w-7.8L Diesel (6HK1)\F-T Series w-7.8L Diesel (6HK1) AUTO\Transmission		√	√	√		
ISUZU\North American ISUZU series\2008\F-T Series w-7.8L Diesel (6HK1)\F-T Series w-7.8L Diesel (6HK1) AUTO\ABS		√	√	√		0014, 0265, 0456, 0457, 0458, 0459, 0483, 0601, 0602, 0603, 0604, 0615, 0666
ISUZU\North American ISUZU series\2008\F-T Series w-7.8L Diesel (6HK1)\F-T Series w-7.8L Diesel (6HK1) AUTO\IPC Data Display		√	√	√		
ISUZU\North American ISUZU series\2008\F-T Series w-7.8L Diesel (6HK1)\F-T Series w-7.8L Diesel (6HK1) AUTO\Chime Data Display		√	√	√		
ISUZU\North American ISUZU series\2008\F-T Series w-7.8L Diesel (6HK1)\F-T Series w-7.8L Diesel (6HK1) AUTO\SDGM Data Display(If Equipped)		√	√	√		
ISUZU\North American ISUZU series\2008\F-T Series w-7.8L Diesel (6HK1)\F-T Series w-7.8L Diesel (6HK1) Manual\Engine	√	√	√	√		0035, 0075, 0119, 0129, 0139, 0149, 0159, 0162, 0188, 0190, 0264, 0349, 0350, 0490, 0535
ISUZU\North American ISUZU series\2008\F-T Series w-7.8L Diesel (6HK1)\F-T Series w-7.8L Diesel (6HK1) Manual\ABS		√	√	√		0014, 0265, 0456, 0457, 0458, 0459, 0483, 0601, 0602, 0603, 0604, 0615, 0666
ISUZU\North American ISUZU series\2008\F-T Series w-7.8L Diesel (6HK1)\F-T Series w-7.8L Diesel (6HK1) Manual\IPC Data Display		√	√	√		
ISUZU\North American ISUZU series\2008\F-T Series w-7.8L Diesel (6HK1)\F-T Series w-7.8L Diesel (6HK1) Manual\Chime Data Display		√	√	√		
ISUZU\North American ISUZU series\2008\F-T Series w-7.8L Diesel (6HK1)\F-T Series w-7.8L Diesel (6HK1) Manual\SDGM Data Display(If Equipped)		√	√	√		
ISUZU\North American ISUZU series\2008\C-Series w-7.8L Diesel (6HK1)\C-Series w-7.8L Diesel (6HK1) AUTO\Engine	√	√	√	√		0035, 0075, 0119, 0129, 0139, 0149, 0159, 0162, 0188, 0190, 0264, 0349, 0350, 0490, 0535
ISUZU\North American ISUZU series\2008\C-Series w-7.8L Diesel (6HK1)\C-Series w-7.8L Diesel (6HK1) AUTO\Transmission		√	√	√		
ISUZU\North American ISUZU series\2008\C-Series w-7.8L Diesel (6HK1)\C-Series w-7.8L Diesel (6HK1) AUTO\ABS		√	√	√		0014, 0265, 0456, 0457, 0458, 0459, 0483, 0601, 0602, 0603, 0604, 0615, 0666
ISUZU\North American ISUZU series\2008\C-Series w-7.8L Diesel (6HK1)\C-Series w-7.8L Diesel (6HK1) AUTO\IPC Data Display		√	√	√		
ISUZU\North American ISUZU series\2008\C-Series w-7.8L Diesel (6HK1)\C-Series w-7.8L Diesel (6HK1) AUTO\Chime Data Display		√	√	√		
ISUZU\North American ISUZU series\2008\C-Series w-7.8L Diesel (6HK1)\C-Series w-7.8L Diesel (6HK1) AUTO\SDGM Data Display(If Equipped)		√	√	√		
ISUZU\North American ISUZU series\2008\C-Series w-7.8L Diesel (6HK1)\C-Series w-7.8L Diesel (6HK1) Manual\Engine	√	√	√	√		0035, 0075, 0119, 0129, 0139, 0149, 0159, 0162, 0188, 0190, 0264, 0349, 0350, 0490, 0535
ISUZU\North American ISUZU series\2008\C-Series w-7.8L Diesel (6HK1)\C-Series w-7.8L Diesel (6HK1) Manual\ABS		√	√	√		0014, 0265, 0456, 0457, 0458, 0459, 0483, 0601, 0602, 0603, 0604, 0615, 0666
ISUZU\North American ISUZU series\2008\C-Series w-7.8L Diesel (6HK1)\C-Series w-7.8L Diesel (6HK1) Manual\IPC Data Display		√	√	√		
ISUZU\North American ISUZU series\2008\C-Series w-7.8L Diesel (6HK1)\C-Series w-7.8L Diesel (6HK1) Manual\Chime Data Display		√	√	√		

ISUZU\North American ISUZU series\2008\C-Series w-7.8L Diesel (6HK1)\C-Series w-7.8L Diesel (6HK1) Manual\SDGM Data Display(If Equipped)		√	√	√		
ISUZU\North American ISUZU series\2007\N-W Series w-5.2L Diesel(4HK1)\Engine	√	√	√	√		0034, 0112, 0113, 0350, 0490, 0691
ISUZU\North American ISUZU series\2007\N-W Series w-5.2L Diesel(4HK1)\Transmission		√	√	√		0054, 0620, 0622, 0629, 0656
ISUZU\North American ISUZU series\2007\N-W Series w-5.2L Diesel(4HK1)\ABS		√	√	√		0014, 0015, 0016, 0266, 0452, 0453, 0454, 0455, 0574, 0575, 0577, 0578
ISUZU\North American ISUZU series\2007\N-W Series w-6.0L Gas\Engine	√	√	√	√		0005, 0245, 0321, 0482, 0490, 0510
ISUZU\North American ISUZU series\2007\N-W Series w-6.0L Gas\Transmission		√	√	√		0002, 0003, 0656
ISUZU\North American ISUZU series\2007\N-W Series w-6.0L Gas\ABS		√	√	√		0014, 0015, 0016, 0452, 0453, 0454, 0455, 0574, 0575, 0577, 0578
ISUZU\North American ISUZU series\2007\F-T Series w-7.8L Diesel (6HK1)\Engine	√	√	√	√		0265, 0350, 0490, 0535, 0691
ISUZU\North American ISUZU series\2007\F-T Series w-7.8L Diesel (6HK1)\Transmission		√	√	√		
ISUZU\North American ISUZU series\2007\F-T Series w-7.8L Diesel (6HK1)\ABS		√	√	√		0014, 0265, 0456, 0457, 0458, 0459, 0483, 0601, 0602, 0603, 0604, 0615, 0666
ISUZU\North American ISUZU series\2007\F-T Series w-7.8L Diesel (6HK1)\IPC Data Display		√	√	√		
ISUZU\North American ISUZU series\2007\F-T Series w-7.8L Diesel (6HK1)\Chime Data Display		√	√	√		
ISUZU\North American ISUZU series\2007\F-T Series w-7.8L Diesel (6HK1)\SDGM Data Display(If Equipped)		√	√	√		
ISUZU\North American ISUZU series\2007\C-Series w-7.8L Diesel (6HK1)\Engine	√	√	√	√		0265, 0350, 0490, 0535, 0691
ISUZU\North American ISUZU series\2007\C-Series w-7.8L Diesel (6HK1)\Transmission		√	√	√		
ISUZU\North American ISUZU series\2007\C-Series w-7.8L Diesel (6HK1)\ABS		√	√	√		0014, 0265, 0456, 0457, 0458, 0459, 0483, 0601, 0602, 0603, 0604, 0615, 0666
ISUZU\North American ISUZU series\2007\C-Series w-7.8L Diesel (6HK1)\IPC Data Display		√	√	√		
ISUZU\North American ISUZU series\2007\C-Series w-7.8L Diesel (6HK1)\Chime Data Display		√	√	√		
ISUZU\North American ISUZU series\2007\C-Series w-7.8L Diesel (6HK1)\SDGM Data Display(If Equipped)		√	√	√		
ISUZU\North American ISUZU series\2006\N-W Series w-5.2L Diesel(4HK1)\Engine	√	√	√	√		0034, 0112, 0113, 0350, 0490, 0614, 0691
ISUZU\North American ISUZU series\2006\N-W Series w-5.2L Diesel(4HK1)\Transmission		√	√	√		0054, 0620, 0622, 0629, 0656
ISUZU\North American ISUZU series\2006\N-W Series w-5.2L Diesel(4HK1)\ABS		√	√	√		0014, 0015, 0016, 0266, 0452, 0453, 0454, 0455, 0574, 0575, 0577, 0578
ISUZU\North American ISUZU series\2006\N-W Series w-6.0L Gas\Engine	√	√	√	√		0005, 0245, 0321, 0482, 0490, 0510
ISUZU\North American ISUZU series\2006\N-W Series w-6.0L Gas\Transmission		√	√	√		0002, 0003, 0656
ISUZU\North American ISUZU series\2006\N-W Series w-6.0L Gas\ABS		√	√	√		0014, 0015, 0016, 0452, 0453, 0454, 0455, 0574, 0575, 0577, 0578
ISUZU\North American ISUZU series\2006\F-T Series w-7.8L Diesel (6HK1)\Engine	√	√	√	√		0265, 0350, 0490, 0535, 0691
ISUZU\North American ISUZU series\2006\F-T Series w-7.8L Diesel (6HK1)\Transmission		√	√	√		0062, 0063, 0064, 0065, 0066, 0067, 0071, 0072, 0567, 0568, 0569, 0626, 0627, 0628, 0642, 0656
ISUZU\North American ISUZU series\2006\F-T Series w-7.8L Diesel (6HK1)\ABS		√	√	√		0014, 0265, 0456, 0457, 0458, 0459, 0483, 0601, 0602, 0603, 0604, 0615, 0666
ISUZU\North American ISUZU series\2006\F-T Series w-7.8L Diesel (6HK1)\IPC Data Display		√	√	√		
ISUZU\North American ISUZU series\2006\F-T Series w-7.8L Diesel (6HK1)\Chime Data Display		√	√	√		
ISUZU\North American ISUZU series\2006\F-T Series w-7.8L Diesel (6HK1)\SDGM Data Display(If Equipped)		√	√	√		
ISUZU\North American ISUZU series\2006\C-Series w-7.8L Diesel (6HK1)\Engine	√	√	√	√		0265, 0350, 0490, 0535, 0691

ISUZU\North American ISUZU series\2006\C-Series w-7.8L Diesel (6HK1)\Transmission		√	√	√		0062, 0063, 0064, 0065, 0066, 0067, 0071, 0072, 0567, 0568, 0569, 0626, 0627, 0628, 0642, 0656
ISUZU\North American ISUZU series\2006\C-Series w-7.8L Diesel (6HK1)\ABS		√	√	√		0014, 0265, 0456, 0457, 0458, 0459, 0483, 0601, 0602, 0603, 0604, 0615, 0666
ISUZU\North American ISUZU series\2006\C-Series w-7.8L Diesel (6HK1)\IPC Data Display		√	√	√		
ISUZU\North American ISUZU series\2006\C-Series w-7.8L Diesel (6HK1)\Chime Data Display		√	√	√		
ISUZU\North American ISUZU series\2006\C-Series w-7.8L Diesel (6HK1)\SDGM Data Display(If Equipped)		√	√	√		
ISUZU\North American ISUZU series\2005\N-W Series w-5.2L Diesel(4HK1)\Engine	√	√	√	√		0034, 0112, 0113, 0490, 0614, 0691
ISUZU\North American ISUZU series\2005\N-W Series w-5.2L Diesel(4HK1)\Transmission		√	√	√		0054, 0620, 0622, 0629, 0656
ISUZU\North American ISUZU series\2005\N-W Series w-5.2L Diesel(4HK1)\ABS		√	√	√		0014, 0015, 0016, 0266, 0452, 0453, 0454, 0455, 0574, 0575, 0577, 0578
ISUZU\North American ISUZU series\2005\N-W Series w-6.0L Gas\Engine	√	√	√	√		0005, 0245, 0321, 0482, 0490, 0510
ISUZU\North American ISUZU series\2005\N-W Series w-6.0L Gas\Transmission		√	√	√		0002, 0003, 0656
ISUZU\North American ISUZU series\2005\N-W Series w-6.0L Gas\ABS		√	√	√		0014, 0015, 0016, 0452, 0453, 0454, 0455, 0574, 0575, 0577, 0578
ISUZU\North American ISUZU series\2005\F-T Series w-7.8L Diesel (6HK1)\Engine	√	√	√	√		0119, 0129, 0139, 0149, 0159, 0162, 0265, 0350, 0490, 0535, 0691
ISUZU\North American ISUZU series\2005\F-T Series w-7.8L Diesel (6HK1)\Transmission		√	√	√		0062, 0063, 0064, 0065, 0066, 0067, 0071, 0072, 0567, 0568, 0569, 0626, 0627, 0628, 0642, 0656
ISUZU\North American ISUZU series\2005\F-T Series w-7.8L Diesel (6HK1)\ABS		√	√	√		0014, 0265, 0456, 0457, 0458, 0459, 0483, 0601, 0602, 0603, 0604, 0615, 0666
ISUZU\North American ISUZU series\2005\F-T Series w-7.8L Diesel (6HK1)\IPC Data Display		√	√	√		
ISUZU\North American ISUZU series\2005\F-T Series w-7.8L Diesel (6HK1)\Chime Data Display		√	√	√		
ISUZU\North American ISUZU series\2005\F-T Series w-7.8L Diesel (6HK1)\SDGM Data Display(If Equipped)		√	√	√		
ISUZU\North American ISUZU series\2005\C-Series w-7.8L Diesel (6HK1)\Engine	√	√	√	√		0119, 0129, 0139, 0149, 0159, 0162, 0265, 0350, 0490, 0535, 0691
ISUZU\North American ISUZU series\2005\C-Series w-7.8L Diesel (6HK1)\Transmission		√	√	√		0062, 0063, 0064, 0065, 0066, 0067, 0071, 0072, 0567, 0568, 0569, 0626, 0627, 0628, 0642, 0656
ISUZU\North American ISUZU series\2005\C-Series w-7.8L Diesel (6HK1)\ABS		√	√	√		0014, 0265, 0456, 0457, 0458, 0459, 0483, 0601, 0602, 0603, 0604, 0615, 0666
ISUZU\North American ISUZU series\2005\C-Series w-7.8L Diesel (6HK1)\IPC Data Display		√	√	√		
ISUZU\North American ISUZU series\2005\C-Series w-7.8L Diesel (6HK1)\Chime Data Display		√	√	√		
ISUZU\North American ISUZU series\2005\C-Series w-7.8L Diesel (6HK1)\SDGM Data Display(If Equipped)		√	√	√		
ISUZU\North American ISUZU series\2004\N-W Series w-6.0L Gas\Engine	√	√	√	√		0005, 0245, 0321, 0325, 0482, 0490
ISUZU\North American ISUZU series\2004\N-W Series w-6.0L Gas\Transmission		√	√	√		0002, 0003, 0656
ISUZU\North American ISUZU series\2004\N-W Series w-6.0L Gas\ABS		√	√	√		0014, 0015, 0016, 0452, 0453, 0454, 0455, 0574, 0575, 0577, 0578
ISUZU\North American ISUZU series\2004\F-T Series w-7.8L Diesel (6HK1)\Engine	√	√	√	√		0119, 0129, 0139, 0149, 0159, 0162, 0265, 0350, 0490, 0535, 0691
ISUZU\North American ISUZU series\2004\F-T Series w-7.8L Diesel (6HK1)\Transmission		√	√	√		0062, 0063, 0064, 0065, 0066, 0067, 0068, 0069, 0071, 0072, 0567, 0568, 0569, 0626, 0627, 0628, 0642, 0656

ISUZU\North American ISUZU series\2004\F-T Series w-7.8L Diesel (6HK1)\ABS		√	√	√		0014, 0265, 0456, 0457, 0458, 0459, 0483, 0601, 0602, 0603, 0604, 0615, 0666
ISUZU\North American ISUZU series\2004\F-T Series w-7.8L Diesel (6HK1)\IPC Data Display		√	√	√		
ISUZU\North American ISUZU series\2004\F-T Series w-7.8L Diesel (6HK1)\Chime Data Display		√	√	√		
ISUZU\North American ISUZU series\2004\F-T Series w-7.8L Diesel (6HK1)\SDGM Data Display(If Equipped)		√	√	√		
ISUZU\North American ISUZU series\2004\C-Series w-7.8L Diesel (6HK1)\Engine	√	√	√	√		0119, 0129, 0139, 0149, 0159, 0162, 0265, 0350, 0490, 0535, 0691
ISUZU\North American ISUZU series\2004\C-Series w-7.8L Diesel (6HK1)\Transmission		√	√	√		0062, 0063, 0064, 0065, 0066, 0067, 0068, 0069, 0071, 0072, 0567, 0568, 0569, 0626, 0627, 0628, 0642, 0656
ISUZU\North American ISUZU series\2004\C-Series w-7.8L Diesel (6HK1)\ABS		√	√	√		0014, 0265, 0456, 0457, 0458, 0459, 0483, 0601, 0602, 0603, 0604, 0615, 0666
ISUZU\North American ISUZU series\2004\C-Series w-7.8L Diesel (6HK1)\IPC Data Display		√	√	√		
ISUZU\North American ISUZU series\2004\C-Series w-7.8L Diesel (6HK1)\Chime Data Display		√	√	√		
ISUZU\North American ISUZU series\2004\C-Series w-7.8L Diesel (6HK1)\SDGM Data Display(If Equipped)		√	√	√		
ISUZU\North American ISUZU series\2003\N-W Series w-6.0L Gas\Engine	√	√	√	√		0005, 0245, 0321, 0325, 0482, 0490
ISUZU\North American ISUZU series\2003\N-W Series w-6.0L Gas\Transmission		√	√	√		0002, 0003, 0656
ISUZU\North American ISUZU series\2003\N-W Series w-6.0L Gas\ABS		√	√	√		0014, 0015, 0016, 0452, 0453, 0454, 0455, 0574, 0575, 0577, 0578
ISUZU\North American ISUZU series\2003\C-Series w-7.8L Diesel (6HK1)\Engine	√	√	√	√		0119, 0129, 0139, 0149, 0159, 0162, 0265, 0350, 0490, 0535, 0691
ISUZU\North American ISUZU series\2003\C-Series w-7.8L Diesel (6HK1)\Transmission		√	√	√		0062, 0063, 0064, 0065, 0066, 0067, 0068, 0069, 0071, 0072, 0567, 0568, 0569, 0626, 0627, 0628, 0642, 0656
ISUZU\North American ISUZU series\2003\C-Series w-7.8L Diesel (6HK1)\ABS		√	√	√		0014, 0265, 0456, 0457, 0458, 0459, 0483, 0601, 0602, 0603, 0604, 0615, 0666
ISUZU\North American ISUZU series\2003\C-Series w-7.8L Diesel (6HK1)\IPC Data Display		√	√	√		
ISUZU\North American ISUZU series\2003\C-Series w-7.8L Diesel (6HK1)\Chime Data Display		√	√	√		
ISUZU\North American ISUZU series\2003\C-Series w-7.8L Diesel (6HK1)\SDGM Data Display(If Equipped)		√	√	√		
ISUZU\North American ISUZU series\2003\N-W Series w-5.7L (CAL) Gas\Engine	√	√	√	√		0005, 0245, 0321, 0325, 0482, 0490
ISUZU\North American ISUZU series\2003\N-W Series w-5.7L (CAL) Gas\Transmission		√	√	√		0002, 0003, 0656
ISUZU\North American ISUZU series\2003\N-W Series w-5.7L (CAL) Gas\ABS		√	√	√		0014, 0015, 0016, 0452, 0453, 0454, 0455, 0574, 0575, 0577, 0578
ISUZU\North American ISUZU series\2003\N-W Series w-5.7L (FED) Gas\Engine	√	√	√	√		0005, 0245, 0321, 0325, 0482, 0490
ISUZU\North American ISUZU series\2003\N-W Series w-5.7L (FED) Gas\Transmission		√	√	√		0002, 0003, 0656
ISUZU\North American ISUZU series\2003\N-W Series w-5.7L (FED) Gas\ABS		√	√	√		0014, 0015, 0016, 0452, 0453, 0454, 0455, 0574, 0575, 0577, 0578
ISUZU\North American ISUZU series\2002\N-W Series w-5.7L (CAL) Gas\Engine	√	√	√	√		0005, 0245, 0321, 0325, 0482, 0490
ISUZU\North American ISUZU series\2002\N-W Series w-5.7L (CAL) Gas\Transmission		√	√	√		0002, 0003, 0656
ISUZU\North American ISUZU series\2002\N-W Series w-5.7L (CAL) Gas\ABS		√	√	√		
ISUZU\North American ISUZU series\2002\N-W Series w-5.7L (FED) Gas\Engine	√	√	√	√		0005, 0245, 0321, 0325, 0482, 0490
ISUZU\North American ISUZU series\2002\N-W Series w-5.7L (FED) Gas\Transmission		√	√	√		0002, 0003, 0656
ISUZU\North American ISUZU series\2002\N-W Series w-5.7L (FED) Gas\ABS		√	√	√		
ISUZU\North American ISUZU series\2001\N-W Series w-5.7L (CAL) Gas\Engine	√	√	√	√		0005, 0245, 0321, 0325, 0482, 0490

ISUZU\North American ISUZU series\2001\N-W Series w-5.7L (CAL) Gas\Transmission		√	√	√		0002, 0003, 0656
ISUZU\North American ISUZU series\2001\N-W Series w-5.7L (CAL) Gas\ABS		√	√	√		
ISUZU\North American ISUZU series\2001\N-W Series w-5.7L (FED) Gas\Engine	√	√	√	√		0005, 0245, 0321, 0325, 0482, 0490
ISUZU\North American ISUZU series\2001\N-W Series w-5.7L (FED) Gas\Transmission		√	√	√		0002, 0003, 0656
ISUZU\North American ISUZU series\2001\N-W Series w-5.7L (FED) Gas\ABS		√	√	√		
ISUZU\North American ISUZU series\2000\N-W Series w-5.7L (CAL) Gas\Engine	√	√	√	√		0005, 0245, 0490
ISUZU\North American ISUZU series\2000\N-W Series w-5.7L (CAL) Gas\Transmission		√	√	√		
ISUZU\North American ISUZU series\2000\N-W Series w-5.7L (CAL) Gas\ABS		√	√	√		0002, 0003, 0656
ISUZU\North American ISUZU series\2000\N-W Series w-5.7L (FED) Gas\Engine	√	√	√	√		0005, 0245, 0490
ISUZU\North American ISUZU series\2000\N-W Series w-5.7L (FED) Gas\Transmission		√	√	√		
ISUZU\North American ISUZU series\2000\N-W Series w-5.7L (FED) Gas\ABS		√	√	√		
ISUZU\North American ISUZU series\1999\N-W Series w-5.7L (CAL) Gas\Engine	√	√	√	√		0005, 0245, 0490
ISUZU\North American ISUZU series\1999\N-W Series w-5.7L (CAL) Gas\Transmission		√	√	√		
ISUZU\North American ISUZU series\1999\N-W Series w-5.7L (CAL) Gas\ABS		√	√	√		
ISUZU\North American ISUZU series\1999\N-W Series w-5.7L (FED) Gas\Engine	√	√	√	√		0005, 0245, 0490
ISUZU\North American ISUZU series\1999\N-W Series w-5.7L (FED) Gas\Transmission		√	√	√		
ISUZU\North American ISUZU series\1999\N-W Series w-5.7L (FED) Gas\ABS		√	√	√		
ISUZU\North American ISUZU series\1998\N-W Series w-5.7L (CAL) Gas\Engine	√	√	√	√		
ISUZU\North American ISUZU series\1998\N-W Series w-5.7L (CAL) Gas\Transmission		√	√	√		
ISUZU\North American ISUZU series\1998\N-W Series w-5.7L (FED) Gas\Engine	√	√	√	√		
ISUZU\North American ISUZU series\1998\N-W Series w-5.7L (FED) Gas\Transmission		√	√	√		
ISUZU\Euro 5,Euro 4,Euro 3,Euro 2 series\Euro 4 && Euro 5\F]2015\N-Series w-5.2L Diesel(4HK1)\Engine	√	√	√	√		0075, 0077, 0112, 0113, 0119, 0129, 0139, 0149, 0189, 0212, 0269, 0270, 0349, 0351, 0375, 0401, 0405, 0409, 0413, 0490, 0535, 0584, 0585, 0617, 0652, 0697
ISUZU\Euro 5,Euro 4,Euro 3,Euro 2 series\Euro 4 && Euro 5\F]2015\N-Series w-5.2L Diesel(4HK1)\TRANSMISSION		√	√	√		0054, 0467, 0468, 0469, 0470, 0620, 0622, 0624, 0625, 0667
ISUZU\Euro 5,Euro 4,Euro 3,Euro 2 series\Euro 4 && Euro 5\F]2015\N-Series w-5.2L Diesel(4HK1)\ABS		√	√			
ISUZU\Euro 5,Euro 4,Euro 3,Euro 2 series\Euro 4 && Euro 5\F]2015\N-Series w-5.2L Diesel(4HK1)\Mimamori ECU		√	√			0011, 0012, 0013, 0251, 0252, 0318, 0589, 0611, 0612
ISUZU\Euro 5,Euro 4,Euro 3,Euro 2 series\Euro 4 && Euro 5\F]2015\N-Series w-5.2L Diesel(4HK1)\Diesel Exhaust Fluid Control Module	√	√	√			0174, 0175, 0176, 0177, 0178, 0187, 0240, 0497, 0498, 0522, 0609, 0610
ISUZU\Euro 5,Euro 4,Euro 3,Euro 2 series\Euro 4 && Euro 5\E]2014\N-Series w-5.2L Diesel(4HK1)\Engine	√	√	√	√		0075, 0077, 0112, 0113, 0119, 0129, 0139, 0149, 0189, 0212, 0269, 0270, 0349, 0351, 0375, 0401, 0405, 0409, 0413, 0490, 0535, 0584, 0585, 0617, 0652, 0697
ISUZU\Euro 5,Euro 4,Euro 3,Euro 2 series\Euro 4 && Euro 5\E]2014\N-Series w-5.2L Diesel(4HK1)\Engine-EURO5	√	√	√	√	√	0120, 0130, 0140, 0150, 0248, 0265, 0296, 0320, 0361, 0391, 0401, 0402, 0405, 0406, 0409, 0410, 0413, 0414, 0542, 0672
ISUZU\Euro 5,Euro 4,Euro 3,Euro 2 series\Euro 4 && Euro 5\E]2014\N-Series w-5.2L Diesel(4HK1)\TRANSMISSION		√	√	√		0054, 0467, 0468, 0469, 0470, 0620, 0622, 0624, 0625, 0667
ISUZU\Euro 5,Euro 4,Euro 3,Euro 2 series\Euro 4 && Euro 5\E]2014\N-Series w-5.2L Diesel(4HK1)\ABS		√	√			

ISUZU\Euro 5,Euro 4,Euro 3,Euro 2 series\Euro 4 && Euro 5\E]2014\N-Series w-5.2L Diesel(4HK1)\Mimamori ECU		√	√			0011, 0012, 0013, 0251, 0252, 0318, 0589, 0611, 0612
ISUZU\Euro 5,Euro 4,Euro 3,Euro 2 series\Euro 4 && Euro 5\E]2014\N-Series w-5.2L Diesel(4HK1)\Diesel Exhaust Fluid Control Module	√	√	√			0174, 0175, 0176, 0177, 0178, 0187, 0240, 0497, 0498, 0522, 0609, 0610
ISUZU\Euro 5,Euro 4,Euro 3,Euro 2 series\Euro 4 && Euro 5\E]2014\N-Series w-3.0L Diesel(4JJ1)\Engine	√	√	√	√		0075, 0077, 0112, 0113, 0119, 0129, 0139, 0149, 0189, 0212, 0219, 0269, 0270, 0349, 0351, 0375, 0401, 0405, 0409, 0413, 0490, 0535, 0585, 0617, 0652
ISUZU\Euro 5,Euro 4,Euro 3,Euro 2 series\Euro 4 && Euro 5\E]2014\N-Series w-3.0L Diesel(4JJ1)\TRANSMISSION		√	√	√		0054, 0467, 0468, 0469, 0470, 0620, 0622, 0624, 0625, 0667
ISUZU\Euro 5,Euro 4,Euro 3,Euro 2 series\Euro 4 && Euro 5\E]2014\N-Series w-3.0L Diesel(4JJ1)\ABS		√	√			
ISUZU\Euro 5,Euro 4,Euro 3,Euro 2 series\Euro 4 && Euro 5\E]2014\N-Series w-3.0L Diesel(4JJ1)\Mimamori ECU		√	√			0011, 0012, 0013, 0251, 0252, 0318, 0589, 0611, 0612
ISUZU\Euro 5,Euro 4,Euro 3,Euro 2 series\Euro 4 && Euro 5\E]2014\N-Series w-3.0L Diesel(4JJ1)\Diesel Exhaust Fluid Control Module	√	√	√			0174, 0175, 0176, 0177, 0178, 0187, 0240, 0497, 0498, 0522, 0609, 0610
ISUZU\Euro 5,Euro 4,Euro 3,Euro 2 series\Euro 4 && Euro 5\D]2013\N-Series w-5.2L Diesel(4HK1)\Engine	√	√	√	√		0075, 0077, 0112, 0113, 0119, 0129, 0139, 0149, 0189, 0212, 0269, 0270, 0349, 0351, 0375, 0401, 0405, 0409, 0413, 0490, 0535, 0584, 0585, 0617, 0652, 0697
ISUZU\Euro 5,Euro 4,Euro 3,Euro 2 series\Euro 4 && Euro 5\D]2013\N-Series w-5.2L Diesel(4HK1)\TRANSMISSION		√	√	√		0054, 0467, 0468, 0469, 0470, 0620, 0622, 0624, 0625, 0667
ISUZU\Euro 5,Euro 4,Euro 3,Euro 2 series\Euro 4 && Euro 5\D]2013\N-Series w-5.2L Diesel(4HK1)\ABS		√	√			
ISUZU\Euro 5,Euro 4,Euro 3,Euro 2 series\Euro 4 && Euro 5\D]2013\N-Series w-5.2L Diesel(4HK1)\Mimamori ECU		√	√			0011, 0012, 0013, 0251, 0252, 0318, 0589, 0611, 0612
ISUZU\Euro 5,Euro 4,Euro 3,Euro 2 series\Euro 4 && Euro 5\D]2013\N-Series w-5.2L Diesel(4HK1)\Diesel Exhaust Fluid Control Module	√	√	√			0174, 0175, 0176, 0177, 0178, 0187, 0240, 0497, 0498, 0522, 0609, 0610
ISUZU\Euro 5,Euro 4,Euro 3,Euro 2 series\Euro 4 && Euro 5\D]2013\N-Series w-3.0L Diesel(4JJ1)\Engine	√	√	√	√		0075, 0077, 0112, 0113, 0119, 0129, 0139, 0149, 0189, 0212, 0219, 0269, 0270, 0349, 0351, 0375, 0401, 0405, 0409, 0413, 0490, 0535, 0585, 0617, 0652
ISUZU\Euro 5,Euro 4,Euro 3,Euro 2 series\Euro 4 && Euro 5\D]2013\N-Series w-3.0L Diesel(4JJ1)\TRANSMISSION		√	√	√		0054, 0467, 0468, 0469, 0470, 0620, 0622, 0624, 0625, 0667
ISUZU\Euro 5,Euro 4,Euro 3,Euro 2 series\Euro 4 && Euro 5\D]2013\N-Series w-3.0L Diesel(4JJ1)\ABS		√	√			
ISUZU\Euro 5,Euro 4,Euro 3,Euro 2 series\Euro 4 && Euro 5\D]2013\N-Series w-3.0L Diesel(4JJ1)\Mimamori ECU		√	√			0011, 0012, 0013, 0251, 0252, 0318, 0589, 0611, 0612
ISUZU\Euro 5,Euro 4,Euro 3,Euro 2 series\Euro 4 && Euro 5\D]2013\N-Series w-3.0L Diesel(4JJ1)\Diesel Exhaust Fluid Control Module	√	√	√			0174, 0175, 0176, 0177, 0178, 0187, 0240, 0497, 0498, 0522, 0609, 0610
ISUZU\Euro 5,Euro 4,Euro 3,Euro 2 series\Euro 4 && Euro 5\C]2012\N-Series w-5.2L Diesel(4HK1)\Engine	√	√	√	√		0075, 0077, 0112, 0113, 0119, 0129, 0139, 0149, 0189, 0212, 0269, 0270, 0349, 0351, 0375, 0401, 0405, 0409, 0413, 0490, 0535, 0584, 0585, 0617, 0652, 0697
ISUZU\Euro 5,Euro 4,Euro 3,Euro 2 series\Euro 4 && Euro 5\C]2012\N-Series w-5.2L Diesel(4HK1)\TRANSMISSION		√	√	√		0054, 0467, 0468, 0469, 0470, 0620, 0622, 0624, 0625, 0667
ISUZU\Euro 5,Euro 4,Euro 3,Euro 2 series\Euro 4 && Euro 5\C]2012\N-Series w-5.2L Diesel(4HK1)\ABS		√	√			
ISUZU\Euro 5,Euro 4,Euro 3,Euro 2 series\Euro 4 && Euro 5\C]2012\N-Series w-5.2L Diesel(4HK1)\Mimamori ECU		√	√			0011, 0012, 0013, 0251, 0252, 0318, 0589, 0611, 0612

ISUZU\Euro 5,Euro 4,Euro 3,Euro 2 series\Euro 4 && Euro 5\ [C]2012\N-Series w-5.2L Diesel(4HK1)\Diesel Exhaust Fluid Control Module	√	√	√			0174, 0175, 0176, 0177, 0178, 0187, 0240, 0497, 0498, 0522, 0609, 0610
ISUZU\Euro 5,Euro 4,Euro 3,Euro 2 series\Euro 4 && Euro 5\ [C]2012\N-Series w-3.0L Diesel(4JJ1)\Engine	√	√	√	√		0075, 0077, 0112, 0113, 0119, 0129, 0139, 0149, 0189, 0212, 0219, 0269, 0270, 0349, 0351, 0375, 0401, 0405, 0409, 0413, 0490, 0535, 0585, 0617, 0652
ISUZU\Euro 5,Euro 4,Euro 3,Euro 2 series\Euro 4 && Euro 5\ [C]2012\N-Series w-3.0L Diesel(4JJ1)\TRANSMISSION		√	√	√		0054, 0467, 0468, 0469, 0470, 0620, 0622, 0624, 0625, 0667
ISUZU\Euro 5,Euro 4,Euro 3,Euro 2 series\Euro 4 && Euro 5\ [C]2012\N-Series w-3.0L Diesel(4JJ1)\ABS		√	√			
ISUZU\Euro 5,Euro 4,Euro 3,Euro 2 series\Euro 4 && Euro 5\ [C]2012\N-Series w-3.0L Diesel(4JJ1)\Mimamori ECU		√	√			0011, 0012, 0013, 0251, 0252, 0318, 0589, 0611, 0612
ISUZU\Euro 5,Euro 4,Euro 3,Euro 2 series\Euro 4 && Euro 5\ [C]2012\N-Series w-3.0L Diesel(4JJ1)\Diesel Exhaust Fluid Control Module	√	√	√			0174, 0175, 0176, 0177, 0178, 0187, 0240, 0497, 0498, 0522, 0609, 0610
ISUZU\Euro 5,Euro 4,Euro 3,Euro 2 series\Euro 4 && Euro 5\ [B]2011\N-Series w-5.2L Diesel(4HK1)\Engine	√	√	√	√		0075, 0077, 0112, 0113, 0119, 0129, 0139, 0149, 0189, 0212, 0269, 0270, 0349, 0351, 0375, 0401, 0405, 0409, 0413, 0490, 0535, 0584, 0585, 0617, 0652, 0697
ISUZU\Euro 5,Euro 4,Euro 3,Euro 2 series\Euro 4 && Euro 5\ [B]2011\N-Series w-5.2L Diesel(4HK1)\TRANSMISSION		√	√	√		0054, 0467, 0468, 0469, 0470, 0620, 0622, 0624, 0625, 0667
ISUZU\Euro 5,Euro 4,Euro 3,Euro 2 series\Euro 4 && Euro 5\ [B]2011\N-Series w-5.2L Diesel(4HK1)\ABS		√	√			
ISUZU\Euro 5,Euro 4,Euro 3,Euro 2 series\Euro 4 && Euro 5\ [B]2011\N-Series w-5.2L Diesel(4HK1)\Mimamori ECU		√	√			0011, 0012, 0013, 0251, 0252, 0318, 0589, 0611, 0612
ISUZU\Euro 5,Euro 4,Euro 3,Euro 2 series\Euro 4 && Euro 5\ [B]2011\N-Series w-5.2L Diesel(4HK1)\Diesel Exhaust Fluid Control Module	√	√	√			0174, 0175, 0176, 0177, 0178, 0187, 0240, 0497, 0498, 0522, 0609, 0610
ISUZU\Euro 5,Euro 4,Euro 3,Euro 2 series\Euro 4 && Euro 5\ [B]2011\N-Series w-3.0L Diesel(4JJ1)\Engine	√	√	√	√		0075, 0077, 0112, 0113, 0119, 0129, 0139, 0149, 0189, 0212, 0219, 0269, 0270, 0349, 0351, 0375, 0401, 0405, 0409, 0413, 0490, 0535, 0585, 0617, 0652
ISUZU\Euro 5,Euro 4,Euro 3,Euro 2 series\Euro 4 && Euro 5\ [B]2011\N-Series w-3.0L Diesel(4JJ1)\TRANSMISSION		√	√	√		0054, 0467, 0468, 0469, 0470, 0620, 0622, 0624, 0625, 0667
ISUZU\Euro 5,Euro 4,Euro 3,Euro 2 series\Euro 4 && Euro 5\ [B]2011\N-Series w-3.0L Diesel(4JJ1)\ABS		√	√			
ISUZU\Euro 5,Euro 4,Euro 3,Euro 2 series\Euro 4 && Euro 5\ [B]2011\N-Series w-3.0L Diesel(4JJ1)\Mimamori ECU		√	√			0011, 0012, 0013, 0251, 0252, 0318, 0589, 0611, 0612
ISUZU\Euro 5,Euro 4,Euro 3,Euro 2 series\Euro 4 && Euro 5\ [B]2011\N-Series w-3.0L Diesel(4JJ1)\Diesel Exhaust Fluid Control Module	√	√	√			0174, 0175, 0176, 0177, 0178, 0187, 0240, 0497, 0498, 0522, 0609, 0610
ISUZU\Euro 5,Euro 4,Euro 3,Euro 2 series\Euro 4 && Euro 5\ [B]2011\F-G Series Truck\Engine\4HK1-TC (C-Rail)	√	√	√	√		0032, 0202, 0214, 0270, 0312, 0343, 0401, 0405, 0409, 0413, 0508, 0509, 0543, 0564, 0592, 0671, 0704
ISUZU\Euro 5,Euro 4,Euro 3,Euro 2 series\Euro 4 && Euro 5\ [B]2011\F-G Series Truck\Engine\6HK1-TC (C-Rail)	√	√	√	√		0120, 0130, 0140, 0150, 0203, 0221, 0248, 0265, 0296, 0320, 0361, 0391, 0401, 0402, 0405, 0406, 0409, 0410, 0413, 0414, 0499, 0516, 0542, 0573, 0640, 0672
ISUZU\Euro 5,Euro 4,Euro 3,Euro 2 series\Euro 4 && Euro 5\ [B]2011\F-G Series Truck\TRANSMISSION\Smother (TransTron)		√	√	√		
ISUZU\Euro 5,Euro 4,Euro 3,Euro 2 series\Euro 4 && Euro 5\ [B]2011\F-G Series Truck\TRANSMISSION\TRANSMISSION		√	√	√		0054, 0467, 0468, 0469, 0470, 0620, 0622, 0624, 0625, 0667
ISUZU\Euro 5,Euro 4,Euro 3,Euro 2 series\Euro 4 && Euro 5\ [B]2011\F-G Series Truck\Body\Immobiliser		√	√	√		

ISUZU\Euro 5,Euro 4,Euro 3,Euro 2 series\Euro 4 && Euro 5\B]2011\C-E Series Truck\Engine\6WG1-TC (C-Rail)	√	√	√	√		0120, 0130, 0140, 0150, 0203, 0221, 0248, 0265, 0296, 0320, 0361, 0391, 0401, 0402, 0405, 0406, 0409, 0410, 0413, 0414, 0499, 0516, 0542, 0573, 0640, 0672
ISUZU\Euro 5,Euro 4,Euro 3,Euro 2 series\Euro 4 && Euro 5\B]2011\LT-LV Series Bus\Engine\6HK1-TC (C-Rail)	√	√	√	√		0120, 0130, 0140, 0150, 0203, 0221, 0248, 0265, 0296, 0320, 0361, 0391, 0401, 0402, 0405, 0406, 0409, 0410, 0413, 0414, 0499, 0516, 0542, 0573, 0640, 0672
ISUZU\Euro 5,Euro 4,Euro 3,Euro 2 series\Euro 4 && Euro 5\B]2011\LT-LV Series Bus\TRANSMISSION\TRANSMISSION		√	√	√		0054, 0467, 0468, 0469, 0470, 0620, 0622, 0624, 0625, 0667
ISUZU\Euro 5,Euro 4,Euro 3,Euro 2 series\Euro 4 && Euro 5\B]2011\TF-UC Serise\Engine\2.5L 4JK1-TC (Delphi)		√	√	√		0291, 0394, 0401, 0405, 0409, 0413, 0444, 0490, 0545, 0564, 0580, 0588, 0687
ISUZU\Euro 5,Euro 4,Euro 3,Euro 2 series\Euro 4 && Euro 5\B]2011\TF-UC Serise\Engine\2.5L 4JK1-TC (TransTron)		√	√	√		0291, 0394, 0401, 0405, 0409, 0413, 0444, 0490, 0545, 0564, 0580, 0588, 0687
ISUZU\Euro 5,Euro 4,Euro 3,Euro 2 series\Euro 4 && Euro 5\B]2011\TF-UC Serise\Engine\3.0L 4JJ1-TC (Delphi)		√	√	√		0291, 0394, 0401, 0405, 0409, 0413, 0444, 0490, 0545, 0564, 0580, 0588, 0687
ISUZU\Euro 5,Euro 4,Euro 3,Euro 2 series\Euro 4 && Euro 5\B]2011\TF-UC Serise\Engine\3.0L 4JJ1-TC (TransTron)		√	√	√		0291, 0394, 0401, 0405, 0409, 0413, 0444, 0490, 0545, 0564, 0580, 0588, 0687
ISUZU\Euro 5,Euro 4,Euro 3,Euro 2 series\Euro 4 && Euro 5\B]2011\TF-UC Serise\TRANSMISSION\TRANSMISSION		√	√	√		0054, 0467, 0468, 0469, 0470, 0620, 0622, 0624, 0625, 0667
ISUZU\Euro 5,Euro 4,Euro 3,Euro 2 series\Euro 4 && Euro 5\B]2011\TF-UC Serise\TRANSMISSION\AT JR405E		√	√	√		0004, 0037, 0347, 0369, 0480, 0481, 0484, 0540, 0572, 0653, 0661, 0669
ISUZU\Euro 5,Euro 4,Euro 3,Euro 2 series\Euro 4 && Euro 5\B]2011\TF-UC Serise\Chassis\ABS		√	√	√		0022, 0025, 0026, 0293, 0382, 0460, 0462, 0605, 0607
ISUZU\Euro 5,Euro 4,Euro 3,Euro 2 series\Euro 4 && Euro 5\B]2011\TF-UC Serise\Body\Immobiliser (Delphi)		√	√	√		
ISUZU\Euro 5,Euro 4,Euro 3,Euro 2 series\Euro 4 && Euro 5\B]2011\TF-UC Serise\Body\Immobiliser (Transtron)		√	√	√		
ISUZU\Euro 5,Euro 4,Euro 3,Euro 2 series\Euro 4 && Euro 5\B]2011\TF-UC Serise\Body\Airbag		√	√	√		
ISUZU\Euro 5,Euro 4,Euro 3,Euro 2 series\Euro 4 && Euro 5\B]2011\TF-UC Serise\Body\Powertrain Interface Module	√			√		
ISUZU\Euro 5,Euro 4,Euro 3,Euro 2 series\Euro 4 && Euro 5\A]2010\N-W Series w-5.2L Diesel(4HK1)\Engine-Euro 4	√	√	√	√		0120, 0130, 0140, 0150, 0203, 0221, 0248, 0265, 0296, 0320, 0361, 0391, 0401, 0402, 0405, 0406, 0409, 0410, 0413, 0414, 0499, 0516, 0542, 0573, 0640, 0672
ISUZU\Euro 5,Euro 4,Euro 3,Euro 2 series\Euro 4 && Euro 5\A]2010\N-W Series w-5.2L Diesel(4HK1)\Engine-4HK1	√	√	√	√		0075, 0112, 0113, 0119, 0129, 0139, 0149, 0189, 0270, 0349, 0351, 0401, 0405, 0409, 0413, 0490, 0535, 0585, 0617, 0652
ISUZU\Euro 5,Euro 4,Euro 3,Euro 2 series\Euro 4 && Euro 5\A]2010\N-W Series w-5.2L Diesel(4HK1)\TRANSMISSION		√	√	√		0054, 0467, 0468, 0469, 0470, 0620, 0622, 0624, 0625, 0667
ISUZU\Euro 5,Euro 4,Euro 3,Euro 2 series\Euro 4 && Euro 5\A]2010\N-W Series w-5.2L Diesel(4HK1)\ABS		√	√			

ISUZU\Euro 5,Euro 4,Euro 3,Euro 2 series\Euro 4 && Euro 5\9\2009\N-W Series w-6.0L Gas\Engine-V8	√	√	√	√		0005, 0048, 0049, 0119, 0129, 0139, 0149, 0159, 0162, 0165, 0166, 0211, 0243, 0245, 0322, 0324, 0325, 0348, 0362, 0363, 0364, 0365, 0366, 0374, 0376, 0401, 0405, 0409, 0413, 0417, 0419, 0421, 0422, 0482, 0490, 0647
ISUZU\Euro 5,Euro 4,Euro 3,Euro 2 series\Euro 4 && Euro 5\9\2009\N-W Series w-6.0L Gas\TRANSMISSION	√	√	√			0002, 0003, 0597, 0656
ISUZU\Euro 5,Euro 4,Euro 3,Euro 2 series\Euro 4 && Euro 5\9\2009\N-W Series w-5.2L Diesel(4HK1)\Engine	√	√	√	√		0075, 0112, 0113, 0119, 0129, 0139, 0149, 0189, 0270, 0349, 0351, 0401, 0405, 0409, 0413, 0490, 0535, 0585, 0617, 0652
ISUZU\Euro 5,Euro 4,Euro 3,Euro 2 series\Euro 4 && Euro 5\9\2009\N-W Series w-5.2L Diesel(4HK1)\TRANSMISSION		√	√	√		0054, 0467, 0468, 0469, 0470, 0620, 0622, 0624, 0625, 0667
ISUZU\Euro 5,Euro 4,Euro 3,Euro 2 series\Euro 4 && Euro 5\9\2009\F-G Series Truck\Engine\4HK1-TC (C-Rail)	√	√	√	√		0032, 0202, 0214, 0270, 0312, 0343, 0401, 0405, 0409, 0413, 0508, 0509, 0543, 0564, 0592, 0671, 0704
ISUZU\Euro 5,Euro 4,Euro 3,Euro 2 series\Euro 4 && Euro 5\9\2009\F-G Series Truck\Engine\6HK1-TC (C-Rail)	√	√	√	√		0120, 0130, 0140, 0150, 0203, 0221, 0248, 0265, 0296, 0320, 0361, 0391, 0401, 0402, 0405, 0406, 0409, 0410, 0413, 0414, 0499, 0516, 0542, 0573, 0640, 0672
ISUZU\Euro 5,Euro 4,Euro 3,Euro 2 series\Euro 4 && Euro 5\9\2009\F-G Series Truck\TRANSMISSION\Smoother (TransTron)		√	√	√		
ISUZU\Euro 5,Euro 4,Euro 3,Euro 2 series\Euro 4 && Euro 5\9\2009\F-G Series Truck\TRANSMISSION\TRANSMISSION		√	√	√		0054, 0467, 0468, 0469, 0470, 0620, 0622, 0624, 0625, 0667
ISUZU\Euro 5,Euro 4,Euro 3,Euro 2 series\Euro 4 && Euro 5\9\2009\F-G Series Truck\Body\Immobiliser		√	√	√		
ISUZU\Euro 5,Euro 4,Euro 3,Euro 2 series\Euro 4 && Euro 5\9\2009\C-E Series Truck\Engine\6WG1-TC (C-Rail)		√	√	√		0119, 0120, 0129, 0130, 0139, 0140, 0149, 0150, 0159, 0160, 0162, 0163, 0203, 0221, 0248, 0265, 0296, 0320, 0361, 0391, 0402, 0406, 0410, 0414, 0499, 0504, 0505, 0507, 0542, 0573, 0586, 0640, 0672
ISUZU\Euro 5,Euro 4,Euro 3,Euro 2 series\Euro 4 && Euro 5\9\2009\LT-LV Series Bus\Engine\6HK1-TC (C-Rail)	√	√	√	√		0225, 0296, 0401, 0405, 0409, 0413, 0489, 0502, 0503, 0506, 0508, 0543, 0564, 0583, 0587, 0598, 0674
ISUZU\Euro 5,Euro 4,Euro 3,Euro 2 series\Euro 4 && Euro 5\9\2009\LT-LV Series Bus\TRANSMISSION\TRANSMISSION		√	√	√		0054, 0467, 0468, 0469, 0470, 0620, 0622, 0624, 0625, 0667
ISUZU\Euro 5,Euro 4,Euro 3,Euro 2 series\Euro 4 && Euro 5\9\2009\TF-UC Serise\Engine\2.5L 4JK1-TC (Delphi)		√	√	√		0291, 0394, 0401, 0405, 0409, 0413, 0444, 0490, 0545, 0564, 0580, 0588, 0687
ISUZU\Euro 5,Euro 4,Euro 3,Euro 2 series\Euro 4 && Euro 5\9\2009\TF-UC Serise\Engine\2.5L 4JK1-TC (TransTron)		√	√	√		0291, 0394, 0401, 0405, 0409, 0413, 0444, 0490, 0545, 0564, 0580, 0588, 0687
ISUZU\Euro 5,Euro 4,Euro 3,Euro 2 series\Euro 4 && Euro 5\9\2009\TF-UC Serise\Engine\3.0L 4JJ1-TC (Delphi)		√	√	√		0291, 0394, 0401, 0405, 0409, 0413, 0444, 0490, 0545, 0564, 0580, 0588, 0687
ISUZU\Euro 5,Euro 4,Euro 3,Euro 2 series\Euro 4 && Euro 5\9\2009\TF-UC Serise\Engine\3.0L 4JJ1-TC (TransTron)		√	√	√		0291, 0394, 0401, 0405, 0409, 0413, 0444, 0490, 0545, 0564, 0580, 0588, 0687
ISUZU\Euro 5,Euro 4,Euro 3,Euro 2 series\Euro 4 && Euro 5\9\2009\TF-UC Serise\TRANSMISSION\TRANSMISSION		√	√	√		0054, 0467, 0468, 0469, 0470, 0620, 0622, 0624, 0625, 0667
ISUZU\Euro 5,Euro 4,Euro 3,Euro 2 series\Euro 4 && Euro 5\9\2009\TF-UC Serise\TRANSMISSION\AT JR405E		√	√	√		0004, 0037, 0347, 0369, 0480, 0481, 0484, 0540, 0572, 0653, 0661, 0669

ISUZU\Euro 5,Euro 4,Euro 3,Euro 2 series\Euro 4 && Euro 5\9]2009\TF-UC Serise\Chassis\ABS		√	√			
ISUZU\Euro 5,Euro 4,Euro 3,Euro 2 series\Euro 4 && Euro 5\9]2009\TF-UC Serise\Body\Immobiliser (Delphi)		√	√	√		
ISUZU\Euro 5,Euro 4,Euro 3,Euro 2 series\Euro 4 && Euro 5\9]2009\TF-UC Serise\Body\Immobiliser (Transtron)		√	√	√		
ISUZU\Euro 5,Euro 4,Euro 3,Euro 2 series\Euro 4 && Euro 5\9]2009\TF-UC Serise\Body\Airbag		√	√	√		
ISUZU\Euro 5,Euro 4,Euro 3,Euro 2 series\Euro 4 && Euro 5\9]2009\TF-UC Serise\Body\Powertrain Interface Module	√			√		
ISUZU\Euro 5,Euro 4,Euro 3,Euro 2 series\Euro 4 && Euro 5\8]2008\N-W Series w-6.0L Gas\Engine-V8	√	√	√	√		0005, 0048, 0049, 0119, 0129, 0139, 0149, 0159, 0162, 0165, 0166, 0211, 0243, 0245, 0322, 0324, 0325, 0348, 0362, 0363, 0364, 0365, 0366, 0374, 0376, 0401, 0405, 0409, 0413, 0417, 0419, 0421, 0422, 0482, 0490, 0647
ISUZU\Euro 5,Euro 4,Euro 3,Euro 2 series\Euro 4 && Euro 5\8]2008\N-W Series w-6.0L Gas\TRANSMISSION	√	√	√			0002, 0003, 0597, 0656
ISUZU\Euro 5,Euro 4,Euro 3,Euro 2 series\Euro 4 && Euro 5\8]2008\N-W Series w-5.2L Diesel(4HK1)\Engine	√	√	√	√		0075, 0112, 0113, 0119, 0129, 0139, 0149, 0189, 0270, 0349, 0351, 0401, 0405, 0409, 0413, 0490, 0535, 0585, 0617, 0652
ISUZU\Euro 5,Euro 4,Euro 3,Euro 2 series\Euro 4 && Euro 5\8]2008\N-W Series w-5.2L Diesel(4HK1)\TRANSMISSION		√	√	√		0054, 0467, 0468, 0469, 0470, 0620, 0622, 0624, 0625, 0667
ISUZU\Euro 5,Euro 4,Euro 3,Euro 2 series\Euro 4 && Euro 5\8]2008\F-G Series Truck\Engine\4HK1-TC (C-Rail)	√	√	√	√		0032, 0202, 0214, 0270, 0312, 0343, 0401, 0405, 0409, 0413, 0508, 0509, 0543, 0564, 0592, 0671, 0704
ISUZU\Euro 5,Euro 4,Euro 3,Euro 2 series\Euro 4 && Euro 5\8]2008\F-G Series Truck\Engine\6HK1-TC (C-Rail)	√	√	√	√		0120, 0130, 0140, 0150, 0203, 0221, 0248, 0265, 0296, 0320, 0361, 0391, 0401, 0402, 0405, 0406, 0409, 0410, 0413, 0414, 0499, 0516, 0542, 0573, 0640, 0672
ISUZU\Euro 5,Euro 4,Euro 3,Euro 2 series\Euro 4 && Euro 5\8]2008\F-G Series Truck\TRANSMISSION\Smoother (TransTron)		√	√	√		
ISUZU\Euro 5,Euro 4,Euro 3,Euro 2 series\Euro 4 && Euro 5\8]2008\F-G Series Truck\TRANSMISSION\TRANSMISSION		√	√	√		0054, 0467, 0468, 0469, 0470, 0620, 0622, 0624, 0625, 0667
ISUZU\Euro 5,Euro 4,Euro 3,Euro 2 series\Euro 4 && Euro 5\8]2008\F-G Series Truck\Body\Immobiliser		√	√	√		
ISUZU\Euro 5,Euro 4,Euro 3,Euro 2 series\Euro 4 && Euro 5\8]2008\C-E Series Truck\Engine\6WG1-TC (C-Rail)	√	√	√	√		0120, 0130, 0140, 0150, 0203, 0221, 0248, 0265, 0296, 0320, 0361, 0391, 0401, 0402, 0405, 0406, 0409, 0410, 0413, 0414, 0499, 0516, 0542, 0573, 0640, 0672
ISUZU\Euro 5,Euro 4,Euro 3,Euro 2 series\Euro 4 && Euro 5\8]2008\LT-LV Series Bus\Engine\6HK1-TC (C-Rail)	√	√	√	√		0120, 0130, 0140, 0150, 0203, 0221, 0248, 0265, 0296, 0320, 0361, 0391, 0401, 0402, 0405, 0406, 0409, 0410, 0413, 0414, 0499, 0516, 0542, 0573, 0640, 0672
ISUZU\Euro 5,Euro 4,Euro 3,Euro 2 series\Euro 4 && Euro 5\8]2008\LT-LV Series Bus\TRANSMISSION\TRANSMISSION		√	√	√		0054, 0467, 0468, 0469, 0470, 0620, 0622, 0624, 0625, 0667
ISUZU\Euro 5,Euro 4,Euro 3,Euro 2 series\Euro 4 && Euro 5\8]2008\TF-UC Serise\Engine\2.5L 4JK1-TC (Delphi)		√	√	√		0291, 0394, 0401, 0405, 0409, 0413, 0444, 0490, 0545, 0564, 0580, 0588, 0687
ISUZU\Euro 5,Euro 4,Euro 3,Euro 2 series\Euro 4 && Euro 5\8]2008\TF-UC Serise\Engine\2.5L 4JK1-TC (TransTron)		√	√	√		0291, 0394, 0401, 0405, 0409, 0413, 0444, 0490, 0545, 0564, 0580, 0588, 0687

ISUZU\Euro 5,Euro 4,Euro 3,Euro 2 series\Euro 4 && Euro 5\8]2008\TF-UC Serise\Engine\3.0L 4JJ1-TC (Delphi)		√	√	√		0291, 0394, 0401, 0405, 0409, 0413, 0444, 0490, 0545, 0564, 0580, 0588, 0687
ISUZU\Euro 5,Euro 4,Euro 3,Euro 2 series\Euro 4 && Euro 5\8]2008\TF-UC Serise\Engine\3.0L 4JJ1-TC (TransTron)		√	√	√		0291, 0394, 0401, 0405, 0409, 0413, 0444, 0490, 0545, 0564, 0580, 0588, 0687
ISUZU\Euro 5,Euro 4,Euro 3,Euro 2 series\Euro 4 && Euro 5\8]2008\TF-UC Serise\TRANSMISSION\TRANSMISSION		√	√	√		0054, 0467, 0468, 0469, 0470, 0620, 0622, 0624, 0625, 0667
ISUZU\Euro 5,Euro 4,Euro 3,Euro 2 series\Euro 4 && Euro 5\8]2008\TF-UC Serise\TRANSMISSION\AT JR405E		√	√	√		0004, 0037, 0347, 0369, 0480, 0481, 0484, 0540, 0572, 0653, 0661, 0669
ISUZU\Euro 5,Euro 4,Euro 3,Euro 2 series\Euro 4 && Euro 5\8]2008\TF-UC Serise\Chassis\ABS		√	√			
ISUZU\Euro 5,Euro 4,Euro 3,Euro 2 series\Euro 4 && Euro 5\8]2008\TF-UC Serise\Body\Immobiliser (Delphi)		√	√	√		
ISUZU\Euro 5,Euro 4,Euro 3,Euro 2 series\Euro 4 && Euro 5\8]2008\TF-UC Serise\Body\Immobiliser (Transtron)		√	√	√		
ISUZU\Euro 5,Euro 4,Euro 3,Euro 2 series\Euro 4 && Euro 5\8]2008\TF-UC Serise\Body\Airbag		√	√	√		
ISUZU\Euro 5,Euro 4,Euro 3,Euro 2 series\Euro 4 && Euro 5\8]2008\TF-UC Serise\Body\Powertrain Interface Module	√			√		
ISUZU\Euro 5,Euro 4,Euro 3,Euro 2 series\Euro 4 && Euro 5\7]2007\N-W Series w-5.2L Diesel(4HK1)\4HK1-TC (C-Rail)	√	√	√	√		0032, 0202, 0214, 0270, 0312, 0343, 0401, 0405, 0409, 0413, 0508, 0509, 0543, 0564, 0592, 0671, 0704
ISUZU\Euro 5,Euro 4,Euro 3,Euro 2 series\Euro 4 && Euro 5\7]2007\N-W Series w-5.2L Diesel(4HK1)\TRANSMISSION		√	√	√		0054, 0467, 0468, 0469, 0470, 0620, 0622, 0624, 0625, 0667
ISUZU\Euro 5,Euro 4,Euro 3,Euro 2 series\Euro 4 && Euro 5\7]2007\F-G Series Truck\Engine\4HK1-TC (C-Rail)	√	√	√	√		0032, 0202, 0214, 0270, 0312, 0343, 0401, 0405, 0409, 0413, 0508, 0509, 0543, 0564, 0592, 0671, 0704
ISUZU\Euro 5,Euro 4,Euro 3,Euro 2 series\Euro 4 && Euro 5\7]2007\F-G Series Truck\Engine\6HK1-TC (C-Rail)	√	√	√	√		0120, 0130, 0140, 0150, 0203, 0221, 0248, 0265, 0296, 0320, 0361, 0391, 0401, 0402, 0405, 0406, 0409, 0410, 0413, 0414, 0499, 0516, 0542, 0573, 0640, 0672
ISUZU\Euro 5,Euro 4,Euro 3,Euro 2 series\Euro 4 && Euro 5\7]2007\F-G Series Truck\TRANSMISSION\Smoother (TransTron)		√	√	√		
ISUZU\Euro 5,Euro 4,Euro 3,Euro 2 series\Euro 4 && Euro 5\7]2007\F-G Series Truck\TRANSMISSION\TRANSMISSION		√	√	√		0054, 0467, 0468, 0469, 0470, 0620, 0622, 0624, 0625, 0667
ISUZU\Euro 5,Euro 4,Euro 3,Euro 2 series\Euro 4 && Euro 5\7]2007\F-G Series Truck\Body\Immobiliser		√	√	√		
ISUZU\Euro 5,Euro 4,Euro 3,Euro 2 series\Euro 4 && Euro 5\7]2007\C-E Series Truck\Engine\6WG1-TC (C-Rail)	√	√	√	√		0120, 0130, 0140, 0150, 0203, 0221, 0248, 0265, 0296, 0320, 0361, 0391, 0401, 0402, 0405, 0406, 0409, 0410, 0413, 0414, 0499, 0516, 0542, 0573, 0640, 0672
ISUZU\Euro 5,Euro 4,Euro 3,Euro 2 series\Euro 4 && Euro 5\7]2007\LT-LV Series Bus\Engine\6HK1-TC (C-Rail)	√	√	√	√		0120, 0130, 0140, 0150, 0203, 0221, 0248, 0265, 0296, 0320, 0361, 0391, 0401, 0402, 0405, 0406, 0409, 0410, 0413, 0414, 0499, 0516, 0542, 0573, 0640, 0672
ISUZU\Euro 5,Euro 4,Euro 3,Euro 2 series\Euro 4 && Euro 5\7]2007\LT-LV Series Bus\TRANSMISSION\TRANSMISSION		√	√	√		0054, 0467, 0468, 0469, 0470, 0620, 0622, 0624, 0625, 0667
ISUZU\Euro 5,Euro 4,Euro 3,Euro 2 series\Euro 4 && Euro 5\7]2007\TF-UC Serise\Engine\2.5L 4JK1-TC (Delphi)		√	√	√		0291, 0394, 0401, 0405, 0409, 0413, 0444, 0490, 0545, 0564, 0580, 0588, 0687

ISUZU\Euro 5,Euro 4,Euro 3,Euro 2 series\Euro 4 && Euro 5\7\2007\TF-UC Serise\Engine\2.5L 4JK1-TC (TransTron)		√	√	√		0291, 0394, 0401, 0405, 0409, 0413, 0444, 0490, 0545, 0564, 0580, 0588, 0687
ISUZU\Euro 5,Euro 4,Euro 3,Euro 2 series\Euro 4 && Euro 5\7\2007\TF-UC Serise\Engine\3.0L 4JJ1-TC (Delphi)		√	√	√		0291, 0394, 0401, 0405, 0409, 0413, 0444, 0490, 0545, 0564, 0580, 0588, 0687
ISUZU\Euro 5,Euro 4,Euro 3,Euro 2 series\Euro 4 && Euro 5\7\2007\TF-UC Serise\Engine\3.0L 4JJ1-TC (TransTron)		√	√	√		0291, 0394, 0401, 0405, 0409, 0413, 0444, 0490, 0545, 0564, 0580, 0588, 0687
ISUZU\Euro 5,Euro 4,Euro 3,Euro 2 series\Euro 4 && Euro 5\7\2007\TF-UC Serise\TRANSMISSION\TRANSMISSION		√	√	√		0054, 0467, 0468, 0469, 0470, 0620, 0622, 0624, 0625, 0667
ISUZU\Euro 5,Euro 4,Euro 3,Euro 2 series\Euro 4 && Euro 5\7\2007\TF-UC Serise\TRANSMISSION\AT JR405E		√	√	√		0004, 0037, 0347, 0369, 0480, 0481, 0484, 0540, 0572, 0653, 0661, 0669
ISUZU\Euro 5,Euro 4,Euro 3,Euro 2 series\Euro 4 && Euro 5\7\2007\TF-UC Serise\Chassis\ABS		√	√			
ISUZU\Euro 5,Euro 4,Euro 3,Euro 2 series\Euro 4 && Euro 5\7\2007\TF-UC Serise\Body\Immobiliser (Delphi)		√	√	√		
ISUZU\Euro 5,Euro 4,Euro 3,Euro 2 series\Euro 4 && Euro 5\7\2007\TF-UC Serise\Body\Immobiliser (Transtron)		√	√	√		
ISUZU\Euro 5,Euro 4,Euro 3,Euro 2 series\Euro 4 && Euro 5\7\2007\TF-UC Serise\Body\Airbag		√	√	√		
ISUZU\Euro 5,Euro 4,Euro 3,Euro 2 series\Euro 4 && Euro 5\7\2007\TF-UC Serise\Body\Powertrain Interface Module	√			√		
ISUZU\Euro 5,Euro 4,Euro 3,Euro 2 series\Euro 4 && Euro 5\6\2006\TF-UC Serise\TRANSMISSION\TRANSMISSION		√	√	√		0054, 0467, 0468, 0469, 0470, 0620, 0622, 0624, 0625, 0667
ISUZU\Euro 5,Euro 4,Euro 3,Euro 2 series\Euro 4 && Euro 5\6\2006\TF-UC Serise\Chassis\ABS		√	√			
ISUZU\Euro 5,Euro 4,Euro 3,Euro 2 series\Euro 4 && Euro 5\6\2006\TF-UC Serise\Body\Immobiliser		√	√	√		
ISUZU\Euro 5,Euro 4,Euro 3,Euro 2 series\Euro 4 && Euro 5\6\2006\TF-UC Serise\Body\Airbag		√	√	√		
ISUZU\Euro 5,Euro 4,Euro 3,Euro 2 series\Euro 4 && Euro 5\6\2006\TF-UC Serise\Body\Powertrain Interface Module	√			√		
ISUZU\Euro 5,Euro 4,Euro 3,Euro 2 series\Euro 2 && Euro 3\9\2009\IF-UC Series\Powertrain\AT JR405E		√	√	√		0004, 0037, 0347, 0369, 0480, 0481, 0484, 0540, 0572, 0653, 0661, 0669
ISUZU\Euro 5,Euro 4,Euro 3,Euro 2 series\Euro 2 && Euro 3\9\2009\N Series Truck\Engine\4HK1(C-Rail_Euro2)	√	√	√	√		0168, 0275, 0323, 0345, 0396, 0445, 0544, 0556, 0674
ISUZU\Euro 5,Euro 4,Euro 3,Euro 2 series\Euro 2 && Euro 3\9\2009\N Series Truck\Engine\4JJ1(C-Rail_Euro2)	√	√	√	√		0168, 0275, 0323, 0345, 0396, 0445, 0544, 0556, 0674
ISUZU\Euro 5,Euro 4,Euro 3,Euro 2 series\Euro 2 && Euro 3\9\2009\N Series Truck\Engine\4HK1(C-Rail_Euro3)	√	√	√	√		0168, 0218, 0275, 0323, 0345, 0396, 0445, 0544, 0556, 0674
ISUZU\Euro 5,Euro 4,Euro 3,Euro 2 series\Euro 2 && Euro 3\9\2009\N Series Truck\Engine\4JJ1(C-Rail_Euro3)	√	√	√	√		0168, 0218, 0275, 0323, 0345, 0396, 0445, 0544, 0556, 0674
ISUZU\Euro 5,Euro 4,Euro 3,Euro 2 series\Euro 2 && Euro 3\9\2009\N Series Truck\Engine\4HV1(CNG)	√	√	√	√		0005, 0094, 0100, 0102, 0249, 0272, 0284, 0329, 0330, 0399, 0591, 0595, 0644, 0693
ISUZU\Euro 5,Euro 4,Euro 3,Euro 2 series\Euro 2 && Euro 3\9\2009\F-G Series Truck\Engine\4HK1(C-Rail_Euro2)	√	√	√	√		0168, 0275, 0323, 0345, 0396, 0445, 0544, 0556, 0674
ISUZU\Euro 5,Euro 4,Euro 3,Euro 2 series\Euro 2 && Euro 3\9\2009\F-G Series Truck\Engine\6HK1(C-Rail_Euro2)	√	√	√	√		0225, 0296, 0401, 0405, 0409, 0413, 0489, 0502, 0503, 0506, 0508, 0543, 0564, 0583, 0587, 0598, 0674
ISUZU\Euro 5,Euro 4,Euro 3,Euro 2 series\Euro 2 && Euro 3\9\2009\F-G Series Truck\Engine\4HK1(C-Rail_Euro3)	√	√	√	√		0168, 0218, 0275, 0323, 0345, 0396, 0445, 0544, 0556, 0674
ISUZU\Euro 5,Euro 4,Euro 3,Euro 2 series\Euro 2 && Euro 3\9\2009\F-G Series Truck\Engine\6HK1(C-Rail_Euro3)	√	√	√	√		0225, 0296, 0401, 0405, 0409, 0413, 0489, 0502, 0503, 0506, 0508, 0543, 0564, 0583, 0587, 0598, 0674
ISUZU\Euro 5,Euro 4,Euro 3,Euro 2 series\Euro 2 && Euro 3\9\2009\(*,E*,L*,F*)Heavy-Medium Duty\Engine\6WF1-TC(C-Rail)	√	√	√	√		

ISUZU\Euro 5,Euro 4,Euro 3,Euro 2 series\Euro 2 && Euro 3\9]2009\(*,E*,L*,F*)Heavy-Medium Duty\Chassis\ESC(with EBS)	√	√	√	√		
ISUZU\Euro 5,Euro 4,Euro 3,Euro 2 series\Euro 2 && Euro 3\9]2009\(*,E*,L*,F*)Heavy-Medium Duty\Chassis\ABS 6	√	√	√	√		
ISUZU\Euro 5,Euro 4,Euro 3,Euro 2 series\Euro 2 && Euro 3\8]2008\IF-UC Series\Powertrain\AT JR405E		√	√	√		0004, 0037, 0347, 0369, 0480, 0481, 0484, 0540, 0572, 0653, 0661, 0669
ISUZU\Euro 5,Euro 4,Euro 3,Euro 2 series\Euro 2 && Euro 3\8]2008\N Series Truck\Engine\4HK1(C-Rail_Euro2)	√	√	√	√		0168, 0275, 0323, 0345, 0396, 0445, 0544, 0556, 0674
ISUZU\Euro 5,Euro 4,Euro 3,Euro 2 series\Euro 2 && Euro 3\8]2008\N Series Truck\Engine\4JJ1(C-Rail_Euro2)	√	√	√	√		0168, 0275, 0323, 0345, 0396, 0445, 0544, 0556, 0674
ISUZU\Euro 5,Euro 4,Euro 3,Euro 2 series\Euro 2 && Euro 3\8]2008\N Series Truck\Engine\4HK1(C-Rail_Euro3)	√	√	√	√		0168, 0218, 0275, 0323, 0345, 0396, 0445, 0544, 0556, 0674
ISUZU\Euro 5,Euro 4,Euro 3,Euro 2 series\Euro 2 && Euro 3\8]2008\N Series Truck\Engine\4JJ1(C-Rail_Euro3)	√	√	√	√		0168, 0218, 0275, 0323, 0345, 0396, 0445, 0544, 0556, 0674
ISUZU\Euro 5,Euro 4,Euro 3,Euro 2 series\Euro 2 && Euro 3\8]2008\N Series Truck\Engine\4HV1(CNG)	√	√	√	√		0005, 0094, 0100, 0102, 0249, 0272, 0284, 0329, 0330, 0399, 0591, 0595, 0644, 0693
ISUZU\Euro 5,Euro 4,Euro 3,Euro 2 series\Euro 2 && Euro 3\8]2008\F-G Series Truck\Engine\4HK1(C-Rail_Euro2)	√	√	√	√		0168, 0275, 0323, 0345, 0396, 0445, 0544, 0556, 0674
ISUZU\Euro 5,Euro 4,Euro 3,Euro 2 series\Euro 2 && Euro 3\8]2008\F-G Series Truck\Engine\6HK1(C-Rail_Euro2)	√	√	√	√		0225, 0296, 0401, 0405, 0409, 0413, 0489, 0502, 0503, 0506, 0508, 0543, 0564, 0583, 0587, 0598, 0674
ISUZU\Euro 5,Euro 4,Euro 3,Euro 2 series\Euro 2 && Euro 3\8]2008\F-G Series Truck\Engine\4HK1(C-Rail_Euro3)	√	√	√	√		0168, 0218, 0275, 0323, 0345, 0396, 0445, 0544, 0556, 0674
ISUZU\Euro 5,Euro 4,Euro 3,Euro 2 series\Euro 2 && Euro 3\8]2008\F-G Series Truck\Engine\6HK1(C-Rail_Euro3)	√	√	√	√		0225, 0296, 0401, 0405, 0409, 0413, 0489, 0502, 0503, 0506, 0508, 0543, 0564, 0583, 0587, 0598, 0674
ISUZU\Euro 5,Euro 4,Euro 3,Euro 2 series\Euro 2 && Euro 3\8]2008\(*,E*,L*,F*)Heavy-Medium Duty\Engine\6WF1-TC(C-Rail)	√	√	√	√		
ISUZU\Euro 5,Euro 4,Euro 3,Euro 2 series\Euro 2 && Euro 3\8]2008\(*,E*,L*,F*)Heavy-Medium Duty\Chassis\ESC(with EBS)	√	√	√	√		
ISUZU\Euro 5,Euro 4,Euro 3,Euro 2 series\Euro 2 && Euro 3\8]2008\(*,E*,L*,F*)Heavy-Medium Duty\Chassis\ABS 6	√	√	√	√		
ISUZU\Euro 5,Euro 4,Euro 3,Euro 2 series\Euro 2 && Euro 3\7]2007\IF-UC Series\Powertrain\AT JR405E		√	√	√		0004, 0037, 0347, 0369, 0480, 0481, 0484, 0540, 0572, 0653, 0661, 0669
ISUZU\Euro 5,Euro 4,Euro 3,Euro 2 series\Euro 2 && Euro 3\7]2007\N Series Truck\Engine\4HK1(C-Rail_Euro2)	√	√	√	√		0168, 0275, 0323, 0345, 0396, 0445, 0544, 0556, 0674
ISUZU\Euro 5,Euro 4,Euro 3,Euro 2 series\Euro 2 && Euro 3\7]2007\N Series Truck\Engine\4JJ1(C-Rail_Euro2)	√	√	√	√		0168, 0275, 0323, 0345, 0396, 0445, 0544, 0556, 0674
ISUZU\Euro 5,Euro 4,Euro 3,Euro 2 series\Euro 2 && Euro 3\7]2007\N Series Truck\Engine\4HK1(C-Rail_Euro3)	√	√	√	√		0168, 0218, 0275, 0323, 0345, 0396, 0445, 0544, 0556, 0674
ISUZU\Euro 5,Euro 4,Euro 3,Euro 2 series\Euro 2 && Euro 3\7]2007\N Series Truck\Engine\4JJ1(C-Rail_Euro3)	√	√	√	√		0168, 0218, 0275, 0323, 0345, 0396, 0445, 0544, 0556, 0674
ISUZU\Euro 5,Euro 4,Euro 3,Euro 2 series\Euro 2 && Euro 3\7]2007\N Series Truck\Engine\4HV1(CNG)	√	√	√	√		0005, 0094, 0100, 0102, 0249, 0272, 0284, 0329, 0330, 0399, 0591, 0595, 0644, 0693
ISUZU\Euro 5,Euro 4,Euro 3,Euro 2 series\Euro 2 && Euro 3\7]2007\F-G Series Truck\Engine\4HK1(C-Rail_Euro2)	√	√	√	√		0168, 0275, 0323, 0345, 0396, 0445, 0544, 0556, 0674
ISUZU\Euro 5,Euro 4,Euro 3,Euro 2 series\Euro 2 && Euro 3\7]2007\F-G Series Truck\Engine\6HK1(C-Rail_Euro2)	√	√	√	√		0225, 0296, 0401, 0405, 0409, 0413, 0489, 0502, 0503, 0506, 0508, 0543, 0564, 0583, 0587, 0598, 0674
ISUZU\Euro 5,Euro 4,Euro 3,Euro 2 series\Euro 2 && Euro 3\7]2007\F-G Series Truck\Engine\4HK1(C-Rail_Euro3)	√	√	√	√		0168, 0218, 0275, 0323, 0345, 0396, 0445, 0544, 0556, 0674

ISUZU\Euro 5,Euro 4,Euro 3,Euro 2 series\Euro 2 && Euro 3\7]2007\F-G Series Truck\Engine\6HK1(C-Rail_Euro3)	√	√	√	√		0225, 0296, 0401, 0405, 0409, 0413, 0489, 0502, 0503, 0506, 0508, 0543, 0564, 0583, 0587, 0598, 0674
ISUZU\Euro 5,Euro 4,Euro 3,Euro 2 series\Euro 2 && Euro 3\7]2007\(*,E*,L*,F*)Heavy-Medium Duty\Engine\6WF1-TC(C-Rail)	√	√	√	√		
ISUZU\Euro 5,Euro 4,Euro 3,Euro 2 series\Euro 2 && Euro 3\7]2007\(*,E*,L*,F*)Heavy-Medium Duty\Chassis\ESC(with EBS)	√	√	√	√		
ISUZU\Euro 5,Euro 4,Euro 3,Euro 2 series\Euro 2 && Euro 3\7]2007\(*,E*,L*,F*)Heavy-Medium Duty\Chassis\ABS 6	√	√	√	√		
ISUZU\Euro 5,Euro 4,Euro 3,Euro 2 series\Euro 2 && Euro 3\6]2006*(IF-UC)LUV,Rodeo-Frontier,LAO-Rodeo\Powertrain\2.5L 4JK1-TC	√	√	√	√		0218, 0350, 0390, 0423, 0424, 0441, 0490, 0541, 0580, 0685
ISUZU\Euro 5,Euro 4,Euro 3,Euro 2 series\Euro 2 && Euro 3\6]2006*(IF-UC)LUV,Rodeo-Frontier,LAO-Rodeo\Powertrain\3.0L 4JJ1-TC	√	√	√	√		0218, 0350, 0390, 0423, 0424, 0441, 0490, 0541, 0580, 0685
ISUZU\Euro 5,Euro 4,Euro 3,Euro 2 series\Euro 2 && Euro 3\6]2006*(IF-UC)LUV,Rodeo-Frontier,LAO-Rodeo\Powertrain\AT JR405E		√	√	√		0004, 0037, 0347, 0369, 0480, 0481, 0484, 0540, 0572, 0653, 0661, 0669
ISUZU\Euro 5,Euro 4,Euro 3,Euro 2 series\Euro 2 && Euro 3\6]2006\(*,N*) ELF,NPR,NQR,VFR\Engine\4HG1(LPG)	√	√	√	√		0306, 0319, 0382, 0643
ISUZU\Euro 5,Euro 4,Euro 3,Euro 2 series\Euro 2 && Euro 3\6]2006\(*,N*) ELF,NPR,NQR,VFR\Engine\4JG2		√	√	√		0222
ISUZU\Euro 5,Euro 4,Euro 3,Euro 2 series\Euro 2 && Euro 3\6]2006\(*,N*) ELF,NPR,NQR,VFR\Engine\4JG2(LPG)	√	√	√	√		0306, 0319, 0382, 0643
ISUZU\Euro 5,Euro 4,Euro 3,Euro 2 series\Euro 2 && Euro 3\6]2006\(*,N*) ELF,NPR,NQR,VFR\Engine\4HJ-TC Bosch	√	√	√	√		0222, 0255, 0352, 0353, 0576
ISUZU\Euro 5,Euro 4,Euro 3,Euro 2 series\Euro 2 && Euro 3\6]2006\(*,N*) ELF,NPR,NQR,VFR\Engine\4HL1-4HJ1		√	√	√		
ISUZU\Euro 5,Euro 4,Euro 3,Euro 2 series\Euro 2 && Euro 3\6]2006\(*,N*) ELF,NPR,NQR,VFR\Engine\4HL1-4HJ1(Vehicle Interface Module)				√		
ISUZU\Euro 5,Euro 4,Euro 3,Euro 2 series\Euro 2 && Euro 3\6]2006*(Off-Road) Industrial Engine\Engine\4JJ1-TC(C-Rail_Tiler3)	√	√	√	√		0032, 0202, 0214, 0270, 0312, 0343, 0401, 0405, 0409, 0413, 0508, 0509, 0543, 0564, 0592, 0671, 0704
ISUZU\Euro 5,Euro 4,Euro 3,Euro 2 series\Euro 2 && Euro 3\6]2006*(Off-Road) Industrial Engine\Engine\4HK1-TC(C-Rail_Tiler3)	√	√	√	√		0032, 0202, 0214, 0270, 0312, 0343, 0401, 0405, 0409, 0413, 0508, 0509, 0543, 0564, 0592, 0671, 0704
ISUZU\Euro 5,Euro 4,Euro 3,Euro 2 series\Euro 2 && Euro 3\6]2006*(Off-Road) Industrial Engine\Engine\6HK1-TC(C-Rail_Tiler3)	√	√	√	√		0225, 0296, 0401, 0405, 0409, 0413, 0489, 0502, 0503, 0506, 0508, 0543, 0564, 0583, 0587, 0598, 0674
ISUZU\Euro 5,Euro 4,Euro 3,Euro 2 series\Euro 2 && Euro 3\6]2006*(Off-Road) Industrial Engine\Engine\6UZ1-TC(C-Rail_Tiler3)	√	√	√	√		0225, 0296, 0401, 0405, 0409, 0413, 0489, 0502, 0503, 0506, 0508, 0543, 0564, 0583, 0587, 0598, 0674
ISUZU\Euro 5,Euro 4,Euro 3,Euro 2 series\Euro 2 && Euro 3\6]2006*(Off-Road) Industrial Engine\Engine\6WG1-TC(C-Rail_Tiler3)	√	√	√	√		0120, 0130, 0140, 0150, 0203, 0221, 0248, 0265, 0296, 0320, 0361, 0391, 0401, 0402, 0405, 0406, 0409, 0410, 0413, 0414, 0499, 0516, 0542, 0573, 0640, 0672
ISUZU\Euro 5,Euro 4,Euro 3,Euro 2 series\Euro 2 && Euro 3\6]2006\(*,E*,L*,F*)Heavy-Medium Duty\Engine\6WF1-TC(C-Rail)	√	√	√	√		
ISUZU\Euro 5,Euro 4,Euro 3,Euro 2 series\Euro 2 && Euro 3\6]2006\(*,E*,L*,F*)Heavy-Medium Duty\TRANSMISSION\AT Allsion WT		√	√	√		
ISUZU\Euro 5,Euro 4,Euro 3,Euro 2 series\Euro 2 && Euro 3\6]2006\(*,E*,L*,F*)Heavy-Medium Duty\Chassis\ESC(with EBS)	√	√	√	√		
ISUZU\Euro 5,Euro 4,Euro 3,Euro 2 series\Euro 2 && Euro 3\6]2006\(*,E*,L*,F*)Heavy-Medium Duty\Chassis\ABS 6	√	√	√	√		
ISUZU\Euro 5,Euro 4,Euro 3,Euro 2 series\Euro 2 && Euro 3\5]2005*(IF-UC)LUV,Rodeo-Frontier,LAO-Rodeo\Powertrain\2.5L 4JK1-TC	√	√	√	√		0218, 0350, 0390, 0423, 0424, 0441, 0490, 0541, 0580, 0685
ISUZU\Euro 5,Euro 4,Euro 3,Euro 2 series\Euro 2 && Euro 3\5]2005*(IF-UC)LUV,Rodeo-Frontier,LAO-Rodeo\Powertrain\3.0L 4JJ1-TC	√	√	√	√		0218, 0350, 0390, 0423, 0424, 0441, 0490, 0541, 0580, 0685
ISUZU\Euro 5,Euro 4,Euro 3,Euro 2 series\Euro 2 && Euro 3\5]2005*(IF-UC)LUV,Rodeo-Frontier,LAO-Rodeo\Powertrain\AT JR405E		√	√	√		0004, 0037, 0347, 0369, 0480, 0481, 0484, 0540, 0572, 0653, 0661, 0669
ISUZU\Euro 5,Euro 4,Euro 3,Euro 2 series\Euro 2 && Euro 3\5]2005\(*,N*) ELF,NPR,NQR,VFR\Engine\4HG1(LPG)	√	√	√	√		0306, 0319, 0382, 0643
ISUZU\Euro 5,Euro 4,Euro 3,Euro 2 series\Euro 2 && Euro 3\5]2005\(*,N*) ELF,NPR,NQR,VFR\Engine\4JG2		√	√	√		0222
ISUZU\Euro 5,Euro 4,Euro 3,Euro 2 series\Euro 2 && Euro 3\5]2005\(*,N*) ELF,NPR,NQR,VFR\Engine\4JG2(LPG)	√	√	√	√		0306, 0319, 0382, 0643

ISUZU\Euro 5,Euro 4,Euro 3,Euro 2 series\Euro 2 && Euro 3\5]2005\N* ELF,NPR,NQR,VFR\Engine\4HJ-TC Bosch	√	√	√	√		0222, 0255, 0352, 0353, 0576
ISUZU\Euro 5,Euro 4,Euro 3,Euro 2 series\Euro 2 && Euro 3\5]2005\N* ELF,NPR,NQR,VFR\Engine\4HL1-4HJ1		√	√	√		
ISUZU\Euro 5,Euro 4,Euro 3,Euro 2 series\Euro 2 && Euro 3\5]2005\N* ELF,NPR,NQR,VFR\Engine\4HL1-4HJ1(Vehicle Interface Module)				√		
ISUZU\Euro 5,Euro 4,Euro 3,Euro 2 series\Euro 2 && Euro 3\5]2005\Off-Road Industrial Engine\Engine\4JJ1-TC(C-Rail_Tiler3)	√	√	√	√		0032, 0202, 0214, 0270, 0312, 0343, 0401, 0405, 0409, 0413, 0508, 0509, 0543, 0564, 0592, 0671, 0704
ISUZU\Euro 5,Euro 4,Euro 3,Euro 2 series\Euro 2 && Euro 3\5]2005\Off-Road Industrial Engine\Engine\4HK1-TC(C-Rail_Tiler3)	√	√	√	√		0032, 0202, 0214, 0270, 0312, 0343, 0401, 0405, 0409, 0413, 0508, 0509, 0543, 0564, 0592, 0671, 0704
ISUZU\Euro 5,Euro 4,Euro 3,Euro 2 series\Euro 2 && Euro 3\5]2005\Off-Road Industrial Engine\Engine\6HK1-TC(C-Rail_Tiler3)	√	√	√	√		0225, 0296, 0401, 0405, 0409, 0413, 0489, 0502, 0503, 0506, 0508, 0543, 0564, 0583, 0587, 0598, 0674
ISUZU\Euro 5,Euro 4,Euro 3,Euro 2 series\Euro 2 && Euro 3\5]2005\Off-Road Industrial Engine\Engine\6UZ1-TC(C-Rail_Tiler3)	√	√	√	√		0225, 0296, 0401, 0405, 0409, 0413, 0489, 0502, 0503, 0506, 0508, 0543, 0564, 0583, 0587, 0598, 0674
ISUZU\Euro 5,Euro 4,Euro 3,Euro 2 series\Euro 2 && Euro 3\5]2005\Off-Road Industrial Engine\Engine\6WG1-TC(C-Rail_Tiler3)	√	√	√	√		0120, 0130, 0140, 0150, 0203, 0221, 0248, 0265, 0296, 0320, 0361, 0391, 0401, 0402, 0405, 0406, 0409, 0410, 0413, 0414, 0499, 0516, 0542, 0573, 0640, 0672
ISUZU\Euro 5,Euro 4,Euro 3,Euro 2 series\Euro 2 && Euro 3\5]2005\C*,E*,L*,F*)Heavy-Medium Duty\Engine\6WF1-TC(C-Rail)	√	√	√	√		
ISUZU\Euro 5,Euro 4,Euro 3,Euro 2 series\Euro 2 && Euro 3\5]2005\C*,E*,L*,F*)Heavy-Medium Duty\TRANSMISSION\AT Allsion WT		√	√	√		
ISUZU\Euro 5,Euro 4,Euro 3,Euro 2 series\Euro 2 && Euro 3\5]2005\C*,E*,L*,F*)Heavy-Medium Duty\Chassis\ESC(with EBS)	√	√	√	√		
ISUZU\Euro 5,Euro 4,Euro 3,Euro 2 series\Euro 2 && Euro 3\5]2005\C*,E*,L*,F*)Heavy-Medium Duty\Chassis\ABS 6	√	√	√	√		
ISUZU\Euro 5,Euro 4,Euro 3,Euro 2 series\Euro 2 && Euro 3\4]2004\IF-UC)LUV,Rodeo-Frontier,LAO-Rodeo\Powertrain\2.5L 4JK1-TC	√	√	√	√		0218, 0350, 0390, 0423, 0424, 0441, 0490, 0541, 0580, 0685
ISUZU\Euro 5,Euro 4,Euro 3,Euro 2 series\Euro 2 && Euro 3\4]2004\IF-UC)LUV,Rodeo-Frontier,LAO-Rodeo\Powertrain\3.0L 4JJ1-TC	√	√	√	√		0218, 0350, 0390, 0423, 0424, 0441, 0490, 0541, 0580, 0685
ISUZU\Euro 5,Euro 4,Euro 3,Euro 2 series\Euro 2 && Euro 3\4]2004\IF-UC)LUV,Rodeo-Frontier,LAO-Rodeo\Powertrain\AT JR405E		√	√	√		0004, 0037, 0347, 0369, 0480, 0481, 0484, 0540, 0572, 0653, 0661, 0669
ISUZU\Euro 5,Euro 4,Euro 3,Euro 2 series\Euro 2 && Euro 3\4]2004\N* ELF,NPR,NQR,VFR\Engine\4HG1(LPG)	√	√	√	√		0306, 0319, 0382, 0643
ISUZU\Euro 5,Euro 4,Euro 3,Euro 2 series\Euro 2 && Euro 3\4]2004\N* ELF,NPR,NQR,VFR\Engine\4JG2		√	√	√		0222
ISUZU\Euro 5,Euro 4,Euro 3,Euro 2 series\Euro 2 && Euro 3\4]2004\N* ELF,NPR,NQR,VFR\Engine\4JG2(LPG)	√	√	√	√		0306, 0319, 0382, 0643
ISUZU\Euro 5,Euro 4,Euro 3,Euro 2 series\Euro 2 && Euro 3\4]2004\N* ELF,NPR,NQR,VFR\Engine\4HJ-TC Bosch	√	√	√	√		0222, 0255, 0352, 0353, 0576
ISUZU\Euro 5,Euro 4,Euro 3,Euro 2 series\Euro 2 && Euro 3\4]2004\N* ELF,NPR,NQR,VFR\Engine\4HL1-4HJ1		√	√	√		
ISUZU\Euro 5,Euro 4,Euro 3,Euro 2 series\Euro 2 && Euro 3\4]2004\N* ELF,NPR,NQR,VFR\Engine\4HL1-4HJ1(Vehicle Interface Module)				√		
ISUZU\Euro 5,Euro 4,Euro 3,Euro 2 series\Euro 2 && Euro 3\4]2004\Off-Road Industrial Engine\Engine\4JJ1-TC(C-Rail_Tiler3)	√	√	√	√		0032, 0202, 0214, 0270, 0312, 0343, 0401, 0405, 0409, 0413, 0508, 0509, 0543, 0564, 0592, 0671, 0704
ISUZU\Euro 5,Euro 4,Euro 3,Euro 2 series\Euro 2 && Euro 3\4]2004\Off-Road Industrial Engine\Engine\4HK1-TC(C-Rail_Tiler3)	√	√	√	√		0032, 0202, 0214, 0270, 0312, 0343, 0401, 0405, 0409, 0413, 0508, 0509, 0543, 0564, 0592, 0671, 0704
ISUZU\Euro 5,Euro 4,Euro 3,Euro 2 series\Euro 2 && Euro 3\4]2004\Off-Road Industrial Engine\Engine\6HK1-TC(C-Rail_Tiler3)	√	√	√	√		0225, 0296, 0401, 0405, 0409, 0413, 0489, 0502, 0503, 0506, 0508, 0543, 0564, 0583, 0587, 0598, 0674
ISUZU\Euro 5,Euro 4,Euro 3,Euro 2 series\Euro 2 && Euro 3\4]2004\Off-Road Industrial Engine\Engine\6UZ1-TC(C-Rail_Tiler3)	√	√	√	√		0225, 0296, 0401, 0405, 0409, 0413, 0489, 0502, 0503, 0506, 0508, 0543, 0564, 0583, 0587, 0598, 0674

ISUZU\Euro 5,Euro 4,Euro 3,Euro 2 series\Euro 2 && Euro 3\4]2004\Off-Road) Industrial Engine\Engine\6WG1-TC(C-Rail_Tiler3)	√	√	√	√		0120, 0130, 0140, 0150, 0203, 0221, 0248, 0265, 0296, 0320, 0361, 0391, 0401, 0402, 0405, 0406, 0409, 0410, 0413, 0414, 0499, 0516, 0542, 0573, 0640, 0672
ISUZU\Euro 5,Euro 4,Euro 3,Euro 2 series\Euro 2 && Euro 3\4]2004\C*,E*,L*,F*)Heavy-Medium Duty\Engine\6WF1-TC(C-Rail)	√	√	√	√		
ISUZU\Euro 5,Euro 4,Euro 3,Euro 2 series\Euro 2 && Euro 3\4]2004\C*,E*,L*,F*)Heavy-Medium Duty\TRANSMISSION\AT Allsion WT		√	√	√		
ISUZU\Euro 5,Euro 4,Euro 3,Euro 2 series\Euro 2 && Euro 3\4]2004\C*,E*,L*,F*)Heavy-Medium Duty\Chassis\ESC(with EBS)	√	√	√	√		
ISUZU\Euro 5,Euro 4,Euro 3,Euro 2 series\Euro 2 && Euro 3\4]2004\C*,E*,L*,F*)Heavy-Medium Duty\Chassis\ABS 6	√	√	√	√		
ISUZU\Euro 5,Euro 4,Euro 3,Euro 2 series\Euro 2 && Euro 3\3]2003\IF-UC)LUV,Rodeo-Frontier,LAO-Rodeo\Powertrain\2.5L 4JK1-TC	√	√	√	√		0218, 0350, 0390, 0423, 0424, 0441, 0490, 0541, 0580, 0685
ISUZU\Euro 5,Euro 4,Euro 3,Euro 2 series\Euro 2 && Euro 3\3]2003\IF-UC)LUV,Rodeo-Frontier,LAO-Rodeo\Powertrain\3.0L 4JJ1-TC	√	√	√	√		0218, 0350, 0390, 0423, 0424, 0441, 0490, 0541, 0580, 0685
ISUZU\Euro 5,Euro 4,Euro 3,Euro 2 series\Euro 2 && Euro 3\3]2003\IF-UC)LUV,Rodeo-Frontier,LAO-Rodeo\Powertrain\AT JR405E		√	√	√		0004, 0037, 0347, 0369, 0480, 0481, 0484, 0540, 0572, 0653, 0661, 0669
ISUZU\Euro 5,Euro 4,Euro 3,Euro 2 series\Euro 2 && Euro 3\3]2003\N*) ELF,NPR,NQR,VFR\Engine\4HG1(LPG)	√	√	√	√		0306, 0319, 0382, 0643
ISUZU\Euro 5,Euro 4,Euro 3,Euro 2 series\Euro 2 && Euro 3\3]2003\N*) ELF,NPR,NQR,VFR\Engine\4JG2		√	√	√		0222
ISUZU\Euro 5,Euro 4,Euro 3,Euro 2 series\Euro 2 && Euro 3\3]2003\N*) ELF,NPR,NQR,VFR\Engine\4JG2(LPG)	√	√	√	√		0306, 0319, 0382, 0643
ISUZU\Euro 5,Euro 4,Euro 3,Euro 2 series\Euro 2 && Euro 3\3]2003\N*) ELF,NPR,NQR,VFR\Engine\4HJ-TC Bosch	√	√	√	√		0222, 0255, 0352, 0353, 0576
ISUZU\Euro 5,Euro 4,Euro 3,Euro 2 series\Euro 2 && Euro 3\3]2003\N*) ELF,NPR,NQR,VFR\Engine\4HL1-4HJ1		√	√	√		
ISUZU\Euro 5,Euro 4,Euro 3,Euro 2 series\Euro 2 && Euro 3\3]2003\N*) ELF,NPR,NQR,VFR\Engine\4HL1-4HJ1(Vehicle Interface Module)				√		
ISUZU\Euro 5,Euro 4,Euro 3,Euro 2 series\Euro 2 && Euro 3\3]2003\Off-Road) Industrial Engine\Engine\4JJ1-TC(C-Rail_Tiler3)	√	√	√	√		0032, 0202, 0214, 0270, 0312, 0343, 0401, 0405, 0409, 0413, 0508, 0509, 0543, 0564, 0592, 0671, 0704
ISUZU\Euro 5,Euro 4,Euro 3,Euro 2 series\Euro 2 && Euro 3\3]2003\Off-Road) Industrial Engine\Engine\4HK1-TC(C-Rail_Tiler3)	√	√	√	√		0032, 0202, 0214, 0270, 0312, 0343, 0401, 0405, 0409, 0413, 0508, 0509, 0543, 0564, 0592, 0671, 0704
ISUZU\Euro 5,Euro 4,Euro 3,Euro 2 series\Euro 2 && Euro 3\3]2003\Off-Road) Industrial Engine\Engine\6HK1-TC(C-Rail_Tiler3)	√	√	√	√		0225, 0296, 0401, 0405, 0409, 0413, 0489, 0502, 0503, 0506, 0508, 0543, 0564, 0583, 0587, 0598, 0674
ISUZU\Euro 5,Euro 4,Euro 3,Euro 2 series\Euro 2 && Euro 3\3]2003\Off-Road) Industrial Engine\Engine\6UZ1-TC(C-Rail_Tiler3)	√	√	√	√		0225, 0296, 0401, 0405, 0409, 0413, 0489, 0502, 0503, 0506, 0508, 0543, 0564, 0583, 0587, 0598, 0674
ISUZU\Euro 5,Euro 4,Euro 3,Euro 2 series\Euro 2 && Euro 3\3]2003\Off-Road) Industrial Engine\Engine\6WG1-TC(C-Rail_Tiler3)	√	√	√	√		0120, 0130, 0140, 0150, 0203, 0221, 0248, 0265, 0296, 0320, 0361, 0391, 0401, 0402, 0405, 0406, 0409, 0410, 0413, 0414, 0499, 0516, 0542, 0573, 0640, 0672
ISUZU\Euro 5,Euro 4,Euro 3,Euro 2 series\Euro 2 && Euro 3\3]2003\C*,E*,L*,F*)Heavy-Medium Duty\Engine\6WF1-TC(C-Rail)	√	√	√	√		
ISUZU\Euro 5,Euro 4,Euro 3,Euro 2 series\Euro 2 && Euro 3\3]2003\C*,E*,L*,F*)Heavy-Medium Duty\TRANSMISSION\AT Allsion WT		√	√	√		
ISUZU\Euro 5,Euro 4,Euro 3,Euro 2 series\Euro 2 && Euro 3\3]2003\C*,E*,L*,F*)Heavy-Medium Duty\Chassis\ESC(with EBS)	√	√	√	√		
ISUZU\Euro 5,Euro 4,Euro 3,Euro 2 series\Euro 2 && Euro 3\3]2003\C*,E*,L*,F*)Heavy-Medium Duty\Chassis\ABS 6				√		
ISUZU\Euro 5,Euro 4,Euro 3,Euro 2 series\Euro 2 && Euro 3\2]2002\IF-UC)LUV,Rodeo-Frontier,LAO-Rodeo\Powertrain\2.5L 4JK1-TC	√	√	√	√		0218, 0350, 0390, 0423, 0424, 0441, 0490, 0541, 0580, 0685
ISUZU\Euro 5,Euro 4,Euro 3,Euro 2 series\Euro 2 && Euro 3\2]2002\IF-UC)LUV,Rodeo-Frontier,LAO-Rodeo\Powertrain\3.0L 4JJ1-TC	√	√	√	√		0218, 0350, 0390, 0423, 0424, 0441, 0490, 0541, 0580, 0685
ISUZU\Euro 5,Euro 4,Euro 3,Euro 2 series\Euro 2 && Euro 3\2]2002\IF-UC)LUV,Rodeo-Frontier,LAO-Rodeo\Powertrain\AT JR405E		√	√	√		0004, 0037, 0347, 0369, 0480, 0481, 0484, 0540, 0572, 0653, 0661, 0669

ISUZU\Euro 5,Euro 4,Euro 3,Euro 2 series\Euro 2 && Euro 3\2]2002\N*) ELF,NPR,NQR,VFR\Engine\4HG1(LPG)	√	√	√	√		0306, 0319, 0382, 0643
ISUZU\Euro 5,Euro 4,Euro 3,Euro 2 series\Euro 2 && Euro 3\2]2002\N*) ELF,NPR,NQR,VFR\Engine\4JG2		√	√	√		0222
ISUZU\Euro 5,Euro 4,Euro 3,Euro 2 series\Euro 2 && Euro 3\2]2002\N*) ELF,NPR,NQR,VFR\Engine\4JG2(LPG)	√	√	√	√		0306, 0319, 0382, 0643
ISUZU\Euro 5,Euro 4,Euro 3,Euro 2 series\Euro 2 && Euro 3\2]2002\N*) ELF,NPR,NQR,VFR\Engine\4HJ-TC Bosch	√	√	√	√		0222, 0255, 0352, 0353, 0576
ISUZU\Euro 5,Euro 4,Euro 3,Euro 2 series\Euro 2 && Euro 3\2]2002\N*) ELF,NPR,NQR,VFR\Engine\4HL1-4HJ1		√	√	√		
ISUZU\Euro 5,Euro 4,Euro 3,Euro 2 series\Euro 2 && Euro 3\2]2002\N*) ELF,NPR,NQR,VFR\Engine\4HL1-4HJ1(Vehicle Interface Module)				√		
ISUZU\Euro 5,Euro 4,Euro 3,Euro 2 series\Euro 2 && Euro 3\2]2002\Off-Road) Industrial Engine\Engine\4JJ1-TC(C-Rail_Tiler3)	√	√	√	√		0032, 0202, 0214, 0270, 0312, 0343, 0401, 0405, 0409, 0413, 0508, 0509, 0543, 0564, 0592, 0671, 0704
ISUZU\Euro 5,Euro 4,Euro 3,Euro 2 series\Euro 2 && Euro 3\2]2002\Off-Road) Industrial Engine\Engine\4HK1-TC(C-Rail_Tiler3)	√	√	√	√		0032, 0202, 0214, 0270, 0312, 0343, 0401, 0405, 0409, 0413, 0508, 0509, 0543, 0564, 0592, 0671, 0704
ISUZU\Euro 5,Euro 4,Euro 3,Euro 2 series\Euro 2 && Euro 3\2]2002\Off-Road) Industrial Engine\Engine\6HK1-TC(C-Rail_Tiler3)	√	√	√	√		0225, 0296, 0401, 0405, 0409, 0413, 0489, 0502, 0503, 0506, 0508, 0543, 0564, 0583, 0587, 0598, 0674
ISUZU\Euro 5,Euro 4,Euro 3,Euro 2 series\Euro 2 && Euro 3\2]2002\Off-Road) Industrial Engine\Engine\6UZ1-TC(C-Rail_Tiler3)	√	√	√	√		0225, 0296, 0401, 0405, 0409, 0413, 0489, 0502, 0503, 0506, 0508, 0543, 0564, 0583, 0587, 0598, 0674
ISUZU\Euro 5,Euro 4,Euro 3,Euro 2 series\Euro 2 && Euro 3\2]2002\Off-Road) Industrial Engine\Engine\6WG1-TC(C-Rail_Tiler3)	√	√	√	√		0120, 0130, 0140, 0150, 0203, 0221, 0248, 0265, 0296, 0320, 0361, 0391, 0401, 0402, 0405, 0406, 0409, 0410, 0413, 0414, 0499, 0516, 0542, 0573, 0640, 0672
ISUZU\Euro 5,Euro 4,Euro 3,Euro 2 series\Euro 2 && Euro 3\2]2002\(*,E*,L*,F*)Heavy-Medium Duty\Engine\6WF1-TC(C-Rail)	√	√	√	√		
ISUZU\Euro 5,Euro 4,Euro 3,Euro 2 series\Euro 2 && Euro 3\2]2002\(*,E*,L*,F*)Heavy-Medium Duty\TRANSMISSIONAT Allsion WT		√	√	√		
ISUZU\Euro 5,Euro 4,Euro 3,Euro 2 series\Euro 2 && Euro 3\2]2002\(*,E*,L*,F*)Heavy-Medium Duty\Chassis\ESC(with EBS)	√	√	√	√		
ISUZU\Euro 5,Euro 4,Euro 3,Euro 2 series\Euro 2 && Euro 3\2]2002\(*,E*,L*,F*)Heavy-Medium Duty\Chassis\ABS 6	√	√	√	√		
ISUZU\Euro 5,Euro 4,Euro 3,Euro 2 series\Euro 2 && Euro 3\1]2001\IF-UC)LUV,Rodeo-Frontier,LAO-Rodeo\Powertrain\2.5L 4JK1-TC	√	√	√	√		0218, 0350, 0390, 0423, 0424, 0441, 0490, 0541, 0580, 0685
ISUZU\Euro 5,Euro 4,Euro 3,Euro 2 series\Euro 2 && Euro 3\1]2001\IF-UC)LUV,Rodeo-Frontier,LAO-Rodeo\Powertrain\3.0L 4JJ1-TC	√	√	√	√		0218, 0350, 0390, 0423, 0424, 0441, 0490, 0541, 0580, 0685
ISUZU\Euro 5,Euro 4,Euro 3,Euro 2 series\Euro 2 && Euro 3\1]2001\IF-UC)LUV,Rodeo-Frontier,LAO-Rodeo\Powertrain\AT JR405E		√	√	√		0004, 0037, 0347, 0369, 0480, 0481, 0484, 0540, 0572, 0653, 0661, 0669
ISUZU\Euro 5,Euro 4,Euro 3,Euro 2 series\Euro 2 && Euro 3\1]2001\N*) ELF,NPR,NQR,VFR\Engine\4HG1(LPG)	√	√	√	√		0306, 0319, 0382, 0643
ISUZU\Euro 5,Euro 4,Euro 3,Euro 2 series\Euro 2 && Euro 3\1]2001\N*) ELF,NPR,NQR,VFR\Engine\4JG2		√	√	√		0222
ISUZU\Euro 5,Euro 4,Euro 3,Euro 2 series\Euro 2 && Euro 3\1]2001\N*) ELF,NPR,NQR,VFR\Engine\4JG2(LPG)	√	√	√	√		0306, 0319, 0382, 0643
ISUZU\Euro 5,Euro 4,Euro 3,Euro 2 series\Euro 2 && Euro 3\1]2001\N*) ELF,NPR,NQR,VFR\Engine\4HJ-TC Bosch	√	√	√	√		0222, 0255, 0352, 0353, 0576
ISUZU\Euro 5,Euro 4,Euro 3,Euro 2 series\Euro 2 && Euro 3\1]2001\N*) ELF,NPR,NQR,VFR\Engine\4HL1-4HJ1		√	√	√		
ISUZU\Euro 5,Euro 4,Euro 3,Euro 2 series\Euro 2 && Euro 3\1]2001\N*) ELF,NPR,NQR,VFR\Engine\4HL1-4HJ1(Vehicle Interface Module)				√		
ISUZU\Euro 5,Euro 4,Euro 3,Euro 2 series\Euro 2 && Euro 3\1]2001\Off-Road) Industrial Engine\Engine\4JJ1-TC(C-Rail_Tiler3)	√	√	√	√		0032, 0202, 0214, 0270, 0312, 0343, 0401, 0405, 0409, 0413, 0508, 0509, 0543, 0564, 0592, 0671, 0704
ISUZU\Euro 5,Euro 4,Euro 3,Euro 2 series\Euro 2 && Euro 3\1]2001\Off-Road) Industrial Engine\Engine\4HK1-TC(C-Rail_Tiler3)	√	√	√	√		0032, 0202, 0214, 0270, 0312, 0343, 0401, 0405, 0409, 0413, 0508, 0509, 0543, 0564, 0592, 0671, 0704
ISUZU\Euro 5,Euro 4,Euro 3,Euro 2 series\Euro 2 && Euro 3\1]2001\Off-Road) Industrial Engine\Engine\6HK1-TC(C-Rail_Tiler3)	√	√	√	√		0225, 0296, 0401, 0405, 0409, 0413, 0489, 0502, 0503, 0506, 0508, 0543, 0564, 0583, 0587, 0598, 0674

ISUZU\Euro 5,Euro 4,Euro 3,Euro 2 series\Euro 2 && Euro 3\1]2001\Off-Road) Industrial Engine\Engine\6UZ1-TC(C-Rail_Tiler3)	√	√	√	√		0225, 0296, 0401, 0405, 0409, 0413, 0489, 0502, 0503, 0506, 0508, 0543, 0564, 0583, 0587, 0598, 0674
ISUZU\Euro 5,Euro 4,Euro 3,Euro 2 series\Euro 2 && Euro 3\1]2001\Off-Road) Industrial Engine\Engine\6WG1-TC(C-Rail_Tiler3)	√	√	√	√		0120, 0130, 0140, 0150, 0203, 0221, 0248, 0265, 0296, 0320, 0361, 0391, 0401, 0402, 0405, 0406, 0409, 0410, 0413, 0414, 0499, 0516, 0542, 0573, 0640, 0672
ISUZU\Euro 5,Euro 4,Euro 3,Euro 2 series\Euro 2 && Euro 3\1]2001\C*,E*,L*,F*)Heavy-Medium Duty\Engine\6WF1-TC(C-Rail)	√	√	√	√		
ISUZU\Euro 5,Euro 4,Euro 3,Euro 2 series\Euro 2 && Euro 3\1]2001\C*,E*,L*,F*)Heavy-Medium Duty\TRANSMISSION\AT Allsion WT		√	√	√		
ISUZU\Euro 5,Euro 4,Euro 3,Euro 2 series\Euro 2 && Euro 3\1]2001\C*,E*,L*,F*)Heavy-Medium Duty\Chassis\ESC(with EBS)	√	√	√	√		
ISUZU\Euro 5,Euro 4,Euro 3,Euro 2 series\Euro 2 && Euro 3\1]2001\C*,E*,L*,F*)Heavy-Medium Duty\Chassis\ABS 6	√	√	√	√		
ISUZU\Euro 5,Euro 4,Euro 3,Euro 2 series\Euro 2 && Euro 3\0]2000\IF-UC)LUV,Rodeo-Frontier,LAO-Rodeo\Powertrain\2.5L 4JK1-TC	√	√	√	√		0218, 0350, 0390, 0423, 0424, 0441, 0490, 0541, 0580, 0685
ISUZU\Euro 5,Euro 4,Euro 3,Euro 2 series\Euro 2 && Euro 3\0]2000\IF-UC)LUV,Rodeo-Frontier,LAO-Rodeo\Powertrain\3.0L 4JJ1-TC	√	√	√	√		0218, 0350, 0390, 0423, 0424, 0441, 0490, 0541, 0580, 0685
ISUZU\Euro 5,Euro 4,Euro 3,Euro 2 series\Euro 2 && Euro 3\0]2000\IF-UC)LUV,Rodeo-Frontier,LAO-Rodeo\Powertrain\AT JR405E		√	√	√		0004, 0037, 0347, 0369, 0480, 0481, 0484, 0540, 0572, 0653, 0661, 0669
ISUZU\Euro 5,Euro 4,Euro 3,Euro 2 series\Euro 2 && Euro 3\0]2000\N*) ELF,NPR,NQR,VFR\Engine\4HG1(LPG)	√	√	√	√		0306, 0319, 0382, 0643
ISUZU\Euro 5,Euro 4,Euro 3,Euro 2 series\Euro 2 && Euro 3\0]2000\N*) ELF,NPR,NQR,VFR\Engine\4JG2		√	√	√		0222
ISUZU\Euro 5,Euro 4,Euro 3,Euro 2 series\Euro 2 && Euro 3\0]2000\N*) ELF,NPR,NQR,VFR\Engine\4JG2(LPG)	√	√	√	√		0306, 0319, 0382, 0643
ISUZU\Euro 5,Euro 4,Euro 3,Euro 2 series\Euro 2 && Euro 3\0]2000\N*) ELF,NPR,NQR,VFR\Engine\4HJ-TC Bosch	√	√	√	√		0222, 0255, 0352, 0353, 0576
ISUZU\Euro 5,Euro 4,Euro 3,Euro 2 series\Euro 2 && Euro 3\0]2000\N*) ELF,NPR,NQR,VFR\Engine\4HL1-4HJ1		√	√	√		
ISUZU\Euro 5,Euro 4,Euro 3,Euro 2 series\Euro 2 && Euro 3\0]2000\N*) ELF,NPR,NQR,VFR\Engine\4HL1-4HJ1(Vehicle Interface Module)				√		
ISUZU\Euro 5,Euro 4,Euro 3,Euro 2 series\Euro 2 && Euro 3\0]2000\Off-Road) Industrial Engine\Engine\4JJ1-TC(C-Rail_Tiler3)	√	√	√	√		0032, 0202, 0214, 0270, 0312, 0343, 0401, 0405, 0409, 0413, 0508, 0509, 0543, 0564, 0592, 0671, 0704
ISUZU\Euro 5,Euro 4,Euro 3,Euro 2 series\Euro 2 && Euro 3\0]2000\Off-Road) Industrial Engine\Engine\4HK1-TC(C-Rail_Tiler3)	√	√	√	√		0032, 0202, 0214, 0270, 0312, 0343, 0401, 0405, 0409, 0413, 0508, 0509, 0543, 0564, 0592, 0671, 0704
ISUZU\Euro 5,Euro 4,Euro 3,Euro 2 series\Euro 2 && Euro 3\0]2000\Off-Road) Industrial Engine\Engine\6HK1-TC(C-Rail_Tiler3)	√	√	√	√		0225, 0296, 0401, 0405, 0409, 0413, 0489, 0502, 0503, 0506, 0508, 0543, 0564, 0583, 0587, 0598, 0674
ISUZU\Euro 5,Euro 4,Euro 3,Euro 2 series\Euro 2 && Euro 3\0]2000\Off-Road) Industrial Engine\Engine\6UZ1-TC(C-Rail_Tiler3)	√	√	√	√		0225, 0296, 0401, 0405, 0409, 0413, 0489, 0502, 0503, 0506, 0508, 0543, 0564, 0583, 0587, 0598, 0674
ISUZU\Euro 5,Euro 4,Euro 3,Euro 2 series\Euro 2 && Euro 3\0]2000\Off-Road) Industrial Engine\Engine\6WG1-TC(C-Rail_Tiler3)	√	√	√	√		0120, 0130, 0140, 0150, 0203, 0221, 0248, 0265, 0296, 0320, 0361, 0391, 0401, 0402, 0405, 0406, 0409, 0410, 0413, 0414, 0499, 0516, 0542, 0573, 0640, 0672
ISUZU\Euro 5,Euro 4,Euro 3,Euro 2 series\Euro 2 && Euro 3\0]2000\C*,E*,L*,F*)Heavy-Medium Duty\Engine\6WF1-TC(C-Rail)	√	√	√	√		
ISUZU\Euro 5,Euro 4,Euro 3,Euro 2 series\Euro 2 && Euro 3\0]2000\C*,E*,L*,F*)Heavy-Medium Duty\TRANSMISSION\AT Allsion WT		√	√	√		
ISUZU\Euro 5,Euro 4,Euro 3,Euro 2 series\Euro 2 && Euro 3\0]2000\C*,E*,L*,F*)Heavy-Medium Duty\Chassis\ESC(with EBS)	√	√	√	√		
ISUZU\Euro 5,Euro 4,Euro 3,Euro 2 series\Euro 2 && Euro 3\0]2000\C*,E*,L*,F*)Heavy-Medium Duty\Chassis\ABS 6	√	√	√	√		
ISUZU\Euro 5,Euro 4,Euro 3,Euro 2 series\Euro 2 && Euro 3\before 2000\IF-UC)LUV,Rodeo-Frontier,LAO-Rodeo\Powertrain\2.5L 4JK1-TC	√	√	√	√		0218, 0350, 0390, 0423, 0424, 0441, 0490, 0541, 0580, 0685

ISUZU\Euro 5,Euro 4,Euro 3,Euro 2 series\Euro 2 && Euro 3\before 2000\ (IF-UC)LUV,Rodeo-Frontier,LAO-Rodeo\Powertrain\3.0L 4JJ1-TC	√	√	√	√		0218, 0350, 0390, 0423, 0424, 0441, 0490, 0541, 0580, 0685
ISUZU\Euro 5,Euro 4,Euro 3,Euro 2 series\Euro 2 && Euro 3\before 2000\ (IF-UC)LUV,Rodeo-Frontier,LAO-Rodeo\Powertrain\AT JR405E		√	√	√		0004, 0037, 0347, 0369, 0480, 0481, 0484, 0540, 0572, 0653, 0661, 0669
ISUZU\Euro 5,Euro 4,Euro 3,Euro 2 series\Euro 2 && Euro 3\before 2000\ (N*) ELF,NPR,NQR,VFR\Engine\4HG1(LPG)	√	√	√	√		0001, 0096, 0101, 0306, 0319, 0382, 0643
ISUZU\Euro 5,Euro 4,Euro 3,Euro 2 series\Euro 2 && Euro 3\before 2000\ (N*) ELF,NPR,NQR,VFR\Engine\4JG2		√	√	√		0222
ISUZU\Euro 5,Euro 4,Euro 3,Euro 2 series\Euro 2 && Euro 3\before 2000\ (N*) ELF,NPR,NQR,VFR\Engine\4JG2(LPG)	√	√	√	√		0306, 0319, 0382, 0643
ISUZU\Euro 5,Euro 4,Euro 3,Euro 2 series\Euro 2 && Euro 3\before 2000\ (N*) ELF,NPR,NQR,VFR\Engine\4HJ-TC Bosch	√	√	√	√		0222, 0255, 0352, 0353, 0576
ISUZU\Euro 5,Euro 4,Euro 3,Euro 2 series\Euro 2 && Euro 3\before 2000\ (N*) ELF,NPR,NQR,VFR\Engine\4HL1-4HJ1		√	√	√		
ISUZU\Euro 5,Euro 4,Euro 3,Euro 2 series\Euro 2 && Euro 3\before 2000\ (N*) ELF,NPR,NQR,VFR\Engine\4HL1-4HJ1 (Vehicle Interface Module)				√		
ISUZU\Euro 5,Euro 4,Euro 3,Euro 2 series\Euro 2 && Euro 3\before 2000\ (Off-Road) Industrial Engine\Engine\4JJ1-TC(C-Rail_Tiler3)	√	√	√	√		0032, 0202, 0214, 0270, 0312, 0343, 0401, 0405, 0409, 0413, 0508, 0509, 0543, 0564, 0592, 0671, 0704
ISUZU\Euro 5,Euro 4,Euro 3,Euro 2 series\Euro 2 && Euro 3\before 2000\ (Off-Road) Industrial Engine\Engine\4HK1-TC(C-Rail_Tiler3)	√	√	√	√		0032, 0202, 0214, 0270, 0312, 0343, 0401, 0405, 0409, 0413, 0508, 0509, 0543, 0564, 0592, 0671, 0704
ISUZU\Euro 5,Euro 4,Euro 3,Euro 2 series\Euro 2 && Euro 3\before 2000\ (Off-Road) Industrial Engine\Engine\6HK1-TC(C-Rail_Tiler3)	√	√	√	√		0225, 0296, 0401, 0405, 0409, 0413, 0489, 0502, 0503, 0506, 0508, 0543, 0564, 0583, 0587, 0598, 0674
ISUZU\Euro 5,Euro 4,Euro 3,Euro 2 series\Euro 2 && Euro 3\before 2000\ (Off-Road) Industrial Engine\Engine\6UZ1-TC(C-Rail_Tiler3)	√	√	√	√		0225, 0296, 0401, 0405, 0409, 0413, 0489, 0502, 0503, 0506, 0508, 0543, 0564, 0583, 0587, 0598, 0674
ISUZU\Euro 5,Euro 4,Euro 3,Euro 2 series\Euro 2 && Euro 3\before 2000\ (Off-Road) Industrial Engine\Engine\6WG1-TC(C-Rail_Tiler3)	√	√	√	√		0120, 0130, 0140, 0150, 0203, 0221, 0248, 0265, 0296, 0320, 0361, 0391, 0401, 0402, 0405, 0406, 0409, 0410, 0413, 0414, 0499, 0516, 0542, 0573, 0640, 0672
ISUZU\Euro 5,Euro 4,Euro 3,Euro 2 series\Euro 2 && Euro 3\before 2000\ (C*,E*,L*,F*)Heavy-Medium Duty\Engine\6WF1-TC(C-Rail)	√	√	√	√		
ISUZU\Euro 5,Euro 4,Euro 3,Euro 2 series\Euro 2 && Euro 3\before 2000\ (C*,E*,L*,F*)Heavy-Medium Duty\TRANSMISSION\AT Allsion WT		√	√	√		
ISUZU\Euro 5,Euro 4,Euro 3,Euro 2 series\Euro 2 && Euro 3\before 2000\ (C*,E*,L*,F*)Heavy-Medium Duty\Chassis\ESC(with EBS)	√	√	√	√		
ISUZU\Euro 5,Euro 4,Euro 3,Euro 2 series\Euro 2 && Euro 3\before 2000\ (C*,E*,L*,F*)Heavy-Medium Duty\Chassis\ABS 6	√	√	√	√		
ISUZU\Euro 5,Euro 4,Euro 3,Euro 2 series\Euro 2 && Euro 3\ISUZU Light Duty\2.5L 4JK1-TC	√	√	√	√		0218, 0350, 0394, 0441, 0490, 0541, 0580, 0688
ISUZU\Euro 5,Euro 4,Euro 3,Euro 2 series\Euro 2 && Euro 3\ISUZU Light Duty\3.0L 4JJ1-TC	√	√	√	√		0218, 0350, 0394, 0441, 0490, 0541, 0580, 0688
ISUZU\Euro 5,Euro 4,Euro 3,Euro 2 series\Euro 2 && Euro 3\ISUZU Light Duty\4JH1-T Denso	√	√	√	√		0222, 0255, 0352, 0353, 0388, 0466, 0576

Special Function Table

0001	1 threshold value of oxygen sensor
0002	1-2 Solenoid
0003	2-3 Solenoid
0004	2-4 gear brake solenoid test
0005	A/C Relay
0006	A/C and Buzzer test
0007	A/C clutch ON
0008	A/C compressor test

0009	A/C relay
0010	A/C relay;
0011	A/T Data Force Recording
0012	A/T Event Data Clear
0013	A/T Log Data Clear
0014	ABS Motor
0015	ABS Relay
0016	ABS Warning Lamp
0017	ABS motor
0018	ABS relay
0019	ACC#1 Function (EXH./RET. Brake)
0020	ACC#2 Function (Service Brake)
0021	ACC/CMS/Distance to Vehicle Alarm
0022	ASR information lamp test
0023	ASR message indicator lamp
0024	ASR solenoid valve
0025	ASR valve test
0026	ASR warning lamp test
0027	ASR-indicator lamp
0028	AT Engine Oil Temperature Signal Light test
0029	AT oil temperature signal lamp test
0030	Acceleration test
0031	Adjust Start of Injection
0032	Air flow calibration data service model
0033	Air flow correction data service mode
0034	All Parameters(Not Editable)
0035	All parameters(Not Editable)
0036	Anti-lock brake system warning
0037	Automatic transmission oil temperature signal lamp test
0038	BLM (Block Learn Multiplier) reset
0039	BLM (Block Learn Multiplier) self-learning
0040	Basic engine idle speed
0041	Blower relay test
0042	Boost pressure actuator
0043	Brake Assist Function
0044	Brake Pedal Depress Quantity CAN-ID
0045	Buzzer
0046	Buzzer (external)
0047	Buzzer signal
0048	CKP Variation Learn
0049	CMP Actuator Solenoid
0050	Car light as soon as possible maintenance
0051	Carbon canister purging
0052	Carbon canister ventilation
0053	Check Light test
0054	Check Transmission Lamp
0055	Check gearbox lamp
0056	Check gearbox light
0057	Check lamp test
0058	Clean closed throttle learned value;

0059	Clean fuel/air ratio threshold;
0060	Clean injection learned value;
0061	Clean throttle idle learned value;
0062	Clear 1-2 TAP
0063	Clear 2-1 TAP
0064	Clear 2-3 TAP
0065	Clear 3-2 TAP
0066	Clear 3-4 TAP
0067	Clear 4-3 TAP
0068	Clear 4-5 TAP
0069	Clear 5-4 TAP
0070	Clear A/F ratio threshold
0071	Clear All Garage Shift TAP
0072	Clear All TAP Cells
0073	Clear DMU data
0074	Clear DPD data
0075	Clear DPF Data
0076	Clear DPF data
0077	Clear ECM Learned Data
0078	Clear ECM learned data
0079	Clear Feedback Average working in Idling
0080	Clear ISC Learned value
0081	Clear ISC learning value
0082	Clear MAF Learned Data
0083	Clear MIMAMORI data
0084	Clear O2 sensor 1 valve value
0085	Clear Oxygen Sensor 1 threshold value
0086	Clear all DTC record of MIMSMORI
0087	Clear all Engine DMU data
0088	Clear all MIMSMORI data
0089	Clear all TCM DMU data
0090	Clear average value in idle
0091	Clear closed circuit throttle learning value
0092	Clear feedback average work in idle
0093	Clear fuel consumption data
0094	Clear fuel injection learning value
0095	Clear idle control learning value
0096	Clear idle idle feedback
0097	Clear injection learning value
0098	Clear memory
0099	Clear oxygen sensor 1 threshold
0100	Clear shut up throttle learning value
0101	Clear the value of ISC learning
0102	Clear throttle idle learning value
0103	Cold cranking lamp
0104	Common rail pressure test
0105	Compression test
0106	Compressor Relay test
0107	Coolant temperature gauge
0108	Correction data

0109	Corresponding to 2490 wheelbase single-row and double-row vehicles
0110	Corresponding to 2765 and 3360 wheelbase vehicles without exhaust brake
0111	Corresponding to 2765, 3360, 3815 wheelbase vehicles with exhaust brake
0112	Cruise Main Lamp
0113	Cruise Set Lamp
0114	Cruise control Set lamp
0115	Cruise control disabled
0116	Cruise control main switch
0117	Cruise set light
0118	Cruise the main light
0119	Cylinder 1
0120	Cylinder 1 Balance rate test
0121	Cylinder 1 balance rate test
0122	Cylinder 1 contribution/balance
0123	Cylinder 1 injection valve
0124	Cylinder 1 injector injection
0125	Cylinder 1 injector stop
0126	Cylinder 1 injector test
0127	Cylinder 1 injector trim
0128	Cylinder 1:
0129	Cylinder 2
0130	Cylinder 2 Balance rate test
0131	Cylinder 2 balance rate test
0132	Cylinder 2 contribution/balance
0133	Cylinder 2 injection valve
0134	Cylinder 2 injector injection
0135	Cylinder 2 injector stop
0136	Cylinder 2 injector test
0137	Cylinder 2 injector trim
0138	Cylinder 2:
0139	Cylinder 3
0140	Cylinder 3 Balance rate test
0141	Cylinder 3 balance rate test
0142	Cylinder 3 contribution/balance
0143	Cylinder 3 injection valve
0144	Cylinder 3 injector injection
0145	Cylinder 3 injector stop
0146	Cylinder 3 injector test
0147	Cylinder 3 injector trim
0148	Cylinder 3:
0149	Cylinder 4
0150	Cylinder 4 Balance rate test
0151	Cylinder 4 balance rate test
0152	Cylinder 4 contribution/balance
0153	Cylinder 4 injection valve
0154	Cylinder 4 injector injection
0155	Cylinder 4 injector stop
0156	Cylinder 4 injector test
0157	Cylinder 4 injector trim
0158	Cylinder 4:

0159	Cylinder 5
0160	Cylinder 5 balance rate test
0161	Cylinder 5 injector trim
0162	Cylinder 6
0163	Cylinder 6 balance rate test
0164	Cylinder 6 injector trim
0165	Cylinder 7
0166	Cylinder 8
0167	Cylinder Power Balance
0168	Cylinder balance test
0169	Cylinder cut-off test
0170	Cylinder shutoff test
0171	Cylinder5:
0172	Cylinder6:
0173	DCU Lock
0174	DEF Control Module Data Reset
0175	DEF Heater Valve Relay
0176	DEF Injector Data Reset
0177	DEF Reverting Valve
0178	DEF Supply Pump
0179	DEF control module data reset
0180	DEF heater valve relay
0181	DEF nozzle data reset
0182	DEF return valve
0183	DEF supply pump
0184	DPD normal regeneration control
0185	DPD slow regeneration control
0186	DPD status reset
0187	DPF Injector Data Reset
0188	DPF Normal Regen
0189	DPF Normal Regeneration
0190	DPF Slow Regen
0191	DPF Slow Regeneration
0192	DPF normal regeneration
0193	DPF nozzle data reset
0194	DPF option
0195	DPF regeneration is slow
0196	DSA Function (Driving Safety Adviser)
0197	Deceleration brake
0198	Deceleration brake test
0199	Decelerator relay
0200	Diesel particulate filter normal regeneration control
0201	Diesel particulate filter slow regeneration control
0202	Diesel particulate trap regeneration data reset
0203	Diesel particulate trap state reset
0204	Display injector quantity correction
0205	Distance to Vehicle Alarm Function
0206	Door lock test
0207	Door unlock test
0208	Download MAF compensation

0209	Download identification code
0210	Drive Line
0211	EC Ignition Relay
0212	ECT Gauge
0213	ECT meter
0214	EGR
0215	EGR (Exhaust Gas Recirculation) solenoid valve control
0216	EGR (Exhaust Gas Recirculation) test
0217	EGR (Exhaust Gas Recirculation) valve test
0218	EGR Control
0219	EGR Cooler Bypass Solenoid VSV
0220	EGR Pulse Ratio Test
0221	EGR Solenoid Control
0222	EGR Solenoid Test
0223	EGR Valve test
0224	EGR control
0225	EGR control test
0226	EGR control – test sequence 1
0227	EGR control – test sequence 2
0228	EGR control – test sequence 3
0229	EGR control – test sequence 4
0230	EGR cooler output test
0231	EGR solenoid
0232	EGR solenoid control
0233	EGR solenoid valve
0234	EGR solenoid valve 2
0235	EGR solenoid valve control
0236	EGR solenoid valve test
0237	EGR solenoid valve test;
0238	EGR valve control test
0239	EGR valve test
0240	EGT Sensor 3 Data Reset
0241	EGT sensor 3 data reset
0242	ETC Gauge
0243	EVAP Purge Solenoid
0244	EVAP Purge/Seal
0245	EVAP Vent Solenoid
0246	EXH./RET. Brake Signal Convert
0247	Electrical lift working platform;
0248	Electromagnetic valve inlet throttle control
0249	Electronic control throttle operation
0250	Electronic control throttle running
0251	Engine Log Data Clear
0252	Engine Log Data Force Recording
0253	Engine Model
0254	Engine Speed(RPM) Control
0255	Engine Telltale(check light)test
0256	Engine indicator lamp (detector lamp) test
0257	Engine protection mode
0258	Engine protection mode enabled

0259	Engine signal equipment <check light> test;
0260	Engine signal unit (detector lamp) test
0261	Engine speed comparison
0262	Engine speed test
0263	Engine<C/Rail>
0264	Exhaust Brake
0265	Exhaust Brake Control
0266	Exhaust Brake Cut
0267	Exhaust Brake Cut Relay
0268	Exhaust Cut Request
0269	Exhaust Differential Pressure Sensor Learn
0270	Exhaust brake
0271	Exhaust brake (AT) cutoff request
0272	Exhaust brake VSV
0273	Exhaust brake VSV;
0274	Exhaust brake assistance inside the cruise
0275	Exhaust brake command
0276	Exhaust brake control
0277	Exhaust brake cruise off threshold
0278	Exhaust brake cruise open the threshold
0279	Exhaust brake cut off relay
0280	Exhaust brake lamp
0281	Exhaust brake lamp VSV
0282	Exhaust brake lamp;
0283	Exhaust brake latches minimum RPM
0284	Exhaust brake light
0285	Exhaust brake mode
0286	Exhaust brake relay
0287	Exhaust brake test
0288	Exhaust brake valve control
0289	Exhaust differential pressure sensor learning
0290	Exhaust gas brake solenoid valve
0291	Exhaust gas recirculation control
0292	Exhaust gas warning lamp
0293	Exhaust off relay test
0294	Exhaust shutoff relay test
0295	Exhaust throttle
0296	Exhaust throttle control
0297	Exhaust throttle valve control
0298	Exhaust throttle valve of engine brake
0299	Exhaust throttle valve test
0300	Exhaust valve command
0301	Exhaust valve lamp test
0302	External detector test
0303	Fan high speed ON
0304	Fan low speed ON
0305	Fault indicator
0306	Feed Back Solenoid
0307	Feedback solenoid valve test
0308	Forced Exhausting

0309	Forced Intake Air
0310	Forced TCM DMU recording
0311	Forced engine DMU recording
0312	Forced regeneration of diesel particulate filter
0313	Front fuel injection timing
0314	Front injection stop
0315	Front supply pump test
0316	Fuel Cut Solenoid
0317	Fuel Delivery Rate Calibration
0318	Fuel Economy Meter Reset
0319	Fuel Oil Cut-Off Solenoid Valve
0320	Fuel Pressure Control
0321	Fuel Pump
0322	Fuel Pump Relay
0323	Fuel Rail Pressure
0324	Fuel Trim Enable
0325	Fuel Trim Reset
0326	Fuel cut off electromagnetic coil 2;
0327	Fuel cut off electromagnetic coil;
0328	Fuel cut off magnetic coil
0329	Fuel cut solenoid 2
0330	Fuel cutoff solenoid
0331	Fuel cutoff solenoid 1
0332	Fuel cutoff solenoid 2
0333	Fuel cutoff solenoid coil 1
0334	Fuel cutoff solenoid coil 2
0335	Fuel cutoff solenoid valve test
0336	Fuel filter heater
0337	Fuel injection timing
0338	Fuel open loop control
0339	Fuel pressure control
0340	Fuel pump learning
0341	Fuel pump learning reset
0342	Fuel pump self-learning
0343	Fuel rail pressure
0344	Fuel supply pump initialization
0345	Fuel transfer pump learning reset
0346	Fuel transmission ratio data;
0347	Functional lamp test
0348	GEN L-Terminal
0349	Glow Plug Lamp
0350	Glow Plug Relay
0351	Glow Plugs
0352	Glow Time Relay Test
0353	Glow Time Telltale Test
0354	Glow plug light control
0355	Glow plug lights
0356	Glow plug relay
0357	Glow plug relay command
0358	Glow plug relay control

0359	Glow plug relay test
0360	Glow plugs
0361	Glow relay control
0362	HO2S Bank 1 Sensor 1 Heater
0363	HO2S Bank 1 Sensor 2 Heater
0364	HO2S Bank 2 Sensor 1 Heater
0365	HO2S Bank 2 Sensor 2 Heater
0366	HO2S Heater Learn
0367	Height Lamp
0368	High Side Drive 1
0369	High grade clutch solenoid test
0370	High pressure test
0371	Hold valve right front
0372	ISS driving data clear;
0373	ISS maintenance data clear;
0374	Idle Learn Reset
0375	Idle Shutdown Extension
0376	Idle Spark
0377	Idle catalyst monitoring
0378	Idle control
0379	Idle control test
0380	Idle speed comparison
0381	Idle stop extension
0382	Idle-Speed Control Test
0383	Ignition Spark Timing Test
0384	Ignition spark timing test
0385	Illumination control test
0386	Illumination light signal test
0387	Import MAF compensation
0388	Initial capacity
0389	Injected oil quantity comparison
0390	Injection Timing
0391	Injection Timing control
0392	Injection identification code
0393	Injection spark timing change
0394	Injection timing
0395	Injection timing control
0396	Injection valve drive
0397	Injection valve forced driven
0398	Injection valve forced to drive
0399	Injection valve operation
0400	Injection valve running
0401	Injector 1
0402	Injector 1 Forced Drive
0403	Injector 1 driven forcedly
0404	Injector 1 forced drive
0405	Injector 2
0406	Injector 2 Forced Drive
0407	Injector 2 driven forcedly
0408	Injector 2 forced drive

0409	Injector 3
0410	Injector 3 Forced Drive
0411	Injector 3 driven forcedly
0412	Injector 3 forced drive
0413	Injector 4
0414	Injector 4 Forced Drive
0415	Injector 4 driven forcedly
0416	Injector 4 forced drive
0417	Injector 5
0418	Injector 5 driven forcedly
0419	Injector 6
0420	Injector 6 driven forcedly
0421	Injector 7
0422	Injector 8
0423	Injector Balancing
0424	Injector Forced Drive
0425	Injector balance test (cylinder 1)
0426	Injector balance test (cylinder 2)
0427	Injector balance test (cylinder 3)
0428	Injector balance test (cylinder 4)
0429	Injector forced start
0430	Injector forced to drive
0431	Injector match
0432	Injector quantity correction
0433	Injector started forcedly
0434	Injector stop
0435	Injector stop injection test
0436	Injector stopped
0437	Injector trim
0438	Injector valve forced to drive
0439	Inlet throttle solenoid valve control
0440	Inner light test
0441	Intake Throttle Control
0442	Intake air accelerator solenoid control
0443	Intake air throttle control;
0444	Intake throttle control
0445	Intake throttle control (only 4JJ1)
0446	Intake throttle control <only 4JJ1>
0447	Internal Yaw Rate
0448	Into the air volume valve
0449	Keep the valve right
0450	Keep valve left
0451	Kick Drive Light
0452	LF Hold Valve
0453	LF Release Valve
0454	LR Hold Valve
0455	LR Release Valve
0456	Left Front Dump Valve
0457	Left Front Isolation Valve
0458	Left Rear Dump Valve

0459	Left Rear Isolation Valve
0460	Left front control valve test
0461	Left front release valve
0462	Left rear control valve test
0463	Left rear release valve
0464	Lighting control test
0465	Lighting signal test
0466	Limited capacity
0467	Linear Solenoid 1
0468	Linear Solenoid 2
0469	Linear Solenoid 3
0470	Linear Solenoid 4
0471	Linear pressure solenoid valve 1
0472	Linear pressure solenoid valve 2
0473	Linear pressure solenoid valve 3
0474	Linear pressure solenoid valve 4
0475	Linear solenoid valve
0476	Linear solenoid valve 2
0477	Linear solenoid valve 3
0478	Linear solenoid valve 4
0479	Lock ECU
0480	Lock engine control unit
0481	Locking load solenoid valve test
0482	Loop Status
0483	Low Traction Lamp
0484	Low clutch solenoid test
0485	MIL
0486	MIL (Malfunction Indicator Light) control
0487	MIL Lamp
0488	Main injection time
0489	Main injection timing
0490	Malfunction Indicator Lamp
0491	Malfunction Indicator Lamp (MIL)
0492	Malfunction indicator lamp (MIL)
0493	Maximum cruise control speed limit
0494	Minimum cruise control speed limit
0495	Mode 1
0496	Mode 2
0497	NOx Sensor 1 Data Reset
0498	NOx Sensor 2 Data Reset
0499	Normal regeneration control of diesel fuel
0500	Nox Sensor 1 data reset
0501	Nox Sensor 2 data reset
0502	Nozzle #5
0503	Nozzle #6
0504	Nozzle 5 forced drive
0505	Nozzle 6 forced drive
0506	Nozzle balance test
0507	Nozzle correction
0508	Nozzle forced start

0509	Nozzle stop
0510	O2S Heater Control
0511	Odometer indicator test
0512	Odometer lamp test
0513	Oil consumption display test
0514	Oil feed pump initialization
0515	Oil injection timing control
0516	Oil replacement reset (only for 5 Ohm)
0517	Outlet valve FL
0518	Outlet valve FR
0519	Outlet valve RL
0520	Outlet valve RR
0521	Overdrive (OD) off Lamp
0522	Oxidation Catalyst Data Reset
0523	Oxidation catalyst data reset
0524	Oxygen sensor reaction
0525	PC Solenoid 2
0526	PC Solenoid 2 w/DT-47825
0527	PC Solenoid 3
0528	PC Solenoid 3 w/DT-47825
0529	PC Solenoid 4
0530	PC Solenoid 4 w/DT-47825
0531	PC Solenoid 5
0532	PC Solenoid 5 w/DT-47825
0533	PCB Alarm Function (Pre-crash Brake)
0534	PCB Function (Pre-crash Brake)
0535	PTO Relay
0536	PTO Solenoid
0537	PTO relay
0538	PTO requested engine speed
0539	PTO solenoid valve
0540	Pipeline pressure solenoid valve test
0541	Pre Injection Stop
0542	Pre Injection control
0543	Pre injection stop
0544	Pre injection time
0545	Pre spray stop
0546	Pre-heat indicator lamp
0547	Pre-heat relay control
0548	Pre-heat relay test
0549	Pre-heat time control
0550	Pre-ignition unit
0551	Pre-injection control
0552	Pre-injection stop
0553	Pre-injection stop injection test
0554	Pre-injection stopped
0555	Pre-supply pump test
0556	Preheat relay
0557	Preheat relay command
0558	Preheat time indicator lamp test

0559	Preheat time relay test
0560	Preheat time relay test;
0561	Preheat time signal equipment test;
0562	Preheat time signal unit test
0563	Preheating indicator lamp
0564	Preheating plug relay
0565	Preheating relay control
0566	Preheating time control
0567	Preset All TAP Cells
0568	Pressure Control Solenoid A
0569	Pressure Control Solenoid B
0570	Pressure wave correction released
0571	Pressure wave form calibration release
0572	Programming vehicle identification code
0573	Pump initialization
0574	RF Hold Valve
0575	RF Release Valve
0576	RPM control
0577	RR Hold Valve
0578	RR Release Valve
0579	Radar flag reading
0580	Rail Pressure Control
0581	Rail pressure
0582	Rail pressure control
0583	Rail pressure test
0584	Read Engine Serial Number
0585	Read Injector code
0586	Read all fuel injection nozzle data
0587	Read nozzle code
0588	Read nozzle data
0589	Recorded ECM/TCM/DEFCM DTC Data Clear
0590	Refrigerant compressor
0591	Removal of oil / gas ratio limits
0592	Remove oil pump data has been learning
0593	Reply test
0594	Required idle change
0595	Required idle speed change
0596	Reset DPD regeneration
0597	Reset Transmission Adapts
0598	Reset fuel pump calibration
0599	Retarder Command
0600	Retarder relay
0601	Right Front Dump Valve
0602	Right Front Isolation Valve
0603	Right Rear Dump Valve
0604	Right Rear Isolation Valve
0605	Right front control valve test
0606	Right front release valve
0607	Right rear control valve test
0608	Right release valve

0609	SCR Automated Leak Test
0610	SCR Catalyst Data Reset
0611	SCR System Data Force Recording
0612	SCR System Log Data Clear
0613	SCR catalyst data reset
0614	SVS Lamp
0615	Service Brake Soon Lamp
0616	Service Vehicle Soon (SVS) control
0617	Service Vehicle Soon Lamp
0618	Service indicator lamp
0619	Set ECU locking function
0620	Shift Solenoid 1
0621	Shift Solenoid 1 w/DT-47825
0622	Shift Solenoid 2
0623	Shift Solenoid 2 w/DT-47825
0624	Shift Solenoid 3
0625	Shift Solenoid 4
0626	Shift Solenoid C
0627	Shift Solenoid D
0628	Shift Solenoid E
0629	Shift Timing Solenoid
0630	Shift solenoid 1
0631	Shift solenoid 2
0632	Shift solenoid valve 1
0633	Shift solenoid valve 2
0634	Shift solenoid valve 3
0635	Shift solenoid valve 4
0636	Shift solenoid1
0637	Shift solenoid2
0638	Shift solenoid3
0639	Shift timing solenoid
0640	Slow regeneration control of diesel particulate trap
0641	Smoother
0642	Sol.G Modulated Pressure
0643	Spark Timing Test
0644	Spark timing change
0645	Speed control
0646	Spill Value Relay Test
0647	Starter Relay
0648	Steering Angle Input
0649	Steering Angle Input CAN Output
0650	Steering Angle Input CAN-ID
0651	Stop Lamp Request
0652	Supply Pump Learn Reset
0653	Synchronous brake solenoid
0654	System lamp test
0655	TB Idle Air Flow Comp
0656	TCC Control Solenoid
0657	TCC Control Solenoid w/DT-47825
0658	TCC solenoid control

0659	TPS minimum self-learning rule reset
0660	Tachometer
0661	Third start lamp test
0662	Throttle solenoid valve control
0663	Time calibration correction
0664	Time calibration correction deactivated
0665	Time calibration correction release
0666	Traction Off Lamp
0667	Transmission Fluid Overtemp Lamp
0668	Transmission Model
0669	Transmission check lamp
0670	Transmission oil temperature indicator
0671	Turbocharger
0672	Turbocharger Solenoid valve Control
0673	Turbocharger blades
0674	Turbocharger control
0675	Turbocharger solenoid control
0676	Turbocharger solenoid valve control
0677	Turbocharger test
0678	Turn Signal Input
0679	Update Engine type
0680	Update Transmission type
0681	Update vehicle ECU information
0682	Upload fuel transmission ratio data;
0683	Upload identification code
0684	VGIS (Variable Inlet Air)
0685	Variable Swirl Solenoid
0686	Variable swirl solenoid
0687	Variable swirl timing
0688	Varialbe Swirl Solenoid
0689	Vehicle Speed Input
0690	Vehicle Type
0691	Wait To Start Lamp
0692	Wait to start lamp
0693	Warning Lamp
0694	Warning lamp
0695	Warning lamp;
0696	Wiper test
0697	Write Engine Serial Number
0698	Write injector data #2
0699	Write injector data #3
0700	Write injector data #4
0701	Write injector data #5
0702	Write injector data #6
0703	Write injector data#1
0704	exhaust throttle valve