

DAF V13.50 Function list

Note:

√ Functions marked with √ is fully supported and already existed in former software version.

Number Index number of the special function , you can find the name from the special function table.

System	ECU Info.	Read Fault Code	Clear Fault Code	Live Data	Freeze Frame	Active Test	Special Func
DAF\Divided by system\Engine system\PCI							
DAF\Divided by system\Engine system\PMCI2	√	√	√	√			
DAF\Divided by system\Engine system\DMCI	√	√	√	√		√	
DAF\Divided by system\Engine system\DMCI-EMS2	√	√	√	√		√	
DAF\Divided by system\Engine system\ECSDC3		√	√	√			
DAF\Divided by system\Engine system\ECSDC4		√	√	√			
DAF\Divided by system\Engine system\ECSDC5	√	√	√	√	√	√	0009, 0010, 0011, 0015, 0026
DAF\Divided by system\Engine system\UPEC	√	√	√	√		√	
DAF\Divided by system\Engine system\UPEC-EMS2	√	√	√	√		√	
DAF\Divided by system\Retarder system\EST15	√	√	√	√		√	
DAF\Divided by system\Retarder system\EST32	√	√	√	√		√	
DAF\Divided by system\Retarder system\EST41	√	√	√	√			
DAF\Divided by system\Retarder system\EST52	√	√	√	√	√	√	
DAF\Divided by system\Suspension system\ECAS	√	√	√	√		√	
DAF\Divided by system\Suspension system\ECAS3	√	√	√	√		√	
DAF\Divided by system\Suspension system\ECAS4\ECAS4	√	√	√	√	√	√	0005, 0006, 0007, 0012, 0013, 0020
DAF\Divided by system\Suspension system\ECAS4\ECAS4-1 rear level sensor	√	√	√	√		√	
DAF\Divided by system\Suspension system\ECAS4\ECAS4-2 rear level sensor	√	√	√	√		√	
DAF\Divided by system\Suspension system\ECAS4\ECAS4-Full air	√	√	√	√		√	
DAF\Divided by system\Suspension system\ECAS2 6x2	√	√	√	√		√	0017, 0018
DAF\Divided by system\Suspension system\ECAS2 Xx2	√	√	√	√			
DAF\Divided by system\After treatment system\EAS	√	√	√				0001, 0002, 0003, 0004
DAF\Divided by system\After treatment system\EAS2	√	√	√	√			0001, 0002, 0003, 0004
DAF\Divided by system\After treatment system\EAS3	√			√			
DAF\Divided by system\Brake system\EBS	√	√	√	√		√	
DAF\Divided by system\Brake system\EBS2	√	√	√	√			
DAF\Divided by system\Brake system\EBS2-Options	√	√	√	√			
DAF\Divided by system\Brake system\EBS2 CAN	√	√	√	√			
DAF\Divided by system\Brake system\EBS3	√	√	√	√			
DAF\Divided by system\Brake system\ABSC		√	√	√		√	
DAF\Divided by system\Brake system\ABSD		√	√	√		√	
DAF\Divided by system\Brake system\ABS WABCO D-E		√	√	√		√	
DAF\Divided by system\Brake system\ABSE2	√	√	√	√		√	
DAF\Divided by system\Transmission system\ASTRONIC	√	√	√	√		√	0008, 0014, 0016, 0019, 0022, 0027, 0028
DAF\Divided by system\Transmission system\ASTRONIC LITE	√	√	√	√		√	0008, 0014, 0016, 0019, 0021, 0022, 0023, 0027, 0028
DAF\Divided by system\Instrumentation system\DIP4	√					√	

DAF\Divided by system\Instrumentation system\DIP5	√						
DAF\Divided by system\Door control system\CDS3	√	√	√	√			
DAF\Divided by system\Door control system\CDS4	√					√	
DAF\Divided by system\Vehicle control system\VIC - Lighting	√	√	√	√		√	0024
DAF\Divided by system\Vehicle control system\VIC - Speed signal	√	√	√	√		√	0024
DAF\Divided by system\Vehicle control system\VIC - Status signal	√	√	√	√		√	0024
DAF\Divided by system\Vehicle control system\VIC - Turn signal	√	√	√	√		√	0024
DAF\Divided by system\Vehicle control system\VIC - Warning signal	√	√	√	√		√	0024
DAF\Divided by system\Vehicle control system\VIC - Wiper	√	√	√	√		√	0024
DAF\Divided by system\Vehicle control system\VIC2 - Lighting and General	√	√	√				
DAF\Divided by system\Vehicle control system\VIC2 - Speed signals	√	√	√				
DAF\Divided by system\Vehicle control system\VIC2 - Status signals	√	√	√				
DAF\Divided by system\Vehicle control system\VIC2 - Turn signals	√	√	√				
DAF\Divided by system\Vehicle control system\VIC2 - Warning signals	√	√	√				
DAF\Divided by system\Vehicle control system\VIC2 - Wiper	√	√	√				
DAF\Divided by system\Vehicle control system\VIC2 LITE - Lighting and General	√	√	√				
DAF\Divided by system\Vehicle control system\VIC2 LITE - Speed signals	√	√	√				
DAF\Divided by system\Vehicle control system\VIC2 LITE - Status signals	√	√	√				
DAF\Divided by system\Vehicle control system\VIC2 LITE - Turn signals	√	√	√				
DAF\Divided by system\Vehicle control system\VIC2 LITE - Warning signals	√	√	√				
DAF\Divided by system\Vehicle control system\VIC2 LITE - Wiper	√	√	√				
DAF\Divided by system\Vehicle control system\VIC3 - Lighting and General	√	√	√	√	√	√	0025
DAF\Divided by system\Vehicle control system\VIC3 - Speed signals	√	√	√	√	√	√	0025
DAF\Divided by system\Vehicle control system\VIC3 - Status signals	√	√	√	√	√	√	0025
DAF\Divided by system\Vehicle control system\VIC3 - Turn signals	√	√	√	√	√	√	0025
DAF\Divided by system\Vehicle control system\VIC3 - Warning signals	√	√	√	√	√	√	0025
DAF\Divided by system\Vehicle control system\VIC3 - Wiper	√	√	√	√	√	√	0025
DAF\Divided by system\Vehicle control system\BBM - Configuration 1	√	√	√				
DAF\Divided by system\Vehicle control system\BBM - Configuration 2	√	√	√				
DAF\Divided by system\Vehicle control system\SWS		√	√	√			
DAF\Divided by system\CAB climate system\ACHEA	√	√	√	√		√	
DAF\Divided by system\CAB climate system\ACHEW	√	√	√	√		√	
DAF\Divided by system\CAB climate system\ACHW2	√	√	√	√		√	
DAF\Divided by system\Tachograph\MTCO	√	√	√	√			
DAF\Divided by system\Tachograph\DTCO	√	√	√	√			
DAF\Divided by system\Security system\IMMO	√	√	√				
DAF\Divided by system\Security system\ALSS	√	√	√	√			
DAF\Divided by system\Safety system\AIRBAG	√	√	√	√		√	
DAF\Divided by system\Safety system\AIRBAG2	√	√	√				
DAF\Divided by system\Safety system\AIRBAG3	√	√	√				
DAF\Divided by system\Safety system\LDWA	√	√	√				
DAF\Divided by system\Safety system\ACC	√	√	√				
DAF\Divided by system\Safety system\AEBS	√	√	√				
DAF\Divided by system\Auxiliary system\CDM	√	√	√	√			
DAF\Divided by system\Communication system\TELEPHONE	√	√	√	√			
DAF\Divided by system\Communication system\DTS	√	√	√	√		√	
DAF\Divided by system\Steering control system\EMAS	√			√		√	
DAF\Divided by system\Steering control system\RASEC	√	√	√	√			

DAF\Divided by system\Smart Air Supply Control\SAC	√	√	√	√			
DAF\Divided by system\Lighting system\ELC 1394	√	√	√	√		√	
DAF\Divided by system\Audio-video combi\DAS	√						
DAF\Divided by system\Service Light Reset(SLR) Reset service-Diagnose\GENERAL SERVICE RESET(EURO 4-5)						√	
DAF\Divided by vehicle\CF\65CF\Engine system\ECSDC3		√	√	√			
DAF\Divided by vehicle\CF\65CF\Brake system\ABSD		√	√	√		√	
DAF\Divided by vehicle\CF\65CF\CAB climate system\ACHEA	√	√	√	√		√	
DAF\Divided by vehicle\CF\65CF\Suspension system\ECAS	√	√	√	√		√	
DAF\Divided by vehicle\CF\65CF\Suspension system\ECAS2 4x2	√	√	√	√			
DAF\Divided by vehicle\CF\65CF\Suspension system\ECAS3	√	√	√	√		√	
DAF\Divided by vehicle\CF\75CF\Engine system\UPEC	√	√	√	√		√	
DAF\Divided by vehicle\CF\75CF\Brake system\ABSC		√	√	√		√	
DAF\Divided by vehicle\CF\75CF\Brake system\ABSD		√	√	√		√	
DAF\Divided by vehicle\CF\75CF\Retarder system\EST32	√	√	√	√		√	
DAF\Divided by vehicle\CF\75CF\Suspension system\ECAS	√	√	√	√		√	
DAF\Divided by vehicle\CF\75CF\Suspension system\ECAS3	√	√	√	√		√	
DAF\Divided by vehicle\CF\75CF\Suspension system\ECAS4\ECAS4	√	√	√	√	√	√	0005, 0006, 0007, 0012, 0013, 0020
DAF\Divided by vehicle\CF\75CF\Suspension system\ECAS4\ECAS4-1 rear level sensor	√	√	√	√		√	
DAF\Divided by vehicle\CF\75CF\Suspension system\ECAS4\ECAS4-2 rear level sensor	√	√	√	√		√	
DAF\Divided by vehicle\CF\75CF\Suspension system\ECAS4\ECAS4-Full air	√	√	√	√		√	
DAF\Divided by vehicle\CF\75CF\Suspension system\ECAS2 6x2	√	√	√	√		√	0017, 0018
DAF\Divided by vehicle\CF\75CF\Suspension system\ECAS2 Xx2	√	√	√	√			
DAF\Divided by vehicle\CF\75CF\CAB climate system\ACHEA	√	√	√	√		√	
DAF\Divided by vehicle\CF\75CF\CAB climate system\ACHEW	√	√	√	√		√	
DAF\Divided by vehicle\CF\85CF\Engine system\UPEC	√	√	√	√		√	
DAF\Divided by vehicle\CF\85CF\Brake system\ABSC		√	√	√		√	
DAF\Divided by vehicle\CF\85CF\Brake system\ABSD		√	√	√		√	
DAF\Divided by vehicle\CF\85CF\Retarder system\EST32	√	√	√	√		√	
DAF\Divided by vehicle\CF\85CF\Suspension system\ECAS	√	√	√	√		√	
DAF\Divided by vehicle\CF\85CF\Suspension system\ECAS3	√	√	√	√		√	
DAF\Divided by vehicle\CF\85CF\Suspension system\ECAS4\ECAS4	√	√	√	√	√	√	0005, 0006, 0007, 0012, 0013, 0020
DAF\Divided by vehicle\CF\85CF\Suspension system\ECAS4\ECAS4-1 rear level sensor	√	√	√	√		√	
DAF\Divided by vehicle\CF\85CF\Suspension system\ECAS4\ECAS4-2 rear level sensor	√	√	√	√		√	
DAF\Divided by vehicle\CF\85CF\Suspension system\ECAS4\ECAS4-Full air	√	√	√	√		√	
DAF\Divided by vehicle\CF\85CF\Suspension system\ECAS2 6x2	√	√	√	√		√	0017, 0018
DAF\Divided by vehicle\CF\85CF\Suspension system\ECAS2 Xx2	√	√	√	√			
DAF\Divided by vehicle\CF\85CF\CAB climate system\ACHEA	√	√	√	√		√	
DAF\Divided by vehicle\CF\85CF\CAB climate system\ACHEW	√	√	√	√		√	
DAF\Divided by vehicle\CF\85CF\Vehicle control system\VIC - Lighting	√	√	√	√		√	0024
DAF\Divided by vehicle\CF\85CF\Vehicle control system\VIC - Speed signal	√	√	√	√		√	0024
DAF\Divided by vehicle\CF\85CF\Vehicle control system\VIC - Status signal	√	√	√	√		√	0024
DAF\Divided by vehicle\CF\85CF\Vehicle control system\VIC - Turn signal	√	√	√	√		√	0024
DAF\Divided by vehicle\CF\85CF\Vehicle control system\VIC - Warning signal	√	√	√	√		√	0024
DAF\Divided by vehicle\CF\85CF\Vehicle control system\VIC - Wiper	√	√	√	√		√	0024
DAF\Divided by vehicle\CF\CF65\Engine system\ECSDC3		√	√	√			
DAF\Divided by vehicle\CF\CF65\Brake system\ABSD		√	√	√		√	
DAF\Divided by vehicle\CF\CF65\Suspension system\ECAS3	√	√	√	√		√	
DAF\Divided by vehicle\CF\CF65\Auxiliary system\CDM	√	√	√	√			

DAF\Divided by vehicle\CF\CF65\CAB climate system\ACHEA	√	√	√	√		√	
DAF\Divided by vehicle\CF\CF65\Door control system\CDS3	√	√	√	√			
DAF\Divided by vehicle\CF\CF65\Instrumentation system\DIP4	√					√	
DAF\Divided by vehicle\CF\CF65\Security system\IMMO	√	√	√				
DAF\Divided by vehicle\CF\CF65\Security system\ALSS	√	√	√	√			
DAF\Divided by vehicle\CF\CF65\Tachograph\MTCO	√	√	√	√			
DAF\Divided by vehicle\CF\CF65\Tachograph\DTCO	√	√	√	√			
DAF\Divided by vehicle\CF\CF65\Vehicle control system\VIC - Lighting	√	√	√	√		√	0024
DAF\Divided by vehicle\CF\CF65\Vehicle control system\VIC - Speed signal	√	√	√	√		√	0024
DAF\Divided by vehicle\CF\CF65\Vehicle control system\VIC - Status signal	√	√	√	√		√	0024
DAF\Divided by vehicle\CF\CF65\Vehicle control system\VIC - Turn signal	√	√	√	√		√	0024
DAF\Divided by vehicle\CF\CF65\Vehicle control system\VIC - Warning signal	√	√	√	√		√	0024
DAF\Divided by vehicle\CF\CF65\Vehicle control system\VIC - Wiper	√	√	√	√		√	0024
DAF\Divided by vehicle\CF\CF65II\Engine system\ECSDC3		√	√	√			
DAF\Divided by vehicle\CF\CF65II\Brake system\ABSD		√	√	√		√	
DAF\Divided by vehicle\CF\CF65II\Suspension system\ECAS3	√	√	√	√		√	
DAF\Divided by vehicle\CF\CF65II\Auxiliary system\CDM	√	√	√	√			
DAF\Divided by vehicle\CF\CF65II\CAB climate system\ACHEA	√	√	√	√		√	
DAF\Divided by vehicle\CF\CF65II\Door control system\CDS3	√	√	√	√			
DAF\Divided by vehicle\CF\CF65II\Instrumentation system\DIP4	√					√	
DAF\Divided by vehicle\CF\CF65II\Security system\IMMO	√	√	√				
DAF\Divided by vehicle\CF\CF65II\Security system\ALSS	√	√	√	√			
DAF\Divided by vehicle\CF\CF65II\Tachograph\MTCO	√	√	√	√			
DAF\Divided by vehicle\CF\CF65II\Tachograph\DTCO	√	√	√	√			
DAF\Divided by vehicle\CF\CF65II\Vehicle control system\VIC - Lighting	√	√	√	√		√	0024
DAF\Divided by vehicle\CF\CF65II\Vehicle control system\VIC - Speed signal	√	√	√	√		√	0024
DAF\Divided by vehicle\CF\CF65II\Vehicle control system\VIC - Status signal	√	√	√	√		√	0024
DAF\Divided by vehicle\CF\CF65II\Vehicle control system\VIC - Turn signal	√	√	√	√		√	0024
DAF\Divided by vehicle\CF\CF65II\Vehicle control system\VIC - Warning signal	√	√	√	√		√	0024
DAF\Divided by vehicle\CF\CF65II\Vehicle control system\VIC - Wiper	√	√	√	√		√	0024
DAF\Divided by vehicle\CF\CF75\Engine system\UPEC	√	√	√	√		√	
DAF\Divided by vehicle\CF\CF75\Brake system\ABSD		√	√	√		√	
DAF\Divided by vehicle\CF\CF75\Brake system\ABS WABCO D-E		√	√	√		√	
DAF\Divided by vehicle\CF\CF75\Brake system\EBS	√	√	√	√		√	
DAF\Divided by vehicle\CF\CF75\Brake system\EBS2	√	√	√	√			
DAF\Divided by vehicle\CF\CF75\Transmission system\ASTRONIC	√	√	√	√		√	0008, 0014, 0016, 0019, 0022, 0027, 0028
DAF\Divided by vehicle\CF\CF75\Steering control system\EMAS	√			√		√	
DAF\Divided by vehicle\CF\CF75\Suspension system\ECAS	√	√	√	√		√	
DAF\Divided by vehicle\CF\CF75\Suspension system\ECAS2 6x2	√	√	√	√		√	0017, 0018
DAF\Divided by vehicle\CF\CF75\Suspension system\ECAS3	√	√	√	√		√	
DAF\Divided by vehicle\CF\CF75\Auxiliary system\CDM	√	√	√	√			
DAF\Divided by vehicle\CF\CF75\CAB climate system\ACHEA	√	√	√	√		√	
DAF\Divided by vehicle\CF\CF75\Door control system\CDS3	√	√	√	√			
DAF\Divided by vehicle\CF\CF75\Instrumentation system\DIP4	√					√	
DAF\Divided by vehicle\CF\CF75\Security system\IMMO	√	√	√				
DAF\Divided by vehicle\CF\CF75\Security system\ALSS	√	√	√	√			
DAF\Divided by vehicle\CF\CF75\Tachograph\MTCO	√	√	√	√			
DAF\Divided by vehicle\CF\CF75\Tachograph\DTCO	√	√	√	√			

DAF\Divided by vehicle\CF\CF75\Vehicle control system\VIC - Lighting	√	√	√	√		√	0024
DAF\Divided by vehicle\CF\CF75\Vehicle control system\VIC - Speed signal	√	√	√	√		√	0024
DAF\Divided by vehicle\CF\CF75\Vehicle control system\VIC - Status signal	√	√	√	√		√	0024
DAF\Divided by vehicle\CF\CF75\Vehicle control system\VIC - Turn signal	√	√	√	√		√	0024
DAF\Divided by vehicle\CF\CF75\Vehicle control system\VIC - Warning signal	√	√	√	√		√	0024
DAF\Divided by vehicle\CF\CF75\Vehicle control system\VIC - Wiper	√	√	√	√		√	0024
DAF\Divided by vehicle\CF\CF85\Engine system\UPEC	√	√	√	√		√	
DAF\Divided by vehicle\CF\CF85\Brake system\ABSD		√	√	√		√	
DAF\Divided by vehicle\CF\CF85\Brake system\ABS WABCO D-E		√	√	√		√	
DAF\Divided by vehicle\CF\CF85\Brake system\EBS	√	√	√	√		√	
DAF\Divided by vehicle\CF\CF85\Brake system\EBS2	√	√	√	√			
DAF\Divided by vehicle\CF\CF85\Transmission system\ASTRONIC	√	√	√	√		√	0008, 0014, 0016, 0019, 0022, 0027, 0028
DAF\Divided by vehicle\CF\CF85\Steering control system\EMAS	√			√		√	
DAF\Divided by vehicle\CF\CF85\Suspension system\ECAS	√	√	√	√		√	
DAF\Divided by vehicle\CF\CF85\Suspension system\ECAS2 6x2	√	√	√	√		√	0017, 0018
DAF\Divided by vehicle\CF\CF85\Suspension system\ECAS3	√	√	√	√		√	
DAF\Divided by vehicle\CF\CF85\Auxiliary system\CDM	√	√	√	√			
DAF\Divided by vehicle\CF\CF85\CAB climate system\ACHEA	√	√	√	√		√	
DAF\Divided by vehicle\CF\CF85\Door control system\CDS3	√	√	√	√			
DAF\Divided by vehicle\CF\CF85\Instrumentation system\DIP4	√					√	
DAF\Divided by vehicle\CF\CF85\Security system\IMMO	√	√	√				
DAF\Divided by vehicle\CF\CF85\Security system\ALSS	√	√	√	√			
DAF\Divided by vehicle\CF\CF85\Tachograph\MTCO	√	√	√	√			
DAF\Divided by vehicle\CF\CF85\Tachograph\DTCO	√	√	√	√			
DAF\Divided by vehicle\CF\CF85\Vehicle control system\VIC - Lighting	√	√	√	√		√	0024
DAF\Divided by vehicle\CF\CF85\Vehicle control system\VIC - Speed signal	√	√	√	√		√	0024
DAF\Divided by vehicle\CF\CF85\Vehicle control system\VIC - Status signal	√	√	√	√		√	0024
DAF\Divided by vehicle\CF\CF85\Vehicle control system\VIC - Turn signal	√	√	√	√		√	0024
DAF\Divided by vehicle\CF\CF85\Vehicle control system\VIC - Warning signal	√	√	√	√		√	0024
DAF\Divided by vehicle\CF\CF85\Vehicle control system\VIC - Wiper	√	√	√	√		√	0024
DAF\Divided by vehicle\F\F1700\Suspension system\ECAS	√	√	√	√		√	
DAF\Divided by vehicle\F\F45\Brake system\ABSC		√	√	√		√	
DAF\Divided by vehicle\F\F45\Suspension system\ECAS	√	√	√	√		√	
DAF\Divided by vehicle\F\F45\Suspension system\ECAS2 Xx2	√	√	√	√			
DAF\Divided by vehicle\F\F55\Brake system\ABSC		√	√	√		√	
DAF\Divided by vehicle\F\F55\Suspension system\ECAS	√	√	√	√		√	
DAF\Divided by vehicle\F\F55\Suspension system\ECAS2 Xx2	√	√	√	√			
DAF\Divided by vehicle\F\F65\Brake system\ABSC		√	√	√		√	
DAF\Divided by vehicle\F\F65\Brake system\ABSD		√	√	√		√	
DAF\Divided by vehicle\F\F65\Brake system\ABS WABCO D-E		√	√	√		√	
DAF\Divided by vehicle\F\F65\Suspension system\ECAS	√	√	√	√		√	
DAF\Divided by vehicle\F\F65\Suspension system\ECAS2 Xx2	√	√	√	√			
DAF\Divided by vehicle\F\F65\CAB climate system\ACHEA	√	√	√	√		√	
DAF\Divided by vehicle\F\F75\Brake system\ABSC		√	√	√		√	
DAF\Divided by vehicle\F\F75\Brake system\ABSD		√	√	√		√	
DAF\Divided by vehicle\F\F75\Brake system\ABS WABCO D-E		√	√	√		√	
DAF\Divided by vehicle\F\F75\Retarder system\EST15	√	√	√	√		√	
DAF\Divided by vehicle\F\F75\Retarder system\EST32	√	√	√	√		√	

DAF\Divided by vehicle\F\F75\Suspension system\ECAS	√	√	√	√		√	
DAF\Divided by vehicle\F\F75\Suspension system\ECAS3	√	√	√	√		√	
DAF\Divided by vehicle\F\F75\Suspension system\ECAS4\ECAS4	√	√	√	√	√	√	0005, 0006, 0007, 0012, 0013, 0020
DAF\Divided by vehicle\F\F75\Suspension system\ECAS4\ECAS4-1 rear level sensor	√	√	√	√		√	
DAF\Divided by vehicle\F\F75\Suspension system\ECAS4\ECAS4-2 rear level sensor	√	√	√	√		√	
DAF\Divided by vehicle\F\F75\Suspension system\ECAS4\ECAS4-Full air	√	√	√	√		√	
DAF\Divided by vehicle\F\F75\Suspension system\ECAS2 6x2	√	√	√	√		√	0017, 0018
DAF\Divided by vehicle\F\F75\Suspension system\ECAS2 Xx2	√	√	√	√			
DAF\Divided by vehicle\F\F75\CAB climate system\ACHEA	√	√	√	√		√	
DAF\Divided by vehicle\F\F75\CAB climate system\ACHEW	√	√	√	√		√	
DAF\Divided by vehicle\F\F85\Brake system\ABSC		√	√	√		√	
DAF\Divided by vehicle\F\F85\Brake system\ABSD		√	√	√		√	
DAF\Divided by vehicle\F\F85\Brake system\ABS WABCO D-E		√	√	√		√	
DAF\Divided by vehicle\F\F85\Retarder system\EST15	√	√	√	√		√	
DAF\Divided by vehicle\F\F85\Retarder system\EST32	√	√	√	√		√	
DAF\Divided by vehicle\F\F85\Suspension system\ECAS	√	√	√	√		√	
DAF\Divided by vehicle\F\F85\Suspension system\ECAS3	√	√	√	√		√	
DAF\Divided by vehicle\F\F85\Suspension system\ECAS4\ECAS4	√	√	√	√	√	√	0005, 0006, 0007, 0012, 0013, 0020
DAF\Divided by vehicle\F\F85\Suspension system\ECAS4\ECAS4-1 rear level sensor	√	√	√	√		√	
DAF\Divided by vehicle\F\F85\Suspension system\ECAS4\ECAS4-2 rear level sensor	√	√	√	√		√	
DAF\Divided by vehicle\F\F85\Suspension system\ECAS4\ECAS4-Full air	√	√	√	√		√	
DAF\Divided by vehicle\F\F85\Suspension system\ECAS2 6x2	√	√	√	√		√	0017, 0018
DAF\Divided by vehicle\F\F85\Suspension system\ECAS2 Xx2	√	√	√	√			
DAF\Divided by vehicle\F\F85\CAB climate system\ACHEA	√	√	√	√		√	
DAF\Divided by vehicle\F\F85\CAB climate system\ACHEW	√	√	√	√		√	
DAF\Divided by vehicle\F\F95\Brake system\ABSC		√	√	√		√	
DAF\Divided by vehicle\F\F95\Retarder system\EST32	√	√	√	√		√	
DAF\Divided by vehicle\F\F95\Suspension system\ECAS	√	√	√	√		√	
DAF\Divided by vehicle\F\F95\Suspension system\ECAS2 6x2	√	√	√	√		√	0017, 0018
DAF\Divided by vehicle\F\F95\Suspension system\ECAS2 Xx2	√	√	√	√			
DAF\Divided by vehicle\F\F95\CAB climate system\ACHEA	√	√	√	√		√	
DAF\Divided by vehicle\F\F95\CAB climate system\ACHEW	√	√	√	√		√	
DAF\Divided by vehicle\LF\FA LF45\Instrumentation system\DIP4	√					√	
DAF\Divided by vehicle\LF\FA LF45\Security system\IMMO	√	√	√				
DAF\Divided by vehicle\LF\FA LF45\Tachograph\MTCO	√	√	√	√			
DAF\Divided by vehicle\LF\LF45\Engine system\ECSDC3		√	√	√			
DAF\Divided by vehicle\LF\LF45\Brake system\ABSD		√	√	√		√	
DAF\Divided by vehicle\LF\LF45\Brake system\ABS WABCO D-E		√	√	√		√	
DAF\Divided by vehicle\LF\LF45\Suspension system\ECAS3	√	√	√	√		√	
DAF\Divided by vehicle\LF\LF45\Door control system\CDS3	√	√	√	√			
DAF\Divided by vehicle\LF\LF45\Instrumentation system\DIP4	√					√	
DAF\Divided by vehicle\LF\LF45\Safety system\AIRBAG	√	√	√	√		√	
DAF\Divided by vehicle\LF\LF45\Security system\IMMO	√	√	√				
DAF\Divided by vehicle\LF\LF45\Security system\ALSS	√	√	√	√			
DAF\Divided by vehicle\LF\LF45\Tachograph\MTCO	√	√	√	√			
DAF\Divided by vehicle\LF\LF45\Tachograph\DTCO	√	√	√	√			
DAF\Divided by vehicle\LF\LF45\Vehicle control system\BBM - Configuration 1	√	√	√				
DAF\Divided by vehicle\LF\LF45\Vehicle control system\BBM - Configuration 2	√	√	√				

DAF\Divided by vehicle\LF\LF45\Vehicle control system\VIC - Lighting	√	√	√	√		√	0024
DAF\Divided by vehicle\LF\LF45\Vehicle control system\VIC - Speed signal	√	√	√	√		√	0024
DAF\Divided by vehicle\LF\LF45\Vehicle control system\VIC - Status signal	√	√	√	√		√	0024
DAF\Divided by vehicle\LF\LF45\Vehicle control system\VIC - Turn signal	√	√	√	√		√	0024
DAF\Divided by vehicle\LF\LF45\Vehicle control system\VIC - Warning signal	√	√	√	√		√	0024
DAF\Divided by vehicle\LF\LF45\Vehicle control system\VIC - Wiper	√	√	√	√		√	0024
DAF\Divided by vehicle\LF\LF55\Engine system\ECSDC3		√	√	√			
DAF\Divided by vehicle\LF\LF55\Brake system\ABSD		√	√	√		√	
DAF\Divided by vehicle\LF\LF55\Brake system\ABSE2	√	√	√	√		√	
DAF\Divided by vehicle\LF\LF55\Brake system\ABS WABCO D-E		√	√	√		√	
DAF\Divided by vehicle\LF\LF55\Steering control system\RASEC	√	√	√	√			
DAF\Divided by vehicle\LF\LF55\Suspension system\ECAS2 6x2	√	√	√	√		√	0017, 0018
DAF\Divided by vehicle\LF\LF55\Suspension system\ECAS3	√	√	√	√		√	
DAF\Divided by vehicle\LF\LF55\Door control system\CDS3	√	√	√	√			
DAF\Divided by vehicle\LF\LF55\Instrumentation system\DIP4	√					√	
DAF\Divided by vehicle\LF\LF55\Safety system\AIRBAG	√	√	√	√		√	
DAF\Divided by vehicle\LF\LF55\Security system\IMMO	√	√	√				
DAF\Divided by vehicle\LF\LF55\Security system\ALSS	√	√	√	√			
DAF\Divided by vehicle\LF\LF55\Tachograph\MTCO	√	√	√	√			
DAF\Divided by vehicle\LF\LF55\Tachograph\DTCO	√	√	√	√			
DAF\Divided by vehicle\LF\LF55\Vehicle control system\VIC - Lighting	√	√	√	√		√	0024
DAF\Divided by vehicle\LF\LF55\Vehicle control system\VIC - Speed signal	√	√	√	√		√	0024
DAF\Divided by vehicle\LF\LF55\Vehicle control system\VIC - Status signal	√	√	√	√		√	0024
DAF\Divided by vehicle\LF\LF55\Vehicle control system\VIC - Turn signal	√	√	√	√		√	0024
DAF\Divided by vehicle\LF\LF55\Vehicle control system\VIC - Warning signal	√	√	√	√		√	0024
DAF\Divided by vehicle\LF\LF55\Vehicle control system\VIC - Wiper	√	√	√	√		√	0024
DAF\Divided by vehicle\LF\LF55IV MEX\Instrumentation system\DIP4	√					√	
DAF\Divided by vehicle\LF\LF55IV MEX\Security system\IMMO	√	√	√				
DAF\Divided by vehicle\LF\LF55IV MEX\Tachograph\MTCO	√	√	√	√			
DAF\Divided by vehicle\XF\95XF\Engine system\UPEC	√	√	√	√		√	
DAF\Divided by vehicle\XF\95XF\Brake system\ABSC		√	√	√		√	
DAF\Divided by vehicle\XF\95XF\Brake system\ABSD		√	√	√		√	
DAF\Divided by vehicle\XF\95XF\Brake system\ABS WABCO D-E		√	√	√		√	
DAF\Divided by vehicle\XF\95XF\Retarder system\EST32	√	√	√	√		√	
DAF\Divided by vehicle\XF\95XF\Suspension system\ECAS	√	√	√	√		√	
DAF\Divided by vehicle\XF\95XF\Suspension system\ECAS3	√	√	√	√		√	
DAF\Divided by vehicle\XF\95XF\Suspension system\ECAS4\ECAS4	√	√	√	√	√	√	0005, 0006, 0007, 0012, 0013, 0020
DAF\Divided by vehicle\XF\95XF\Suspension system\ECAS4\ECAS4-1 rear level sensor	√	√	√	√		√	
DAF\Divided by vehicle\XF\95XF\Suspension system\ECAS4\ECAS4-2 rear level sensor	√	√	√	√		√	
DAF\Divided by vehicle\XF\95XF\Suspension system\ECAS4\ECAS4-Full air	√	√	√	√		√	
DAF\Divided by vehicle\XF\95XF\Suspension system\ECAS2 6x2	√	√	√	√		√	0017, 0018
DAF\Divided by vehicle\XF\95XF\Suspension system\ECAS2 Xx2	√	√	√	√			
DAF\Divided by vehicle\XF\95XF\CAB climate system\ACHEA	√	√	√	√		√	
DAF\Divided by vehicle\XF\95XF\CAB climate system\ACHEW	√	√	√	√		√	
DAF\Divided by vehicle\XF\95XF 530\Engine system\UPEC	√	√	√	√		√	
DAF\Divided by vehicle\XF\95XF 530\Brake system\ABSD		√	√	√		√	
DAF\Divided by vehicle\XF\95XF 530\Brake system\ABS WABCO D-E		√	√	√		√	
DAF\Divided by vehicle\XF\95XF 530\Brake system\EBS	√	√	√	√		√	

DAF\Divided by vehicle\XF\95XF 530\Suspension system\ECAS	√	√	√	√		√	
DAF\Divided by vehicle\XF\95XF 530\Suspension system\ECAS3	√	√	√	√		√	
DAF\Divided by vehicle\XF\95XF 530\Suspension system\ECAS2 Xx2	√	√	√	√			
DAF\Divided by vehicle\XF\95XF 530\CAB climate system\ACHEA	√	√	√	√		√	
DAF\Divided by vehicle\XF\95XF 530\CAB climate system\ACHEW	√	√	√	√		√	
DAF\Divided by vehicle\XF\95XF 530\Instrumentation system\DIP4	√					√	
DAF\Divided by vehicle\XF\95XF 530\Security system\IMMO	√	√	√				
DAF\Divided by vehicle\XF\95XF 530\Tachograph\MTCO	√	√	√	√			
DAF\Divided by vehicle\XF\95XF 530\Vehicle control system\VIC - Lighting	√	√	√	√		√	0024
DAF\Divided by vehicle\XF\95XF 530\Vehicle control system\VIC - Speed signal	√	√	√	√		√	0024
DAF\Divided by vehicle\XF\95XF 530\Vehicle control system\VIC - Status signal	√	√	√	√		√	0024
DAF\Divided by vehicle\XF\95XF 530\Vehicle control system\VIC - Turn signal	√	√	√	√		√	0024
DAF\Divided by vehicle\XF\95XF 530\Vehicle control system\VIC - Warning signal	√	√	√	√		√	0024
DAF\Divided by vehicle\XF\95XF 530\Vehicle control system\VIC - Wiper	√	√	√	√		√	0024
DAF\Divided by vehicle\XF\XF105 BRA\Transmission system\ASTRONIC	√	√	√	√		√	0008, 0014, 0016, 0019, 0022, 0027, 0028
DAF\Divided by vehicle\XF\XF105 BRA\Door control system\CDS3	√	√	√	√			
DAF\Divided by vehicle\XF\XF105 BRA\Instrumentation system\DIP4	√					√	
DAF\Divided by vehicle\XF\XF105 BRA\Security system\IMMO	√	√	√				
DAF\Divided by vehicle\XF\XF105 BRA\Tachograph\MTCO	√	√	√	√			
DAF\Divided by vehicle\XF\XF105 BRA\Vehicle control system\BBM - Configuration 1	√	√	√				
DAF\Divided by vehicle\XF\XF105 BRA\Vehicle control system\BBM - Configuration 2	√	√	√				
DAF\Divided by vehicle\XF\XF 95\Engine system\UPEC	√	√	√	√		√	
DAF\Divided by vehicle\XF\XF 95\Brake system\ABSD		√	√	√		√	
DAF\Divided by vehicle\XF\XF 95\Brake system\ABS WABCO D-E		√	√	√		√	
DAF\Divided by vehicle\XF\XF 95\Brake system\EBS	√	√	√	√		√	
DAF\Divided by vehicle\XF\XF 95\Brake system\EBS2	√	√	√	√			
DAF\Divided by vehicle\XF\XF 95\Brake system\EBS2-Options	√	√	√	√			
DAF\Divided by vehicle\XF\XF 95\Brake system\EBS2 CAN	√	√	√	√			
DAF\Divided by vehicle\XF\XF 95\Transmission system\ASTRONIC	√	√	√	√		√	0008, 0014, 0016, 0019, 0022, 0027, 0028
DAF\Divided by vehicle\XF\XF 95\Steering control system\EMAS	√			√		√	
DAF\Divided by vehicle\XF\XF 95\Suspension system\ECAS3	√	√	√	√		√	
DAF\Divided by vehicle\XF\XF 95\Suspension system\ECAS2 6x2	√	√	√	√		√	0017, 0018
DAF\Divided by vehicle\XF\XF 95\Auxiliary system\CDM	√	√	√	√			
DAF\Divided by vehicle\XF\XF 95\CAB climate system\ACHEA	√	√	√	√		√	
DAF\Divided by vehicle\XF\XF 95\CAB climate system\ACHEW	√	√	√	√		√	
DAF\Divided by vehicle\XF\XF 95\Door control system\CDS3	√	√	√	√			
DAF\Divided by vehicle\XF\XF 95\Instrumentation system\DIP4	√					√	
DAF\Divided by vehicle\XF\XF 95\Safety system\AIRBAG2	√	√	√				
DAF\Divided by vehicle\XF\XF 95\Security system\IMMO	√	√	√				
DAF\Divided by vehicle\XF\XF 95\Security system\ALSS	√	√	√	√			
DAF\Divided by vehicle\XF\XF 95\Tachograph\MTCO	√	√	√	√			
DAF\Divided by vehicle\XF\XF 95\Tachograph\DTCO	√	√	√	√			
DAF\Divided by vehicle\XF\XF 95\Vehicle control system\VIC - Lighting	√	√	√	√		√	0024
DAF\Divided by vehicle\XF\XF 95\Vehicle control system\VIC - Speed signal	√	√	√	√		√	0024
DAF\Divided by vehicle\XF\XF 95\Vehicle control system\VIC - Status signal	√	√	√	√		√	0024
DAF\Divided by vehicle\XF\XF 95\Vehicle control system\VIC - Turn signal	√	√	√	√		√	0024
DAF\Divided by vehicle\XF\XF 95\Vehicle control system\VIC - Warning signal	√	√	√	√		√	0024

DAF\Divided by vehicle\XF\XF 95\Vehicle control system\VIC - Wiper	√	√	√	√		√	0024
DAF\Divided by vehicle\XF\XF 95\Vehicle control system\BBM - Configuration 1	√	√	√				
DAF\Divided by vehicle\XF\XF 95\Vehicle control system\BBM - Configuration 2	√	√	√				
DAF\Divided by vehicle\XF\XF95I\Brake system\ABSD		√	√	√		√	
DAF\Divided by vehicle\XF\XF95I\Brake system\ABS WABCO D-E		√	√	√		√	
DAF\Divided by vehicle\XF\XF95I\Auxiliary system\CDM	√	√	√	√			
DAF\Divided by vehicle\XF\XF95I\Instrumentation system\DIP4	√					√	
DAF\Divided by vehicle\XF\XF95I\Security system\IMMO	√	√	√				
DAF\Divided by vehicle\XF\XF95I\Tachograph\MTCO	√	√	√	√			
DAF\Divided by vehicle\XF\XF95I\Vehicle control system\VIC - Lighting	√	√	√	√		√	0024
DAF\Divided by vehicle\XF\XF95I\Vehicle control system\VIC - Speed signal	√	√	√	√		√	0024
DAF\Divided by vehicle\XF\XF95I\Vehicle control system\VIC - Status signal	√	√	√	√		√	0024
DAF\Divided by vehicle\XF\XF95I\Vehicle control system\VIC - Turn signal	√	√	√	√		√	0024
DAF\Divided by vehicle\XF\XF95I\Vehicle control system\VIC - Warning signal	√	√	√	√		√	0024
DAF\Divided by vehicle\XF\XF95I\Vehicle control system\VIC - Wiper	√	√	√	√		√	0024

Special Function Table

0001	AdBlue filter leakage test
0002	Adblue circuit test with injection of AdBlue
0003	Air circuit test/Dosing module test
0004	Automatic system check test
0005	Calibrate height sensor
0006	Calibration height sensor (including characteristic curve)
0007	Calibration pressure sensor
0008	Clutch check
0009	Customer parameters Engine Speed Control Cab
0010	Customer parameters Engine Speed Control condition cab
0011	Customer parameters Limiters
0012	Display height sensor characteristic curve
0013	Distance sensor calibration data
0014	Empty the accumulator
0015	Engine Protection Data
0016	Filling the accumulator
0017	Level calibration
0018	Level sensor calibrat.
0019	Maintenance information
0020	Pressure sensor calibration data flow
0021	Programming
0022	Recalculate the rdyn factor
0023	Repair & Maintenance
0024	Reset ECU
0025	Retset ECU
0026	Service/engineering information
0027	To parameterize
0028	Transmission system check