

IVECO V13.35 Function list

Note:

√ Functions marked with √ is fully supported and already existed in former software version.

Number Index number of the special function , you can find the name from the special function table.

System	ECU Info.	Read Fault Code	Clear Fault Code	Live Data	Active Test	Special Func
IVECO\China Area\Iveco by model\Daily\Euro 2-3\City Camion M.Y.2000\Engine System\EDC 16 BOSCH\EDC 16 BOSCH						
IVECO\China Area\Iveco by model\Daily\Euro 2-3\City Camion M.Y.2000\Engine System\EDC 16 BOSCH\EDC16C39.5	√	√	√	√	√	0007
IVECO\China Area\Iveco by model\Daily\Euro 2-3\City Camion M.Y.2000\Engine System\EDC MS6.3 BOSCH	√	√	√	√	√	
IVECO\China Area\Iveco by model\Daily\Euro 2-3\City Camion M.Y.2000\Braking system\ABS8-ASR8-ESP8 BOSCH	√	√	√	√		
IVECO\China Area\Iveco by model\Daily\Euro 2-3\City Camion HPI-HPT\Engine System\EDC 16 BOSCH\EDC 16 BOSCH						
IVECO\China Area\Iveco by model\Daily\Euro 2-3\City Camion HPI-HPT\Engine System\EDC 16 BOSCH\EDC16C39.5	√	√	√	√	√	0007
IVECO\China Area\Iveco by model\Daily\Euro 2-3\City Camion HPI-HPT\Engine System\EDC MS6.3 BOSCH	√	√	√	√	√	
IVECO\China Area\Iveco by model\Daily\Euro 2-3\City Camion HPI-HPT\Braking system\ABS8-ASR8-ESP8 BOSCH	√	√	√	√		
IVECO\China Area\Iveco by model\Eurocargo\Euro 2-3\ML Tector M.Y.2002\Engine System\EDC 7 BOSCH		√	√	√		
IVECO\China Area\Iveco by model\Eurocargo\Euro 2-3\ML Tector M.Y.2002\Braking system\ABS 2X Knorr-BOSCH	√	√	√	√	√	
IVECO\China Area\Iveco by model\Eurocargo\Euro 2-3\Other engines of ML\Braking system\ABS 2X Knorr-BOSCH	√	√	√	√	√	
IVECO\China Area\Iveco by model\Eurocargo\Euro 2-3\ML Tector M.Y.2003\Engine System\EDC 7 BOSCH		√	√	√		
IVECO\China Area\Iveco by model\Eurocargo\Euro 2-3\ML Tector M.Y.2003\Braking system\ABS 2X Knorr-BOSCH	√	√	√	√	√	
IVECO\China Area\Iveco by model\Eurocargo\Euro 2-3\ML Tector M.Y.2003\Suspension system\ECAS EUROCARGO RESTYLING	√	√	√	√	√	
IVECO\China Area\Iveco by model\Eurocargo\Euro 2-3\ML Tector M.Y.2003\Multiplexer\IBC EUROCARGO NEW	√	√	√	√	√	
IVECO\China Area\Iveco by model\Eurocargo\Euro 2-3\ML Tector M.Y.2003\Instrument\IC EUROCARGO NEW	√	√	√	√	√	
IVECO\China Area\Iveco by model\Eurocargo\Euro 2-3\Cavallino\Engine System\EDC MS6.2 BOSCH VERSION 1						
IVECO\China Area\Iveco by model\Eurocargo\Euro 2-3\Cavallino\Engine System\EDC MS6.2 BOSCH VERSION 2	√	√	√	√	√	
IVECO\China Area\Iveco by model\Eurocargo\Euro 4-5-EEV\ML Tector M.Y.2006\Engine System\DeNoxtronic 2	√	√	√	√	√	
IVECO\China Area\Iveco by model\Eurocargo\Euro 4-5-EEV\ML Tector M.Y.2006\Engine System\VCM-anti-theft system	√	√	√	√	√	
IVECO\China Area\Iveco by model\Eurocargo\Euro 4-5-EEV\ML Tector M.Y.2006\Suspension system\ECAS EUROCARGO RESTYLING	√	√	√	√	√	
IVECO\China Area\Iveco by model\Eurocargo\Euro 4-5-EEV\ML Tector M.Y.2006\Multiplexer\Extension module	√	√	√	√		
IVECO\China Area\Iveco by model\Eurocargo\Euro 4-5-EEV\ML Tector M.Y.2006\Multiplexer\IVECO body controller	√	√	√	√	√	
IVECO\China Area\Iveco by model\Eurocargo\Euro 4-5-EEV\ML Tector M.Y.2006\Instrument\Instrument cluster	√	√	√	√	√	
IVECO\China Area\Iveco by model\Eurocargo\Euro 4-5-EEV\ML Tector M.Y.2006\Power train\allison can gen 4	√			√		
IVECO\China Area\Iveco by model\Eurocargo\Euro 4-5-EEV\EUROCARGO M.Y.2008\Engine System\DeNoxtronic 2	√	√	√	√	√	
IVECO\China Area\Iveco by model\Eurocargo\Euro 4-5-EEV\EUROCARGO M.Y.2008\Engine System\VCM-anti-theft system	√	√	√	√	√	
IVECO\China Area\Iveco by model\Eurocargo\Euro 4-5-EEV\EUROCARGO M.Y.2008\Suspension system\ECAS EUROCARGO RESTYLING	√	√	√	√	√	
IVECO\China Area\Iveco by model\Eurocargo\Euro 4-5-EEV\EUROCARGO M.Y.2008\Multiplexer\Driver door module	√	√	√	√	√	
IVECO\China Area\Iveco by model\Eurocargo\Euro 4-5-EEV\EUROCARGO M.Y.2008\Multiplexer\Extension module	√	√	√	√		
IVECO\China Area\Iveco by model\Eurocargo\Euro 4-5-EEV\EUROCARGO M.Y.2008\Multiplexer\Passenger door module	√	√	√	√	√	
IVECO\China Area\Iveco by model\Eurocargo\Euro 4-5-EEV\EUROCARGO M.Y.2008\Multiplexer\IVECO body controller	√	√	√	√	√	
IVECO\China Area\Iveco by model\Eurocargo\Euro 4-5-EEV\EUROCARGO M.Y.2008\Instrument\Instrument cluster	√	√	√	√	√	

IVECO\China Area\Iveco by model\Eurocargo\Euro 4-5-EEV\EUROCARGO CNG M.Y.2008\Extension module	√	√	√	√		
IVECO\China Area\Iveco by model\Eurocargo\Euro 4-5-EEV\EUROCARGO CNG M.Y.2008\IVECO body controller	√	√	√	√	√	
IVECO\China Area\Iveco by model\Stralis\Euro 2-3\AS\Engine System\EDC MS6.2 BOSCH VERSION 1						
IVECO\China Area\Iveco by model\Stralis\Euro 2-3\AS\Engine System\EDC MS6.2 BOSCH VERSION 2	√	√	√	√	√	
IVECO\China Area\Iveco by model\Stralis\Euro 2-3\AS\Braking system\EBS WABCO	√	√	√	√	√	
IVECO\China Area\Iveco by model\Stralis\Euro 2-3\AS\Braking system\ABS D-E-E2	√	√	√	√		
IVECO\China Area\Iveco by model\Stralis\Euro 2-3\AS\Transmission system\EUROTTRONIC 2	√	√	√	√	√	
IVECO\China Area\Iveco by model\Stralis\Euro 2-3\AS\Suspension system\ECAS WABCO CAN	√	√	√	√	√	
IVECO\China Area\Iveco by model\Stralis\Euro 2-3\AS\Multiplexer\Body computer	√	√	√	√	√	
IVECO\China Area\Iveco by model\Stralis\Euro 2-3\AS\Multiplexer\Driver door module	√	√	√	√	√	
IVECO\China Area\Iveco by model\Stralis\Euro 2-3\AS\Multiplexer\Front frame computer	√	√	√	√	√	
IVECO\China Area\Iveco by model\Stralis\Euro 2-3\AS\Multiplexer\Passenger door module	√	√	√	√	√	
IVECO\China Area\Iveco by model\Stralis\Euro 2-3\AS\Multiplexer\WABCO-IVTM	√	√	√	√		
IVECO\China Area\Iveco by model\Stralis\Euro 2-3\AS\Instrument\Instrument cluster	√	√	√	√	√	
IVECO\China Area\Iveco by model\Stralis\Euro 2-3\AS\Climate control\Air heater(Stralis)	√	√	√	√		
IVECO\China Area\Iveco by model\Stralis\Euro 2-3\AT-AD\Engine System\EDC MS6.2 BOSCH VERSION 1						
IVECO\China Area\Iveco by model\Stralis\Euro 2-3\AT-AD\Engine System\EDC MS6.2 BOSCH VERSION 2	√	√	√	√	√	
IVECO\China Area\Iveco by model\Stralis\Euro 2-3\AT-AD\Braking system\EBS WABCO	√	√	√	√	√	
IVECO\China Area\Iveco by model\Stralis\Euro 2-3\AT-AD\Braking system\ABS D-E-E2	√	√	√	√		
IVECO\China Area\Iveco by model\Stralis\Euro 2-3\AT-AD\Transmission system\EUROTTRONIC 2	√	√	√	√	√	
IVECO\China Area\Iveco by model\Stralis\Euro 2-3\AT-AD\Suspension system\ECAS WABCO CAN	√	√	√	√	√	
IVECO\China Area\Iveco by model\Stralis\Euro 2-3\AT-AD\Multiplexer\Body computer	√	√	√	√	√	
IVECO\China Area\Iveco by model\Stralis\Euro 2-3\AT-AD\Multiplexer\Driver door module	√	√	√	√	√	
IVECO\China Area\Iveco by model\Stralis\Euro 2-3\AT-AD\Multiplexer\Front frame computer	√	√	√	√	√	
IVECO\China Area\Iveco by model\Stralis\Euro 2-3\AT-AD\Multiplexer\Passenger door module	√	√	√	√	√	
IVECO\China Area\Iveco by model\Stralis\Euro 2-3\AT-AD\Multiplexer\WABCO-IVTM	√	√	√	√		
IVECO\China Area\Iveco by model\Stralis\Euro 2-3\AT-AD\Instrument\Instrument cluster	√	√	√	√	√	
IVECO\China Area\Iveco by model\Stralis\Euro 2-3\AT-AD\Climate control\Air heater(Stralis)	√	√	√	√		
IVECO\China Area\Iveco by model\Stralis\Euro 4-5-EEV\AS\Engine System\DeNoxtronic 2	√	√	√	√	√	
IVECO\China Area\Iveco by model\Stralis\Euro 4-5-EEV\AS\Engine System\VCM-anti-theft system	√	√	√	√	√	
IVECO\China Area\Iveco by model\Stralis\Euro 4-5-EEV\AS\Engine System\EDC 7 UC31	√	√	√	√	√	
IVECO\China Area\Iveco by model\Stralis\Euro 4-5-EEV\AS\Braking system\EBS WABCO	√	√	√	√	√	
IVECO\China Area\Iveco by model\Stralis\Euro 4-5-EEV\AS\Braking system\ABS D-E-E2	√	√	√	√		
IVECO\China Area\Iveco by model\Stralis\Euro 4-5-EEV\AS\Transmission system\EUROTTRONIC 2	√	√	√	√	√	
IVECO\China Area\Iveco by model\Stralis\Euro 4-5-EEV\AS\Suspension system\ECAS WABCO CAN	√	√	√	√	√	
IVECO\China Area\Iveco by model\Stralis\Euro 4-5-EEV\AS\Multiplexer\Body computer	√	√	√	√	√	
IVECO\China Area\Iveco by model\Stralis\Euro 4-5-EEV\AS\Multiplexer\Cab module	√			√	√	
IVECO\China Area\Iveco by model\Stralis\Euro 4-5-EEV\AS\Multiplexer\Driver door module	√	√	√	√	√	
IVECO\China Area\Iveco by model\Stralis\Euro 4-5-EEV\AS\Multiplexer\Front frame computer	√	√	√	√	√	
IVECO\China Area\Iveco by model\Stralis\Euro 4-5-EEV\AS\Multiplexer\Passenger door module	√	√	√	√	√	

IVECO\China Area\Iveco by model\Stralis\Euro 4-5-EEV\AS\Multiplexer\Rear frame computer	√	√	√	√	√	
IVECO\China Area\Iveco by model\Stralis\Euro 4-5-EEV\AS\Instrument\Instrument cluster	√	√	√	√	√	
IVECO\China Area\Iveco by model\Stralis\Euro 4-5-EEV\AS\Climate control\Air heater(Stralis)	√	√	√	√		
IVECO\China Area\Iveco by model\Stralis\Euro 4-5-EEV\AT-AD\Engine System\DeNoxtronic 2	√	√	√	√	√	
IVECO\China Area\Iveco by model\Stralis\Euro 4-5-EEV\AT-AD\Engine System\VCM-anti-theft system	√	√	√	√	√	
IVECO\China Area\Iveco by model\Stralis\Euro 4-5-EEV\AT-AD\Engine System\EDC 7 UC31	√	√	√	√	√	
IVECO\China Area\Iveco by model\Stralis\Euro 4-5-EEV\AT-AD\Braking system\EBS WABCO	√	√	√	√	√	
IVECO\China Area\Iveco by model\Stralis\Euro 4-5-EEV\AT-AD\Braking system\ABS D-E-E2	√	√	√	√		
IVECO\China Area\Iveco by model\Stralis\Euro 4-5-EEV\AT-AD\Transmission system\EUROTRONIC 2	√	√	√	√	√	
IVECO\China Area\Iveco by model\Stralis\Euro 4-5-EEV\AT-AD\Suspension system\ECAS WABCO CAN	√	√	√	√	√	
IVECO\China Area\Iveco by model\Stralis\Euro 4-5-EEV\AT-AD\Multiplexer\Body computer	√	√	√	√	√	
IVECO\China Area\Iveco by model\Stralis\Euro 4-5-EEV\AT-AD\Multiplexer\Cab module	√			√	√	
IVECO\China Area\Iveco by model\Stralis\Euro 4-5-EEV\AT-AD\Multiplexer\Driver door module	√	√	√	√	√	
IVECO\China Area\Iveco by model\Stralis\Euro 4-5-EEV\AT-AD\Multiplexer\Front frame computer	√	√	√	√	√	
IVECO\China Area\Iveco by model\Stralis\Euro 4-5-EEV\AT-AD\Multiplexer\Passenger door module	√	√	√	√	√	
IVECO\China Area\Iveco by model\Stralis\Euro 4-5-EEV\AT-AD\Multiplexer\Rear frame computer	√	√	√	√	√	
IVECO\China Area\Iveco by model\Stralis\Euro 4-5-EEV\AT-AD\Instrument\Instrument cluster	√	√	√	√	√	
IVECO\China Area\Iveco by model\Stralis\Euro 4-5-EEV\AT-AD\Climate control\Air heater(Stralis)	√	√	√	√		
IVECO\China Area\Iveco by model\Stralis\Euro 4-5-EEV\AS-L M.Y.2007\Engine System\DeNoxtronic 2	√	√	√	√	√	
IVECO\China Area\Iveco by model\Stralis\Euro 4-5-EEV\AS-L M.Y.2007\Engine System\VCM-anti-theft system	√	√	√	√	√	
IVECO\China Area\Iveco by model\Stralis\Euro 4-5-EEV\AS-L M.Y.2007\Engine System\EDC 7 UC31	√	√	√	√	√	
IVECO\China Area\Iveco by model\Stralis\Euro 4-5-EEV\AS-L M.Y.2007\Transmission system\EUROTRONIC 2	√	√	√	√	√	
IVECO\China Area\Iveco by model\Stralis\Euro 4-5-EEV\AS-L M.Y.2007\Suspension system\ECAS WABCO CAN	√	√	√	√	√	
IVECO\China Area\Iveco by model\Stralis\Euro 4-5-EEV\AS-L M.Y.2007\Multiplexer\Body Computer 2	√	√	√	√	√	
IVECO\China Area\Iveco by model\Stralis\Euro 4-5-EEV\AS-L M.Y.2007\Multiplexer\Driver door module	√	√	√	√	√	
IVECO\China Area\Iveco by model\Stralis\Euro 4-5-EEV\AS-L M.Y.2007\Multiplexer\Front frame computer	√	√	√	√	√	
IVECO\China Area\Iveco by model\Stralis\Euro 4-5-EEV\AS-L M.Y.2007\Multiplexer\Extension module	√	√	√	√		
IVECO\China Area\Iveco by model\Stralis\Euro 4-5-EEV\AS-L M.Y.2007\Multiplexer\Passenger door module	√	√	√	√	√	
IVECO\China Area\Iveco by model\Stralis\Euro 4-5-EEV\AS-L M.Y.2007\Multiplexer\Rear frame computer	√	√	√	√	√	
IVECO\China Area\Iveco by model\Stralis\Euro 4-5-EEV\AS-L M.Y.2007\Instrument\Instrument cluster	√	√	√	√	√	
IVECO\China Area\Iveco by model\Stralis\Euro 4-5-EEV\AS-L M.Y.2007\Climate control\Air heater(Stralis)	√	√	√	√		
IVECO\China Area\Iveco by model\Stralis\Euro 4-5-EEV\AT-N-AD-N M.Y.2007\Engine System\DeNoxtronic 2	√	√	√	√	√	
IVECO\China Area\Iveco by model\Stralis\Euro 4-5-EEV\AT-N-AD-N M.Y.2007\Engine System\VCM-anti-theft system	√	√	√	√	√	
IVECO\China Area\Iveco by model\Stralis\Euro 4-5-EEV\AT-N-AD-N M.Y.2007\Engine System\EDC 7 UC31	√	√	√	√	√	
IVECO\China Area\Iveco by model\Stralis\Euro 4-5-EEV\AT-N-AD-N M.Y.2007\Transmission system\EUROTRONIC 2	√	√	√	√	√	
IVECO\China Area\Iveco by model\Stralis\Euro 4-5-EEV\AT-N-AD-N M.Y.2007\Suspension system\ECAS WABCO CAN	√	√	√	√	√	
IVECO\China Area\Iveco by model\Stralis\Euro 4-5-EEV\AT-N-AD-N M.Y.2007\Multiplexer\Body Computer 2	√	√	√	√	√	
IVECO\China Area\Iveco by model\Stralis\Euro 4-5-EEV\AT-N-AD-N M.Y.2007\Multiplexer\Driver door module	√	√	√	√	√	
IVECO\China Area\Iveco by model\Stralis\Euro 4-5-EEV\AT-N-AD-N M.Y.2007\Multiplexer\Front frame computer	√	√	√	√	√	
IVECO\China Area\Iveco by model\Stralis\Euro 4-5-EEV\AT-N-AD-N M.Y.2007\Multiplexer\Extension module	√	√	√	√		

IVECO\China Area\Iveco by model\Stralis\Euro 4-5-EEV\AT-N-AD-N M.Y.2007\Multiplexer\Passenger door module	√	√	√	√	√	
IVECO\China Area\Iveco by model\Stralis\Euro 4-5-EEV\AT-N-AD-N M.Y.2007\Multiplexer\Rear frame computer	√	√	√	√	√	
IVECO\China Area\Iveco by model\Stralis\Euro 4-5-EEV\AT-N-AD-N M.Y.2007\Instrument\Instrument cluster	√	√	√	√	√	
IVECO\China Area\Iveco by model\Stralis\Euro 4-5-EEV\AT-N-AD-N M.Y.2007\Climate control\Air heater(Stralis)	√	√	√	√		
IVECO\China Area\Iveco by model\Stralis\Euro 4-5-EEV\AD CNG\Suspension system\ECAS WABCO CAN	√	√	√	√	√	
IVECO\China Area\Iveco by model\Stralis\Euro 4-5-EEV\AD CNG\Multiplexer\Body computer	√	√	√	√	√	
IVECO\China Area\Iveco by model\Stralis\Euro 4-5-EEV\AD CNG\Multiplexer\Cab module	√			√	√	
IVECO\China Area\Iveco by model\Stralis\Euro 4-5-EEV\AD CNG\Multiplexer\Driver door module	√	√	√	√	√	
IVECO\China Area\Iveco by model\Stralis\Euro 4-5-EEV\AD CNG\Multiplexer\Front frame computer	√	√	√	√	√	
IVECO\China Area\Iveco by model\Stralis\Euro 4-5-EEV\AD CNG\Multiplexer\Passenger door module	√	√	√	√	√	
IVECO\China Area\Iveco by model\Stralis\Euro 4-5-EEV\AD CNG\Multiplexer\Rear frame computer	√	√	√	√	√	
IVECO\China Area\Iveco by model\Stralis\Euro 4-5-EEV\AD CNG\Instrument\Instrument cluster	√	√	√	√	√	
IVECO\China Area\Iveco by model\Stralis\Euro 4-5-EEV\AD CNG\Climate control\Air heater(Stralis)	√	√	√	√		
IVECO\China Area\Iveco by model\Stralis\Euro 4-5-EEV\AT-N-AD-N CNG M.Y.2008\Engine System\VCM-anti-theft system	√	√	√	√	√	
IVECO\China Area\Iveco by model\Stralis\Euro 4-5-EEV\AT-N-AD-N CNG M.Y.2008\Suspension system\ECAS WABCO CAN	√	√	√	√	√	
IVECO\China Area\Iveco by model\Stralis\Euro 4-5-EEV\AT-N-AD-N CNG M.Y.2008\Multiplexer\Body Computer 2	√	√	√	√	√	
IVECO\China Area\Iveco by model\Stralis\Euro 4-5-EEV\AT-N-AD-N CNG M.Y.2008\Multiplexer\Driver door module	√	√	√	√	√	
IVECO\China Area\Iveco by model\Stralis\Euro 4-5-EEV\AT-N-AD-N CNG M.Y.2008\Multiplexer\Front frame computer	√	√	√	√	√	
IVECO\China Area\Iveco by model\Stralis\Euro 4-5-EEV\AT-N-AD-N CNG M.Y.2008\Multiplexer\Extension module	√	√	√	√		
IVECO\China Area\Iveco by model\Stralis\Euro 4-5-EEV\AT-N-AD-N CNG M.Y.2008\Multiplexer\Passenger door module	√	√	√	√	√	
IVECO\China Area\Iveco by model\Stralis\Euro 4-5-EEV\AT-N-AD-N CNG M.Y.2008\Multiplexer\Rear frame computer	√	√	√	√	√	
IVECO\China Area\Iveco by model\Stralis\Euro 4-5-EEV\AT-N-AD-N CNG M.Y.2008\Instrument\Instrument cluster	√	√	√	√	√	
IVECO\China Area\Iveco by model\Stralis\Euro 4-5-EEV\AT-N-AD-N CNG M.Y.2008\Climate control\Air heater(Stralis)	√	√	√	√		
IVECO\China Area\Iveco by model\Trakker\Euro 2-3\Trakker\Engine System\EDC MS6.2 BOSCH VERSION 1						
IVECO\China Area\Iveco by model\Trakker\Euro 2-3\Trakker\Engine System\EDC MS6.2 BOSCH VERSION 2	√	√	√	√	√	
IVECO\China Area\Iveco by model\Trakker\Euro 2-3\Trakker\Transmission system\EUROTTRONIC 2	√	√	√	√	√	
IVECO\China Area\Iveco by model\Trakker\Euro 2-3\Trakker\Suspension system\ECAS WABCO CAN	√	√	√	√	√	
IVECO\China Area\Iveco by model\Trakker\Euro 2-3\Trakker\Multiplexer\Body computer trakker	√	√	√	√	√	
IVECO\China Area\Iveco by model\Trakker\Euro 2-3\Trakker\Multiplexer\Cab module	√			√	√	
IVECO\China Area\Iveco by model\Trakker\Euro 2-3\Trakker\Multiplexer\Driver door module	√	√	√	√	√	
IVECO\China Area\Iveco by model\Trakker\Euro 2-3\Trakker\Multiplexer\Front frame computer	√	√	√	√	√	
IVECO\China Area\Iveco by model\Trakker\Euro 2-3\Trakker\Multiplexer\Passenger door module	√	√	√	√	√	
IVECO\China Area\Iveco by model\Trakker\Euro 2-3\Trakker\Multiplexer\Rear frame computer	√	√	√	√	√	
IVECO\China Area\Iveco by model\Trakker\Euro 2-3\Trakker\Instrument\Instrument cluster	√	√	√	√	√	
IVECO\China Area\Iveco by model\Trakker\Euro 2-3\Trakker E.E.M.Y.2008\Engine System\VCM-anti-theft system	√	√	√	√	√	
IVECO\China Area\Iveco by model\Trakker\Euro 2-3\Trakker E.E.M.Y.2008\Transmission system\EUROTTRONIC 2	√	√	√	√	√	
IVECO\China Area\Iveco by model\Trakker\Euro 2-3\Trakker E.E.M.Y.2008\Multiplexer\Body computer trakker	√	√	√	√	√	
IVECO\China Area\Iveco by model\Trakker\Euro 2-3\Trakker E.E.M.Y.2008\Multiplexer\Driver door module	√	√	√	√	√	
IVECO\China Area\Iveco by model\Trakker\Euro 2-3\Trakker E.E.M.Y.2008\Multiplexer\Extension module	√	√	√	√		
IVECO\China Area\Iveco by model\Trakker\Euro 2-3\Trakker E.E.M.Y.2008\Multiplexer\Passenger door module	√	√	√	√	√	

IVECO\China Area\Iveco by model\Trakker\Euro 2-3\Trakker E.E.M.Y.2008\Multiplexer\Trakker chassis electronics module	√	√	√	√		
IVECO\China Area\Iveco by model\Trakker\Euro 2-3\Trakker E.E.M.Y.2008\Multiplexer\IVECO body controller	√	√	√	√	√	
IVECO\China Area\Iveco by model\Trakker\Euro 2-3\Trakker E.E.M.Y.2008\Instrument\IC(instrument)TRAKKER	√	√	√	√	√	
IVECO\China Area\Iveco by model\Trakker\Euro 4-5-EEV\Engine System\DeNoxtronic 2	√	√	√	√	√	
IVECO\China Area\Iveco by model\Trakker\Euro 4-5-EEV\Engine System\VCM-anti-theft system	√	√	√	√	√	
IVECO\China Area\Iveco by model\Trakker\Euro 4-5-EEV\Transmission system\EUROTRONIC 2	√	√	√	√	√	
IVECO\China Area\Iveco by model\Trakker\Euro 4-5-EEV\Suspension system\ECAS WABCO CAN	√	√	√	√	√	
IVECO\China Area\Iveco by model\Trakker\Euro 4-5-EEV\Multiplexer\Body computer trakker	√	√	√	√	√	
IVECO\China Area\Iveco by model\Trakker\Euro 4-5-EEV\Multiplexer\Driver door module	√	√	√	√	√	
IVECO\China Area\Iveco by model\Trakker\Euro 4-5-EEV\Multiplexer\Extension module	√	√	√	√		
IVECO\China Area\Iveco by model\Trakker\Euro 4-5-EEV\Multiplexer\Passenger door module	√	√	√	√	√	
IVECO\China Area\Iveco by model\Trakker\Euro 4-5-EEV\Multiplexer\Trakker chassis electronics module	√	√	√	√		
IVECO\China Area\Iveco by model\Trakker\Euro 4-5-EEV\Multiplexer\IVECO body controller	√	√	√	√	√	
IVECO\China Area\Iveco by model\Trakker\Euro 4-5-EEV\Instrument\IC(instrument)TRAKKER	√	√	√	√	√	
IVECO\China Area\Iveco by model\EuroTech\MH-MP Cursor\Engine System\EDC MS6.2 BOSCH VERSION 1						
IVECO\China Area\Iveco by model\EuroTech\MH-MP Cursor\Engine System\EDC MS6.2 BOSCH VERSION 2	√	√	√	√	√	
IVECO\China Area\Iveco by model\EuroTech\MH-MP Cursor\Braking system\EBS WABCO	√	√	√	√	√	
IVECO\China Area\Iveco by model\EuroTech\MH-MP Cursor\Braking system\ABS D-E-E2	√	√	√	√		
IVECO\China Area\Iveco by model\EuroTech\MH-MP Cursor\Transmission system\EUROTRONIC 2	√	√	√	√	√	
IVECO\China Area\Iveco by model\EuroTech\MH RSU Cursor\Engine System\EDC MS6.2 BOSCH VERSION 1						
IVECO\China Area\Iveco by model\EuroTech\MH RSU Cursor\Engine System\EDC MS6.2 BOSCH VERSION 2	√	√	√	√	√	
IVECO\China Area\Iveco by model\EuroTech\MH RSU Cursor\Transmission system\EUROTRONIC 2	√	√	√	√	√	
IVECO\China Area\Iveco by model\EuroStar\LD Cursor\Engine System\EDC MS6.2 BOSCH VERSION 1						
IVECO\China Area\Iveco by model\EuroStar\LD Cursor\Engine System\EDC MS6.2 BOSCH VERSION 2	√	√	√	√	√	
IVECO\China Area\Iveco by model\EuroStar\LD Cursor\Braking system\EBS WABCO	√	√	√	√	√	
IVECO\China Area\Iveco by model\EuroStar\LD Cursor\Braking system\ABS D-E-E2	√	√	√	√		
IVECO\China Area\Iveco by model\EuroStar\LD Cursor\Transmission system\EUROTRONIC 2	√	√	√	√	√	
IVECO\China Area\Iveco by model\EuroTrakker\MP Cursor\Engine System\EDC MS6.2 BOSCH VERSION 1						
IVECO\China Area\Iveco by model\EuroTrakker\MP Cursor\Engine System\EDC MS6.2 BOSCH VERSION 2	√	√	√	√	√	
IVECO\China Area\Iveco by model\EuroTrakker\MP Cursor\Braking system\EBS WABCO	√	√	√	√	√	
IVECO\China Area\Iveco by model\EuroTrakker\MP Cursor\Braking system\ABS D-E-E2	√	√	√	√		
IVECO\China Area\Iveco by model\EuroTrakker\MP Cursor\Transmission system\EUROTRONIC 2	√	√	√	√	√	
IVECO\China Area\Iveco by model\EuroFire\Euro 2-3\ML Tector M.Y.2002\Engine System\EDC 7 BOSCH		√	√	√		
IVECO\China Area\Iveco by model\EuroFire\Euro 2-3\ML Tector M.Y.2002\Braking system\ABS 2X Knorr-BOSCH	√	√	√	√	√	
IVECO\China Area\Iveco by model\EuroFire\Euro 2-3\Other engines of ML\Braking system\ABS 2X Knorr-BOSCH	√	√	√	√	√	
IVECO\China Area\Iveco by model\EuroFire\Euro 2-3\ML Tector M.Y.2003\Engine System\EDC 7 BOSCH		√	√	√		
IVECO\China Area\Iveco by model\EuroFire\Euro 2-3\ML Tector M.Y.2003\Braking system\ABS 2X Knorr-BOSCH	√	√	√	√	√	
IVECO\China Area\Iveco by model\EuroFire\Euro 2-3\ML Tector M.Y.2003\Suspension system\ECAS EURO CARGO RESTYLING	√	√	√	√	√	
IVECO\China Area\Iveco by model\EuroFire\Euro 2-3\ML Tector M.Y.2003\Multiplexer\IBC EURO CARGO NEW	√	√	√	√	√	
IVECO\China Area\Iveco by model\EuroFire\Euro 2-3\ML Tector M.Y.2003\Multiplexer\IVECO body controller	√	√	√	√	√	

IVECO\China Area\Iveco by model\EuroFire\Euro 2-3\ML Tector M.Y.2003\Instrument\IC EURO CARGO NEW	√	√	√	√	√	
IVECO\China Area\Iveco by model\EuroFire\Euro 4-5-EEV\ML Tector M.Y.2006\Engine System\DeNoxtronic 2	√	√	√	√	√	
IVECO\China Area\Iveco by model\EuroFire\Euro 4-5-EEV\ML Tector M.Y.2006\Engine System\VCM-anti-theft system	√	√	√	√	√	
IVECO\China Area\Iveco by model\EuroFire\Euro 4-5-EEV\ML Tector M.Y.2006\Suspension system\ECAS EURO CARGO RESTYLING	√	√	√	√	√	
IVECO\China Area\Iveco by model\EuroFire\Euro 4-5-EEV\ML Tector M.Y.2006\Multiplexer\Extension module	√	√	√	√		
IVECO\China Area\Iveco by model\EuroFire\Euro 4-5-EEV\ML Tector M.Y.2006\Instrument\Instrument cluster	√	√	√	√	√	
IVECO\China Area\Iveco by model\EuroMover\Euro 2-3\Engine System\EDC MS6.2 BOSCH VERSION 1						
IVECO\China Area\Iveco by model\EuroMover\Euro 2-3\Engine System\EDC MS6.2 BOSCH VERSION 2	√	√	√	√	√	
IVECO\China Area\Iveco by model\Seddon Atkinson\Euro 2-3\R5 Strato-M5 Pacer\Engine System\EDC 7 BOSCH		√	√	√		
IVECO\China Area\Iveco by model\Seddon Atkinson\Euro 2-3\R5 Strato-M5 Pacer\Multiplexer\IBC EURO CARGO NEW	√	√	√	√	√	
IVECO\China Area\Iveco by model\Seddon Atkinson\Euro 2-3\R6 Strato-M6 Pacer\Engine System\EDC MS6.2 BOSCH VERSION 1						
IVECO\China Area\Iveco by model\Seddon Atkinson\Euro 2-3\R6 Strato-M6 Pacer\Engine System\EDC MS6.2 BOSCH VERSION 2	√	√	√	√	√	
IVECO\China Area\Iveco by model\Seddon Atkinson\Euro 2-3\R6 Strato-M6 Pacer\Multiplexer\IBC EURO CARGO NEW	√	√	√	√	√	
IVECO\China Area\Iveco by model\Seddon Atkinson\Euro 2-3\T6 Strato\Engine System\EDC MS6.2 BOSCH VERSION 1						
IVECO\China Area\Iveco by model\Seddon Atkinson\Euro 2-3\T6 Strato\Engine System\EDC MS6.2 BOSCH VERSION 2	√	√	√	√	√	
IVECO\China Area\Iveco by model\Seddon Atkinson\Euro 2-3\T6 Strato\Multiplexer\IBC EURO CARGO NEW	√	√	√	√	√	
IVECO\China Area\Iveco by model\Seddon Atkinson\Euro 2-3\T6 Strato\Transmission system\EUROTRONIC 2	√	√	√	√	√	
IVECO\China Area\Iveco by model\PowerDaily\Euro 2-3\Engine System\EDC 16 BOSCH\EDC 16 BOSCH						
IVECO\China Area\Iveco by model\PowerDaily\Euro 2-3\Engine System\EDC 16 BOSCH\EDC16C39.5	√	√	√	√	√	0007
IVECO\China Area\Iveco by model\PowerDaily\Euro 2-3\Engine System\EDC MS6.3 BOSCH	√	√	√	√	√	
IVECO\China Area\Iveco by model\PowerTech\Euro 2-3\Instrument\Instrument cluster	√	√	√	√	√	
IVECO\China Area\Defense vehicle part\LMV-VILM\Engine System\EDC 16 BOSCH\EDC 16 BOSCH						
IVECO\China Area\Defense vehicle part\LMV-VILM\Engine System\EDC 16 BOSCH\EDC16C39.5	√	√	√	√	√	0007
IVECO\China Area\Defense vehicle part\LMV-VILM\Braking system\ABS 2X Knorr-BOSCH	√	√	√	√	√	
IVECO\China Area\Defense vehicle part\MMV\Engine System\EDC 7 BOSCH		√	√	√		
IVECO\China Area\Defense vehicle part\MMV\Braking system\ABS 2X Knorr-BOSCH	√	√	√	√	√	
IVECO\China Area\Defense vehicle part\VM90\Engine System\EDC MS6.3 BOSCH	√	√	√	√	√	
IVECO\China Area\Defense vehicle part\RG12\Engine System\EDC 7 BOSCH		√	√	√		
IVECO\China Area\Defense vehicle part\MG410\Engine System\DeNoxtronic 2	√	√	√	√	√	
IVECO\China Area\Defense vehicle part\MG410\Engine System\VCM-anti-theft system	√	√	√	√	√	
IVECO\China Area\Defense vehicle part\MG410\Engine System\EDC 7 UC31	√	√	√	√	√	
IVECO\China Area\Defense vehicle part\MG410\Transmission system\EUROTRONIC 2	√	√	√	√	√	
IVECO\China Area\Defense vehicle part\MG410\Suspension system\ECAS WABCO CAN	√	√	√	√	√	
IVECO\China Area\Defense vehicle part\MG410\Multiplexer\Extension module	√	√	√	√		
IVECO\China Area\Defense vehicle part\MG410\Multiplexer\IVECO body controller	√	√	√	√	√	
IVECO\China Area\Defense vehicle part\MG410\Multiplexer\Trakker chassis electronics module	√	√	√	√		
IVECO\China Area\Defense vehicle part\MG410\Instrument\IC(instrument) TRAKKER	√	√	√	√	√	
IVECO\China Area\Defense vehicle part\MG410\Climate control\Air heater(Stralis)	√	√	√	√		
IVECO\China Area\Defense vehicle part\MG410\Pneumatic-hydraulic system\WABCO-IVTM	√	√	√	√		
IVECO\China Area\Astra\Cursor\Engine System\EDC 7 UC31	√	√	√	√	√	

IVECO\China Area\Astra\Cursor\Engine System\EDC MS6.3 BOSCH	√	√	√	√	√	
IVECO\China Area\Astra\Cursor\Transmission system\EUROTRONIC 2	√	√	√	√	√	
IVECO\China Area\Astra\Cursor Extra-Europe(one-B0x)\Engine System\EDC 7 UC31	√	√	√	√	√	
IVECO\China Area\Astra\Cursor Extra-Europe(one-B0x)\Transmission system\EUROTRONIC 2	√	√	√	√	√	
IVECO\China Area\Astra\Cursor Euro 4\Engine System\DeNoxtronic 2	√	√	√	√	√	
IVECO\China Area\Astra\Cursor Euro 4\Engine System\EDC 7 UC31	√	√	√	√	√	
IVECO\China Area\IVECO\Engine ECU\Engine System\DeNoxtronic 2	√	√	√	√	√	
IVECO\China Area\IVECO\Engine ECU\Engine System\EDC 16 BOSCH\EDC 16 BOSCH						
IVECO\China Area\IVECO\Engine ECU\Engine System\EDC 16 BOSCH\EDC16C39.5	√	√	√	√	√	0007
IVECO\China Area\IVECO\Engine ECU\Engine System\EDC 7 BOSCH		√	√	√		
IVECO\China Area\IVECO\Engine ECU\Engine System\EDC MS6.2 BOSCH VERSION 1						
IVECO\China Area\IVECO\Engine ECU\Engine System\EDC MS6.2 BOSCH VERSION 2	√	√	√	√	√	
IVECO\China Area\IVECO\Engine ECU\Engine System\EDC MS6.3 BOSCH	√	√	√	√	√	
IVECO\China Area\IVECO\Multicar EOL\Engine System\DeNoxtronic 2	√	√	√	√	√	
IVECO\China Area\IVECO\Multicar EOL\Engine System\EDC 16 BOSCH\EDC 16 BOSCH						
IVECO\China Area\IVECO\Multicar EOL\Engine System\EDC 16 BOSCH\EDC16C39.5	√	√	√	√	√	0007
IVECO\China Area\IVECO\Multicar EOL\Engine System\EDC 7 BOSCH		√	√	√		
IVECO\China Area\IVECO\Multicar EOL\Engine System\EDC MS6.2 BOSCH VERSION 1						
IVECO\China Area\IVECO\Multicar EOL\Engine System\EDC MS6.2 BOSCH VERSION 2	√	√	√	√	√	
IVECO\China Area\IVECO\Multicar EOL\Engine System\EDC MS6.3 BOSCH	√	√	√	√	√	
IVECO\China Area\IVECO\UAZ manufacturing\Engine System\DeNoxtronic 2	√	√	√	√	√	
IVECO\China Area\IVECO\UAZ manufacturing\Engine System\EDC 16 BOSCH\EDC 16 BOSCH						
IVECO\China Area\IVECO\UAZ manufacturing\Engine System\EDC 16 BOSCH\EDC16C39.5	√	√	√	√	√	0007
IVECO\China Area\IVECO\UAZ manufacturing\Engine System\EDC 7 BOSCH		√	√	√		
IVECO\China Area\IVECO\UAZ manufacturing\Engine System\EDC MS6.2 BOSCH VERSION 1						
IVECO\China Area\IVECO\UAZ manufacturing\Engine System\EDC MS6.2 BOSCH VERSION 2	√	√	√	√	√	
IVECO\China Area\IVECO\UAZ manufacturing\Engine System\EDC MS6.3 BOSCH	√	√	√	√	√	
IVECO\China Area\IVECO\UAZ CS\Engine System\DeNoxtronic 2	√	√	√	√	√	
IVECO\China Area\IVECO\UAZ CS\Engine System\EDC 16 BOSCH\EDC 16 BOSCH						
IVECO\China Area\IVECO\UAZ CS\Engine System\EDC 16 BOSCH\EDC16C39.5	√	√	√	√	√	0007
IVECO\China Area\IVECO\UAZ CS\Engine System\EDC 7 BOSCH		√	√	√		
IVECO\China Area\IVECO\UAZ CS\Engine System\EDC MS6.2 BOSCH VERSION 1						
IVECO\China Area\IVECO\UAZ CS\Engine System\EDC MS6.2 BOSCH VERSION 2	√	√	√	√	√	
IVECO\China Area\IVECO\UAZ CS\Engine System\EDC MS6.3 BOSCH	√	√	√	√	√	
IVECO\China Area\Swiss Army\Sa Vehicles\Engine System\EDC MS6.2 BOSCH VERSION 1						
IVECO\China Area\Swiss Army\Sa Vehicles\Engine System\EDC MS6.2 BOSCH VERSION 2	√	√	√	√	√	
IVECO\China Area\Swiss Army\Sa Vehicles\Braking system\EBS WABCO	√	√	√	√	√	
IVECO\China Area\Swiss Army\Sa Vehicles\Braking system\ABS D-E-E2	√	√	√	√		
IVECO\China Area\Swiss Army\Sa Vehicles\Transmission system\EUROTRONIC 2	√	√	√	√	√	
IVECO\China Area\Tata Daewoo\Engine ECU\Engine System\EDC 7 BOSCH		√	√	√		

[illegible]

[illegible]

[illegible]

[illegible]

[illegible]

[illegible]

[illegible]

[illegible]

[illegible]

[illegible]

[illegible]

[illegible]

[illegible]

[illegible]

[illegible]

[illegible]

IVECO\Universal Area\EuroCargo\EuroCargo by model\9\90E18\ABS\Wabco C3	√			√		
IVECO\Universal Area\EuroCargo\EuroCargo by model\9\90E18\Immobilizer\Bosch EDC unlock 3	√				√	
IVECO\Universal Area\EuroCargo\EuroCargo by model\9\90E18\Suspensions\Wabco ECAS All configurations	√				√	
IVECO\Universal Area\EuroCargo\EuroCargo by model\9\90E18\Suspensions\Wabco Iveco ECAS 4x2 FP	√			√	√	
IVECO\Universal Area\EuroCargo\EuroCargo by model\9\90E18\Suspensions\Wabco Iveco ECAS 4x2 P Tractors	√			√	√	
IVECO\Universal Area\EuroCargo\EuroCargo by model\9\90E18\Suspensions\Wabco Iveco ECAS 4x2 P Trucks	√			√	√	
IVECO\Universal Area\EuroCargo\EuroCargo by model\9\90E21\ABS\Bosch 2x	√	√	√	√	√	
IVECO\Universal Area\EuroCargo\EuroCargo by model\9\90E21\ABS\Wabco C3	√			√		
IVECO\Universal Area\EuroCargo\EuroCargo by model\9\90E21\Immobilizer\Bosch EDC unlock 3	√				√	
IVECO\Universal Area\EuroCargo\EuroCargo by model\9\90E21\Suspensions\Wabco ECAS All configurations	√				√	
IVECO\Universal Area\EuroCargo\EuroCargo by model\9\90E21\Suspensions\Wabco Iveco ECAS 4x2 FP	√			√	√	
IVECO\Universal Area\EuroCargo\EuroCargo by model\9\90E21\Suspensions\Wabco Iveco ECAS 4x2 P Tractors	√			√	√	
IVECO\Universal Area\EuroCargo\EuroCargo by model\9\90E21\Suspensions\Wabco Iveco ECAS 4x2 P Trucks	√			√	√	
IVECO\Universal Area\EuroCargo\EuroCargo by model\9\95E15\ABS\Bosch 2x	√	√	√	√	√	
IVECO\Universal Area\EuroCargo\EuroCargo by model\9\95E15\ABS\Wabco C3	√			√		
IVECO\Universal Area\EuroCargo\EuroCargo by model\9\95E15\Immobilizer\Bosch EDC unlock 3	√				√	
IVECO\Universal Area\EuroCargo\EuroCargo by model\9\95E15\Suspensions\Wabco ECAS All configurations	√				√	
IVECO\Universal Area\EuroCargo\EuroCargo by model\9\95E15\Suspensions\Wabco Iveco ECAS 4x2 FP	√			√	√	
IVECO\Universal Area\EuroCargo\EuroCargo by model\9\95E15\Suspensions\Wabco Iveco ECAS 4x2 P Tractors	√			√	√	
IVECO\Universal Area\EuroCargo\EuroCargo by model\9\95E15\Suspensions\Wabco Iveco ECAS 4x2 P Trucks	√			√	√	
IVECO\Universal Area\EuroCargo\EuroCargo by model\9\95E21\ABS\Bosch 2x	√	√	√	√	√	
IVECO\Universal Area\EuroCargo\EuroCargo by model\9\95E21\ABS\Wabco C3	√			√		
IVECO\Universal Area\EuroCargo\EuroCargo by model\9\95E21\Immobilizer\Bosch EDC unlock 3	√				√	
IVECO\Universal Area\EuroCargo\EuroCargo by model\9\95E21\Suspensions\Wabco ECAS All configurations	√				√	
IVECO\Universal Area\EuroCargo\EuroCargo by model\9\95E21\Suspensions\Wabco Iveco ECAS 4x2 FP	√			√	√	
IVECO\Universal Area\EuroCargo\EuroCargo by model\9\95E21\Suspensions\Wabco Iveco ECAS 4x2 P Tractors	√			√	√	
IVECO\Universal Area\EuroCargo\EuroCargo by model\9\95E21\Suspensions\Wabco Iveco ECAS 4x2 P Trucks	√			√	√	
IVECO\Universal Area\EuroCargo\EuroCargo by years\2012\Diesel\AdBlue system\Denoxtronic	√	√	√	√	√	
IVECO\Universal Area\EuroCargo\EuroCargo by years\2012\Diesel\AdBlue system\Denoxtronic 2	√	√	√	√	√	0002, 0004, 0008, 0010, 0011
IVECO\Universal Area\EuroCargo\EuroCargo by years\2012\Diesel\Engine control\EDC 7 UC31	√	√	√	√	√	
IVECO\Universal Area\EuroCargo\EuroCargo by years\2012\Brake\ABS\Abs 6 Bosch-knorr	√	√	√	√	√	
IVECO\Universal Area\EuroCargo\EuroCargo by years\2012\Instrument\Dashboard\Instrument cluster	√	√	√	√	√	
IVECO\Universal Area\EuroCargo\EuroCargo by years\2012\Climate\Auxiliary heater\Air heater	√	√	√	√	√	
IVECO\Universal Area\EuroCargo\EuroCargo by years\2012\Gearbox\Gearbox\Astronic lite	√	√	√	√		
IVECO\Universal Area\EuroCargo\EuroCargo by years\2012\Multifunction\Driver Door Module\Diagnose	√	√	√	√	√	
IVECO\Universal Area\EuroCargo\EuroCargo by years\2012\Multifunction\Iveco body controller\IBC 3	√	√	√	√	√	
IVECO\Universal Area\EuroCargo\EuroCargo by years\2012\Multifunction\Passenger Door Module\Diagnose	√	√	√	√	√	
IVECO\Universal Area\EuroCargo\EuroCargo by years\2012\Multifunction\VCM-Immobilizer\Diagnose	√	√	√	√		
IVECO\Universal Area\EuroCargo\EuroCargo by years\2012\Suspension\Air Suspension\Ecas Eurocargo Restyling	√	√	√	√	√	
IVECO\Universal Area\EuroCargo\EuroCargo by years\2011\Diesel\AdBlue system\Denoxtronic	√	√	√	√	√	

IVECO\Universal Area\EuroCargo\EuroCargo by years\2011\Diesel\AdBlue system\Denoxtronic 2	√	√	√	√	√	0002, 0004, 0008, 0010, 0011
IVECO\Universal Area\EuroCargo\EuroCargo by years\2011\Diesel\Engine control\EDC 7 UC31	√	√	√	√	√	
IVECO\Universal Area\EuroCargo\EuroCargo by years\2011\Brake\ABS\Abs 6 Bosch-knorr	√	√	√	√	√	
IVECO\Universal Area\EuroCargo\EuroCargo by years\2011\Instrument\Dashboard\Instrument cluster	√	√	√	√	√	
IVECO\Universal Area\EuroCargo\EuroCargo by years\2011\Climate\Auxiliary heater\Air heater	√	√	√	√	√	
IVECO\Universal Area\EuroCargo\EuroCargo by years\2011\Gearbox\Gearbox\Astronic lite	√	√	√	√		
IVECO\Universal Area\EuroCargo\EuroCargo by years\2011\Multifunction\Driver Door Module\Diagnose	√	√	√	√	√	
IVECO\Universal Area\EuroCargo\EuroCargo by years\2011\Multifunction\Iveco body controller\IBC 3	√	√	√	√	√	
IVECO\Universal Area\EuroCargo\EuroCargo by years\2011\Multifunction\Passenger Door Module\Diagnose	√	√	√	√	√	
IVECO\Universal Area\EuroCargo\EuroCargo by years\2011\Multifunction\VCM-Immobilizer\Diagnose	√	√	√	√		
IVECO\Universal Area\EuroCargo\EuroCargo by years\2011\Suspension\Air Suspension\Ecas Eurocargo Restyling	√	√	√	√	√	
IVECO\Universal Area\EuroCargo\EuroCargo by years\2010\Diesel\AdBlue system\Denoxtronic	√	√	√	√	√	
IVECO\Universal Area\EuroCargo\EuroCargo by years\2010\Diesel\AdBlue system\Denoxtronic 2	√	√	√	√	√	0002, 0004, 0008, 0010, 0011
IVECO\Universal Area\EuroCargo\EuroCargo by years\2010\Diesel\Engine control\EDC 7 UC31	√	√	√	√	√	
IVECO\Universal Area\EuroCargo\EuroCargo by years\2010\Brake\ABS\Abs 6 Bosch-knorr	√	√	√	√	√	
IVECO\Universal Area\EuroCargo\EuroCargo by years\2010\Instrument\Dashboard\Instrument cluster	√	√	√	√	√	
IVECO\Universal Area\EuroCargo\EuroCargo by years\2010\Climate\Auxiliary heater\Air heater	√	√	√	√	√	
IVECO\Universal Area\EuroCargo\EuroCargo by years\2010\Gearbox\Gearbox\Astronic lite	√	√	√	√		
IVECO\Universal Area\EuroCargo\EuroCargo by years\2010\Multifunction\Driver Door Module\Diagnose	√	√	√	√	√	
IVECO\Universal Area\EuroCargo\EuroCargo by years\2010\Multifunction\Iveco body controller\IBC 3	√	√	√	√	√	
IVECO\Universal Area\EuroCargo\EuroCargo by years\2010\Multifunction\Passenger Door Module\Diagnose	√	√	√	√	√	
IVECO\Universal Area\EuroCargo\EuroCargo by years\2010\Multifunction\VCM-Immobilizer\Diagnose	√	√	√	√		
IVECO\Universal Area\EuroCargo\EuroCargo by years\2010\Suspension\Air Suspension\Ecas Eurocargo Restyling	√	√	√	√	√	
IVECO\Universal Area\EuroCargo\EuroCargo by years\2009\Diesel\AdBlue system\Denoxtronic	√	√	√	√	√	
IVECO\Universal Area\EuroCargo\EuroCargo by years\2009\Diesel\AdBlue system\Denoxtronic 2	√	√	√	√	√	0002, 0004, 0008, 0010, 0011
IVECO\Universal Area\EuroCargo\EuroCargo by years\2009\Diesel\Engine control\EDC 7 UC31	√	√	√	√	√	
IVECO\Universal Area\EuroCargo\EuroCargo by years\2009\Brake\ABS\Abs 6 Bosch-knorr	√	√	√	√	√	
IVECO\Universal Area\EuroCargo\EuroCargo by years\2009\Instrument\Dashboard\Instrument cluster	√	√	√	√	√	
IVECO\Universal Area\EuroCargo\EuroCargo by years\2009\Climate\Auxiliary heater\Air heater	√	√	√	√	√	
IVECO\Universal Area\EuroCargo\EuroCargo by years\2009\Gearbox\Gearbox\Astronic lite	√	√	√	√		
IVECO\Universal Area\EuroCargo\EuroCargo by years\2009\Multifunction\Driver Door Module\Diagnose	√	√	√	√	√	
IVECO\Universal Area\EuroCargo\EuroCargo by years\2009\Multifunction\Iveco body controller\IBC 3	√	√	√	√	√	
IVECO\Universal Area\EuroCargo\EuroCargo by years\2009\Multifunction\Passenger Door Module\Diagnose	√	√	√	√	√	
IVECO\Universal Area\EuroCargo\EuroCargo by years\2009\Multifunction\VCM-Immobilizer\Diagnose	√	√	√	√		
IVECO\Universal Area\EuroCargo\EuroCargo by years\2009\Suspension\Air Suspension\Ecas Eurocargo Restyling	√	√	√	√	√	
IVECO\Universal Area\EuroCargo\EuroCargo by years\2008\Diesel\AdBlue system\Denoxtronic	√	√	√	√	√	
IVECO\Universal Area\EuroCargo\EuroCargo by years\2008\Diesel\AdBlue system\Denoxtronic 2	√	√	√	√	√	0002, 0004, 0008, 0010, 0011
IVECO\Universal Area\EuroCargo\EuroCargo by years\2008\Diesel\Engine control\EDC 7 UC31	√	√	√	√	√	
IVECO\Universal Area\EuroCargo\EuroCargo by years\2008\Brake\ABS\Abs 6 Bosch-knorr	√	√	√	√	√	
IVECO\Universal Area\EuroCargo\EuroCargo by years\2008\Instrument\Dashboard\Instrument cluster	√	√	√	√	√	

IVECO\Universal Area\EuroCargo\EuroCargo by years\2008\Climate\Auxiliary heater\Air heater	√	√	√	√	√	
IVECO\Universal Area\EuroCargo\EuroCargo by years\2008\Gearbox\Gearbox\Astronic lite	√	√	√	√		
IVECO\Universal Area\EuroCargo\EuroCargo by years\2008\Multifunction\Driver Door Module\Diagnose	√	√	√	√	√	
IVECO\Universal Area\EuroCargo\EuroCargo by years\2008\Multifunction\Iveco body controller\IBC 3	√	√	√	√	√	
IVECO\Universal Area\EuroCargo\EuroCargo by years\2008\Multifunction\Passenger Door Module\Diagnose	√	√	√	√	√	
IVECO\Universal Area\EuroCargo\EuroCargo by years\2008\Multifunction\VCM-Immobilizer\Diagnose	√	√	√	√		
IVECO\Universal Area\EuroCargo\EuroCargo by years\2008\Suspension\Air Suspension\Ecas Eurocargo Restyling	√	√	√	√	√	
IVECO\Universal Area\EuroCargo\EuroCargo by years\2007\Diesel\AdBlue system\Denoxtronic	√	√	√	√	√	
IVECO\Universal Area\EuroCargo\EuroCargo by years\2007\Diesel\AdBlue system\Denoxtronic 2	√	√	√	√	√	0002, 0004, 0008, 0010, 0011
IVECO\Universal Area\EuroCargo\EuroCargo by years\2007\Diesel\Engine control\EDC 7 UC31	√	√	√	√	√	
IVECO\Universal Area\EuroCargo\EuroCargo by years\2007\Brake\ABS\Abs 6 Bosch-knorr	√	√	√	√	√	
IVECO\Universal Area\EuroCargo\EuroCargo by years\2007\Instrument\Dashboard\Instrument cluster	√	√	√	√	√	
IVECO\Universal Area\EuroCargo\EuroCargo by years\2007\Climate\Auxiliary heater\Air heater	√	√	√	√	√	
IVECO\Universal Area\EuroCargo\EuroCargo by years\2007\Gearbox\Gearbox\Astronic lite	√	√	√	√		
IVECO\Universal Area\EuroCargo\EuroCargo by years\2007\Multifunction\Driver Door Module\Diagnose	√	√	√	√	√	
IVECO\Universal Area\EuroCargo\EuroCargo by years\2007\Multifunction\Iveco body controller\IBC 3	√	√	√	√	√	
IVECO\Universal Area\EuroCargo\EuroCargo by years\2007\Multifunction\Passenger Door Module\Diagnose	√	√	√	√	√	
IVECO\Universal Area\EuroCargo\EuroCargo by years\2007\Multifunction\VCM-Immobilizer\Diagnose	√	√	√	√		
IVECO\Universal Area\EuroCargo\EuroCargo by years\2007\Suspension\Air Suspension\Ecas Eurocargo Restyling	√	√	√	√	√	
IVECO\Universal Area\EuroCargo\EuroCargo by years\2006\Diesel\AdBlue system\Denoxtronic	√	√	√	√	√	
IVECO\Universal Area\EuroCargo\EuroCargo by years\2006\Diesel\AdBlue system\Denoxtronic 2	√	√	√	√	√	0002, 0004, 0008, 0010, 0011
IVECO\Universal Area\EuroCargo\EuroCargo by years\2006\Diesel\Engine control\EDC 7 UC31	√	√	√	√	√	
IVECO\Universal Area\EuroCargo\EuroCargo by years\2006\Diesel\Engine control\EDC 7 Bosch		√	√	√	√	
IVECO\Universal Area\EuroCargo\EuroCargo by years\2006\Brake\ABS\Abs 6 Bosch-knorr	√	√	√	√	√	
IVECO\Universal Area\EuroCargo\EuroCargo by years\2006\Brake\ABS\Abs 2x Knorr-Bosch	√	√	√	√	√	
IVECO\Universal Area\EuroCargo\EuroCargo by years\2006\Instrument\Dashboard\Instrument cluster	√	√	√	√	√	
IVECO\Universal Area\EuroCargo\EuroCargo by years\2006\Gearbox\Gearbox\Astronic lite	√	√	√	√		
IVECO\Universal Area\EuroCargo\EuroCargo by years\2006\Multifunction\Iveco body controller\IBC 3	√	√	√	√	√	
IVECO\Universal Area\EuroCargo\EuroCargo by years\2006\Multifunction\Iveco body controller\IBC	√	√	√	√	√	
IVECO\Universal Area\EuroCargo\EuroCargo by years\2006\Multifunction\VCM-Immobilizer\Diagnose	√	√	√	√		
IVECO\Universal Area\EuroCargo\EuroCargo by years\2006\Suspension\Air Suspension\Ecas Eurocargo Restyling	√	√	√	√	√	
IVECO\Universal Area\EuroCargo\EuroCargo by years\2005\Diesel\Engine control\Engine control 1\EDC 7 Bosch		√	√	√	√	
IVECO\Universal Area\EuroCargo\EuroCargo by years\2005\Diesel\Engine control\Engine control 2\EDC 7 BOSCH		√	√	√		
IVECO\Universal Area\EuroCargo\EuroCargo by years\2005\Brake\ABS\Abs 2x Knorr-Bosch	√	√	√	√	√	
IVECO\Universal Area\EuroCargo\EuroCargo by years\2005\Multifunction\Iveco body controller\IBC	√	√	√	√	√	
IVECO\Universal Area\EuroCargo\EuroCargo by years\2005\Suspension\Air Suspension\Ecas Eurocargo Restyling	√	√	√	√	√	
IVECO\Universal Area\EuroCargo\EuroCargo by years\2004\Diesel\Engine control\Engine control 1\EDC 7 Bosch		√	√	√	√	
IVECO\Universal Area\EuroCargo\EuroCargo by years\2004\Diesel\Engine control\Engine control 2\EDC 7 BOSCH		√	√	√		
IVECO\Universal Area\EuroCargo\EuroCargo by years\2004\Brake\ABS\Abs 2x Knorr-Bosch	√	√	√	√	√	
IVECO\Universal Area\EuroCargo\EuroCargo by years\2004\Multifunction\Iveco body controller\IBC	√	√	√	√	√	

IVECO\Universal Area\EuroCargo\EuroCargo by years\2003\Diesel\Engine control\Engine control 1\EDC 7 Bosch		√	√	√	√	
IVECO\Universal Area\EuroCargo\EuroCargo by years\2003\Diesel\Engine control\Engine control 2\EDC 7 BOSCH		√	√	√		
IVECO\Universal Area\EuroCargo\EuroCargo by years\2003\Brake\ABS\Abs 2x Knorr-Bosch	√	√	√	√	√	
IVECO\Universal Area\EuroCargo\EuroCargo by years\2003\Multifunction\Iveco body controller\IBC	√	√	√	√	√	
IVECO\Universal Area\EuroCargo\EuroCargo by years\2002\Diesel\Engine control\Engine control 1\EDC 7 Bosch		√	√	√	√	
IVECO\Universal Area\EuroCargo\EuroCargo by years\2002\Diesel\Engine control\Engine control 2\EDC 7 BOSCH		√	√	√		
IVECO\Universal Area\EuroCargo\EuroCargo by years\2002\Brake\ABS\Abs 2x Knorr-Bosch	√	√	√	√	√	
IVECO\Universal Area\EuroCargo\EuroCargo Euro 6\ABS\Wabco D-E-E2	√	√	√	√	√	
IVECO\Universal Area\EuroCargo\EuroCargo Euro 6\Chassis equipment and design\Expansion Module	√	√	√	√	√	
IVECO\Universal Area\EuroCargo\EuroCargo Euro 6\Diesel injection\Bosch EDC 17 CV 41	√	√	√	√	√	
IVECO\Universal Area\EuroCargo\EuroCargo Euro 6\Engine-vehicle adjustment\VCM	√	√	√	√	√	
IVECO\Universal Area\EuroCargo\EuroCargo Euro 6\Instrument panel\Instrument Cluster	√	√	√	√	√	0009
IVECO\Universal Area\EuroCargo\EuroCargo Restyling\1\100E17\ABS\Bosch-2x ABS 6	√	√	√	√	√	
IVECO\Universal Area\EuroCargo\EuroCargo Restyling\1\100E17\Diesel injection\Bosch EDC 7	√	√	√	√		
IVECO\Universal Area\EuroCargo\EuroCargo Restyling\1\100E17\Suspensions\Wabco ECAS CAN 2 Iveco protocol	√	√	√	√	√	
IVECO\Universal Area\EuroCargo\EuroCargo Restyling\1\100E17\Suspensions\Wabco ECAS CAN 2 Wabco protocol	√	√	√	√	√	
IVECO\Universal Area\EuroCargo\EuroCargo Restyling\1\100E18\ABS\Bosch-2x ABS 6	√	√	√	√	√	
IVECO\Universal Area\EuroCargo\EuroCargo Restyling\1\100E18\Diesel injection\Bosch EDC 7	√	√	√	√		
IVECO\Universal Area\EuroCargo\EuroCargo Restyling\1\100E18\Suspensions\Wabco ECAS CAN 2 Iveco protocol	√	√	√	√	√	
IVECO\Universal Area\EuroCargo\EuroCargo Restyling\1\100E18\Suspensions\Wabco ECAS CAN 2 Wabco protocol	√	√	√	√	√	
IVECO\Universal Area\EuroCargo\EuroCargo Restyling\1\100E21\ABS\Bosch-2x ABS 6	√	√	√	√	√	
IVECO\Universal Area\EuroCargo\EuroCargo Restyling\1\100E21\Diesel injection\Bosch EDC 7	√	√	√	√		
IVECO\Universal Area\EuroCargo\EuroCargo Restyling\1\100E21\Suspensions\Wabco ECAS CAN 2 Iveco protocol	√	√	√	√	√	
IVECO\Universal Area\EuroCargo\EuroCargo Restyling\1\100E21\Suspensions\Wabco ECAS CAN 2 Wabco protocol	√	√	√	√	√	
IVECO\Universal Area\EuroCargo\EuroCargo Restyling\1\110E17\ABS\Bosch-2x ABS 6	√	√	√	√	√	
IVECO\Universal Area\EuroCargo\EuroCargo Restyling\1\110E17\Diesel injection\Bosch EDC 7	√	√	√	√		
IVECO\Universal Area\EuroCargo\EuroCargo Restyling\1\110E17\Suspensions\Wabco ECAS CAN 2 Iveco protocol	√	√	√	√	√	
IVECO\Universal Area\EuroCargo\EuroCargo Restyling\1\110E17\Suspensions\Wabco ECAS CAN 2 Wabco protocol	√	√	√	√	√	
IVECO\Universal Area\EuroCargo\EuroCargo Restyling\1\110E21\ABS\Bosch-2x ABS 6	√	√	√	√	√	
IVECO\Universal Area\EuroCargo\EuroCargo Restyling\1\110E21\Diesel injection\Bosch EDC 7	√	√	√	√		
IVECO\Universal Area\EuroCargo\EuroCargo Restyling\1\110E21\Suspensions\Wabco ECAS CAN 2 Iveco protocol	√	√	√	√	√	
IVECO\Universal Area\EuroCargo\EuroCargo Restyling\1\110E21\Suspensions\Wabco ECAS CAN 2 Wabco protocol	√	√	√	√	√	
IVECO\Universal Area\EuroCargo\EuroCargo Restyling\1\120E17\ABS\Bosch-2x ABS 6	√	√	√	√	√	
IVECO\Universal Area\EuroCargo\EuroCargo Restyling\1\120E17\Diesel injection\Bosch EDC 7	√	√	√	√		
IVECO\Universal Area\EuroCargo\EuroCargo Restyling\1\120E17\Suspensions\Wabco ECAS CAN 2 Iveco protocol	√	√	√	√	√	
IVECO\Universal Area\EuroCargo\EuroCargo Restyling\1\120E17\Suspensions\Wabco ECAS CAN 2 Wabco protocol	√	√	√	√	√	
IVECO\Universal Area\EuroCargo\EuroCargo Restyling\1\120E18\ABS\Bosch-2x ABS 6	√	√	√	√	√	
IVECO\Universal Area\EuroCargo\EuroCargo Restyling\1\120E18\Diesel injection\Bosch EDC 7	√	√	√	√		
IVECO\Universal Area\EuroCargo\EuroCargo Restyling\1\120E18\Suspensions\Wabco ECAS CAN 2 Iveco protocol	√	√	√	√	√	
IVECO\Universal Area\EuroCargo\EuroCargo Restyling\1\120E18\Suspensions\Wabco ECAS CAN 2 Wabco protocol	√	√	√	√	√	

[illegible]

[illegible]

[illegible]

IVECO\Universal Area\EuroCargo\EuroCargo Restyling\7\75E18\ABS\Bosch-2x ABS 6	√	√	√	√	√	
IVECO\Universal Area\EuroCargo\EuroCargo Restyling\7\75E18\Diesel injection\Bosch EDC 7	√	√	√	√		
IVECO\Universal Area\EuroCargo\EuroCargo Restyling\7\75E18\Suspensions\Wabco ECAS CAN 2 Iveco protocol	√	√	√	√	√	
IVECO\Universal Area\EuroCargo\EuroCargo Restyling\7\75E18\Suspensions\Wabco ECAS CAN 2 Wabco protocol	√	√	√	√	√	
IVECO\Universal Area\EuroCargo\EuroCargo Restyling\8\80E15\ABS\Bosch-2x ABS 6	√	√	√	√	√	
IVECO\Universal Area\EuroCargo\EuroCargo Restyling\8\80E15\Diesel injection\Bosch EDC 7	√	√	√	√		
IVECO\Universal Area\EuroCargo\EuroCargo Restyling\8\80E15\Suspensions\Wabco ECAS CAN 2 Iveco protocol	√	√	√	√	√	
IVECO\Universal Area\EuroCargo\EuroCargo Restyling\8\80E15\Suspensions\Wabco ECAS CAN 2 Wabco protocol	√	√	√	√	√	
IVECO\Universal Area\EuroCargo\EuroCargo Restyling\8\80E17\ABS\Bosch-2x ABS 6	√	√	√	√	√	
IVECO\Universal Area\EuroCargo\EuroCargo Restyling\8\80E17\Diesel injection\Bosch EDC 7	√	√	√	√		
IVECO\Universal Area\EuroCargo\EuroCargo Restyling\8\80E17\Suspensions\Wabco ECAS CAN 2 Iveco protocol	√	√	√	√	√	
IVECO\Universal Area\EuroCargo\EuroCargo Restyling\8\80E17\Suspensions\Wabco ECAS CAN 2 Wabco protocol	√	√	√	√	√	
IVECO\Universal Area\EuroCargo\EuroCargo Restyling\8\80E18\ABS\Bosch-2x ABS 6	√	√	√	√	√	
IVECO\Universal Area\EuroCargo\EuroCargo Restyling\8\80E18\Diesel injection\Bosch EDC 7	√	√	√	√		
IVECO\Universal Area\EuroCargo\EuroCargo Restyling\8\80E18\Suspensions\Wabco ECAS CAN 2 Iveco protocol	√	√	√	√	√	
IVECO\Universal Area\EuroCargo\EuroCargo Restyling\8\80E18\Suspensions\Wabco ECAS CAN 2 Wabco protocol	√	√	√	√	√	
IVECO\Universal Area\EuroCargo\EuroCargo Restyling\8\80E21\ABS\Bosch-2x ABS 6	√	√	√	√	√	
IVECO\Universal Area\EuroCargo\EuroCargo Restyling\8\80E21\Diesel injection\Bosch EDC 7	√	√	√	√		
IVECO\Universal Area\EuroCargo\EuroCargo Restyling\8\80E21\Suspensions\Wabco ECAS CAN 2 Iveco protocol	√	√	√	√	√	
IVECO\Universal Area\EuroCargo\EuroCargo Restyling\8\80E21\Suspensions\Wabco ECAS CAN 2 Wabco protocol	√	√	√	√	√	
IVECO\Universal Area\EuroCargo\EuroCargo Restyling\9\90E17\ABS\Bosch-2x ABS 6	√	√	√	√	√	
IVECO\Universal Area\EuroCargo\EuroCargo Restyling\9\90E17\Diesel injection\Bosch EDC 7	√	√	√	√		
IVECO\Universal Area\EuroCargo\EuroCargo Restyling\9\90E17\Suspensions\Wabco ECAS CAN 2 Iveco protocol	√	√	√	√	√	
IVECO\Universal Area\EuroCargo\EuroCargo Restyling\9\90E17\Suspensions\Wabco ECAS CAN 2 Wabco protocol	√	√	√	√	√	
IVECO\Universal Area\EuroCargo\EuroCargo Restyling\9\90E18\ABS\Bosch-2x ABS 6	√	√	√	√	√	
IVECO\Universal Area\EuroCargo\EuroCargo Restyling\9\90E18\Diesel injection\Bosch EDC 7	√	√	√	√		
IVECO\Universal Area\EuroCargo\EuroCargo Restyling\9\90E18\Suspensions\Wabco ECAS CAN 2 Iveco protocol	√	√	√	√	√	
IVECO\Universal Area\EuroCargo\EuroCargo Restyling\9\90E18\Suspensions\Wabco ECAS CAN 2 Wabco protocol	√	√	√	√	√	
IVECO\Universal Area\EuroCargo\EuroCargo Restyling\9\90E21\ABS\Bosch-2x ABS 6	√	√	√	√	√	
IVECO\Universal Area\EuroCargo\EuroCargo Restyling\9\90E21\Diesel injection\Bosch EDC 7	√	√	√	√		
IVECO\Universal Area\EuroCargo\EuroCargo Restyling\9\90E21\Suspensions\Wabco ECAS CAN 2 Iveco protocol	√	√	√	√	√	
IVECO\Universal Area\EuroCargo\EuroCargo Restyling\9\90E21\Suspensions\Wabco ECAS CAN 2 Wabco protocol	√	√	√	√	√	
IVECO\Universal Area\EuroCargo\EuroCargo Restyling Euro 4-Euro 5-EEV\1\100E18\ABS\Bosch-knorr ABS 6	√	√	√	√	√	
IVECO\Universal Area\EuroCargo\EuroCargo Restyling Euro 4-Euro 5-EEV\1\100E18\Body computer\Bosch IBC 3		√	√	√	√	
IVECO\Universal Area\EuroCargo\EuroCargo Restyling Euro 4-Euro 5-EEV\1\100E18\Chassis equipment and design\Expansion Module	√	√	√	√	√	
IVECO\Universal Area\EuroCargo\EuroCargo Restyling Euro 4-Euro 5-EEV\1\100E18\Chassis management system\MET	√	√	√	√	√	
IVECO\Universal Area\EuroCargo\EuroCargo Restyling Euro 4-Euro 5-EEV\1\100E18\Diesel injection\Bosch EDC 7 UC 31	√	√	√	√		
IVECO\Universal Area\EuroCargo\EuroCargo Restyling Euro 4-Euro 5-EEV\1\100E18\Diesel injection\Bosch Denoxtronic 2 Diagnosis	√	√	√	√	√	
IVECO\Universal Area\EuroCargo\EuroCargo Restyling Euro 4-Euro 5-EEV\1\100E18\Engine-vehicle adjustment\VCM	√	√	√	√		
IVECO\Universal Area\EuroCargo\EuroCargo Restyling Euro 4-Euro 5-EEV\1\100E18\Instrument panel\IC Eurocargo	√	√	√	√	√	

[illegible]

[illegible]

[illegible]

IVECO\Universal Area\EuroCargo\EuroCargo Restyling Euro 4-Euro 5-EEV\1\120EL18\Suspensions\Wabco ECAS CAN 2 Iveco protocol	√	√	√	√	√	
IVECO\Universal Area\EuroCargo\EuroCargo Restyling Euro 4-Euro 5-EEV\1\120EL18\Suspensions\Wabco ECAS CAN 2 Wabco protocol	√	√	√	√	√	
IVECO\Universal Area\EuroCargo\EuroCargo Restyling Euro 4-Euro 5-EEV\1\120EL18\Transmission\Allison Generation 4	√	√	√	√	√	
IVECO\Universal Area\EuroCargo\EuroCargo Restyling Euro 4-Euro 5-EEV\1\120EL18\Transmission\ZF AS-Tronic LITE	√	√	√	√	√	
IVECO\Universal Area\EuroCargo\EuroCargo Restyling Euro 4-Euro 5-EEV\1\120EL22\ABS\Bosch-knorr ABS 6	√	√	√	√	√	
IVECO\Universal Area\EuroCargo\EuroCargo Restyling Euro 4-Euro 5-EEV\1\120EL22\Body computer\Bosch IBC 3		√	√	√	√	
IVECO\Universal Area\EuroCargo\EuroCargo Restyling Euro 4-Euro 5-EEV\1\120EL22\Chassis equipment and design\Expansion Module	√	√	√	√	√	
IVECO\Universal Area\EuroCargo\EuroCargo Restyling Euro 4-Euro 5-EEV\1\120EL22\Chassis management system\MET	√	√	√	√	√	
IVECO\Universal Area\EuroCargo\EuroCargo Restyling Euro 4-Euro 5-EEV\1\120EL22\Diesel injection\Bosch EDC 7 UC 31	√	√	√	√		
IVECO\Universal Area\EuroCargo\EuroCargo Restyling Euro 4-Euro 5-EEV\1\120EL22\Diesel injection\Bosch Denoxtronic 2 Diagnosis	√	√	√	√	√	
IVECO\Universal Area\EuroCargo\EuroCargo Restyling Euro 4-Euro 5-EEV\1\120EL22\Engine-vehicle adjustment\VCM	√	√	√	√		
IVECO\Universal Area\EuroCargo\EuroCargo Restyling Euro 4-Euro 5-EEV\1\120EL22\Instrument panel\NC Eurocargo	√	√	√	√	√	
IVECO\Universal Area\EuroCargo\EuroCargo Restyling Euro 4-Euro 5-EEV\1\120EL22\Suspensions\Wabco ECAS CAN 2 Iveco protocol	√	√	√	√	√	
IVECO\Universal Area\EuroCargo\EuroCargo Restyling Euro 4-Euro 5-EEV\1\120EL22\Suspensions\Wabco ECAS CAN 2 Wabco protocol	√	√	√	√	√	
IVECO\Universal Area\EuroCargo\EuroCargo Restyling Euro 4-Euro 5-EEV\1\120EL22\Transmission\Allison Generation 4	√	√	√	√	√	
IVECO\Universal Area\EuroCargo\EuroCargo Restyling Euro 4-Euro 5-EEV\1\120EL22\Transmission\ZF AS-Tronic LITE	√	√	√	√	√	
IVECO\Universal Area\EuroCargo\EuroCargo Restyling Euro 4-Euro 5-EEV\1\130E18\ABS\Bosch-knorr ABS 6	√	√	√	√	√	
IVECO\Universal Area\EuroCargo\EuroCargo Restyling Euro 4-Euro 5-EEV\1\130E18\Body computer\Bosch IBC 3		√	√	√	√	
IVECO\Universal Area\EuroCargo\EuroCargo Restyling Euro 4-Euro 5-EEV\1\130E18\Chassis equipment and design\Expansion Module	√	√	√	√	√	
IVECO\Universal Area\EuroCargo\EuroCargo Restyling Euro 4-Euro 5-EEV\1\130E18\Chassis management system\MET	√	√	√	√	√	
IVECO\Universal Area\EuroCargo\EuroCargo Restyling Euro 4-Euro 5-EEV\1\130E18\Diesel injection\Bosch EDC 7 UC 31	√	√	√	√		
IVECO\Universal Area\EuroCargo\EuroCargo Restyling Euro 4-Euro 5-EEV\1\130E18\Diesel injection\Bosch Denoxtronic 2 Diagnosis	√	√	√	√	√	
IVECO\Universal Area\EuroCargo\EuroCargo Restyling Euro 4-Euro 5-EEV\1\130E18\Engine-vehicle adjustment\VCM	√	√	√	√		
IVECO\Universal Area\EuroCargo\EuroCargo Restyling Euro 4-Euro 5-EEV\1\130E18\Instrument panel\NC Eurocargo	√	√	√	√	√	
IVECO\Universal Area\EuroCargo\EuroCargo Restyling Euro 4-Euro 5-EEV\1\130E18\Suspensions\Wabco ECAS CAN 2 Iveco protocol	√	√	√	√	√	
IVECO\Universal Area\EuroCargo\EuroCargo Restyling Euro 4-Euro 5-EEV\1\130E18\Suspensions\Wabco ECAS CAN 2 Wabco protocol	√	√	√	√	√	
IVECO\Universal Area\EuroCargo\EuroCargo Restyling Euro 4-Euro 5-EEV\1\130E18\Transmission\Allison Generation 4	√	√	√	√	√	
IVECO\Universal Area\EuroCargo\EuroCargo Restyling Euro 4-Euro 5-EEV\1\130E18\Transmission\ZF AS-Tronic LITE	√	√	√	√	√	
IVECO\Universal Area\EuroCargo\EuroCargo Restyling Euro 4-Euro 5-EEV\1\130E25\ABS\Bosch-knorr ABS 6	√	√	√	√	√	
IVECO\Universal Area\EuroCargo\EuroCargo Restyling Euro 4-Euro 5-EEV\1\130E25\Body computer\Bosch IBC 3		√	√	√	√	
IVECO\Universal Area\EuroCargo\EuroCargo Restyling Euro 4-Euro 5-EEV\1\130E25\Chassis equipment and design\Expansion Module	√	√	√	√	√	
IVECO\Universal Area\EuroCargo\EuroCargo Restyling Euro 4-Euro 5-EEV\1\130E25\Chassis management system\MET	√	√	√	√	√	
IVECO\Universal Area\EuroCargo\EuroCargo Restyling Euro 4-Euro 5-EEV\1\130E25\Diesel injection\Bosch EDC 7 UC 31	√	√	√	√		
IVECO\Universal Area\EuroCargo\EuroCargo Restyling Euro 4-Euro 5-EEV\1\130E25\Diesel injection\Bosch Denoxtronic 2 Diagnosis	√	√	√	√	√	
IVECO\Universal Area\EuroCargo\EuroCargo Restyling Euro 4-Euro 5-EEV\1\130E25\Engine-vehicle adjustment\VCM	√	√	√	√		
IVECO\Universal Area\EuroCargo\EuroCargo Restyling Euro 4-Euro 5-EEV\1\130E25\Instrument panel\NC Eurocargo	√	√	√	√	√	
IVECO\Universal Area\EuroCargo\EuroCargo Restyling Euro 4-Euro 5-EEV\1\130E25\Suspensions\Wabco ECAS CAN 2 Iveco protocol	√	√	√	√	√	
IVECO\Universal Area\EuroCargo\EuroCargo Restyling Euro 4-Euro 5-EEV\1\130E25\Suspensions\Wabco ECAS CAN 2 Wabco protocol	√	√	√	√	√	
IVECO\Universal Area\EuroCargo\EuroCargo Restyling Euro 4-Euro 5-EEV\1\130E25\Transmission\Allison Generation 4	√	√	√	√	√	
IVECO\Universal Area\EuroCargo\EuroCargo Restyling Euro 4-Euro 5-EEV\1\130E25\Transmission\ZF AS-Tronic LITE	√	√	√	√	√	

[illegible]

[illegible]

[illegible]

[illegible]

IVECO\Universal Area\EuroCargo\EuroCargo Restyling Euro 4-Euro 5-EEV\1\160EL18\Diesel injection\Bosch EDC 7 UC 31	√	√	√	√		
IVECO\Universal Area\EuroCargo\EuroCargo Restyling Euro 4-Euro 5-EEV\1\160EL18\Diesel injection\Bosch Denoxtronic 2 Diagnosis	√	√	√	√	√	
IVECO\Universal Area\EuroCargo\EuroCargo Restyling Euro 4-Euro 5-EEV\1\160EL18\Engine-vehicle adjustment\VCM	√	√	√	√		
IVECO\Universal Area\EuroCargo\EuroCargo Restyling Euro 4-Euro 5-EEV\1\160EL18\Instrument panel\IC Eurocargo	√	√	√	√	√	
IVECO\Universal Area\EuroCargo\EuroCargo Restyling Euro 4-Euro 5-EEV\1\160EL18\Suspensions\Wabco ECAS CAN 2 Iveco protocol	√	√	√	√	√	
IVECO\Universal Area\EuroCargo\EuroCargo Restyling Euro 4-Euro 5-EEV\1\160EL18\Suspensions\Wabco ECAS CAN 2 Wabco protocol	√	√	√	√	√	
IVECO\Universal Area\EuroCargo\EuroCargo Restyling Euro 4-Euro 5-EEV\1\160EL18\Transmission\Allison Generation 4	√	√	√	√	√	
IVECO\Universal Area\EuroCargo\EuroCargo Restyling Euro 4-Euro 5-EEV\1\160EL18\Transmission\ZF AS-Tronic LITE	√	√	√	√	√	
IVECO\Universal Area\EuroCargo\EuroCargo Restyling Euro 4-Euro 5-EEV\1\160EL22\ABS\Bosch-knorr ABS 6	√	√	√	√	√	
IVECO\Universal Area\EuroCargo\EuroCargo Restyling Euro 4-Euro 5-EEV\1\160EL22\Body computer\Bosch IBC 3		√	√	√	√	
IVECO\Universal Area\EuroCargo\EuroCargo Restyling Euro 4-Euro 5-EEV\1\160EL22\Chassis equipment and design\Expansion Module	√	√	√	√	√	
IVECO\Universal Area\EuroCargo\EuroCargo Restyling Euro 4-Euro 5-EEV\1\160EL22\Chassis management system\MET	√	√	√	√	√	
IVECO\Universal Area\EuroCargo\EuroCargo Restyling Euro 4-Euro 5-EEV\1\160EL22\Diesel injection\Bosch EDC 7 UC 31	√	√	√	√		
IVECO\Universal Area\EuroCargo\EuroCargo Restyling Euro 4-Euro 5-EEV\1\160EL22\Diesel injection\Bosch Denoxtronic 2 Diagnosis	√	√	√	√	√	
IVECO\Universal Area\EuroCargo\EuroCargo Restyling Euro 4-Euro 5-EEV\1\160EL22\Engine-vehicle adjustment\VCM	√	√	√	√		
IVECO\Universal Area\EuroCargo\EuroCargo Restyling Euro 4-Euro 5-EEV\1\160EL22\Instrument panel\IC Eurocargo	√	√	√	√	√	
IVECO\Universal Area\EuroCargo\EuroCargo Restyling Euro 4-Euro 5-EEV\1\160EL22\Suspensions\Wabco ECAS CAN 2 Iveco protocol	√	√	√	√	√	
IVECO\Universal Area\EuroCargo\EuroCargo Restyling Euro 4-Euro 5-EEV\1\160EL22\Suspensions\Wabco ECAS CAN 2 Wabco protocol	√	√	√	√	√	
IVECO\Universal Area\EuroCargo\EuroCargo Restyling Euro 4-Euro 5-EEV\1\160EL22\Transmission\Allison Generation 4	√	√	√	√	√	
IVECO\Universal Area\EuroCargo\EuroCargo Restyling Euro 4-Euro 5-EEV\1\160EL22\Transmission\ZF AS-Tronic LITE	√	√	√	√	√	
IVECO\Universal Area\EuroCargo\EuroCargo Restyling Euro 4-Euro 5-EEV\1\180E25\ABS\Bosch-knorr ABS 6	√	√	√	√	√	
IVECO\Universal Area\EuroCargo\EuroCargo Restyling Euro 4-Euro 5-EEV\1\180E25\Body computer\Bosch IBC 3		√	√	√	√	
IVECO\Universal Area\EuroCargo\EuroCargo Restyling Euro 4-Euro 5-EEV\1\180E25\Chassis equipment and design\Expansion Module	√	√	√	√	√	
IVECO\Universal Area\EuroCargo\EuroCargo Restyling Euro 4-Euro 5-EEV\1\180E25\Chassis management system\MET	√	√	√	√	√	
IVECO\Universal Area\EuroCargo\EuroCargo Restyling Euro 4-Euro 5-EEV\1\180E25\Diesel injection\Bosch EDC 7 UC 31	√	√	√	√		
IVECO\Universal Area\EuroCargo\EuroCargo Restyling Euro 4-Euro 5-EEV\1\180E25\Diesel injection\Bosch Denoxtronic 2 Diagnosis	√	√	√	√	√	
IVECO\Universal Area\EuroCargo\EuroCargo Restyling Euro 4-Euro 5-EEV\1\180E25\Engine-vehicle adjustment\VCM	√	√	√	√		
IVECO\Universal Area\EuroCargo\EuroCargo Restyling Euro 4-Euro 5-EEV\1\180E25\Instrument panel\IC Eurocargo	√	√	√	√	√	
IVECO\Universal Area\EuroCargo\EuroCargo Restyling Euro 4-Euro 5-EEV\1\180E25\Suspensions\Wabco ECAS CAN 2 Iveco protocol	√	√	√	√	√	
IVECO\Universal Area\EuroCargo\EuroCargo Restyling Euro 4-Euro 5-EEV\1\180E25\Suspensions\Wabco ECAS CAN 2 Wabco protocol	√	√	√	√	√	
IVECO\Universal Area\EuroCargo\EuroCargo Restyling Euro 4-Euro 5-EEV\1\180E25\Transmission\Allison Generation 4	√	√	√	√	√	
IVECO\Universal Area\EuroCargo\EuroCargo Restyling Euro 4-Euro 5-EEV\1\180E25\Transmission\ZF AS-Tronic LITE	√	√	√	√	√	
IVECO\Universal Area\EuroCargo\EuroCargo Restyling Euro 4-Euro 5-EEV\1\180E28\ABS\Bosch-knorr ABS 6	√	√	√	√	√	
IVECO\Universal Area\EuroCargo\EuroCargo Restyling Euro 4-Euro 5-EEV\1\180E28\Body computer\Bosch IBC 3		√	√	√	√	
IVECO\Universal Area\EuroCargo\EuroCargo Restyling Euro 4-Euro 5-EEV\1\180E28\Chassis equipment and design\Expansion Module	√	√	√	√	√	
IVECO\Universal Area\EuroCargo\EuroCargo Restyling Euro 4-Euro 5-EEV\1\180E28\Chassis management system\MET	√	√	√	√	√	
IVECO\Universal Area\EuroCargo\EuroCargo Restyling Euro 4-Euro 5-EEV\1\180E28\Diesel injection\Bosch EDC 7 UC 31	√	√	√	√		
IVECO\Universal Area\EuroCargo\EuroCargo Restyling Euro 4-Euro 5-EEV\1\180E28\Diesel injection\Bosch Denoxtronic 2 Diagnosis	√	√	√	√	√	
IVECO\Universal Area\EuroCargo\EuroCargo Restyling Euro 4-Euro 5-EEV\1\180E28\Engine-vehicle adjustment\VCM	√	√	√	√		
IVECO\Universal Area\EuroCargo\EuroCargo Restyling Euro 4-Euro 5-EEV\1\180E28\Instrument panel\IC Eurocargo	√	√	√	√	√	

[illegible]

IVECO\Universal Area\EuroCargo\EuroCargo Restyling Euro 4-Euro 5-EEV\1\190E30\ABS\Bosch-knorr ABS 6	√	√	√	√	√	
IVECO\Universal Area\EuroCargo\EuroCargo Restyling Euro 4-Euro 5-EEV\1\190E30\Body computer\Bosch IBC 3		√	√	√	√	
IVECO\Universal Area\EuroCargo\EuroCargo Restyling Euro 4-Euro 5-EEV\1\190E30\Chassis equipment and design\Expansion Module	√	√	√	√	√	
IVECO\Universal Area\EuroCargo\EuroCargo Restyling Euro 4-Euro 5-EEV\1\190E30\Chassis management system\MET	√	√	√	√	√	
IVECO\Universal Area\EuroCargo\EuroCargo Restyling Euro 4-Euro 5-EEV\1\190E30\Diesel injection\Bosch EDC 7 UC 31	√	√	√	√		
IVECO\Universal Area\EuroCargo\EuroCargo Restyling Euro 4-Euro 5-EEV\1\190E30\Diesel injection\Bosch Denoxtronic 2 Diagnosis	√	√	√	√	√	
IVECO\Universal Area\EuroCargo\EuroCargo Restyling Euro 4-Euro 5-EEV\1\190E30\Engine-vehicle adjustment\VCM	√	√	√	√		
IVECO\Universal Area\EuroCargo\EuroCargo Restyling Euro 4-Euro 5-EEV\1\190E30\Instrument panel\IC Eurocargo	√	√	√	√	√	
IVECO\Universal Area\EuroCargo\EuroCargo Restyling Euro 4-Euro 5-EEV\1\190E30\Suspensions\Wabco ECAS CAN 2 Iveco protocol	√	√	√	√	√	
IVECO\Universal Area\EuroCargo\EuroCargo Restyling Euro 4-Euro 5-EEV\1\190E30\Suspensions\Wabco ECAS CAN 2 Wabco protocol	√	√	√	√	√	
IVECO\Universal Area\EuroCargo\EuroCargo Restyling Euro 4-Euro 5-EEV\1\190E30\Transmission\Allison Generation 4	√	√	√	√	√	
IVECO\Universal Area\EuroCargo\EuroCargo Restyling Euro 4-Euro 5-EEV\1\190E30\Transmission\ZF AS-Tronic LITE	√	√	√	√	√	
IVECO\Universal Area\EuroCargo\EuroCargo Restyling Euro 4-Euro 5-EEV\6\60E13\ABS\Bosch-knorr ABS 6	√	√	√	√	√	
IVECO\Universal Area\EuroCargo\EuroCargo Restyling Euro 4-Euro 5-EEV\6\60E13\Body computer\Bosch IBC 3		√	√	√	√	
IVECO\Universal Area\EuroCargo\EuroCargo Restyling Euro 4-Euro 5-EEV\6\60E13\Chassis equipment and design\Expansion Module	√	√	√	√	√	
IVECO\Universal Area\EuroCargo\EuroCargo Restyling Euro 4-Euro 5-EEV\6\60E13\Chassis management system\MET	√	√	√	√	√	
IVECO\Universal Area\EuroCargo\EuroCargo Restyling Euro 4-Euro 5-EEV\6\60E13\Diesel injection\Bosch EDC 7 UC 31	√	√	√	√		
IVECO\Universal Area\EuroCargo\EuroCargo Restyling Euro 4-Euro 5-EEV\6\60E13\Diesel injection\Bosch Denoxtronic 2 Diagnosis	√	√	√	√	√	
IVECO\Universal Area\EuroCargo\EuroCargo Restyling Euro 4-Euro 5-EEV\6\60E13\Engine-vehicle adjustment\VCM	√	√	√	√		
IVECO\Universal Area\EuroCargo\EuroCargo Restyling Euro 4-Euro 5-EEV\6\60E13\Instrument panel\IC Eurocargo	√	√	√	√	√	
IVECO\Universal Area\EuroCargo\EuroCargo Restyling Euro 4-Euro 5-EEV\6\60E13\Suspensions\Wabco ECAS CAN 2 Iveco protocol	√	√	√	√	√	
IVECO\Universal Area\EuroCargo\EuroCargo Restyling Euro 4-Euro 5-EEV\6\60E13\Suspensions\Wabco ECAS CAN 2 Wabco protocol	√	√	√	√	√	
IVECO\Universal Area\EuroCargo\EuroCargo Restyling Euro 4-Euro 5-EEV\6\60E13\Transmission\Allison Generation 4	√	√	√	√	√	
IVECO\Universal Area\EuroCargo\EuroCargo Restyling Euro 4-Euro 5-EEV\6\60E13\Transmission\ZF AS-Tronic LITE	√	√	√	√	√	
IVECO\Universal Area\EuroCargo\EuroCargo Restyling Euro 4-Euro 5-EEV\6\60E15\ABS\Bosch-knorr ABS 6	√	√	√	√	√	
IVECO\Universal Area\EuroCargo\EuroCargo Restyling Euro 4-Euro 5-EEV\6\60E15\Body computer\Bosch IBC 3		√	√	√	√	
IVECO\Universal Area\EuroCargo\EuroCargo Restyling Euro 4-Euro 5-EEV\6\60E15\Chassis equipment and design\Expansion Module	√	√	√	√	√	
IVECO\Universal Area\EuroCargo\EuroCargo Restyling Euro 4-Euro 5-EEV\6\60E15\Chassis management system\MET	√	√	√	√	√	
IVECO\Universal Area\EuroCargo\EuroCargo Restyling Euro 4-Euro 5-EEV\6\60E15\Diesel injection\Bosch EDC 7 UC 31	√	√	√	√		
IVECO\Universal Area\EuroCargo\EuroCargo Restyling Euro 4-Euro 5-EEV\6\60E15\Diesel injection\Bosch Denoxtronic 2 Diagnosis	√	√	√	√	√	
IVECO\Universal Area\EuroCargo\EuroCargo Restyling Euro 4-Euro 5-EEV\6\60E15\Engine-vehicle adjustment\VCM	√	√	√	√		
IVECO\Universal Area\EuroCargo\EuroCargo Restyling Euro 4-Euro 5-EEV\6\60E15\Instrument panel\IC Eurocargo	√	√	√	√	√	
IVECO\Universal Area\EuroCargo\EuroCargo Restyling Euro 4-Euro 5-EEV\6\60E15\Suspensions\Wabco ECAS CAN 2 Iveco protocol	√	√	√	√	√	
IVECO\Universal Area\EuroCargo\EuroCargo Restyling Euro 4-Euro 5-EEV\6\60E15\Suspensions\Wabco ECAS CAN 2 Wabco protocol	√	√	√	√	√	
IVECO\Universal Area\EuroCargo\EuroCargo Restyling Euro 4-Euro 5-EEV\6\60E15\Transmission\Allison Generation 4	√	√	√	√	√	
IVECO\Universal Area\EuroCargo\EuroCargo Restyling Euro 4-Euro 5-EEV\6\60E15\Transmission\ZF AS-Tronic LITE	√	√	√	√	√	
IVECO\Universal Area\EuroCargo\EuroCargo Restyling Euro 4-Euro 5-EEV\6\65E13\ABS\Bosch-knorr ABS 6	√	√	√	√	√	
IVECO\Universal Area\EuroCargo\EuroCargo Restyling Euro 4-Euro 5-EEV\6\65E13\Body computer\Bosch IBC 3		√	√	√	√	
IVECO\Universal Area\EuroCargo\EuroCargo Restyling Euro 4-Euro 5-EEV\6\65E13\Chassis equipment and design\Expansion Module	√	√	√	√	√	
IVECO\Universal Area\EuroCargo\EuroCargo Restyling Euro 4-Euro 5-EEV\6\65E13\Chassis management system\MET	√	√	√	√	√	

[illegible]

[illegible]

IVECO\Universal Area\EuroCargo\EuroCargo Restyling Euro 4-Euro 5-EEV\8\80E22\ABS\Bosch-knorr ABS 6	√	√	√	√	√	
IVECO\Universal Area\EuroCargo\EuroCargo Restyling Euro 4-Euro 5-EEV\8\80E22\Body computer\Bosch IBC 3		√	√	√	√	
IVECO\Universal Area\EuroCargo\EuroCargo Restyling Euro 4-Euro 5-EEV\8\80E22\Chassis equipment and design\Expansion Module	√	√	√	√	√	
IVECO\Universal Area\EuroCargo\EuroCargo Restyling Euro 4-Euro 5-EEV\8\80E22\Chassis management system\MET	√	√	√	√	√	
IVECO\Universal Area\EuroCargo\EuroCargo Restyling Euro 4-Euro 5-EEV\8\80E22\Diesel injection\Bosch EDC 7 UC 31	√	√	√	√		
IVECO\Universal Area\EuroCargo\EuroCargo Restyling Euro 4-Euro 5-EEV\8\80E22\Diesel injection\Bosch Denoxtronic 2 Diagnosis	√	√	√	√	√	
IVECO\Universal Area\EuroCargo\EuroCargo Restyling Euro 4-Euro 5-EEV\8\80E22\Engine-vehicle adjustment\VCM	√	√	√	√		
IVECO\Universal Area\EuroCargo\EuroCargo Restyling Euro 4-Euro 5-EEV\8\80E22\Instrument panel\IC Eurocargo	√	√	√	√	√	
IVECO\Universal Area\EuroCargo\EuroCargo Restyling Euro 4-Euro 5-EEV\8\80E22\Suspensions\Wabco ECAS CAN 2 Iveco protocol	√	√	√	√	√	
IVECO\Universal Area\EuroCargo\EuroCargo Restyling Euro 4-Euro 5-EEV\8\80E22\Suspensions\Wabco ECAS CAN 2 Wabco protocol	√	√	√	√	√	
IVECO\Universal Area\EuroCargo\EuroCargo Restyling Euro 4-Euro 5-EEV\8\80E22\Transmission\Allison Generation 4	√	√	√	√	√	
IVECO\Universal Area\EuroCargo\EuroCargo Restyling Euro 4-Euro 5-EEV\8\80E22\Transmission\ZF AS-Tronic LITE	√	√	√	√	√	
IVECO\Universal Area\EuroCargo\EuroCargo Restyling Euro 4-Euro 5-EEV\9\90E18\ABS\Bosch-knorr ABS 6	√	√	√	√	√	
IVECO\Universal Area\EuroCargo\EuroCargo Restyling Euro 4-Euro 5-EEV\9\90E18\Body computer\Bosch IBC 3		√	√	√	√	
IVECO\Universal Area\EuroCargo\EuroCargo Restyling Euro 4-Euro 5-EEV\9\90E18\Chassis equipment and design\Expansion Module	√	√	√	√	√	
IVECO\Universal Area\EuroCargo\EuroCargo Restyling Euro 4-Euro 5-EEV\9\90E18\Chassis management system\MET	√	√	√	√	√	
IVECO\Universal Area\EuroCargo\EuroCargo Restyling Euro 4-Euro 5-EEV\9\90E18\Diesel injection\Bosch EDC 7 UC 31	√	√	√	√		
IVECO\Universal Area\EuroCargo\EuroCargo Restyling Euro 4-Euro 5-EEV\9\90E18\Diesel injection\Bosch Denoxtronic 2 Diagnosis	√	√	√	√	√	
IVECO\Universal Area\EuroCargo\EuroCargo Restyling Euro 4-Euro 5-EEV\9\90E18\Engine-vehicle adjustment\VCM	√	√	√	√		
IVECO\Universal Area\EuroCargo\EuroCargo Restyling Euro 4-Euro 5-EEV\9\90E18\Instrument panel\IC Eurocargo	√	√	√	√	√	
IVECO\Universal Area\EuroCargo\EuroCargo Restyling Euro 4-Euro 5-EEV\9\90E18\Suspensions\Wabco ECAS CAN 2 Iveco protocol	√	√	√	√	√	
IVECO\Universal Area\EuroCargo\EuroCargo Restyling Euro 4-Euro 5-EEV\9\90E18\Suspensions\Wabco ECAS CAN 2 Wabco protocol	√	√	√	√	√	
IVECO\Universal Area\EuroCargo\EuroCargo Restyling Euro 4-Euro 5-EEV\9\90E18\Transmission\Allison Generation 4	√	√	√	√	√	
IVECO\Universal Area\EuroCargo\EuroCargo Restyling Euro 4-Euro 5-EEV\9\90E18\Transmission\ZF AS-Tronic LITE	√	√	√	√	√	
IVECO\Universal Area\EuroCargo\EuroCargo Restyling Euro 4-Euro 5-EEV\9\90E22\ABS\Bosch-knorr ABS 6	√	√	√	√	√	
IVECO\Universal Area\EuroCargo\EuroCargo Restyling Euro 4-Euro 5-EEV\9\90E22\Body computer\Bosch IBC 3		√	√	√	√	
IVECO\Universal Area\EuroCargo\EuroCargo Restyling Euro 4-Euro 5-EEV\9\90E22\Chassis equipment and design\Expansion Module	√	√	√	√	√	
IVECO\Universal Area\EuroCargo\EuroCargo Restyling Euro 4-Euro 5-EEV\9\90E22\Chassis management system\MET	√	√	√	√	√	
IVECO\Universal Area\EuroCargo\EuroCargo Restyling Euro 4-Euro 5-EEV\9\90E22\Diesel injection\Bosch EDC 7 UC 31	√	√	√	√		
IVECO\Universal Area\EuroCargo\EuroCargo Restyling Euro 4-Euro 5-EEV\9\90E22\Diesel injection\Bosch Denoxtronic 2 Diagnosis	√	√	√	√	√	
IVECO\Universal Area\EuroCargo\EuroCargo Restyling Euro 4-Euro 5-EEV\9\90E22\Engine-vehicle adjustment\VCM	√	√	√	√		
IVECO\Universal Area\EuroCargo\EuroCargo Restyling Euro 4-Euro 5-EEV\9\90E22\Instrument panel\IC Eurocargo	√	√	√	√	√	
IVECO\Universal Area\EuroCargo\EuroCargo Restyling Euro 4-Euro 5-EEV\9\90E22\Suspensions\Wabco ECAS CAN 2 Iveco protocol	√	√	√	√	√	
IVECO\Universal Area\EuroCargo\EuroCargo Restyling Euro 4-Euro 5-EEV\9\90E22\Suspensions\Wabco ECAS CAN 2 Wabco protocol	√	√	√	√	√	
IVECO\Universal Area\EuroCargo\EuroCargo Restyling Euro 4-Euro 5-EEV\9\90E22\Transmission\Allison Generation 4	√	√	√	√	√	
IVECO\Universal Area\EuroCargo\EuroCargo Restyling Euro 4-Euro 5-EEV\9\90E22\Transmission\ZF AS-Tronic LITE	√	√	√	√	√	
IVECO\Universal Area\EuroTrakker\2004\Brake\ABS\Abs Wabco D-E-E2		√	√	√	√	
IVECO\Universal Area\EuroTrakker\2004\Brake\EBS\Ebs-Ebs 2	√	√	√	√	√	
IVECO\Universal Area\EuroTrakker\2004\Gearbox\Gearbox\Eurotronic 2\Fault codes, Real time data	√	√	√	√	√	
IVECO\Universal Area\EuroTrakker\2004\Gearbox\Gearbox\Eurotronic 2\Activations					√	

IVECO\Universal Area\EuroTrakker\2004\Multifunction\Driver Door Module\Diagnose		√	√	√	√	
IVECO\Universal Area\EuroTrakker\2004\Multifunction\Passenger Door Module\Diagnose		√	√	√	√	
IVECO\Universal Area\EuroTrakker\2003\Brake\ABS\Abs Wabco D-E-E2		√	√	√	√	
IVECO\Universal Area\EuroTrakker\2003\Brake\EBS\Ebs-Ebs 2	√	√	√	√	√	
IVECO\Universal Area\EuroTrakker\2003\Gearbox\Gearbox\Eurotronic 2\Fault codes, Real time data	√	√	√	√	√	
IVECO\Universal Area\EuroTrakker\2003\Gearbox\Gearbox\Eurotronic 2\Activations					√	
IVECO\Universal Area\EuroTrakker\2003\Multifunction\Driver Door Module\Diagnose		√	√	√	√	
IVECO\Universal Area\EuroTrakker\2003\Multifunction\Passenger Door Module\Diagnose		√	√	√	√	
IVECO\Universal Area\EuroTrakker\2002\Brake\ABS\Abs Wabco D-E-E2		√	√	√	√	
IVECO\Universal Area\EuroTrakker\2002\Brake\EBS\Ebs-Ebs 2	√	√	√	√	√	
IVECO\Universal Area\EuroTrakker\2002\Gearbox\Gearbox\Eurotronic 2\Fault codes, Real time data	√	√	√	√	√	
IVECO\Universal Area\EuroTrakker\2002\Gearbox\Gearbox\Eurotronic 2\Activations					√	
IVECO\Universal Area\EuroTrakker\2002\Multifunction\Driver Door Module\Diagnose		√	√	√	√	
IVECO\Universal Area\EuroTrakker\2002\Multifunction\Passenger Door Module\Diagnose		√	√	√	√	
IVECO\Universal Area\EuroMover\1\180E24\ABS\Wabco D E E2	√	√	√	√	√	
IVECO\Universal Area\EuroMover\1\180E24\EBS\Wabco EBS Iveco protocol	√	√	√	√	√	
IVECO\Universal Area\EuroMover\1\180E24\EBS\Wabco EBS Wabco protocol	√	√	√	√	√	
IVECO\Universal Area\EuroMover\1\180E24\Immobilizer\Bosch EDC unlock 3	√				√	
IVECO\Universal Area\EuroMover\1\180E27\EBS\Wabco EBS Iveco protocol	√	√	√	√	√	
IVECO\Universal Area\EuroMover\1\180E27\EBS\Wabco EBS Wabco protocol	√	√	√	√	√	
IVECO\Universal Area\EuroMover\1\180E30\ABS\Wabco D E E2	√	√	√	√	√	
IVECO\Universal Area\EuroMover\1\180E30\EBS\Wabco EBS Iveco protocol	√	√	√	√	√	
IVECO\Universal Area\EuroMover\1\180E30\EBS\Wabco EBS Wabco protocol	√	√	√	√	√	
IVECO\Universal Area\EuroMover\1\180E30\Immobilizer\Bosch EDC unlock 3	√				√	
IVECO\Universal Area\EuroMover\1\180E34\EBS\Wabco EBS Iveco protocol	√	√	√	√	√	
IVECO\Universal Area\EuroMover\1\180E34\EBS\Wabco EBS Wabco protocol	√	√	√	√	√	
IVECO\Universal Area\EuroMover\1\180E38\EBS\Wabco EBS Iveco protocol	√	√	√	√	√	
IVECO\Universal Area\EuroMover\1\180E38\EBS\Wabco EBS Wabco protocol	√	√	√	√	√	
IVECO\Universal Area\EuroMover\1\180E42\EBS\Wabco EBS Iveco protocol	√	√	√	√	√	
IVECO\Universal Area\EuroMover\1\180E42\EBS\Wabco EBS Wabco protocol	√	√	√	√	√	
IVECO\Universal Area\EuroMover\1\190E24\ABS\Wabco D E E2	√	√	√	√	√	
IVECO\Universal Area\EuroMover\1\190E24\EBS\Wabco EBS Iveco protocol	√	√	√	√	√	
IVECO\Universal Area\EuroMover\1\190E24\EBS\Wabco EBS Wabco protocol	√	√	√	√	√	
IVECO\Universal Area\EuroMover\1\190E24\Immobilizer\Bosch EDC unlock 3	√				√	
IVECO\Universal Area\EuroMover\1\190E27\ABS\Wabco D E E2	√	√	√	√	√	
IVECO\Universal Area\EuroMover\1\190E27\EBS\Wabco EBS Iveco protocol	√	√	√	√	√	
IVECO\Universal Area\EuroMover\1\190E27\EBS\Wabco EBS Wabco protocol	√	√	√	√	√	
IVECO\Universal Area\EuroMover\1\190E27\Immobilizer\Bosch EDC unlock 3	√				√	
IVECO\Universal Area\EuroMover\1\190E30\ABS\Wabco D E E2	√	√	√	√	√	
IVECO\Universal Area\EuroMover\1\190E30\EBS\Wabco EBS Iveco protocol	√	√	√	√	√	

[illegible]

[illegible]

IVECO\Universal Area\EuroMover\4\440E40\EBS\Wabco EBS Wabco protocol	√	√	√	√	√	
IVECO\Universal Area\EuroMover\4\440E40\Immobilizer\Bosch EDC unlock 3	√				√	
IVECO\Universal Area\EuroMover\4\440E43\EBS\Wabco EBS Iveco protocol	√	√	√	√	√	
IVECO\Universal Area\EuroMover\4\440E43\EBS\Wabco EBS Wabco protocol	√	√	√	√	√	
IVECO\Universal Area\EuroMover\4\440E43\Immobilizer\Bosch EDC unlock 3	√				√	
IVECO\Universal Area\Daily\Daily[00-06]\2006\Diesel\8140.43 2.8L\EDC MS 6.3(38 pin)		√	√	√	√	
IVECO\Universal Area\Daily\Daily[00-06]\2006\Diesel\F1A 2.3L\EDC 16(38 pin)		√	√	√	√	
IVECO\Universal Area\Daily\Daily[00-06]\2006\Diesel\F1C 3.0L\EDC 16(38 pin)		√	√	√	√	
IVECO\Universal Area\Daily\Daily[00-06]\2006\Brake\ABS\ABS 5.3	√			√		
IVECO\Universal Area\Daily\Daily[00-06]\2006\Brake\ESP\ABS 8-ASR 8-ESP 8 Bosch	√	√	√	√		
IVECO\Universal Area\Daily\Daily[00-06]\2006\Gearbox\Gearbox\ESV1 Agile		√	√	√		
IVECO\Universal Area\Daily\Daily[00-06]\2005\Diesel\8140.43 2.8L\EDC MS 6.3(38 pin)		√	√	√	√	
IVECO\Universal Area\Daily\Daily[00-06]\2005\Diesel\F1A 2.3L\EDC 16(38 pin)		√	√	√	√	
IVECO\Universal Area\Daily\Daily[00-06]\2005\Diesel\F1C 3.0L\EDC 16(38 pin)		√	√	√	√	
IVECO\Universal Area\Daily\Daily[00-06]\2005\Brake\ABS\ABS 5.3	√			√		
IVECO\Universal Area\Daily\Daily[00-06]\2005\Brake\ESP\ABS 8-ASR 8-ESP 8 Bosch	√	√	√	√		
IVECO\Universal Area\Daily\Daily[00-06]\2005\Gearbox\Gearbox\ESV1 Agile		√	√	√		
IVECO\Universal Area\Daily\Daily[00-06]\2004\Diesel\8140.43 2.8L\EDC MS 6.3(38 pin)		√	√	√	√	
IVECO\Universal Area\Daily\Daily[00-06]\2004\Diesel\F1A 2.3L\EDC 16(38 pin)		√	√	√	√	
IVECO\Universal Area\Daily\Daily[00-06]\2004\Diesel\F1C 3.0L\EDC 16(38 pin)		√	√	√	√	
IVECO\Universal Area\Daily\Daily[00-06]\2004\Brake\ABS\ABS 5.3	√			√		
IVECO\Universal Area\Daily\Daily[00-06]\2004\Brake\ESP\ABS 8-ASR 8-ESP 8 Bosch	√	√	√	√		
IVECO\Universal Area\Daily\Daily[00-06]\2004\Gearbox\Gearbox\ESV1 Agile		√	√	√		
IVECO\Universal Area\Daily\Daily[00-06]\2003\Diesel\8140.43 2.8L\EDC MS 6.3(38 pin)		√	√	√	√	
IVECO\Universal Area\Daily\Daily[00-06]\2003\Diesel\F1A 2.3L\EDC 16(38 pin)		√	√	√	√	
IVECO\Universal Area\Daily\Daily[00-06]\2003\Diesel\F1C 3.0L\EDC 16(38 pin)		√	√	√	√	
IVECO\Universal Area\Daily\Daily[00-06]\2003\Brake\ABS\ABS 5.3	√			√		
IVECO\Universal Area\Daily\Daily[00-06]\2003\Brake\ESP\ABS 8-ASR 8-ESP 8 Bosch	√	√	√	√		
IVECO\Universal Area\Daily\Daily[00-06]\2003\Gearbox\Gearbox\ESV1 Agile		√	√	√		
IVECO\Universal Area\Daily\Daily[00-06]\2002\Diesel\8140.43 2.8L\EDC MS 6.3(38 pin)		√	√	√	√	
IVECO\Universal Area\Daily\Daily[00-06]\2002\Diesel\F1A 2.3L\EDC 16(38 pin)		√	√	√	√	
IVECO\Universal Area\Daily\Daily[00-06]\2002\Diesel\F1C 3.0L\EDC 16(38 pin)		√	√	√	√	
IVECO\Universal Area\Daily\Daily[00-06]\2002\Brake\ABS\ABS 5.3	√			√		
IVECO\Universal Area\Daily\Daily[00-06]\2002\Brake\ESP\ABS 8-ASR 8-ESP 8 Bosch	√	√	√	√		
IVECO\Universal Area\Daily\Daily[00-06]\2002\Gearbox\Gearbox\ESV1 Agile		√	√	√		
IVECO\Universal Area\Daily\Daily[00-06]\2001\Diesel\8140.43 2.8L\EDC MS 6.3(38 pin)		√	√	√	√	
IVECO\Universal Area\Daily\Daily[00-06]\2001\Diesel\F1A 2.3L\EDC 16(38 pin)		√	√	√	√	
IVECO\Universal Area\Daily\Daily[00-06]\2001\Diesel\F1C 3.0L\EDC 16(38 pin)		√	√	√	√	
IVECO\Universal Area\Daily\Daily[00-06]\2001\Brake\ABS\ABS 5.3	√			√		
IVECO\Universal Area\Daily\Daily[00-06]\2001\Brake\ESP\ABS 8-ASR 8-ESP 8 Bosch	√	√	√	√		

IVECO\Universal Area\Daily\Daily[00-06]\2001\Gearbox\Gearbox\ESV1 Agile		√	√	√		
IVECO\Universal Area\Daily\Daily[00-06]\2000\Diesel\8140.43 2.8L\EDC MS 6.3(38 pin)		√	√	√	√	
IVECO\Universal Area\Daily\Daily[00-06]\2000\Diesel\F1A 2.3L\EDC 16(38 pin)		√	√	√	√	
IVECO\Universal Area\Daily\Daily[00-06]\2000\Diesel\F1C 3.0L\EDC 16(38 pin)		√	√	√	√	
IVECO\Universal Area\Daily\Daily[00-06]\2000\Brake\ABS\ABS 5.3	√			√		
IVECO\Universal Area\Daily\Daily[00-06]\2000\Brake\ESP\ABS 8-ASR 8-ESP 8 Bosch	√	√	√	√		
IVECO\Universal Area\Daily\Daily[00-06]\2000\Gearbox\Gearbox\ESV1 Agile		√	√	√		
IVECO\Universal Area\Daily\Daily[06-11]\2011\Petrol\Engine control\5SF Methane CNG - ECM	√	√	√	√	√	
IVECO\Universal Area\Daily\Daily[06-11]\2011\Diesel\F1A 2.3L\Bosch EDC 16 C39		√	√	√	√	
IVECO\Universal Area\Daily\Daily[06-11]\2011\Diesel\F1A 2.3L\Bosch EDC 17	√			√	√	
IVECO\Universal Area\Daily\Daily[06-11]\2011\Diesel\F1C 3.0L\Bosch EDC 16 C39		√	√	√	√	
IVECO\Universal Area\Daily\Daily[06-11]\2011\Diesel\F1C 3.0L\Bosch EDC 17	√			√	√	
IVECO\Universal Area\Daily\Daily[06-11]\2011\Brake\ABS\ABS 5.3	√			√		
IVECO\Universal Area\Daily\Daily[06-11]\2011\Brake\ESP\ABS 8-ASR 8-ESP 8 Bosch CAN	√	√	√	√	√	
IVECO\Universal Area\Daily\Daily[06-11]\2011\Instrument\Dashboard\Marelli dashboard	√			√	√	
IVECO\Universal Area\Daily\Daily[06-11]\2011\Climate\Auxiliary heating\Webasto TT	√	√	√	√	√	
IVECO\Universal Area\Daily\Daily[06-11]\2011\Gearbox\Gearbox\ESV1 Agile CAN		√	√	√		
IVECO\Universal Area\Daily\Daily[06-11]\2011\Restraints\Airbag\Airbag Autoliv	√			√	√	
IVECO\Universal Area\Daily\Daily[06-11]\2011\Multifunction\Iveco body controller\Marelli	√			√	√	
IVECO\Universal Area\Daily\Daily[06-11]\2011\Multifunction\Tachograph\DTCO VDO	√			√		
IVECO\Universal Area\Daily\Daily[06-11]\2011\Service Light Reset(SLR)\Reset service\Start					√	
IVECO\Universal Area\Daily\Daily[06-11]\2011\Suspension\Air Suspension\Wabco type ecas	√			√		
IVECO\Universal Area\Daily\Daily[06-11]\2010\Petrol\Engine control\5SF Methane CNG - ECM	√	√	√	√	√	
IVECO\Universal Area\Daily\Daily[06-11]\2010\Diesel\F1A 2.3L\Bosch EDC 16 C39		√	√	√	√	
IVECO\Universal Area\Daily\Daily[06-11]\2010\Diesel\F1C 3.0L\Bosch EDC 16 C39		√	√	√	√	
IVECO\Universal Area\Daily\Daily[06-11]\2010\Brake\ABS\ABS 5.3	√			√		
IVECO\Universal Area\Daily\Daily[06-11]\2010\Brake\ESP\ABS 8-ASR 8-ESP 8 Bosch CAN	√	√	√	√	√	
IVECO\Universal Area\Daily\Daily[06-11]\2010\Instrument\Dashboard\Marelli dashboard	√			√	√	
IVECO\Universal Area\Daily\Daily[06-11]\2010\Climate\Auxiliary heating\Webasto TT	√	√	√	√	√	
IVECO\Universal Area\Daily\Daily[06-11]\2010\Gearbox\Gearbox\ESV1 Agile CAN		√	√	√		
IVECO\Universal Area\Daily\Daily[06-11]\2010\Restraints\Airbag\Airbag Autoliv	√			√	√	
IVECO\Universal Area\Daily\Daily[06-11]\2010\Multifunction\Iveco body controller\Marelli	√			√	√	
IVECO\Universal Area\Daily\Daily[06-11]\2010\Multifunction\Tachograph\DTCO VDO	√			√		
IVECO\Universal Area\Daily\Daily[06-11]\2010\Service Light Reset(SLR)\Reset service\Start					√	
IVECO\Universal Area\Daily\Daily[06-11]\2010\Suspension\Air Suspension\Wabco type ecas	√			√		
IVECO\Universal Area\Daily\Daily[06-11]\2009\Petrol\Engine control\5SF Methane CNG - ECM	√	√	√	√	√	
IVECO\Universal Area\Daily\Daily[06-11]\2009\Diesel\F1A 2.3L\Bosch EDC 16 C39		√	√	√	√	
IVECO\Universal Area\Daily\Daily[06-11]\2009\Diesel\F1C 3.0L\Bosch EDC 16 C39		√	√	√	√	
IVECO\Universal Area\Daily\Daily[06-11]\2009\Brake\ABS\ABS 5.3	√			√		
IVECO\Universal Area\Daily\Daily[06-11]\2009\Brake\ESP\ABS 8-ASR 8-ESP 8 Bosch CAN	√	√	√	√	√	

IVECO\Universal Area\Daily\Daily[06-11]\2009\Instrument\Dashboard\Marelli dashboard	√			√	√	
IVECO\Universal Area\Daily\Daily[06-11]\2009\Climate\Auxiliary heating\Webasto TT	√	√	√	√	√	
IVECO\Universal Area\Daily\Daily[06-11]\2009\Gearbox\Gearbox\ESV1 Agile CAN		√	√	√		
IVECO\Universal Area\Daily\Daily[06-11]\2009\Restraints\Airbag\Airbag Autoliv	√			√	√	
IVECO\Universal Area\Daily\Daily[06-11]\2009\Multifunction\Iveco body controller\Marelli	√			√	√	
IVECO\Universal Area\Daily\Daily[06-11]\2009\Multifunction\Tachograph\DTCO VDO	√			√		
IVECO\Universal Area\Daily\Daily[06-11]\2009\Service Light Reset(SLR)\Reset service\Start					√	
IVECO\Universal Area\Daily\Daily[06-11]\2009\Suspension\Air Suspension\Wabco type ecas	√			√		
IVECO\Universal Area\Daily\Daily[06-11]\2008\Petrol\Engine control\5SF Methane CNG - ECM	√	√	√	√	√	
IVECO\Universal Area\Daily\Daily[06-11]\2008\Diesel\F1A 2.3L\Bosch EDC 16 C39		√	√	√	√	
IVECO\Universal Area\Daily\Daily[06-11]\2008\Diesel\F1C 3.0L\Bosch EDC 16 C39		√	√	√	√	
IVECO\Universal Area\Daily\Daily[06-11]\2008\Brake\ABS\ABS 5.3	√			√		
IVECO\Universal Area\Daily\Daily[06-11]\2008\Brake\ESP\ABS 8-ASR 8-ESP 8 Bosch CAN	√	√	√	√	√	
IVECO\Universal Area\Daily\Daily[06-11]\2008\Instrument\Dashboard\Marelli dashboard	√			√	√	
IVECO\Universal Area\Daily\Daily[06-11]\2008\Climate\Auxiliary heating\Webasto TT	√	√	√	√	√	
IVECO\Universal Area\Daily\Daily[06-11]\2008\Gearbox\Gearbox\ESV1 Agile CAN		√	√	√		
IVECO\Universal Area\Daily\Daily[06-11]\2008\Restraints\Airbag\Airbag Autoliv	√			√	√	
IVECO\Universal Area\Daily\Daily[06-11]\2008\Multifunction\Iveco body controller\Marelli	√			√	√	
IVECO\Universal Area\Daily\Daily[06-11]\2008\Multifunction\Tachograph\DTCO VDO	√			√		
IVECO\Universal Area\Daily\Daily[06-11]\2008\Service Light Reset(SLR)\Reset service\Start					√	
IVECO\Universal Area\Daily\Daily[06-11]\2008\Suspension\Air Suspension\Wabco type ecas	√			√		
IVECO\Universal Area\Daily\Daily[06-11]\2007\Petrol\Engine control\5SF Methane CNG - ECM	√	√	√	√	√	
IVECO\Universal Area\Daily\Daily[06-11]\2007\Diesel\F1A 2.3L\Bosch EDC 16 C39		√	√	√	√	
IVECO\Universal Area\Daily\Daily[06-11]\2007\Diesel\F1C 3.0L\Bosch EDC 16 C39		√	√	√	√	
IVECO\Universal Area\Daily\Daily[06-11]\2007\Brake\ABS\ABS 5.3	√			√		
IVECO\Universal Area\Daily\Daily[06-11]\2007\Brake\ESP\ABS 8-ASR 8-ESP 8 Bosch CAN	√	√	√	√	√	
IVECO\Universal Area\Daily\Daily[06-11]\2007\Instrument\Dashboard\Marelli dashboard	√			√	√	
IVECO\Universal Area\Daily\Daily[06-11]\2007\Climate\Auxiliary heating\Webasto TT	√	√	√	√	√	
IVECO\Universal Area\Daily\Daily[06-11]\2007\Gearbox\Gearbox\ESV1 Agile CAN		√	√	√		
IVECO\Universal Area\Daily\Daily[06-11]\2007\Restraints\Airbag\Airbag Autoliv	√			√	√	
IVECO\Universal Area\Daily\Daily[06-11]\2007\Multifunction\Iveco body controller\Marelli	√			√	√	
IVECO\Universal Area\Daily\Daily[06-11]\2007\Multifunction\Tachograph\DTCO VDO	√			√		
IVECO\Universal Area\Daily\Daily[06-11]\2007\Service Light Reset(SLR)\Reset service\Start					√	
IVECO\Universal Area\Daily\Daily[06-11]\2007\Suspension\Air Suspension\Wabco type ecas	√			√		
IVECO\Universal Area\Daily\Daily[06-11]\2006\Petrol\Engine control\5SF Methane CNG - ECM	√	√	√	√	√	
IVECO\Universal Area\Daily\Daily[06-11]\2006\Diesel\F1A 2.3L\Bosch EDC 16 C39		√	√	√	√	
IVECO\Universal Area\Daily\Daily[06-11]\2006\Diesel\F1C 3.0L\Bosch EDC 16 C39		√	√	√	√	
IVECO\Universal Area\Daily\Daily[06-11]\2006\Brake\ABS\ABS 5.3	√			√		
IVECO\Universal Area\Daily\Daily[06-11]\2006\Brake\ESP\ABS 8-ASR 8-ESP 8 Bosch CAN	√	√	√	√	√	
IVECO\Universal Area\Daily\Daily[06-11]\2006\Instrument\Dashboard\Marelli dashboard	√			√	√	

IVECO\Universal Area\Daily\Daily[06-11]\2006\Climate\Auxiliary heating\Webasto TT	√	√	√	√	√	
IVECO\Universal Area\Daily\Daily[06-11]\2006\Gearbox\Gearbox\ESV1 Agile CAN		√	√	√		
IVECO\Universal Area\Daily\Daily[06-11]\2006\Restraints\Airbag\Airbag Autoliv	√			√	√	
IVECO\Universal Area\Daily\Daily[06-11]\2006\Multifunction\Iveco body controller\Marelli	√			√	√	
IVECO\Universal Area\Daily\Daily[06-11]\2006\Multifunction\Tachograph\DTCO VDO	√			√		
IVECO\Universal Area\Daily\Daily[06-11]\2006\Service Light Reset(SLR)\Reset service\Start					√	
IVECO\Universal Area\Daily\Daily[06-11]\2006\Suspension\Air Suspension\Wabco type ecas	√			√		
IVECO\Universal Area\Daily\Daily[12-]\2013\Petrol\Engine control\5SF Methane CNG - ECM	√	√	√	√	√	
IVECO\Universal Area\Daily\Daily[12-]\2013\Diesel\F1A 2.3L\Bosch EDC 17	√			√	√	
IVECO\Universal Area\Daily\Daily[12-]\2013\Diesel\F1C 3.0L\Bosch EDC 17	√			√	√	
IVECO\Universal Area\Daily\Daily[12-]\2013\Brake\ESP-BSM\ABS9-ASR9-ESP9-BSM	√			√	√	
IVECO\Universal Area\Daily\Daily[12-]\2013\Instrument\Dashboard\Marelli dashboard-IPC	√			√		
IVECO\Universal Area\Daily\Daily[12-]\2013\Climate\Climate control\Webasto TT heater-AHCU	√	√	√	√	√	
IVECO\Universal Area\Daily\Daily[12-]\2013\Restraints\Airbag\Airbag Autoliv-SDM	√			√	√	
IVECO\Universal Area\Daily\Daily[12-]\2013\Multifunction\Body computer\Body computer marelli-BCM	√			√		
IVECO\Universal Area\Daily\Daily[12-]\2013\Suspension\Air Suspension\Wabco type ecas - ASCU	√			√		
IVECO\Universal Area\Daily\Daily[12-]\2012\Petrol\Engine control\5SF Methane CNG - ECM	√	√	√	√	√	
IVECO\Universal Area\Daily\Daily[12-]\2012\Diesel\F1A 2.3L\Bosch EDC 17	√			√	√	
IVECO\Universal Area\Daily\Daily[12-]\2012\Diesel\F1C 3.0L\Bosch EDC 17	√			√	√	
IVECO\Universal Area\Daily\Daily[12-]\2012\Brake\ESP-BSM\ABS9-ASR9-ESP9-BSM	√			√	√	
IVECO\Universal Area\Daily\Daily[12-]\2012\Instrument\Dashboard\Marelli dashboard-IPC	√			√		
IVECO\Universal Area\Daily\Daily[12-]\2012\Climate\Climate control\Webasto TT heater-AHCU	√	√	√	√	√	
IVECO\Universal Area\Daily\Daily[12-]\2012\Restraints\Airbag\Airbag Autoliv-SDM	√			√	√	
IVECO\Universal Area\Daily\Daily[12-]\2012\Multifunction\Body computer\Body computer marelli-BCM	√			√		
IVECO\Universal Area\Daily\Daily[12-]\2012\Suspension\Air Suspension\Wabco type ecas - ASCU	√			√		
IVECO\Universal Area\Daily\Daily 2012\System selection\2.3 DIESEL\Engine\BOSCH EDC 17\System diagnosis	√	√	√	√	√	
IVECO\Universal Area\Daily\Daily 2012\System selection\2.3 DIESEL\Engine\BOSCH EDC 17\Service reset	√	√	√			
IVECO\Universal Area\Daily\Daily 2012\System selection\2.3 DIESEL\Engine\BOSCH EDC 17\Service reset-engine oil	√	√	√		√	
IVECO\Universal Area\Daily\Daily 2012\System selection\2.3 DIESEL\Engine\BOSCH EDC 17\Fap regeneration	√	√	√			
IVECO\Universal Area\Daily\Daily 2012\System selection\2.3 DIESEL\Engine\BOSCH EDC 17\Service reset-fap filter	√	√	√			
IVECO\Universal Area\Daily\Daily 2012\System selection\2.3 DIESEL\Engine\BOSCH EDC 17\Injectors coding	√	√	√			
IVECO\Universal Area\Daily\Daily 2012\System selection\2.3 DIESEL\ABS-traction control-ESP	√	√	√	√	√	
IVECO\Universal Area\Daily\Daily 2012\System selection\2.3 DIESEL\Airbag	√			√		
IVECO\Universal Area\Daily\Daily 2012\System selection\2.3 DIESEL\Instrument cluster	√	√	√	√		
IVECO\Universal Area\Daily\Daily 2012\System selection\2.3 DIESEL\Body Computer	√	√	√	√		
IVECO\Universal Area\Daily\Daily 2012\System selection\2.3 DIESEL\Gearbox Electronics	√	√	√	√		
IVECO\Universal Area\Daily\Daily 2012\System selection\2.3 DIESEL\Steering Angle Control	√	√	√	√		
IVECO\Universal Area\Daily\Daily 2012\System selection\2.3 DIESEL\Particulate Filte Regeneration	√	√	√	√		
IVECO\Universal Area\Daily\Daily 2012\System selection\2.3 DIESEL\Second Body Computer	√	√	√	√		
IVECO\Universal Area\Daily\Daily 2012\System selection\3.0 CNG BIFUEL\Engine\IAW_5SF	√	√	√	√	√	

IVECO\Universal Area\Daily\Daily 2012\System selection\3.0 CNG BIFUEL\ABS-traction control-ESP	√	√	√	√	√	
IVECO\Universal Area\Daily\Daily 2012\System selection\3.0 CNG BIFUEL\Airbag	√			√		
IVECO\Universal Area\Daily\Daily 2012\System selection\3.0 CNG BIFUEL\Instrument cluster	√	√	√	√		
IVECO\Universal Area\Daily\Daily 2012\System selection\3.0 CNG BIFUEL\Body Computer	√	√	√	√		
IVECO\Universal Area\Daily\Daily 2012\System selection\3.0 CNG BIFUEL\Gearbox Electronics	√	√	√	√		
IVECO\Universal Area\Daily\Daily 2012\System selection\3.0 CNG BIFUEL\Steering Angle Control	√	√	√	√		
IVECO\Universal Area\Daily\Daily 2012\System selection\3.0 CNG BIFUEL\Second Body Computer	√	√	√	√		
IVECO\Universal Area\Daily\Daily 2012\System selection\3.0 DIESEL\Engine\BOSCH EDC 17\System diagnosis	√	√	√	√	√	
IVECO\Universal Area\Daily\Daily 2012\System selection\3.0 DIESEL\Engine\BOSCH EDC 17\Service reset	√	√	√			
IVECO\Universal Area\Daily\Daily 2012\System selection\3.0 DIESEL\Engine\BOSCH EDC 17\Service reset-engine oil	√	√	√		√	
IVECO\Universal Area\Daily\Daily 2012\System selection\3.0 DIESEL\Engine\BOSCH EDC 17\Fap regeneration	√	√	√			
IVECO\Universal Area\Daily\Daily 2012\System selection\3.0 DIESEL\Engine\BOSCH EDC 17\Service reset-fap filter	√	√	√			
IVECO\Universal Area\Daily\Daily 2012\System selection\3.0 DIESEL\Engine\BOSCH EDC 17\Injectors coding	√	√	√			
IVECO\Universal Area\Daily\Daily 2012\System selection\3.0 DIESEL\ABS-traction control-ESP	√	√	√	√	√	
IVECO\Universal Area\Daily\Daily 2012\System selection\3.0 DIESEL\Airbag	√			√		
IVECO\Universal Area\Daily\Daily 2012\System selection\3.0 DIESEL\Instrument cluster	√	√	√	√		
IVECO\Universal Area\Daily\Daily 2012\System selection\3.0 DIESEL\Body Computer	√	√	√	√		
IVECO\Universal Area\Daily\Daily 2012\System selection\3.0 DIESEL\Gearbox Electronics	√	√	√	√		
IVECO\Universal Area\Daily\Daily 2012\System selection\3.0 DIESEL\Steering Angle Control	√	√	√	√		
IVECO\Universal Area\Daily\Daily 2012\System selection\3.0 DIESEL\Particulate Filte Regeneration	√	√	√	√		
IVECO\Universal Area\Daily\Daily 2012\System selection\3.0 DIESEL\Second Body Computer	√	√	√	√		
IVECO\Universal Area\Daily\Daily 2012\Usual services\MAINTENANCE-SERVICE RESET\Service reset	√	√	√			
IVECO\Universal Area\Daily\Daily 2012\Usual services\MAINTENANCE-SERVICE RESET\Service reset-engine oil	√	√	√		√	
IVECO\Universal Area\Daily\Daily 2012\Usual services\BRAKES-EPB\BRAKE EPB BLEEDING	√	√	√			
IVECO\Universal Area\Daily\Daily 2012\Usual services\DPF-OIL ADDITIVE	√	√	√			
IVECO\Universal Area\Daily\Daily 2012\Usual services\TPMS-STEERING-SUSPENSIONS	√	√	√			
IVECO\Universal Area\Daily\Daily 2013\System selection\2.3 DIESEL\Engine\BOSCH EDC 17\System diagnosis	√	√	√	√	√	
IVECO\Universal Area\Daily\Daily 2013\System selection\2.3 DIESEL\Engine\BOSCH EDC 17\Service reset	√	√	√			
IVECO\Universal Area\Daily\Daily 2013\System selection\2.3 DIESEL\Engine\BOSCH EDC 17\Service reset-engine oil	√	√	√		√	
IVECO\Universal Area\Daily\Daily 2013\System selection\2.3 DIESEL\Engine\BOSCH EDC 17\Fap regeneration	√	√	√			
IVECO\Universal Area\Daily\Daily 2013\System selection\2.3 DIESEL\Engine\BOSCH EDC 17\Service reset-fap filter	√	√	√			
IVECO\Universal Area\Daily\Daily 2013\System selection\2.3 DIESEL\Engine\BOSCH EDC 17\Injectors coding	√	√	√			
IVECO\Universal Area\Daily\Daily 2013\System selection\2.3 DIESEL\ABS-traction control-ESP	√	√	√	√	√	
IVECO\Universal Area\Daily\Daily 2013\System selection\2.3 DIESEL\Airbag	√			√		
IVECO\Universal Area\Daily\Daily 2013\System selection\2.3 DIESEL\Instrument cluster	√	√	√	√		
IVECO\Universal Area\Daily\Daily 2013\System selection\2.3 DIESEL\Body Computer	√	√	√	√		
IVECO\Universal Area\Daily\Daily 2013\System selection\2.3 DIESEL\Gearbox Electronics	√	√	√	√		
IVECO\Universal Area\Daily\Daily 2013\System selection\2.3 DIESEL\Steering Angle Control	√	√	√	√		
IVECO\Universal Area\Daily\Daily 2013\System selection\2.3 DIESEL\Particulate Filte Regeneration	√	√	√	√		
IVECO\Universal Area\Daily\Daily 2013\System selection\2.3 DIESEL\Second Body Computer	√	√	√	√		

IVECO\Universal Area\Daily\Daily 2013\System selection\3.0 CNG BIFUEL\Engine\IAW_5SF	√	√	√	√	√	
IVECO\Universal Area\Daily\Daily 2013\System selection\3.0 CNG BIFUEL\ABS-traction control-ESP	√	√	√	√	√	
IVECO\Universal Area\Daily\Daily 2013\System selection\3.0 CNG BIFUEL\Airbag	√			√		
IVECO\Universal Area\Daily\Daily 2013\System selection\3.0 CNG BIFUEL\Instrument cluster	√	√	√	√		
IVECO\Universal Area\Daily\Daily 2013\System selection\3.0 CNG BIFUEL\Body Computer	√	√	√	√		
IVECO\Universal Area\Daily\Daily 2013\System selection\3.0 CNG BIFUEL\Gearbox Electronics	√	√	√	√		
IVECO\Universal Area\Daily\Daily 2013\System selection\3.0 CNG BIFUEL\Steering Angle Control	√	√	√	√		
IVECO\Universal Area\Daily\Daily 2013\System selection\3.0 CNG BIFUEL\Second Body Computer	√	√	√	√		
IVECO\Universal Area\Daily\Daily 2013\System selection\3.0 DIESEL\Engine\BOSCH EDC 17\System diagnosis	√	√	√	√	√	
IVECO\Universal Area\Daily\Daily 2013\System selection\3.0 DIESEL\Engine\BOSCH EDC 17\Service reset	√	√	√			
IVECO\Universal Area\Daily\Daily 2013\System selection\3.0 DIESEL\Engine\BOSCH EDC 17\Service reset-engine oil	√	√	√		√	
IVECO\Universal Area\Daily\Daily 2013\System selection\3.0 DIESEL\Engine\BOSCH EDC 17\Fap regeneration	√	√	√			
IVECO\Universal Area\Daily\Daily 2013\System selection\3.0 DIESEL\Engine\BOSCH EDC 17\Service reset-fap filter	√	√	√			
IVECO\Universal Area\Daily\Daily 2013\System selection\3.0 DIESEL\Engine\BOSCH EDC 17\Injectors coding	√	√	√			
IVECO\Universal Area\Daily\Daily 2013\System selection\3.0 DIESEL\ABS-traction control-ESP	√	√	√	√	√	
IVECO\Universal Area\Daily\Daily 2013\System selection\3.0 DIESEL\Airbag	√			√		
IVECO\Universal Area\Daily\Daily 2013\System selection\3.0 DIESEL\Instrument cluster	√	√	√	√		
IVECO\Universal Area\Daily\Daily 2013\System selection\3.0 DIESEL\Body Computer	√	√	√	√		
IVECO\Universal Area\Daily\Daily 2013\System selection\3.0 DIESEL\Gearbox Electronics	√	√	√	√		
IVECO\Universal Area\Daily\Daily 2013\System selection\3.0 DIESEL\Steering Angle Control	√	√	√	√		
IVECO\Universal Area\Daily\Daily 2013\System selection\3.0 DIESEL\Particulate Filte Regeneration	√	√	√	√		
IVECO\Universal Area\Daily\Daily 2013\System selection\3.0 DIESEL\Second Body Computer	√	√	√	√		
IVECO\Universal Area\Daily\Daily 2013\Usual services\MAINTENANCE-SERVICE RESET\Service reset	√	√	√			
IVECO\Universal Area\Daily\Daily 2013\Usual services\MAINTENANCE-SERVICE RESET\Service reset-engine oil	√	√	√		√	
IVECO\Universal Area\Daily\Daily 2013\Usual services\BRAKES-EPB\BRAKE EPB BLEEDING	√	√	√			
IVECO\Universal Area\Daily\Daily 2013\Usual services\DPF-OIL ADDITIVE	√	√	√			
IVECO\Universal Area\Daily\Daily 2013\Usual services\TPMS-STEERING-SUSPENSIONS	√	√	√			
IVECO\Universal Area\Daily\Daily 2014\2.3 MJ DIESEL\Engine\EDC 17C49 ECM\System diagnosis	√	√	√	√		
IVECO\Universal Area\Daily\Daily 2014\2.3 MJ DIESEL\ABS6\ABS-traction control-ESP	√	√	√	√		
IVECO\Universal Area\Daily\Daily 2014\2.3 MJ DIESEL\Airbag	√	√	√	√		
IVECO\Universal Area\Daily\Daily 2014\2.3 MJ DIESEL\Instrument cluster	√	√	√	√		
IVECO\Universal Area\Daily\Daily 2014\2.3 MJ DIESEL\Body Computer	√	√	√	√		
IVECO\Universal Area\Daily\Daily 2014\2.3 MJ DIESEL\Autoradio	√	√	√	√		
IVECO\Universal Area\Daily\Daily 2014\2.3 MJ DIESEL\Parking Assist	√	√	√	√		
IVECO\Universal Area\Daily\Daily 2014\2.3 MJ DIESEL\Lane change indicator	√			√		
IVECO\Universal Area\Daily\Daily 2014\3.0 CNG BIFUEL\Engine\5SF-ECM	√	√	√	√	√	0003, 0005, 0006
IVECO\Universal Area\Daily\Daily 2014\3.0 CNG BIFUEL\ABS6\ABS-traction control-ESP	√	√	√	√		
IVECO\Universal Area\Daily\Daily 2014\3.0 CNG BIFUEL\Airbag	√	√	√	√		
IVECO\Universal Area\Daily\Daily 2014\3.0 CNG BIFUEL\Instrument cluster	√	√	√	√		
IVECO\Universal Area\Daily\Daily 2014\3.0 CNG BIFUEL\Body Computer	√	√	√	√		

IVECO\Universal Area\Daily\Daily 2014\3.0 CNG BIFUEL\Autoradio	√	√	√	√		
IVECO\Universal Area\Daily\Daily 2014\3.0 CNG BIFUEL\Parking Assist	√	√	√	√		
IVECO\Universal Area\Daily\Daily 2014\3.0 CNG BIFUEL\Lane change indicator	√			√		
IVECO\Universal Area\Daily\Daily 2014\3.0 MJ DIESEL\Engine\EDC 17C49 ECM\System diagnosis	√	√	√	√		
IVECO\Universal Area\Daily\Daily 2014\3.0 MJ DIESEL\ABS6\ABS-traction control-ESP	√	√	√	√		
IVECO\Universal Area\Daily\Daily 2014\3.0 MJ DIESEL\Airbag	√	√	√	√		
IVECO\Universal Area\Daily\Daily 2014\3.0 MJ DIESEL\Instrument cluster	√	√	√	√		
IVECO\Universal Area\Daily\Daily 2014\3.0 MJ DIESEL\Body Computer	√	√	√	√		
IVECO\Universal Area\Daily\Daily 2014\3.0 MJ DIESEL\Autoradio	√	√	√	√		
IVECO\Universal Area\Daily\Daily 2014\3.0 MJ DIESEL\Parking Assist	√	√	√	√		
IVECO\Universal Area\Daily\Daily 2014\3.0 MJ DIESEL\Lane change indicator	√			√		
IVECO\Universal Area\Daily\Daily 2015\2.3 MJ DIESEL\Engine\EDC 17C49 ECM\System diagnosis	√	√	√	√		
IVECO\Universal Area\Daily\Daily 2015\2.3 MJ DIESEL\ABS6\ABS-traction control-ESP	√	√	√	√		
IVECO\Universal Area\Daily\Daily 2015\2.3 MJ DIESEL\Airbag	√	√	√	√		
IVECO\Universal Area\Daily\Daily 2015\2.3 MJ DIESEL\Instrument cluster	√	√	√	√		
IVECO\Universal Area\Daily\Daily 2015\2.3 MJ DIESEL\Body Computer	√	√	√	√		
IVECO\Universal Area\Daily\Daily 2015\2.3 MJ DIESEL\Autoradio	√	√	√	√		
IVECO\Universal Area\Daily\Daily 2015\2.3 MJ DIESEL\Parking Assist	√	√	√	√		
IVECO\Universal Area\Daily\Daily 2015\2.3 MJ DIESEL\Lane change indicator	√			√		
IVECO\Universal Area\Daily\Daily 2015\3.0 CNG BIFUEL\Engine\5SF-ECM	√	√	√	√	√	0003, 0005, 0006
IVECO\Universal Area\Daily\Daily 2015\3.0 CNG BIFUEL\ABS6\ABS-traction control-ESP	√	√	√	√		
IVECO\Universal Area\Daily\Daily 2015\3.0 CNG BIFUEL\Airbag	√	√	√	√		
IVECO\Universal Area\Daily\Daily 2015\3.0 CNG BIFUEL\Instrument cluster	√	√	√	√		
IVECO\Universal Area\Daily\Daily 2015\3.0 CNG BIFUEL\Body Computer	√	√	√	√		
IVECO\Universal Area\Daily\Daily 2015\3.0 CNG BIFUEL\Autoradio	√	√	√	√		
IVECO\Universal Area\Daily\Daily 2015\3.0 CNG BIFUEL\Parking Assist	√	√	√	√		
IVECO\Universal Area\Daily\Daily 2015\3.0 CNG BIFUEL\Lane change indicator	√			√		
IVECO\Universal Area\Daily\Daily 2015\3.0 MJ DIESEL\Engine\EDC 17C49 ECM\System diagnosis	√	√	√	√		
IVECO\Universal Area\Daily\Daily 2015\3.0 MJ DIESEL\ABS6\ABS-traction control-ESP	√	√	√	√		
IVECO\Universal Area\Daily\Daily 2015\3.0 MJ DIESEL\Airbag	√	√	√	√		
IVECO\Universal Area\Daily\Daily 2015\3.0 MJ DIESEL\Instrument cluster	√	√	√	√		
IVECO\Universal Area\Daily\Daily 2015\3.0 MJ DIESEL\Body Computer	√	√	√	√		
IVECO\Universal Area\Daily\Daily 2015\3.0 MJ DIESEL\Autoradio	√	√	√	√		
IVECO\Universal Area\Daily\Daily 2015\3.0 MJ DIESEL\Parking Assist	√	√	√	√		
IVECO\Universal Area\Daily\Daily 2015\3.0 MJ DIESEL\Lane change indicator	√			√		
IVECO\Universal Area\Daily\Daily 2016\2.3 MJ DIESEL\Engine\EDC 17C49 ECM\System diagnosis	√	√	√	√		
IVECO\Universal Area\Daily\Daily 2016\2.3 MJ DIESEL\ABS6\ABS-traction control-ESP	√	√	√	√		
IVECO\Universal Area\Daily\Daily 2016\2.3 MJ DIESEL\Airbag	√	√	√	√		
IVECO\Universal Area\Daily\Daily 2016\2.3 MJ DIESEL\Instrument cluster	√	√	√	√		
IVECO\Universal Area\Daily\Daily 2016\2.3 MJ DIESEL\Body Computer	√	√	√	√		

IVECO\Universal Area\Daily\Daily 2016\2.3 MJ DIESEL\Autoradio	√	√	√	√		
IVECO\Universal Area\Daily\Daily 2016\2.3 MJ DIESEL\Parking Assist	√	√	√	√		
IVECO\Universal Area\Daily\Daily 2016\2.3 MJ DIESEL\Lane change indicator	√			√		
IVECO\Universal Area\Daily\Daily 2016\3.0 CNG BIFUEL\Engine\5SF-ECM	√	√	√	√	√	0003, 0005, 0006
IVECO\Universal Area\Daily\Daily 2016\3.0 CNG BIFUEL\ABS6\ABS-traction control-ESP	√	√	√	√		
IVECO\Universal Area\Daily\Daily 2016\3.0 CNG BIFUEL\Airbag	√	√	√	√		
IVECO\Universal Area\Daily\Daily 2016\3.0 CNG BIFUEL\Instrument cluster	√	√	√	√		
IVECO\Universal Area\Daily\Daily 2016\3.0 CNG BIFUEL\Body Computer	√	√	√	√		
IVECO\Universal Area\Daily\Daily 2016\3.0 CNG BIFUEL\Autoradio	√	√	√	√		
IVECO\Universal Area\Daily\Daily 2016\3.0 CNG BIFUEL\Parking Assist	√	√	√	√		
IVECO\Universal Area\Daily\Daily 2016\3.0 CNG BIFUEL\Lane change indicator	√			√		
IVECO\Universal Area\Daily\Daily 2016\3.0 MJ DIESEL\Engine\EDC 17C49 ECM\System diagnosis	√	√	√	√		
IVECO\Universal Area\Daily\Daily 2016\3.0 MJ DIESEL\ABS6\ABS-traction control-ESP	√	√	√	√		
IVECO\Universal Area\Daily\Daily 2016\3.0 MJ DIESEL\Airbag	√	√	√	√		
IVECO\Universal Area\Daily\Daily 2016\3.0 MJ DIESEL\Instrument cluster	√	√	√	√		
IVECO\Universal Area\Daily\Daily 2016\3.0 MJ DIESEL\Body Computer	√	√	√	√		
IVECO\Universal Area\Daily\Daily 2016\3.0 MJ DIESEL\Autoradio	√	√	√	√		
IVECO\Universal Area\Daily\Daily 2016\3.0 MJ DIESEL\Parking Assist	√	√	√	√		
IVECO\Universal Area\Daily\Daily 2016\3.0 MJ DIESEL\Lane change indicator	√			√		
IVECO\Universal Area\Daily\Daily 2017\2.3 MJ DIESEL\Engine\EDC 17C49 ECM\System diagnosis	√	√	√	√		
IVECO\Universal Area\Daily\Daily 2017\2.3 MJ DIESEL\ABS6\ABS-traction control-ESP	√	√	√	√		
IVECO\Universal Area\Daily\Daily 2017\2.3 MJ DIESEL\Airbag	√	√	√	√		
IVECO\Universal Area\Daily\Daily 2017\2.3 MJ DIESEL\Instrument cluster	√	√	√	√		
IVECO\Universal Area\Daily\Daily 2017\2.3 MJ DIESEL\Body Computer	√	√	√	√		
IVECO\Universal Area\Daily\Daily 2017\2.3 MJ DIESEL\Autoradio	√	√	√	√		
IVECO\Universal Area\Daily\Daily 2017\2.3 MJ DIESEL\Parking Assist	√	√	√	√		
IVECO\Universal Area\Daily\Daily 2017\2.3 MJ DIESEL\Lane change indicator	√			√		
IVECO\Universal Area\Daily\Daily 2017\3.0 CNG BIFUEL\Engine\5SF-ECM	√	√	√	√	√	0003, 0005, 0006
IVECO\Universal Area\Daily\Daily 2017\3.0 CNG BIFUEL\ABS6\ABS-traction control-ESP	√	√	√	√		
IVECO\Universal Area\Daily\Daily 2017\3.0 CNG BIFUEL\Airbag	√	√	√	√		
IVECO\Universal Area\Daily\Daily 2017\3.0 CNG BIFUEL\Instrument cluster	√	√	√	√		
IVECO\Universal Area\Daily\Daily 2017\3.0 CNG BIFUEL\Body Computer	√	√	√	√		
IVECO\Universal Area\Daily\Daily 2017\3.0 CNG BIFUEL\Autoradio	√	√	√	√		
IVECO\Universal Area\Daily\Daily 2017\3.0 CNG BIFUEL\Parking Assist	√	√	√	√		
IVECO\Universal Area\Daily\Daily 2017\3.0 CNG BIFUEL\Lane change indicator	√			√		
IVECO\Universal Area\Daily\Daily 2017\3.0 MJ DIESEL\Engine\EDC 17C49 ECM\System diagnosis	√	√	√	√		
IVECO\Universal Area\Daily\Daily 2017\3.0 MJ DIESEL\ABS6\ABS-traction control-ESP	√	√	√	√		
IVECO\Universal Area\Daily\Daily 2017\3.0 MJ DIESEL\Airbag	√	√	√	√		
IVECO\Universal Area\Daily\Daily 2017\3.0 MJ DIESEL\Instrument cluster	√	√	√	√		
IVECO\Universal Area\Daily\Daily 2017\3.0 MJ DIESEL\Body Computer	√	√	√	√		

IVECO\Universal Area\Daily\Daily 2017\3.0 MJ DIESEL\Autoradio	√	√	√	√		
IVECO\Universal Area\Daily\Daily 2017\3.0 MJ DIESEL\Parking Assist	√	√	√	√		
IVECO\Universal Area\Daily\Daily 2017\3.0 MJ DIESEL\Lane change indicator	√			√		
IVECO\Universal Area\Powerstar\2012\Diesel\AdBlue system\Denoxtronic	√	√	√	√	√	
IVECO\Universal Area\Powerstar\2012\Diesel\AdBlue system\Denoxtronic 2	√	√	√	√	√	0002, 0004, 0008, 0010, 0011
IVECO\Universal Area\Powerstar\2012\Diesel\Engine control\EDC 7 UC31	√	√	√	√	√	
IVECO\Universal Area\Powerstar\2012\Brake\ABS\Abs Wabco D-E-E2		√	√	√	√	
IVECO\Universal Area\Powerstar\2012\Brake\EBS\Ebs-Ebs 2	√	√	√	√	√	
IVECO\Universal Area\Powerstar\2012\Instrument\Dashboard\Instrument cluster	√	√	√	√	√	
IVECO\Universal Area\Powerstar\2012\Climate\Auxiliary heater\Air heater	√	√	√	√	√	
IVECO\Universal Area\Powerstar\2012\Climate\Auxiliary heater\Water heater	√	√	√	√	√	
IVECO\Universal Area\Powerstar\2012\Climate\Climate control\Webasto		√	√	√	√	
IVECO\Universal Area\Powerstar\2012\Gearbox\Gearbox\Eurotronic 2\Fault codes, Real time data	√	√	√	√	√	
IVECO\Universal Area\Powerstar\2012\Gearbox\Gearbox\Eurotronic 2\Activations					√	
IVECO\Universal Area\Powerstar\2012\Multifunction\Body computer\Diagnose		√	√	√	√	
IVECO\Universal Area\Powerstar\2012\Multifunction\Driver Door Module\Diagnose		√	√	√	√	
IVECO\Universal Area\Powerstar\2012\Multifunction\Front interface module\Diagnose		√	√	√	√	
IVECO\Universal Area\Powerstar\2012\Multifunction\Passenger Door Module\Diagnose		√	√	√	√	
IVECO\Universal Area\Powerstar\2012\Multifunction\Rear interface module\Diagnose		√	√	√	√	
IVECO\Universal Area\Powerstar\2012\Multifunction\VCM-Immobilizer\Diagnose	√	√	√	√		
IVECO\Universal Area\Powerstar\2012\Suspension\Air Suspension\Ecas Wabco can\Rear air	√	√	√	√	√	0001
IVECO\Universal Area\Powerstar\2012\Suspension\Air Suspension\Ecas Wabco can\Full air	√	√	√	√	√	0001
IVECO\Universal Area\Powerstar\2011\Diesel\AdBlue system\Denoxtronic	√	√	√	√	√	
IVECO\Universal Area\Powerstar\2011\Diesel\AdBlue system\Denoxtronic 2	√	√	√	√	√	0002, 0004, 0008, 0010, 0011
IVECO\Universal Area\Powerstar\2011\Diesel\Engine control\EDC 7 UC31	√	√	√	√	√	
IVECO\Universal Area\Powerstar\2011\Brake\ABS\Abs Wabco D-E-E2		√	√	√	√	
IVECO\Universal Area\Powerstar\2011\Brake\EBS\Ebs-Ebs 2	√	√	√	√	√	
IVECO\Universal Area\Powerstar\2011\Instrument\Dashboard\Instrument cluster	√	√	√	√	√	
IVECO\Universal Area\Powerstar\2011\Climate\Auxiliary heater\Air heater	√	√	√	√	√	
IVECO\Universal Area\Powerstar\2011\Climate\Auxiliary heater\Water heater	√	√	√	√	√	
IVECO\Universal Area\Powerstar\2011\Climate\Climate control\Webasto		√	√	√	√	
IVECO\Universal Area\Powerstar\2011\Gearbox\Gearbox\Eurotronic 2\Fault codes, Real time data	√	√	√	√	√	
IVECO\Universal Area\Powerstar\2011\Gearbox\Gearbox\Eurotronic 2\Activations					√	
IVECO\Universal Area\Powerstar\2011\Multifunction\Body computer\Diagnose		√	√	√	√	
IVECO\Universal Area\Powerstar\2011\Multifunction\Driver Door Module\Diagnose		√	√	√	√	
IVECO\Universal Area\Powerstar\2011\Multifunction\Front interface module\Diagnose		√	√	√	√	
IVECO\Universal Area\Powerstar\2011\Multifunction\Passenger Door Module\Diagnose		√	√	√	√	
IVECO\Universal Area\Powerstar\2011\Multifunction\Rear interface module\Diagnose		√	√	√	√	
IVECO\Universal Area\Powerstar\2011\Multifunction\VCM-Immobilizer\Diagnose	√	√	√	√		
IVECO\Universal Area\Powerstar\2011\Suspension\Air Suspension\Ecas Wabco can\Rear air	√	√	√	√	√	0001

IVECO\Universal Area\Powerstar\2011\Suspension\Air Suspension\Ecas Wabco can\Full air	√	√	√	√	√	0001
IVECO\Universal Area\Powerstar\2010\Diesel\AdBlue system\Denoxtronic	√	√	√	√	√	
IVECO\Universal Area\Powerstar\2010\Diesel\AdBlue system\Denoxtronic 2	√	√	√	√	√	0002, 0004, 0008, 0010, 0011
IVECO\Universal Area\Powerstar\2010\Diesel\Engine control\EDC 7 UC31	√	√	√	√	√	
IVECO\Universal Area\Powerstar\2010\Brake\ABS\Abs Wabco D-E-E2		√	√	√	√	
IVECO\Universal Area\Powerstar\2010\Brake\EBS\Ebs-Ebs 2	√	√	√	√	√	
IVECO\Universal Area\Powerstar\2010\Instrument\Dashboard\Instrument cluster	√	√	√	√	√	
IVECO\Universal Area\Powerstar\2010\Climate\Auxiliary heater\Air heater	√	√	√	√	√	
IVECO\Universal Area\Powerstar\2010\Climate\Auxiliary heater\Water heater	√	√	√	√	√	
IVECO\Universal Area\Powerstar\2010\Climate\Climate control\Webasto		√	√	√	√	
IVECO\Universal Area\Powerstar\2010\Gearbox\Gearbox\Eurotronic 2\Fault codes, Real time data	√	√	√	√	√	
IVECO\Universal Area\Powerstar\2010\Gearbox\Gearbox\Eurotronic 2\Activations					√	
IVECO\Universal Area\Powerstar\2010\Multifunction\Body computer\Diagnose		√	√	√	√	
IVECO\Universal Area\Powerstar\2010\Multifunction\Driver Door Module\Diagnose		√	√	√	√	
IVECO\Universal Area\Powerstar\2010\Multifunction\Front interface module\Diagnose		√	√	√	√	
IVECO\Universal Area\Powerstar\2010\Multifunction\Passenger Door Module\Diagnose		√	√	√	√	
IVECO\Universal Area\Powerstar\2010\Multifunction\Rear interface module\Diagnose		√	√	√	√	
IVECO\Universal Area\Powerstar\2010\Multifunction\VCM-Immobilizer\Diagnose	√	√	√	√		
IVECO\Universal Area\Powerstar\2010\Suspension\Air Suspension\Ecas Wabco can\Rear air	√	√	√	√	√	0001
IVECO\Universal Area\Powerstar\2010\Suspension\Air Suspension\Ecas Wabco can\Full air	√	√	√	√	√	0001
IVECO\Universal Area\Powerstar\2009\Diesel\AdBlue system\Denoxtronic	√	√	√	√	√	
IVECO\Universal Area\Powerstar\2009\Diesel\AdBlue system\Denoxtronic 2	√	√	√	√	√	0002, 0004, 0008, 0010, 0011
IVECO\Universal Area\Powerstar\2009\Diesel\Engine control\EDC 7 UC31	√	√	√	√	√	
IVECO\Universal Area\Powerstar\2009\Brake\ABS\Abs Wabco D-E-E2		√	√	√	√	
IVECO\Universal Area\Powerstar\2009\Brake\EBS\Ebs-Ebs 2	√	√	√	√	√	
IVECO\Universal Area\Powerstar\2009\Instrument\Dashboard\Instrument cluster	√	√	√	√	√	
IVECO\Universal Area\Powerstar\2009\Climate\Auxiliary heater\Air heater	√	√	√	√	√	
IVECO\Universal Area\Powerstar\2009\Climate\Auxiliary heater\Water heater	√	√	√	√	√	
IVECO\Universal Area\Powerstar\2009\Climate\Climate control\Webasto		√	√	√	√	
IVECO\Universal Area\Powerstar\2009\Gearbox\Gearbox\Eurotronic 2\Fault codes, Real time data	√	√	√	√	√	
IVECO\Universal Area\Powerstar\2009\Gearbox\Gearbox\Eurotronic 2\Activations					√	
IVECO\Universal Area\Powerstar\2009\Multifunction\Body computer\Diagnose		√	√	√	√	
IVECO\Universal Area\Powerstar\2009\Multifunction\Driver Door Module\Diagnose		√	√	√	√	
IVECO\Universal Area\Powerstar\2009\Multifunction\Front interface module\Diagnose		√	√	√	√	
IVECO\Universal Area\Powerstar\2009\Multifunction\Passenger Door Module\Diagnose		√	√	√	√	
IVECO\Universal Area\Powerstar\2009\Multifunction\Rear interface module\Diagnose		√	√	√	√	
IVECO\Universal Area\Powerstar\2009\Multifunction\VCM-Immobilizer\Diagnose	√	√	√	√		
IVECO\Universal Area\Powerstar\2009\Suspension\Air Suspension\Ecas Wabco can\Rear air	√	√	√	√	√	0001
IVECO\Universal Area\Powerstar\2009\Suspension\Air Suspension\Ecas Wabco can\Full air	√	√	√	√	√	0001
IVECO\Universal Area\Powerstar\2008\Diesel\AdBlue system\Denoxtronic	√	√	√	√	√	

IVECO\Universal Area\Powerstar\2008\Diesel\AdBlue system\Denoxtronic 2	√	√	√	√	√	0002, 0004, 0008, 0010, 0011
IVECO\Universal Area\Powerstar\2008\Diesel\Engine control\EDC 7 UC31	√	√	√	√	√	
IVECO\Universal Area\Powerstar\2008\Brake\ABS\Abs Wabco D-E-E2		√	√	√	√	
IVECO\Universal Area\Powerstar\2008\Brake\EBS\Ebs-Ebs 2	√	√	√	√	√	
IVECO\Universal Area\Powerstar\2008\Instrument\Dashboard\Instrument cluster	√	√	√	√	√	
IVECO\Universal Area\Powerstar\2008\Climate\Auxiliary heater\Air heater	√	√	√	√	√	
IVECO\Universal Area\Powerstar\2008\Climate\Auxiliary heater\Water heater	√	√	√	√	√	
IVECO\Universal Area\Powerstar\2008\Climate\Climate control\Webasto		√	√	√	√	
IVECO\Universal Area\Powerstar\2008\Gearbox\Gearbox\Eurotronic 2\Fault codes, Real time data	√	√	√	√	√	
IVECO\Universal Area\Powerstar\2008\Gearbox\Gearbox\Eurotronic 2\Activations					√	
IVECO\Universal Area\Powerstar\2008\Multifunction\Body computer\Diagnose		√	√	√	√	
IVECO\Universal Area\Powerstar\2008\Multifunction\Driver Door Module\Diagnose		√	√	√	√	
IVECO\Universal Area\Powerstar\2008\Multifunction\Front interface module\Diagnose		√	√	√	√	
IVECO\Universal Area\Powerstar\2008\Multifunction\Passenger Door Module\Diagnose		√	√	√	√	
IVECO\Universal Area\Powerstar\2008\Multifunction\Rear interface module\Diagnose		√	√	√	√	
IVECO\Universal Area\Powerstar\2008\Multifunction\VCM-Immobilizer\Diagnose	√	√	√	√		
IVECO\Universal Area\Powerstar\2008\Suspension\Air Suspension\Ecas Wabco can\Rear air	√	√	√	√	√	0001
IVECO\Universal Area\Powerstar\2008\Suspension\Air Suspension\Ecas Wabco can\Full air	√	√	√	√	√	0001
IVECO\Universal Area\Powerstar\2007\Diesel\Engine control\MS 6.2		√	√	√	√	
IVECO\Universal Area\Powerstar\2007\Diesel\Engine control\EDC MS6.2 BOSCH VERSION 1						
IVECO\Universal Area\Powerstar\2007\Diesel\Engine control\EDC MS6.2 BOSCH VERSION 2	√	√	√	√	√	
IVECO\Universal Area\Powerstar\2007\Diesel\Engine control\EDC 7 UC31	√	√	√	√	√	
IVECO\Universal Area\Powerstar\2007\Brake\ABS\Abs Wabco D-E-E2		√	√	√	√	
IVECO\Universal Area\Powerstar\2007\Brake\EBS\Ebs-Ebs 2	√	√	√	√	√	
IVECO\Universal Area\Powerstar\2007\Instrument\Dashboard\Instrument cluster	√	√	√	√	√	
IVECO\Universal Area\Powerstar\2007\Climate\Auxiliary heater\Air heater	√	√	√	√	√	
IVECO\Universal Area\Powerstar\2007\Climate\Auxiliary heater\Water heater	√	√	√	√	√	
IVECO\Universal Area\Powerstar\2007\Climate\Climate control\Webasto		√	√	√	√	
IVECO\Universal Area\Powerstar\2007\Gearbox\Gearbox\Eurotronic 2\Fault codes, Real time data	√	√	√	√	√	
IVECO\Universal Area\Powerstar\2007\Gearbox\Gearbox\Eurotronic 2\Activations					√	
IVECO\Universal Area\Powerstar\2007\Multifunction\Body computer\Diagnose		√	√	√	√	
IVECO\Universal Area\Powerstar\2007\Multifunction\Driver Door Module\Diagnose		√	√	√	√	
IVECO\Universal Area\Powerstar\2007\Multifunction\Front interface module\Diagnose		√	√	√	√	
IVECO\Universal Area\Powerstar\2007\Multifunction\Passenger Door Module\Diagnose		√	√	√	√	
IVECO\Universal Area\Powerstar\2007\Multifunction\Rear interface module\Diagnose		√	√	√	√	
IVECO\Universal Area\Powerstar\2007\Multifunction\VCM-Immobilizer\Diagnose	√	√	√	√		
IVECO\Universal Area\Powerstar\2007\Suspension\Air Suspension\Ecas Wabco can\Rear air	√	√	√	√	√	0001
IVECO\Universal Area\Powerstar\2007\Suspension\Air Suspension\Ecas Wabco can\Full air	√	√	√	√	√	0001
IVECO\Universal Area\Powerstar\2006\Diesel\Engine control\MS 6.2		√	√	√	√	
IVECO\Universal Area\Powerstar\2006\Brake\ABS\Abs Wabco D-E-E2		√	√	√	√	

IVECO\Universal Area\Powerstar\2006\Brake\EBS\Ebs-Ebs 2	√	√	√	√	√	
IVECO\Universal Area\Powerstar\2006\Instrument\Dashboard\Instrument cluster	√	√	√	√	√	
IVECO\Universal Area\Powerstar\2006\Climate\Auxiliary heater\Air heater	√	√	√	√	√	
IVECO\Universal Area\Powerstar\2006\Climate\Auxiliary heater\Water heater	√	√	√	√	√	
IVECO\Universal Area\Powerstar\2006\Climate\Climate control\Webasto		√	√	√	√	
IVECO\Universal Area\Powerstar\2006\Gearbox\Gearbox\Eurotronic 2\Fault codes, Real time data	√	√	√	√	√	
IVECO\Universal Area\Powerstar\2006\Gearbox\Gearbox\Eurotronic 2\Activations					√	
IVECO\Universal Area\Powerstar\2006\Multifunction\Body computer\Diagnose		√	√	√	√	
IVECO\Universal Area\Powerstar\2006\Multifunction\Driver Door Module\Diagnose		√	√	√	√	
IVECO\Universal Area\Powerstar\2006\Multifunction\Front interface module\Diagnose		√	√	√	√	
IVECO\Universal Area\Powerstar\2006\Multifunction\Passenger Door Module\Diagnose		√	√	√	√	
IVECO\Universal Area\Powerstar\2006\Multifunction\Rear interface module\Diagnose		√	√	√	√	
IVECO\Universal Area\Powerstar\2006\Suspension\Air Suspension\Ecas Wabco can\Rear air	√	√	√	√	√	0001
IVECO\Universal Area\Powerstar\2006\Suspension\Air Suspension\Ecas Wabco can\Full air	√	√	√	√	√	0001
IVECO\Universal Area\Powerstar\2005\Diesel\Engine control\MS 6.2		√	√	√	√	
IVECO\Universal Area\Powerstar\2005\Brake\ABS\Abs Wabco D-E-E2		√	√	√	√	
IVECO\Universal Area\Powerstar\2005\Brake\EBS\Ebs-Ebs 2	√	√	√	√	√	
IVECO\Universal Area\Powerstar\2005\Instrument\Dashboard\Instrument cluster	√	√	√	√	√	
IVECO\Universal Area\Powerstar\2005\Climate\Auxiliary heater\Air heater	√	√	√	√	√	
IVECO\Universal Area\Powerstar\2005\Climate\Auxiliary heater\Water heater	√	√	√	√	√	
IVECO\Universal Area\Powerstar\2005\Climate\Climate control\Webasto		√	√	√	√	
IVECO\Universal Area\Powerstar\2005\Gearbox\Gearbox\Eurotronic 2\Fault codes, Real time data	√	√	√	√	√	
IVECO\Universal Area\Powerstar\2005\Gearbox\Gearbox\Eurotronic 2\Activations					√	
IVECO\Universal Area\Powerstar\2005\Multifunction\Body computer\Diagnose		√	√	√	√	
IVECO\Universal Area\Powerstar\2005\Multifunction\Driver Door Module\Diagnose		√	√	√	√	
IVECO\Universal Area\Powerstar\2005\Multifunction\Front interface module\Diagnose		√	√	√	√	
IVECO\Universal Area\Powerstar\2005\Multifunction\Passenger Door Module\Diagnose		√	√	√	√	
IVECO\Universal Area\Powerstar\2005\Multifunction\Rear interface module\Diagnose		√	√	√	√	
IVECO\Universal Area\Powerstar\2005\Suspension\Air Suspension\Ecas Wabco can\Rear air	√	√	√	√	√	0001
IVECO\Universal Area\Powerstar\2005\Suspension\Air Suspension\Ecas Wabco can\Full air	√	√	√	√	√	0001
IVECO\Universal Area\Powerstar\2004\Diesel\Engine control\MS 6.2		√	√	√	√	
IVECO\Universal Area\Powerstar\2004\Brake\ABS\Abs Wabco D-E-E2		√	√	√	√	
IVECO\Universal Area\Powerstar\2004\Brake\EBS\Ebs-Ebs 2	√	√	√	√	√	
IVECO\Universal Area\Powerstar\2004\Instrument\Dashboard\Instrument cluster	√	√	√	√	√	
IVECO\Universal Area\Powerstar\2004\Climate\Auxiliary heater\Air heater	√	√	√	√	√	
IVECO\Universal Area\Powerstar\2004\Climate\Auxiliary heater\Water heater	√	√	√	√	√	
IVECO\Universal Area\Powerstar\2004\Climate\Climate control\Webasto		√	√	√	√	
IVECO\Universal Area\Powerstar\2004\Gearbox\Gearbox\Eurotronic 2\Fault codes, Real time data	√	√	√	√	√	
IVECO\Universal Area\Powerstar\2004\Gearbox\Gearbox\Eurotronic 2\Activations					√	
IVECO\Universal Area\Powerstar\2004\Multifunction\Body computer\Diagnose		√	√	√	√	

IVECO\Universal Area\Powerstar\2004\Multifunction\Driver Door Module\Diagnose		√	√	√	√	
IVECO\Universal Area\Powerstar\2004\Multifunction\Front interface module\Diagnose		√	√	√	√	
IVECO\Universal Area\Powerstar\2004\Multifunction\Passenger Door Module\Diagnose		√	√	√	√	
IVECO\Universal Area\Powerstar\2004\Multifunction\Rear interface module\Diagnose		√	√	√	√	
IVECO\Universal Area\Powerstar\2004\Suspension\Air Suspension\Ecas Wabco can\Rear air	√	√	√	√	√	0001
IVECO\Universal Area\Powerstar\2004\Suspension\Air Suspension\Ecas Wabco can\Full air	√	√	√	√	√	0001
IVECO\Universal Area\Powerstar\2003\Diesel\Engine control\MS 6.2		√	√	√	√	
IVECO\Universal Area\Powerstar\2003\Brake\ABS\Abs Wabco D-E-E2		√	√	√	√	
IVECO\Universal Area\Powerstar\2003\Brake\EBS\Ebs-Ebs 2	√	√	√	√	√	
IVECO\Universal Area\Powerstar\2003\Instrument\Dashboard\Instrument cluster	√	√	√	√	√	
IVECO\Universal Area\Powerstar\2003\Climate\Auxiliary heater\Air heater	√	√	√	√	√	
IVECO\Universal Area\Powerstar\2003\Climate\Auxiliary heater\Water heater	√	√	√	√	√	
IVECO\Universal Area\Powerstar\2003\Climate\Climate control\Webasto		√	√	√	√	
IVECO\Universal Area\Powerstar\2003\Gearbox\Gearbox\Eurotronic 2\Fault codes, Real time data	√	√	√	√	√	
IVECO\Universal Area\Powerstar\2003\Gearbox\Gearbox\Eurotronic 2\Activations					√	
IVECO\Universal Area\Powerstar\2003\Multifunction\Body computer\Diagnose		√	√	√	√	
IVECO\Universal Area\Powerstar\2003\Multifunction\Driver Door Module\Diagnose		√	√	√	√	
IVECO\Universal Area\Powerstar\2003\Multifunction\Front interface module\Diagnose		√	√	√	√	
IVECO\Universal Area\Powerstar\2003\Multifunction\Passenger Door Module\Diagnose		√	√	√	√	
IVECO\Universal Area\Powerstar\2003\Multifunction\Rear interface module\Diagnose		√	√	√	√	
IVECO\Universal Area\Powerstar\2003\Suspension\Air Suspension\Ecas Wabco can\Rear air	√	√	√	√	√	0001
IVECO\Universal Area\Powerstar\2003\Suspension\Air Suspension\Ecas Wabco can\Full air	√	√	√	√	√	0001
IVECO\Universal Area\Powerstar\2002\Diesel\Engine control\MS 6.2		√	√	√	√	
IVECO\Universal Area\Powerstar\2002\Brake\ABS\Abs Wabco D-E-E2		√	√	√	√	
IVECO\Universal Area\Powerstar\2002\Brake\EBS\Ebs-Ebs 2	√	√	√	√	√	
IVECO\Universal Area\Powerstar\2002\Instrument\Dashboard\Instrument cluster	√	√	√	√	√	
IVECO\Universal Area\Powerstar\2002\Climate\Auxiliary heater\Air heater	√	√	√	√	√	
IVECO\Universal Area\Powerstar\2002\Climate\Auxiliary heater\Water heater	√	√	√	√	√	
IVECO\Universal Area\Powerstar\2002\Climate\Climate control\Webasto		√	√	√	√	
IVECO\Universal Area\Powerstar\2002\Gearbox\Gearbox\Eurotronic 2\Fault codes, Real time data	√	√	√	√	√	
IVECO\Universal Area\Powerstar\2002\Gearbox\Gearbox\Eurotronic 2\Activations					√	
IVECO\Universal Area\Powerstar\2002\Multifunction\Body computer\Diagnose		√	√	√	√	
IVECO\Universal Area\Powerstar\2002\Multifunction\Driver Door Module\Diagnose		√	√	√	√	
IVECO\Universal Area\Powerstar\2002\Multifunction\Front interface module\Diagnose		√	√	√	√	
IVECO\Universal Area\Powerstar\2002\Multifunction\Passenger Door Module\Diagnose		√	√	√	√	
IVECO\Universal Area\Powerstar\2002\Multifunction\Rear interface module\Diagnose		√	√	√	√	
IVECO\Universal Area\Powerstar\2002\Suspension\Air Suspension\Ecas Wabco can\Rear air	√	√	√	√	√	0001
IVECO\Universal Area\Powerstar\2002\Suspension\Air Suspension\Ecas Wabco can\Full air	√	√	√	√	√	0001
IVECO\Universal Area\Stralis\2017\Stralis Euro 6\ENGINE\EDC 17CV41	√	√	√	√	√	
IVECO\Universal Area\Stralis\2016\Stralis Euro 6\ENGINE\EDC 17CV41	√	√	√	√	√	

IVECO\Universal Area\Stralis\2015\Stralis Euro 6\ENGINE\EDC 17CV41	√	√	√	√	√	
IVECO\Universal Area\Stralis\2014\Stralis Euro 6\ENGINE\EDC 17CV41	√	√	√	√	√	
IVECO\Universal Area\Stralis\2013\Stralis Euro 6\ENGINE\EDC 17CV41	√	√	√	√	√	
IVECO\Universal Area\Stralis\2012\Diesel\AdBlue system\Denoxtronic	√	√	√	√	√	
IVECO\Universal Area\Stralis\2012\Diesel\AdBlue system\Denoxtronic 2	√	√	√	√	√	0002, 0004, 0008, 0010, 0011
IVECO\Universal Area\Stralis\2012\Diesel\Engine control\EDC 7 UC31	√	√	√	√	√	
IVECO\Universal Area\Stralis\2012\Brake\ABS\Abs Wabco D-E-E2		√	√	√	√	
IVECO\Universal Area\Stralis\2012\Brake\EBS\Ebs-Ebs 2	√	√	√	√	√	
IVECO\Universal Area\Stralis\2012\Instrument\Dashboard\Instrument cluster	√	√	√	√	√	
IVECO\Universal Area\Stralis\2012\Climate\Auxiliary heater\Air heater	√	√	√	√	√	
IVECO\Universal Area\Stralis\2012\Climate\Auxiliary heater\Water heater	√	√	√	√	√	
IVECO\Universal Area\Stralis\2012\Climate\Climate control\Webasto		√	√	√	√	
IVECO\Universal Area\Stralis\2012\Gearbox\Gearbox\Eurotronic 2\Fault codes, Real time data	√	√	√	√	√	
IVECO\Universal Area\Stralis\2012\Gearbox\Gearbox\Eurotronic 2\Activations					√	
IVECO\Universal Area\Stralis\2012\Multifunction\Body computer\Diagnose		√	√	√	√	
IVECO\Universal Area\Stralis\2012\Multifunction\Driver Door Module\Diagnose		√	√	√	√	
IVECO\Universal Area\Stralis\2012\Multifunction\Front interface module\Diagnose		√	√	√	√	
IVECO\Universal Area\Stralis\2012\Multifunction\Passenger Door Module\Diagnose		√	√	√	√	
IVECO\Universal Area\Stralis\2012\Multifunction\Rear interface module\Diagnose		√	√	√	√	
IVECO\Universal Area\Stralis\2012\Multifunction\VCM-Immobilizer\Diagnose	√	√	√	√		
IVECO\Universal Area\Stralis\2012\Suspension\Air Suspension\Ecas Wabco can\Rear air	√	√	√	√	√	0001
IVECO\Universal Area\Stralis\2012\Suspension\Air Suspension\Ecas Wabco can\Full air	√	√	√	√	√	0001
IVECO\Universal Area\Stralis\2011\Diesel\AdBlue system\Denoxtronic	√	√	√	√	√	
IVECO\Universal Area\Stralis\2011\Diesel\AdBlue system\Denoxtronic 2	√	√	√	√	√	0002, 0004, 0008, 0010, 0011
IVECO\Universal Area\Stralis\2011\Diesel\Engine control\EDC 7 UC31	√	√	√	√	√	
IVECO\Universal Area\Stralis\2011\Brake\ABS\Abs Wabco D-E-E2		√	√	√	√	
IVECO\Universal Area\Stralis\2011\Brake\EBS\Ebs-Ebs 2	√	√	√	√	√	
IVECO\Universal Area\Stralis\2011\Instrument\Dashboard\Instrument cluster	√	√	√	√	√	
IVECO\Universal Area\Stralis\2011\Climate\Auxiliary heater\Air heater	√	√	√	√	√	
IVECO\Universal Area\Stralis\2011\Climate\Auxiliary heater\Water heater	√	√	√	√	√	
IVECO\Universal Area\Stralis\2011\Climate\Climate control\Webasto		√	√	√	√	
IVECO\Universal Area\Stralis\2011\Gearbox\Gearbox\Eurotronic 2\Fault codes, Real time data	√	√	√	√	√	
IVECO\Universal Area\Stralis\2011\Gearbox\Gearbox\Eurotronic 2\Activations					√	
IVECO\Universal Area\Stralis\2011\Multifunction\Body computer\Diagnose		√	√	√	√	
IVECO\Universal Area\Stralis\2011\Multifunction\Driver Door Module\Diagnose		√	√	√	√	
IVECO\Universal Area\Stralis\2011\Multifunction\Front interface module\Diagnose		√	√	√	√	
IVECO\Universal Area\Stralis\2011\Multifunction\Passenger Door Module\Diagnose		√	√	√	√	
IVECO\Universal Area\Stralis\2011\Multifunction\Rear interface module\Diagnose		√	√	√	√	
IVECO\Universal Area\Stralis\2011\Multifunction\VCM-Immobilizer\Diagnose	√	√	√	√		
IVECO\Universal Area\Stralis\2011\Suspension\Air Suspension\Ecas Wabco can\Rear air	√	√	√	√	√	0001

IVECO\Universal Area\Stralis\2011\Suspension\Air Suspension\Ecas Wabco can\Full air	√	√	√	√	√	0001
IVECO\Universal Area\Stralis\2010\Diesel\AdBlue system\Denoxtronic	√	√	√	√	√	
IVECO\Universal Area\Stralis\2010\Diesel\AdBlue system\Denoxtronic 2	√	√	√	√	√	0002, 0004, 0008, 0010, 0011
IVECO\Universal Area\Stralis\2010\Diesel\Engine control\EDC 7 UC31	√	√	√	√	√	
IVECO\Universal Area\Stralis\2010\Brake\ABS\Abs Wabco D-E-E2		√	√	√	√	
IVECO\Universal Area\Stralis\2010\Brake\EBS\Ebs-Ebs 2	√	√	√	√	√	
IVECO\Universal Area\Stralis\2010\Instrument\Dashboard\Instrument cluster	√	√	√	√	√	
IVECO\Universal Area\Stralis\2010\Climate\Auxiliary heater\Air heater	√	√	√	√	√	
IVECO\Universal Area\Stralis\2010\Climate\Auxiliary heater\Water heater	√	√	√	√	√	
IVECO\Universal Area\Stralis\2010\Climate\Climate control\Webasto		√	√	√	√	
IVECO\Universal Area\Stralis\2010\Gearbox\Gearbox\Eurotronic 2\Fault codes, Real time data	√	√	√	√	√	
IVECO\Universal Area\Stralis\2010\Gearbox\Gearbox\Eurotronic 2\Activations					√	
IVECO\Universal Area\Stralis\2010\Multifunction\Body computer\Diagnose		√	√	√	√	
IVECO\Universal Area\Stralis\2010\Multifunction\Driver Door Module\Diagnose		√	√	√	√	
IVECO\Universal Area\Stralis\2010\Multifunction\Front interface module\Diagnose		√	√	√	√	
IVECO\Universal Area\Stralis\2010\Multifunction\Passenger Door Module\Diagnose		√	√	√	√	
IVECO\Universal Area\Stralis\2010\Multifunction\Rear interface module\Diagnose		√	√	√	√	
IVECO\Universal Area\Stralis\2010\Multifunction\VCM-Immobilizer\Diagnose	√	√	√	√		
IVECO\Universal Area\Stralis\2010\Suspension\Air Suspension\Ecas Wabco can\Rear air	√	√	√	√	√	0001
IVECO\Universal Area\Stralis\2010\Suspension\Air Suspension\Ecas Wabco can\Full air	√	√	√	√	√	0001
IVECO\Universal Area\Stralis\2009\Diesel\AdBlue system\Denoxtronic	√	√	√	√	√	
IVECO\Universal Area\Stralis\2009\Diesel\AdBlue system\Denoxtronic 2	√	√	√	√	√	0002, 0004, 0008, 0010, 0011
IVECO\Universal Area\Stralis\2009\Diesel\Engine control\EDC 7 UC31	√	√	√	√	√	
IVECO\Universal Area\Stralis\2009\Brake\ABS\Abs Wabco D-E-E2		√	√	√	√	
IVECO\Universal Area\Stralis\2009\Brake\EBS\Ebs-Ebs 2	√	√	√	√	√	
IVECO\Universal Area\Stralis\2009\Instrument\Dashboard\Instrument cluster	√	√	√	√	√	
IVECO\Universal Area\Stralis\2009\Climate\Auxiliary heater\Air heater	√	√	√	√	√	
IVECO\Universal Area\Stralis\2009\Climate\Auxiliary heater\Water heater	√	√	√	√	√	
IVECO\Universal Area\Stralis\2009\Climate\Climate control\Webasto		√	√	√	√	
IVECO\Universal Area\Stralis\2009\Gearbox\Gearbox\Eurotronic 2\Fault codes, Real time data	√	√	√	√	√	
IVECO\Universal Area\Stralis\2009\Gearbox\Gearbox\Eurotronic 2\Activations					√	
IVECO\Universal Area\Stralis\2009\Multifunction\Body computer\Diagnose		√	√	√	√	
IVECO\Universal Area\Stralis\2009\Multifunction\Driver Door Module\Diagnose		√	√	√	√	
IVECO\Universal Area\Stralis\2009\Multifunction\Front interface module\Diagnose		√	√	√	√	
IVECO\Universal Area\Stralis\2009\Multifunction\Passenger Door Module\Diagnose		√	√	√	√	
IVECO\Universal Area\Stralis\2009\Multifunction\Rear interface module\Diagnose		√	√	√	√	
IVECO\Universal Area\Stralis\2009\Multifunction\VCM-Immobilizer\Diagnose	√	√	√	√		
IVECO\Universal Area\Stralis\2009\Suspension\Air Suspension\Ecas Wabco can\Rear air	√	√	√	√	√	0001
IVECO\Universal Area\Stralis\2009\Suspension\Air Suspension\Ecas Wabco can\Full air	√	√	√	√	√	0001
IVECO\Universal Area\Stralis\2008\Diesel\AdBlue system\Denoxtronic	√	√	√	√	√	

IVECO\Universal Area\Stralis\2008\Diesel\AdBlue system\Denoxtronic 2	√	√	√	√	√	0002, 0004, 0008, 0010, 0011
IVECO\Universal Area\Stralis\2008\Diesel\Engine control\EDC 7 UC31	√	√	√	√	√	
IVECO\Universal Area\Stralis\2008\Brake\ABS\Abs Wabco D-E-E2		√	√	√	√	
IVECO\Universal Area\Stralis\2008\Brake\EBS\Ebs-Ebs 2	√	√	√	√	√	
IVECO\Universal Area\Stralis\2008\Instrument\Dashboard\Instrument cluster	√	√	√	√	√	
IVECO\Universal Area\Stralis\2008\Climate\Auxiliary heater\Air heater	√	√	√	√	√	
IVECO\Universal Area\Stralis\2008\Climate\Auxiliary heater\Water heater	√	√	√	√	√	
IVECO\Universal Area\Stralis\2008\Climate\Climate control\Webasto		√	√	√	√	
IVECO\Universal Area\Stralis\2008\Gearbox\Gearbox\Eurotronic 2\Fault codes, Real time data	√	√	√	√	√	
IVECO\Universal Area\Stralis\2008\Gearbox\Gearbox\Eurotronic 2\Activations					√	
IVECO\Universal Area\Stralis\2008\Multifunction\Body computer\Diagnose		√	√	√	√	
IVECO\Universal Area\Stralis\2008\Multifunction\Driver Door Module\Diagnose		√	√	√	√	
IVECO\Universal Area\Stralis\2008\Multifunction\Front interface module\Diagnose		√	√	√	√	
IVECO\Universal Area\Stralis\2008\Multifunction\Passenger Door Module\Diagnose		√	√	√	√	
IVECO\Universal Area\Stralis\2008\Multifunction\Rear interface module\Diagnose		√	√	√	√	
IVECO\Universal Area\Stralis\2008\Multifunction\VCM-Immobilizer\Diagnose	√	√	√	√		
IVECO\Universal Area\Stralis\2008\Suspension\Air Suspension\Ecas Wabco can\Rear air	√	√	√	√	√	0001
IVECO\Universal Area\Stralis\2008\Suspension\Air Suspension\Ecas Wabco can\Full air	√	√	√	√	√	0001
IVECO\Universal Area\Stralis\2007\Diesel\Engine control\MS 6.2		√	√	√	√	
IVECO\Universal Area\Stralis\2007\Diesel\Engine control\EDC MS6.2 BOSCH VERSION 1						
IVECO\Universal Area\Stralis\2007\Diesel\Engine control\EDC MS6.2 BOSCH VERSION 2	√	√	√	√	√	
IVECO\Universal Area\Stralis\2007\Diesel\Engine control\EDC 7 UC31	√	√	√	√	√	
IVECO\Universal Area\Stralis\2007\Brake\ABS\Abs Wabco D-E-E2		√	√	√	√	
IVECO\Universal Area\Stralis\2007\Brake\EBS\Ebs-Ebs 2	√	√	√	√	√	
IVECO\Universal Area\Stralis\2007\Instrument\Dashboard\Instrument cluster	√	√	√	√	√	
IVECO\Universal Area\Stralis\2007\Climate\Auxiliary heater\Air heater	√	√	√	√	√	
IVECO\Universal Area\Stralis\2007\Climate\Auxiliary heater\Water heater	√	√	√	√	√	
IVECO\Universal Area\Stralis\2007\Climate\Climate control\Webasto		√	√	√	√	
IVECO\Universal Area\Stralis\2007\Gearbox\Gearbox\Eurotronic 2\Fault codes, Real time data	√	√	√	√	√	
IVECO\Universal Area\Stralis\2007\Gearbox\Gearbox\Eurotronic 2\Activations					√	
IVECO\Universal Area\Stralis\2007\Multifunction\Body computer\Diagnose		√	√	√	√	
IVECO\Universal Area\Stralis\2007\Multifunction\Driver Door Module\Diagnose		√	√	√	√	
IVECO\Universal Area\Stralis\2007\Multifunction\Front interface module\Diagnose		√	√	√	√	
IVECO\Universal Area\Stralis\2007\Multifunction\Passenger Door Module\Diagnose		√	√	√	√	
IVECO\Universal Area\Stralis\2007\Multifunction\Rear interface module\Diagnose		√	√	√	√	
IVECO\Universal Area\Stralis\2007\Multifunction\VCM-Immobilizer\Diagnose	√	√	√	√		
IVECO\Universal Area\Stralis\2007\Suspension\Air Suspension\Ecas Wabco can\Rear air	√	√	√	√	√	0001
IVECO\Universal Area\Stralis\2007\Suspension\Air Suspension\Ecas Wabco can\Full air	√	√	√	√	√	0001
IVECO\Universal Area\Stralis\2006\Diesel\Engine control\MS 6.2		√	√	√	√	
IVECO\Universal Area\Stralis\2006\Brake\ABS\Abs Wabco D-E-E2		√	√	√	√	

IVECO\Universal Area\Stralis\2006\Brake\EBS\Ebs-Ebs 2	√	√	√	√	√	
IVECO\Universal Area\Stralis\2006\Instrument\Dashboard\Instrument cluster	√	√	√	√	√	
IVECO\Universal Area\Stralis\2006\Climate\Auxiliary heater\Air heater	√	√	√	√	√	
IVECO\Universal Area\Stralis\2006\Climate\Auxiliary heater\Water heater	√	√	√	√	√	
IVECO\Universal Area\Stralis\2006\Climate\Climate control\Webasto		√	√	√	√	
IVECO\Universal Area\Stralis\2006\Gearbox\Gearbox\Eurotronic 2\Fault codes, Real time data	√	√	√	√	√	
IVECO\Universal Area\Stralis\2006\Gearbox\Gearbox\Eurotronic 2\Activations					√	
IVECO\Universal Area\Stralis\2006\Multifunction\Body computer\Diagnose		√	√	√	√	
IVECO\Universal Area\Stralis\2006\Multifunction\Driver Door Module\Diagnose		√	√	√	√	
IVECO\Universal Area\Stralis\2006\Multifunction\Front interface module\Diagnose		√	√	√	√	
IVECO\Universal Area\Stralis\2006\Multifunction\Passenger Door Module\Diagnose		√	√	√	√	
IVECO\Universal Area\Stralis\2006\Multifunction\Rear interface module\Diagnose		√	√	√	√	
IVECO\Universal Area\Stralis\2006\Suspension\Air Suspension\Ecas Wabco can\Rear air	√	√	√	√	√	0001
IVECO\Universal Area\Stralis\2006\Suspension\Air Suspension\Ecas Wabco can\Full air	√	√	√	√	√	0001
IVECO\Universal Area\Stralis\2005\Diesel\Engine control\MS 6.2		√	√	√	√	
IVECO\Universal Area\Stralis\2005\Brake\ABS\Abs Wabco D-E-E2		√	√	√	√	
IVECO\Universal Area\Stralis\2005\Brake\EBS\Ebs-Ebs 2	√	√	√	√	√	
IVECO\Universal Area\Stralis\2005\Instrument\Dashboard\Instrument cluster	√	√	√	√	√	
IVECO\Universal Area\Stralis\2005\Climate\Auxiliary heater\Air heater	√	√	√	√	√	
IVECO\Universal Area\Stralis\2005\Climate\Auxiliary heater\Water heater	√	√	√	√	√	
IVECO\Universal Area\Stralis\2005\Climate\Climate control\Webasto		√	√	√	√	
IVECO\Universal Area\Stralis\2005\Gearbox\Gearbox\Eurotronic 2\Fault codes, Real time data	√	√	√	√	√	
IVECO\Universal Area\Stralis\2005\Gearbox\Gearbox\Eurotronic 2\Activations					√	
IVECO\Universal Area\Stralis\2005\Multifunction\Body computer\Diagnose		√	√	√	√	
IVECO\Universal Area\Stralis\2005\Multifunction\Driver Door Module\Diagnose		√	√	√	√	
IVECO\Universal Area\Stralis\2005\Multifunction\Front interface module\Diagnose		√	√	√	√	
IVECO\Universal Area\Stralis\2005\Multifunction\Passenger Door Module\Diagnose		√	√	√	√	
IVECO\Universal Area\Stralis\2005\Multifunction\Rear interface module\Diagnose		√	√	√	√	
IVECO\Universal Area\Stralis\2005\Suspension\Air Suspension\Ecas Wabco can\Rear air	√	√	√	√	√	0001
IVECO\Universal Area\Stralis\2005\Suspension\Air Suspension\Ecas Wabco can\Full air	√	√	√	√	√	0001
IVECO\Universal Area\Stralis\2004\Diesel\Engine control\MS 6.2		√	√	√	√	
IVECO\Universal Area\Stralis\2004\Brake\ABS\Abs Wabco D-E-E2		√	√	√	√	
IVECO\Universal Area\Stralis\2004\Brake\EBS\Ebs-Ebs 2	√	√	√	√	√	
IVECO\Universal Area\Stralis\2004\Instrument\Dashboard\Instrument cluster	√	√	√	√	√	
IVECO\Universal Area\Stralis\2004\Climate\Auxiliary heater\Air heater	√	√	√	√	√	
IVECO\Universal Area\Stralis\2004\Climate\Auxiliary heater\Water heater	√	√	√	√	√	
IVECO\Universal Area\Stralis\2004\Climate\Climate control\Webasto		√	√	√	√	
IVECO\Universal Area\Stralis\2004\Gearbox\Gearbox\Eurotronic 2\Fault codes, Real time data	√	√	√	√	√	
IVECO\Universal Area\Stralis\2004\Gearbox\Gearbox\Eurotronic 2\Activations					√	
IVECO\Universal Area\Stralis\2004\Multifunction\Body computer\Diagnose		√	√	√	√	

IVECO\Universal Area\Stralis\2004\Multifunction\Driver Door Module\Diagnose		√	√	√	√	
IVECO\Universal Area\Stralis\2004\Multifunction\Front interface module\Diagnose		√	√	√	√	
IVECO\Universal Area\Stralis\2004\Multifunction\Passenger Door Module\Diagnose		√	√	√	√	
IVECO\Universal Area\Stralis\2004\Multifunction\Rear interface module\Diagnose		√	√	√	√	
IVECO\Universal Area\Stralis\2004\Suspension\Air Suspension\Ecas Wabco can\Rear air	√	√	√	√	√	0001
IVECO\Universal Area\Stralis\2004\Suspension\Air Suspension\Ecas Wabco can\Full air	√	√	√	√	√	0001
IVECO\Universal Area\Stralis\2003\Diesel\Engine control\MS 6.2		√	√	√	√	
IVECO\Universal Area\Stralis\2003\Brake\ABS\Abs Wabco D-E-E2		√	√	√	√	
IVECO\Universal Area\Stralis\2003\Brake\EBS\Ebs-Ebs 2	√	√	√	√	√	
IVECO\Universal Area\Stralis\2003\Instrument\Dashboard\Instrument cluster	√	√	√	√	√	
IVECO\Universal Area\Stralis\2003\Climate\Auxiliary heater\Air heater	√	√	√	√	√	
IVECO\Universal Area\Stralis\2003\Climate\Auxiliary heater\Water heater	√	√	√	√	√	
IVECO\Universal Area\Stralis\2003\Climate\Climate control\Webasto		√	√	√	√	
IVECO\Universal Area\Stralis\2003\Gearbox\Gearbox\Eurotronic 2\Fault codes, Real time data	√	√	√	√	√	
IVECO\Universal Area\Stralis\2003\Gearbox\Gearbox\Eurotronic 2\Activations					√	
IVECO\Universal Area\Stralis\2003\Multifunction\Body computer\Diagnose		√	√	√	√	
IVECO\Universal Area\Stralis\2003\Multifunction\Driver Door Module\Diagnose		√	√	√	√	
IVECO\Universal Area\Stralis\2003\Multifunction\Front interface module\Diagnose		√	√	√	√	
IVECO\Universal Area\Stralis\2003\Multifunction\Passenger Door Module\Diagnose		√	√	√	√	
IVECO\Universal Area\Stralis\2003\Multifunction\Rear interface module\Diagnose		√	√	√	√	
IVECO\Universal Area\Stralis\2003\Suspension\Air Suspension\Ecas Wabco can\Rear air	√	√	√	√	√	0001
IVECO\Universal Area\Stralis\2003\Suspension\Air Suspension\Ecas Wabco can\Full air	√	√	√	√	√	0001
IVECO\Universal Area\Stralis\2002\Diesel\Engine control\MS 6.2		√	√	√	√	
IVECO\Universal Area\Stralis\2002\Brake\ABS\Abs Wabco D-E-E2		√	√	√	√	
IVECO\Universal Area\Stralis\2002\Brake\EBS\Ebs-Ebs 2	√	√	√	√	√	
IVECO\Universal Area\Stralis\2002\Instrument\Dashboard\Instrument cluster	√	√	√	√	√	
IVECO\Universal Area\Stralis\2002\Climate\Auxiliary heater\Air heater	√	√	√	√	√	
IVECO\Universal Area\Stralis\2002\Climate\Auxiliary heater\Water heater	√	√	√	√	√	
IVECO\Universal Area\Stralis\2002\Climate\Climate control\Webasto		√	√	√	√	
IVECO\Universal Area\Stralis\2002\Gearbox\Gearbox\Eurotronic 2\Fault codes, Real time data	√	√	√	√	√	
IVECO\Universal Area\Stralis\2002\Gearbox\Gearbox\Eurotronic 2\Activations					√	
IVECO\Universal Area\Stralis\2002\Multifunction\Body computer\Diagnose		√	√	√	√	
IVECO\Universal Area\Stralis\2002\Multifunction\Driver Door Module\Diagnose		√	√	√	√	
IVECO\Universal Area\Stralis\2002\Multifunction\Front interface module\Diagnose		√	√	√	√	
IVECO\Universal Area\Stralis\2002\Multifunction\Passenger Door Module\Diagnose		√	√	√	√	
IVECO\Universal Area\Stralis\2002\Multifunction\Rear interface module\Diagnose		√	√	√	√	
IVECO\Universal Area\Stralis\2002\Suspension\Air Suspension\Ecas Wabco can\Rear air	√	√	√	√	√	0001
IVECO\Universal Area\Stralis\2002\Suspension\Air Suspension\Ecas Wabco can\Full air	√	√	√	√	√	0001
IVECO\Universal Area\Trakker\2012\Diesel\AdBlue system\Denoxtronic	√	√	√	√	√	
IVECO\Universal Area\Trakker\2012\Diesel\AdBlue system\Denoxtronic 2	√	√	√	√	√	0002, 0004, 0008, 0010, 0011

IVECO\Universal Area\Trakker\2012\Diesel\Engine control\EDC 7 UC31	√	√	√	√	√	
IVECO\Universal Area\Trakker\2012\Brake\ABS\Abs Wabco D-E-E2		√	√	√	√	
IVECO\Universal Area\Trakker\2012\Brake\EBS\Ebs-Ebs 2	√	√	√	√	√	
IVECO\Universal Area\Trakker\2012\Climate\Auxiliary heater\Air heater	√	√	√	√	√	
IVECO\Universal Area\Trakker\2012\Climate\Auxiliary heater\Water heater	√	√	√	√	√	
IVECO\Universal Area\Trakker\2012\Climate\Climate control\Webasto		√	√	√	√	
IVECO\Universal Area\Trakker\2012\Gearbox\Gearbox\Eurotronic 2\Fault codes, Real time data	√	√	√	√	√	
IVECO\Universal Area\Trakker\2012\Gearbox\Gearbox\Eurotronic 2\Activations					√	
IVECO\Universal Area\Trakker\2012\Multifunction\Driver Door Module\Diagnose		√	√	√	√	
IVECO\Universal Area\Trakker\2012\Multifunction\Passenger Door Module\Diagnose		√	√	√	√	
IVECO\Universal Area\Trakker\2012\Multifunction\VCM-Immobilizer\Diagnose	√	√	√	√		
IVECO\Universal Area\Trakker\2012\Suspension\Air Suspension\Ecas Wabco can\Rear air	√	√	√	√	√	0001
IVECO\Universal Area\Trakker\2012\Suspension\Air Suspension\Ecas Wabco can\Full air	√	√	√	√	√	0001
IVECO\Universal Area\Trakker\2011\Diesel\AdBlue system\Denoxtronic	√	√	√	√	√	
IVECO\Universal Area\Trakker\2011\Diesel\AdBlue system\Denoxtronic 2	√	√	√	√	√	0002, 0004, 0008, 0010, 0011
IVECO\Universal Area\Trakker\2011\Diesel\Engine control\EDC 7 UC31	√	√	√	√	√	
IVECO\Universal Area\Trakker\2011\Brake\ABS\Abs Wabco D-E-E2		√	√	√	√	
IVECO\Universal Area\Trakker\2011\Brake\EBS\Ebs-Ebs 2	√	√	√	√	√	
IVECO\Universal Area\Trakker\2011\Climate\Auxiliary heater\Air heater	√	√	√	√	√	
IVECO\Universal Area\Trakker\2011\Climate\Auxiliary heater\Water heater	√	√	√	√	√	
IVECO\Universal Area\Trakker\2011\Climate\Climate control\Webasto		√	√	√	√	
IVECO\Universal Area\Trakker\2011\Gearbox\Gearbox\Eurotronic 2\Fault codes, Real time data	√	√	√	√	√	
IVECO\Universal Area\Trakker\2011\Gearbox\Gearbox\Eurotronic 2\Activations					√	
IVECO\Universal Area\Trakker\2011\Multifunction\Driver Door Module\Diagnose		√	√	√	√	
IVECO\Universal Area\Trakker\2011\Multifunction\Passenger Door Module\Diagnose		√	√	√	√	
IVECO\Universal Area\Trakker\2011\Multifunction\VCM-Immobilizer\Diagnose	√	√	√	√		
IVECO\Universal Area\Trakker\2011\Suspension\Air Suspension\Ecas Wabco can\Rear air	√	√	√	√	√	0001
IVECO\Universal Area\Trakker\2011\Suspension\Air Suspension\Ecas Wabco can\Full air	√	√	√	√	√	0001
IVECO\Universal Area\Trakker\2010\Diesel\AdBlue system\Denoxtronic	√	√	√	√	√	
IVECO\Universal Area\Trakker\2010\Diesel\AdBlue system\Denoxtronic 2	√	√	√	√	√	0002, 0004, 0008, 0010, 0011
IVECO\Universal Area\Trakker\2010\Diesel\Engine control\EDC 7 UC31	√	√	√	√	√	
IVECO\Universal Area\Trakker\2010\Brake\ABS\Abs Wabco D-E-E2		√	√	√	√	
IVECO\Universal Area\Trakker\2010\Brake\EBS\Ebs-Ebs 2	√	√	√	√	√	
IVECO\Universal Area\Trakker\2010\Climate\Auxiliary heater\Air heater	√	√	√	√	√	
IVECO\Universal Area\Trakker\2010\Climate\Auxiliary heater\Water heater	√	√	√	√	√	
IVECO\Universal Area\Trakker\2010\Climate\Climate control\Webasto		√	√	√	√	
IVECO\Universal Area\Trakker\2010\Gearbox\Gearbox\Eurotronic 2\Fault codes, Real time data	√	√	√	√	√	
IVECO\Universal Area\Trakker\2010\Gearbox\Gearbox\Eurotronic 2\Activations					√	
IVECO\Universal Area\Trakker\2010\Multifunction\Driver Door Module\Diagnose		√	√	√	√	
IVECO\Universal Area\Trakker\2010\Multifunction\Passenger Door Module\Diagnose		√	√	√	√	

IVECO\Universal Area\Trakker\2010\Multifunction\VCM-Immobilizer\Diagnose	√	√	√	√		
IVECO\Universal Area\Trakker\2010\Suspension\Air Suspension\Ecas Wabco can\Rear air	√	√	√	√	√	0001
IVECO\Universal Area\Trakker\2010\Suspension\Air Suspension\Ecas Wabco can\Full air	√	√	√	√	√	0001
IVECO\Universal Area\Trakker\2009\Diesel\AdBlue system\Denoxtronic	√	√	√	√	√	
IVECO\Universal Area\Trakker\2009\Diesel\AdBlue system\Denoxtronic 2	√	√	√	√	√	0002, 0004, 0008, 0010, 0011
IVECO\Universal Area\Trakker\2009\Diesel\Engine control\EDC 7 UC31	√	√	√	√	√	
IVECO\Universal Area\Trakker\2009\Brake\ABS\Abs Wabco D-E-E2		√	√	√	√	
IVECO\Universal Area\Trakker\2009\Brake\EBS\Ebs-Ebs 2	√	√	√	√	√	
IVECO\Universal Area\Trakker\2009\Climate\Auxiliary heater\Air heater	√	√	√	√	√	
IVECO\Universal Area\Trakker\2009\Climate\Auxiliary heater\Water heater	√	√	√	√	√	
IVECO\Universal Area\Trakker\2009\Climate\Climate control\Webasto		√	√	√	√	
IVECO\Universal Area\Trakker\2009\Gearbox\Gearbox\Eurotronic 2\Fault codes, Real time data	√	√	√	√	√	
IVECO\Universal Area\Trakker\2009\Gearbox\Gearbox\Eurotronic 2\Activations					√	
IVECO\Universal Area\Trakker\2009\Multifunction\Driver Door Module\Diagnose		√	√	√	√	
IVECO\Universal Area\Trakker\2009\Multifunction\Passenger Door Module\Diagnose		√	√	√	√	
IVECO\Universal Area\Trakker\2009\Multifunction\VCM-Immobilizer\Diagnose	√	√	√	√		
IVECO\Universal Area\Trakker\2009\Suspension\Air Suspension\Ecas Wabco can\Rear air	√	√	√	√	√	0001
IVECO\Universal Area\Trakker\2009\Suspension\Air Suspension\Ecas Wabco can\Full air	√	√	√	√	√	0001
IVECO\Universal Area\Trakker\2008\Diesel\AdBlue system\Denoxtronic	√	√	√	√	√	
IVECO\Universal Area\Trakker\2008\Diesel\AdBlue system\Denoxtronic 2	√	√	√	√	√	0002, 0004, 0008, 0010, 0011
IVECO\Universal Area\Trakker\2008\Diesel\Engine control\EDC 7 UC31	√	√	√	√	√	
IVECO\Universal Area\Trakker\2008\Brake\ABS\Abs Wabco D-E-E2		√	√	√	√	
IVECO\Universal Area\Trakker\2008\Brake\EBS\Ebs-Ebs 2	√	√	√	√	√	
IVECO\Universal Area\Trakker\2008\Climate\Auxiliary heater\Air heater	√	√	√	√	√	
IVECO\Universal Area\Trakker\2008\Climate\Auxiliary heater\Water heater	√	√	√	√	√	
IVECO\Universal Area\Trakker\2008\Climate\Climate control\Webasto		√	√	√	√	
IVECO\Universal Area\Trakker\2008\Gearbox\Gearbox\Eurotronic 2\Fault codes, Real time data	√	√	√	√	√	
IVECO\Universal Area\Trakker\2008\Gearbox\Gearbox\Eurotronic 2\Activations					√	
IVECO\Universal Area\Trakker\2008\Multifunction\Driver Door Module\Diagnose		√	√	√	√	
IVECO\Universal Area\Trakker\2008\Multifunction\Passenger Door Module\Diagnose		√	√	√	√	
IVECO\Universal Area\Trakker\2008\Multifunction\VCM-Immobilizer\Diagnose	√	√	√	√		
IVECO\Universal Area\Trakker\2008\Suspension\Air Suspension\Ecas Wabco can\Rear air	√	√	√	√	√	0001
IVECO\Universal Area\Trakker\2008\Suspension\Air Suspension\Ecas Wabco can\Full air	√	√	√	√	√	0001
IVECO\Universal Area\Trakker\2007\Diesel\AdBlue system\Denoxtronic	√	√	√	√	√	
IVECO\Universal Area\Trakker\2007\Diesel\AdBlue system\Denoxtronic 2	√	√	√	√	√	0002, 0004, 0008, 0010, 0011
IVECO\Universal Area\Trakker\2007\Diesel\Engine control\MS 6.2		√	√	√	√	
IVECO\Universal Area\Trakker\2007\Diesel\Engine control\EDC MS6.2 BOSCH VERSION 1						
IVECO\Universal Area\Trakker\2007\Diesel\Engine control\EDC MS6.2 BOSCH VERSION 2	√	√	√	√	√	
IVECO\Universal Area\Trakker\2007\Diesel\Engine control\EDC 7 UC31	√	√	√	√	√	
IVECO\Universal Area\Trakker\2007\Brake\ABS\Abs Wabco D-E-E2		√	√	√	√	

IVECO\Universal Area\Trakker\2007\Brake\EBS\Ebs-Ebs 2	√	√	√	√	√	
IVECO\Universal Area\Trakker\2007\Climate\Auxiliary heater\Air heater	√	√	√	√	√	
IVECO\Universal Area\Trakker\2007\Climate\Auxiliary heater\Water heater	√	√	√	√	√	
IVECO\Universal Area\Trakker\2007\Climate\Climate control\Webasto		√	√	√	√	
IVECO\Universal Area\Trakker\2007\Gearbox\Gearbox\Eurotronic 2\Fault codes, Real time data	√	√	√	√	√	
IVECO\Universal Area\Trakker\2007\Gearbox\Gearbox\Eurotronic 2\Activations					√	
IVECO\Universal Area\Trakker\2007\Multifunction\Driver Door Module\Diagnose		√	√	√	√	
IVECO\Universal Area\Trakker\2007\Multifunction\Passenger Door Module\Diagnose		√	√	√	√	
IVECO\Universal Area\Trakker\2007\Multifunction\VCM-Immobilizer\Diagnose	√	√	√	√		
IVECO\Universal Area\Trakker\2007\Suspension\Air Suspension\Ecas Wabco can\Rear air	√	√	√	√	√	0001
IVECO\Universal Area\Trakker\2007\Suspension\Air Suspension\Ecas Wabco can\Full air	√	√	√	√	√	0001
IVECO\Universal Area\Trakker\2006\Diesel\AdBlue system\Denoxtronic	√	√	√	√	√	
IVECO\Universal Area\Trakker\2006\Diesel\AdBlue system\Denoxtronic 2	√	√	√	√	√	0002, 0004, 0008, 0010, 0011
IVECO\Universal Area\Trakker\2006\Diesel\Engine control\MS 6.2		√	√	√	√	
IVECO\Universal Area\Trakker\2006\Diesel\Engine control\EDC MS6.2 BOSCH VERSION 1						
IVECO\Universal Area\Trakker\2006\Diesel\Engine control\EDC MS6.2 BOSCH VERSION 2	√	√	√	√	√	
IVECO\Universal Area\Trakker\2006\Diesel\Engine control\EDC 7 UC31	√	√	√	√	√	
IVECO\Universal Area\Trakker\2006\Brake\ABS\Abs Wabco D-E-E2		√	√	√	√	
IVECO\Universal Area\Trakker\2006\Brake\EBS\Ebs-Ebs 2	√	√	√	√	√	
IVECO\Universal Area\Trakker\2006\Climate\Auxiliary heater\Air heater	√	√	√	√	√	
IVECO\Universal Area\Trakker\2006\Climate\Auxiliary heater\Water heater	√	√	√	√	√	
IVECO\Universal Area\Trakker\2006\Climate\Climate control\Webasto		√	√	√	√	
IVECO\Universal Area\Trakker\2006\Gearbox\Gearbox\Eurotronic 2\Fault codes, Real time data	√	√	√	√	√	
IVECO\Universal Area\Trakker\2006\Gearbox\Gearbox\Eurotronic 2\Activations					√	
IVECO\Universal Area\Trakker\2006\Multifunction\Driver Door Module\Diagnose		√	√	√	√	
IVECO\Universal Area\Trakker\2006\Multifunction\Passenger Door Module\Diagnose		√	√	√	√	
IVECO\Universal Area\Trakker\2006\Multifunction\VCM-Immobilizer\Diagnose	√	√	√	√		
IVECO\Universal Area\Trakker\2006\Suspension\Air Suspension\Ecas Wabco can\Rear air	√	√	√	√	√	0001
IVECO\Universal Area\Trakker\2006\Suspension\Air Suspension\Ecas Wabco can\Full air	√	√	√	√	√	0001
IVECO\Universal Area\Trakker\2005\Diesel\AdBlue system\Denoxtronic	√	√	√	√	√	
IVECO\Universal Area\Trakker\2005\Diesel\AdBlue system\Denoxtronic 2	√	√	√	√	√	0002, 0004, 0008, 0010, 0011
IVECO\Universal Area\Trakker\2005\Diesel\Engine control\MS 6.2		√	√	√	√	
IVECO\Universal Area\Trakker\2005\Diesel\Engine control\EDC MS6.2 BOSCH VERSION 1						
IVECO\Universal Area\Trakker\2005\Diesel\Engine control\EDC MS6.2 BOSCH VERSION 2	√	√	√	√	√	
IVECO\Universal Area\Trakker\2005\Diesel\Engine control\EDC 7 UC31	√	√	√	√	√	
IVECO\Universal Area\Trakker\2005\Brake\ABS\Abs Wabco D-E-E2		√	√	√	√	
IVECO\Universal Area\Trakker\2005\Brake\EBS\Ebs-Ebs 2	√	√	√	√	√	
IVECO\Universal Area\Trakker\2005\Climate\Auxiliary heater\Air heater	√	√	√	√	√	
IVECO\Universal Area\Trakker\2005\Climate\Auxiliary heater\Water heater	√	√	√	√	√	
IVECO\Universal Area\Trakker\2005\Climate\Climate control\Webasto		√	√	√	√	

IVECO\Universal Area\Trakker\2005\Gearbox\Gearbox\Eurotronic 2\Fault codes, Real time data	√	√	√	√	√	
IVECO\Universal Area\Trakker\2005\Gearbox\Gearbox\Eurotronic 2\Activations					√	
IVECO\Universal Area\Trakker\2005\Multifunction\Driver Door Module\Diagnose		√	√	√	√	
IVECO\Universal Area\Trakker\2005\Multifunction\Passenger Door Module\Diagnose		√	√	√	√	
IVECO\Universal Area\Trakker\2005\Multifunction\VCM-Immobilizer\Diagnose	√	√	√	√		
IVECO\Universal Area\Trakker\2005\Suspension\Air Suspension\Ecas Wabco can\Rear air	√	√	√	√	√	0001
IVECO\Universal Area\Trakker\2005\Suspension\Air Suspension\Ecas Wabco can\Full air	√	√	√	√	√	0001

Special Function Table

0001	Air suspension calibration
0002	Dosing valve check
0003	EGR reset
0004	Flushing phase
0005	Flywheel programming
0006	Immobilizer override
0007	Particulate filter regeneration
0008	Pressurising phase
0009	Reset password
0010	System emptying
0011	Test of the heater