

SCANIA V13.77 Function list

Note:

√ Functions marked with √ is fully supported and already exited in former software version.

Number Index number of the special function , you can find the name from the special function table.

System	ECU Info.	Read Fault Code	Clear Fault Code	Live Data	Freeze Frame	Active Test	Special Func
Scania\Divided By Vehicle\TRUCK\G-Serie\Engine 230\Truck DC 9 [---07>---13]\ABS\BMS Brake management system-ABS E	√	√	√	√		√	
Scania\Divided By Vehicle\TRUCK\G-Serie\Engine 230\Truck DC 9 [---07>---13]\Aid for keeping lane\LDW Monitor traffic lane	√	√	√				
Scania\Divided By Vehicle\TRUCK\G-Serie\Engine 230\Truck DC 9 [---07>---13]\Air conditioner\CCS Climate control system	√	√	√	√		√	
Scania\Divided By Vehicle\TRUCK\G-Serie\Engine 230\Truck DC 9 [---07>---13]\Airbag\CSS Climate safety system	√	√	√				
Scania\Divided By Vehicle\TRUCK\G-Serie\Engine 230\Truck DC 9 [---07>---13]\Alarm\LAS Locking and alarm system	√	√	√				
Scania\Divided By Vehicle\TRUCK\G-Serie\Engine 230\Truck DC 9 [---07>---13]\Auxiliary heating\ATA Auxiliary heating system air-to-air	√	√	√	√			
Scania\Divided By Vehicle\TRUCK\G-Serie\Engine 230\Truck DC 9 [---07>---13]\Auxiliary heating\WTA Auxiliary heating system water-to-air	√	√	√				
Scania\Divided By Vehicle\TRUCK\G-Serie\Engine 230\Truck DC 9 [---07>---13]\Chassis equipment and design\BWS Preparation system	√	√	√				
Scania\Divided By Vehicle\TRUCK\G-Serie\Engine 230\Truck DC 9 [---07>---13]\Comfort system\CTS Clock and Time System	√	√	√				
Scania\Divided By Vehicle\TRUCK\G-Serie\Engine 230\Truck DC 9 [---07>---13]\Compressed air reserve system\APS Compressed air power supply(Scania protocol)	√	√	√	√			0003
Scania\Divided By Vehicle\TRUCK\G-Serie\Engine 230\Truck DC 9 [---07>---13]\Compressed air reserve system\APS Compressed air power supply(Wabco protocol)	√	√	√	√			
Scania\Divided By Vehicle\TRUCK\G-Serie\Engine 230\Truck DC 9 [---07>---13]\Diesel injection\EEC-Exhaust gas treatment	√	√	√	√		√	
Scania\Divided By Vehicle\TRUCK\G-Serie\Engine 230\Truck DC 9 [---07>---13]\Diesel injection\EMS Engine management system S6-S7	√	√	√	√		√	0002, 0015, 0017
Scania\Divided By Vehicle\TRUCK\G-Serie\Engine 230\Truck DC 9 [---07>---13]\Diesel injection\EMS Engine management system S8(8 Cylindes)	√	√	√	√		√	0001
Scania\Divided By Vehicle\TRUCK\G-Serie\Engine 230\Truck DC 9 [---07>---13]\Diesel injection\EMS Engine management system DC13(6 Cylindes)	√	√	√	√		√	
Scania\Divided By Vehicle\TRUCK\G-Serie\Engine 230\Truck DC 9 [---07>---13]\Distance control\DAS Adaptive Cruise Control	√	√	√				
Scania\Divided By Vehicle\TRUCK\G-Serie\Engine 230\Truck DC 9 [---07>---13]\Distance control\DIS Adaptive Cruise Control	√	√	√				
Scania\Divided By Vehicle\TRUCK\G-Serie\Engine 230\Truck DC 9 [---07>---13]\EBS\BMS Brake management system 5.0 (4x2)	√	√	√	√		√	0004
Scania\Divided By Vehicle\TRUCK\G-Serie\Engine 230\Truck DC 9 [---07>---13]\EBS\BMS Brake management system 5.0 (6x2 - 6x4)	√	√	√	√		√	0004
Scania\Divided By Vehicle\TRUCK\G-Serie\Engine 230\Truck DC 9 [---07>---13]\EBS\BMS Brake management system 5.0 (8x2)	√	√	√	√		√	0004
Scania\Divided By Vehicle\TRUCK\G-Serie\Engine 230\Truck DC 9 [---07>---13]\ECU external light\VIS Visibility system	√	√	√	√		√	
Scania\Divided By Vehicle\TRUCK\G-Serie\Engine 230\Truck DC 9 [---07>---13]\Engine-vehicle adjustment\COO Coordinator module	√	√	√	√		√	
Scania\Divided By Vehicle\TRUCK\G-Serie\Engine 230\Truck DC 9 [---07>---13]\Engine-vehicle adjustment\COO7 (Coordinator)	√	√	√	√		√	
Scania\Divided By Vehicle\TRUCK\G-Serie\Engine 230\Truck DC 9 [---07>---13]\Four-wheel drive\AWD ALL-Wheel Drive	√	√	√				
Scania\Divided By Vehicle\TRUCK\G-Serie\Engine 230\Truck DC 9 [---07>---13]\Instrument panel\NCL Instrument Panel 1	√	√	√	√		√	
Scania\Divided By Vehicle\TRUCK\G-Serie\Engine 230\Truck DC 9 [---07>---13]\Instrument panel\NCL Instrument Panel 2	√	√	√	√		√	
Scania\Divided By Vehicle\TRUCK\G-Serie\Engine 230\Truck DC 9 [---07>---13]\Radio\AUS Audio system	√	√	√				
Scania\Divided By Vehicle\TRUCK\G-Serie\Engine 230\Truck DC 9 [---07>---13]\Retarder\RET Retarder	√	√	√	√		√	
Scania\Divided By Vehicle\TRUCK\G-Serie\Engine 230\Truck DC 9 [---07>---13]\Suspensions\SMS Suspension management system	√	√	√	√			0006, 0007, 0014

Scania\Divided By Vehicle\TRUCK\G-Serie\Engine 230\Truck DC 9 [---07>---13]\Tachograph\DTCO Tachograph	√	√	√				
Scania\Divided By Vehicle\TRUCK\G-Serie\Engine 230\Truck DC 9 [---07>---13]\Tachograph\MTCO Tachograph	√	√	√				
Scania\Divided By Vehicle\TRUCK\G-Serie\Engine 230\Truck DC 9 [---07>---13]\Tire pressure\TPM - Tires Pressure Monitoring System	√	√	√				
Scania\Divided By Vehicle\TRUCK\G-Serie\Engine 230\Truck DC 9 [---07>---13]\Transmission\GMS - Gear management system A4	√	√	√			√	
Scania\Divided By Vehicle\TRUCK\G-Serie\Engine 230\Truck DC 9 [---07>---13]\Transmission\GMS - Gear management system OPC	√	√	√	√		√	0005
Scania\Divided By Vehicle\TRUCK\G-Serie\Engine 230\Truck DC 9 [---07>---13]\Transmission\GMS - Gear management system Opticruise 5	√	√	√	√		√	0009, 0011, 0018
Scania\Divided By Vehicle\TRUCK\G-Serie\Engine 230\Truck DC 9 [---07>---13]\Transmission\GMS - GMS Opticruise 5	√	√	√	√		√	0009, 0011, 0018
Scania\Divided By Vehicle\TRUCK\G-Serie\Engine 230\Truck DC 9 [---07>---13]\Transport information system\RTI - Road Transport Informatics	√	√	√				
Scania\Divided By Vehicle\TRUCK\G-Serie\Engine 230\Truck DC 9 [---07>---13]\Reset service\EMS S8						√	
Scania\Divided By Vehicle\TRUCK\G-Serie\Engine 230\Truck DC 9 [---07>---13]\Reset service\EMS S7						√	
Scania\Divided By Vehicle\TRUCK\G-Serie\Engine 230\Truck DC 9 [---07>---13]\Reset service\EMS S6						√	
Scania\Divided By Vehicle\TRUCK\G-Serie\Engine 270\Truck DC 9 [---07>---13]\ABS\BMS Brake management system-ABS E	√	√	√	√		√	
Scania\Divided By Vehicle\TRUCK\G-Serie\Engine 270\Truck DC 9 [---07>---13]\Aid for keeping lane\LDW Monitor traffic lane	√	√	√				
Scania\Divided By Vehicle\TRUCK\G-Serie\Engine 270\Truck DC 9 [---07>---13]\Air conditioner\CCS Climate control system	√	√	√	√		√	
Scania\Divided By Vehicle\TRUCK\G-Serie\Engine 270\Truck DC 9 [---07>---13]\Airbag\CSS Climate safety system	√	√	√				
Scania\Divided By Vehicle\TRUCK\G-Serie\Engine 270\Truck DC 9 [---07>---13]\Alarm\LAS Locking and alarm system	√	√	√				
Scania\Divided By Vehicle\TRUCK\G-Serie\Engine 270\Truck DC 9 [---07>---13]\Auxiliary heating\ATA Auxiliary heating system air-to-air	√	√	√	√			
Scania\Divided By Vehicle\TRUCK\G-Serie\Engine 270\Truck DC 9 [---07>---13]\Auxiliary heating\WTA Auxiliary heating system water-to-air	√	√	√				
Scania\Divided By Vehicle\TRUCK\G-Serie\Engine 270\Truck DC 9 [---07>---13]\Chassis equipment and design\BWS Preparation system	√	√	√				
Scania\Divided By Vehicle\TRUCK\G-Serie\Engine 270\Truck DC 9 [---07>---13]\Comfort system\CTS Clock and Time System	√	√	√				
Scania\Divided By Vehicle\TRUCK\G-Serie\Engine 270\Truck DC 9 [---07>---13]\Compressed air reserve system\APS Compressed air power supply(Scania protocol)	√	√	√	√			0003
Scania\Divided By Vehicle\TRUCK\G-Serie\Engine 270\Truck DC 9 [---07>---13]\Compressed air reserve system\APS Compressed air power supply(Wabco protocol)	√	√	√	√			
Scania\Divided By Vehicle\TRUCK\G-Serie\Engine 270\Truck DC 9 [---07>---13]\Diesel injection\EEC-Exhaust gas treatment	√	√	√	√		√	
Scania\Divided By Vehicle\TRUCK\G-Serie\Engine 270\Truck DC 9 [---07>---13]\Diesel injection\EMS Engine management system S6-S7	√	√	√	√		√	0002, 0015, 0017
Scania\Divided By Vehicle\TRUCK\G-Serie\Engine 270\Truck DC 9 [---07>---13]\Diesel injection\EMS Engine management system S8(8 Cylindes)	√	√	√	√		√	0001
Scania\Divided By Vehicle\TRUCK\G-Serie\Engine 270\Truck DC 9 [---07>---13]\Diesel injection\EMS Engine management system DC13(6 Cylindes)	√	√	√	√		√	
Scania\Divided By Vehicle\TRUCK\G-Serie\Engine 270\Truck DC 9 [---07>---13]\Distance control\DAS Adaptive Cruise Control	√	√	√				
Scania\Divided By Vehicle\TRUCK\G-Serie\Engine 270\Truck DC 9 [---07>---13]\Distance control\DIS Adaptive Cruise Control	√	√	√				
Scania\Divided By Vehicle\TRUCK\G-Serie\Engine 270\Truck DC 9 [---07>---13]\EBS\BMS Brake management system 5.0 (4x2)	√	√	√	√		√	0004
Scania\Divided By Vehicle\TRUCK\G-Serie\Engine 270\Truck DC 9 [---07>---13]\EBS\BMS Brake management system 5.0 (6x2 - 6x4)	√	√	√	√		√	0004
Scania\Divided By Vehicle\TRUCK\G-Serie\Engine 270\Truck DC 9 [---07>---13]\EBS\BMS Brake management system 5.0 (8x2)	√	√	√	√		√	0004
Scania\Divided By Vehicle\TRUCK\G-Serie\Engine 270\Truck DC 9 [---07>---13]\ECU external light\VIS Visiblity system	√	√	√	√		√	
Scania\Divided By Vehicle\TRUCK\G-Serie\Engine 270\Truck DC 9 [---07>---13]\Engine-vehicle adjustment\COO Coordinator module	√	√	√	√		√	
Scania\Divided By Vehicle\TRUCK\G-Serie\Engine 270\Truck DC 9 [---07>---13]\Engine-vehicle adjustment\COO7 (Coordinator)	√	√	√	√		√	
Scania\Divided By Vehicle\TRUCK\G-Serie\Engine 270\Truck DC 9 [---07>---13]\Four-wheel drive\AWD ALL-Wheel Drive	√	√	√				

Scania\Divided By Vehicle\TRUCK\G-Serie\Engine 270\Truck DC 9 [---07>---13]\Instrument panel\NCL Instrument Panel 1	√	√	√	√		√	
Scania\Divided By Vehicle\TRUCK\G-Serie\Engine 270\Truck DC 9 [---07>---13]\Instrument panel\NCL Instrument Panel 2	√	√	√	√		√	
Scania\Divided By Vehicle\TRUCK\G-Serie\Engine 270\Truck DC 9 [---07>---13]\Radio\AUS Audio system	√	√	√				
Scania\Divided By Vehicle\TRUCK\G-Serie\Engine 270\Truck DC 9 [---07>---13]\Retarder\RET Retarder	√	√	√	√		√	
Scania\Divided By Vehicle\TRUCK\G-Serie\Engine 270\Truck DC 9 [---07>---13]\Suspensions\SMS Suspension management system	√	√	√	√			0006, 0007, 0014
Scania\Divided By Vehicle\TRUCK\G-Serie\Engine 270\Truck DC 9 [---07>---13]\Tachograph\DTCO Tachograph	√	√	√				
Scania\Divided By Vehicle\TRUCK\G-Serie\Engine 270\Truck DC 9 [---07>---13]\Tachograph\MTCO Tachograph	√	√	√				
Scania\Divided By Vehicle\TRUCK\G-Serie\Engine 270\Truck DC 9 [---07>---13]\Tire pressure\TPM - Tires Pressure Monitoring System	√	√	√				
Scania\Divided By Vehicle\TRUCK\G-Serie\Engine 270\Truck DC 9 [---07>---13]\Transmission\GMS - Gear management system A4	√	√	√			√	
Scania\Divided By Vehicle\TRUCK\G-Serie\Engine 270\Truck DC 9 [---07>---13]\Transmission\GMS - Gear management system OPC	√	√	√	√		√	0005
Scania\Divided By Vehicle\TRUCK\G-Serie\Engine 270\Truck DC 9 [---07>---13]\Transmission\GMS - Gear management system Opticruise 5	√	√	√	√		√	0009, 0011, 0018
Scania\Divided By Vehicle\TRUCK\G-Serie\Engine 270\Truck DC 9 [---07>---13]\Transmission\GMS - GMS Opticruise 5	√	√	√	√		√	0009, 0011, 0018
Scania\Divided By Vehicle\TRUCK\G-Serie\Engine 270\Truck DC 9 [---07>---13]\Transport information system\RTI - Road Transport Informatics	√	√	√				
Scania\Divided By Vehicle\TRUCK\G-Serie\Engine 270\Truck DC 9 [---07>---13]\Reset service\EMS S8						√	
Scania\Divided By Vehicle\TRUCK\G-Serie\Engine 270\Truck DC 9 [---07>---13]\Reset service\EMS S7						√	
Scania\Divided By Vehicle\TRUCK\G-Serie\Engine 270\Truck DC 9 [---07>---13]\Reset service\EMS S6						√	
Scania\Divided By Vehicle\TRUCK\G-Serie\Engine 280\Truck DC 9 [---07>---13]\ABS\BMS Brake management system-ABS E	√	√	√	√		√	
Scania\Divided By Vehicle\TRUCK\G-Serie\Engine 280\Truck DC 9 [---07>---13]\Aid for keeping lane\LDW Monitor traffic lane	√	√	√				
Scania\Divided By Vehicle\TRUCK\G-Serie\Engine 280\Truck DC 9 [---07>---13]\Air conditioner\CCS Climate control system	√	√	√	√		√	
Scania\Divided By Vehicle\TRUCK\G-Serie\Engine 280\Truck DC 9 [---07>---13]\Airbag\CSS Climate safety system	√	√	√				
Scania\Divided By Vehicle\TRUCK\G-Serie\Engine 280\Truck DC 9 [---07>---13]\Alarm\LAS Locking and alarm system	√	√	√				
Scania\Divided By Vehicle\TRUCK\G-Serie\Engine 280\Truck DC 9 [---07>---13]\Auxiliary heating\ATA Auxiliary heating system air-to-air	√	√	√	√			
Scania\Divided By Vehicle\TRUCK\G-Serie\Engine 280\Truck DC 9 [---07>---13]\Auxiliary heating\WTA Auxiliary heating system water-to-air	√	√	√				
Scania\Divided By Vehicle\TRUCK\G-Serie\Engine 280\Truck DC 9 [---07>---13]\Chassis equipment and design\BWS Preparation system	√	√	√				
Scania\Divided By Vehicle\TRUCK\G-Serie\Engine 280\Truck DC 9 [---07>---13]\Comfort system\CTS Clock and Time System	√	√	√				
Scania\Divided By Vehicle\TRUCK\G-Serie\Engine 280\Truck DC 9 [---07>---13]\Compressed air reserve system\APS Compressed air power supply(Scania protocol)	√	√	√	√			0003
Scania\Divided By Vehicle\TRUCK\G-Serie\Engine 280\Truck DC 9 [---07>---13]\Compressed air reserve system\APS Compressed air power supply(Wabco protocol)	√	√	√	√			
Scania\Divided By Vehicle\TRUCK\G-Serie\Engine 280\Truck DC 9 [---07>---13]\Diesel injection\EEC-Exhaust gas treatment	√	√	√	√		√	
Scania\Divided By Vehicle\TRUCK\G-Serie\Engine 280\Truck DC 9 [---07>---13]\Diesel injection\EMS Engine management system S6-S7	√	√	√	√		√	0002, 0015, 0017
Scania\Divided By Vehicle\TRUCK\G-Serie\Engine 280\Truck DC 9 [---07>---13]\Diesel injection\EMS Engine management system S8(8 Cylindres)	√	√	√	√		√	0001
Scania\Divided By Vehicle\TRUCK\G-Serie\Engine 280\Truck DC 9 [---07>---13]\Diesel injection\EMS Engine management system DC13(6 Cylindres)	√	√	√	√		√	
Scania\Divided By Vehicle\TRUCK\G-Serie\Engine 280\Truck DC 9 [---07>---13]\Distance control\DAS Adaptive Cruise Control	√	√	√				
Scania\Divided By Vehicle\TRUCK\G-Serie\Engine 280\Truck DC 9 [---07>---13]\Distance control\DIS Adaptive Cruise Control	√	√	√				
Scania\Divided By Vehicle\TRUCK\G-Serie\Engine 280\Truck DC 9 [---07>---13]\EBS\BMS Brake management system 5.0 (4x2)	√	√	√	√		√	0004
Scania\Divided By Vehicle\TRUCK\G-Serie\Engine 280\Truck DC 9 [---07>---13]\EBS\BMS Brake management system 5.0 (6x2 - 6x4)	√	√	√	√		√	0004

Scania\Divided By Vehicle\TRUCK\G-Serie\Engine 280\Truck DC 9 [---07>---13]\EBS\BMS Brake management system 5.0 (8x2)	√	√	√	√		√	0004
Scania\Divided By Vehicle\TRUCK\G-Serie\Engine 280\Truck DC 9 [---07>---13]\ECU external light\VIS Visibility system	√	√	√	√		√	
Scania\Divided By Vehicle\TRUCK\G-Serie\Engine 280\Truck DC 9 [---07>---13]\Engine-vehicle adjustment\COO Coordinator module	√	√	√	√		√	
Scania\Divided By Vehicle\TRUCK\G-Serie\Engine 280\Truck DC 9 [---07>---13]\Engine-vehicle adjustment\COO7 (Coordinator)	√	√	√	√		√	
Scania\Divided By Vehicle\TRUCK\G-Serie\Engine 280\Truck DC 9 [---07>---13]\Four-wheel drive\AWD ALL-Wheel Drive	√	√	√				
Scania\Divided By Vehicle\TRUCK\G-Serie\Engine 280\Truck DC 9 [---07>---13]\Instrument panel\NCL Instrument Panel 1	√	√	√	√		√	
Scania\Divided By Vehicle\TRUCK\G-Serie\Engine 280\Truck DC 9 [---07>---13]\Instrument panel\NCL Instrument Panel 2	√	√	√	√		√	
Scania\Divided By Vehicle\TRUCK\G-Serie\Engine 280\Truck DC 9 [---07>---13]\Radio\AUS Audio system	√	√	√				
Scania\Divided By Vehicle\TRUCK\G-Serie\Engine 280\Truck DC 9 [---07>---13]\Retarder\RET Retarder	√	√	√	√		√	
Scania\Divided By Vehicle\TRUCK\G-Serie\Engine 280\Truck DC 9 [---07>---13]\Suspensions\SMS Supension management system	√	√	√	√			0006, 0007, 0014
Scania\Divided By Vehicle\TRUCK\G-Serie\Engine 280\Truck DC 9 [---07>---13]\Tachograph\DTCO Tachograph	√	√	√				
Scania\Divided By Vehicle\TRUCK\G-Serie\Engine 280\Truck DC 9 [---07>---13]\Tachograph\MTCO Tachograph	√	√	√				
Scania\Divided By Vehicle\TRUCK\G-Serie\Engine 280\Truck DC 9 [---07>---13]\Tire pressure\TPM - Tires Pressure Monitoring System	√	√	√				
Scania\Divided By Vehicle\TRUCK\G-Serie\Engine 280\Truck DC 9 [---07>---13]\Transmission\GMS - Gear management system A4	√	√	√			√	
Scania\Divided By Vehicle\TRUCK\G-Serie\Engine 280\Truck DC 9 [---07>---13]\Transmission\GMS - Gear management system OPC	√	√	√	√		√	0005
Scania\Divided By Vehicle\TRUCK\G-Serie\Engine 280\Truck DC 9 [---07>---13]\Transmission\GMS - Gear management system Opticruise 5	√	√	√	√		√	0009, 0011, 0018
Scania\Divided By Vehicle\TRUCK\G-Serie\Engine 280\Truck DC 9 [---07>---13]\Transmission\GMS - GMS Opticruise 5	√	√	√	√		√	0009, 0011, 0018
Scania\Divided By Vehicle\TRUCK\G-Serie\Engine 280\Truck DC 9 [---07>---13]\Transport information system\RTI - Road Transport Informatics	√	√	√				
Scania\Divided By Vehicle\TRUCK\G-Serie\Engine 280\Truck DC 9 [---07>---13]\Reset service\EMS S8						√	
Scania\Divided By Vehicle\TRUCK\G-Serie\Engine 280\Truck DC 9 [---07>---13]\Reset service\EMS S7						√	
Scania\Divided By Vehicle\TRUCK\G-Serie\Engine 280\Truck DC 9 [---07>---13]\Reset service\EMS S6						√	
Scania\Divided By Vehicle\TRUCK\G-Serie\Engine 310\Truck DC 9 [---07>---13]\ABS\BMS Brake management system-ABS E	√	√	√	√		√	
Scania\Divided By Vehicle\TRUCK\G-Serie\Engine 310\Truck DC 9 [---07>---13]\Aid for keeping lane\LDW Monitor traffic lane	√	√	√				
Scania\Divided By Vehicle\TRUCK\G-Serie\Engine 310\Truck DC 9 [---07>---13]\Air conditioner\CCS Climate control system	√	√	√	√		√	
Scania\Divided By Vehicle\TRUCK\G-Serie\Engine 310\Truck DC 9 [---07>---13]\Airbag\CSS Climate safety system	√	√	√				
Scania\Divided By Vehicle\TRUCK\G-Serie\Engine 310\Truck DC 9 [---07>---13]\Alarm\LAS Locking and alarm system	√	√	√				
Scania\Divided By Vehicle\TRUCK\G-Serie\Engine 310\Truck DC 9 [---07>---13]\Auxiliary heating\ATA Auxiliary heating system air-to-air	√	√	√	√			
Scania\Divided By Vehicle\TRUCK\G-Serie\Engine 310\Truck DC 9 [---07>---13]\Auxiliary heating\WTA Auxiliary heating system water-to-air	√	√	√				
Scania\Divided By Vehicle\TRUCK\G-Serie\Engine 310\Truck DC 9 [---07>---13]\Chassis equipment and design\BWS Preparation system	√	√	√				
Scania\Divided By Vehicle\TRUCK\G-Serie\Engine 310\Truck DC 9 [---07>---13]\Comfort system\CTS Clock and Time System	√	√	√				
Scania\Divided By Vehicle\TRUCK\G-Serie\Engine 310\Truck DC 9 [---07>---13]\Compressed air reserve system\APS Compressed air power supply(Scania protocol)	√	√	√	√			0003
Scania\Divided By Vehicle\TRUCK\G-Serie\Engine 310\Truck DC 9 [---07>---13]\Compressed air reserve system\APS Compressed air power supply(Wabco protocol)	√	√	√	√			
Scania\Divided By Vehicle\TRUCK\G-Serie\Engine 310\Truck DC 9 [---07>---13]\Diesel injection\EEC-Exhaust gas treatment	√	√	√	√		√	
Scania\Divided By Vehicle\TRUCK\G-Serie\Engine 310\Truck DC 9 [---07>---13]\Diesel injection\EMS Engine management system S6-S7	√	√	√	√		√	0002, 0015, 0017
Scania\Divided By Vehicle\TRUCK\G-Serie\Engine 310\Truck DC 9 [---07>---13]\Diesel injection\EMS Engine management system S8(8 Cylindes)	√	√	√	√		√	0001

Scania\Divided By Vehicle\TRUCK\G-Serie\Engine 310\Truck DC 9 [---07>---13]\Diesel injection\EMS Engine management system DC13(6 Cylindres)	√	√	√	√		√	
Scania\Divided By Vehicle\TRUCK\G-Serie\Engine 310\Truck DC 9 [---07>---13]\Distance control\DAS Adaptive Cruise Control	√	√	√				
Scania\Divided By Vehicle\TRUCK\G-Serie\Engine 310\Truck DC 9 [---07>---13]\Distance control\DIS Adaptive Cruise Control	√	√	√				
Scania\Divided By Vehicle\TRUCK\G-Serie\Engine 310\Truck DC 9 [---07>---13]\EBS\BMS Brake management system 5.0 (4x2)	√	√	√	√		√	0004
Scania\Divided By Vehicle\TRUCK\G-Serie\Engine 310\Truck DC 9 [---07>---13]\EBS\BMS Brake management system 5.0 (6x2 - 6x4)	√	√	√	√		√	0004
Scania\Divided By Vehicle\TRUCK\G-Serie\Engine 310\Truck DC 9 [---07>---13]\EBS\BMS Brake management system 5.0 (8x2)	√	√	√	√		√	0004
Scania\Divided By Vehicle\TRUCK\G-Serie\Engine 310\Truck DC 9 [---07>---13]\ECU external light\VIS Visibility system	√	√	√	√		√	
Scania\Divided By Vehicle\TRUCK\G-Serie\Engine 310\Truck DC 9 [---07>---13]\Engine-vehicle adjustment\COO Coordinator module	√	√	√	√		√	
Scania\Divided By Vehicle\TRUCK\G-Serie\Engine 310\Truck DC 9 [---07>---13]\Engine-vehicle adjustment\COO7 (Coordinator)	√	√	√	√		√	
Scania\Divided By Vehicle\TRUCK\G-Serie\Engine 310\Truck DC 9 [---07>---13]\Four-wheel drive\AWD ALL-Wheel Drive	√	√	√				
Scania\Divided By Vehicle\TRUCK\G-Serie\Engine 310\Truck DC 9 [---07>---13]\Instrument panel\NCL Instrument Panel 1	√	√	√	√		√	
Scania\Divided By Vehicle\TRUCK\G-Serie\Engine 310\Truck DC 9 [---07>---13]\Instrument panel\NCL Instrument Panel 2	√	√	√	√		√	
Scania\Divided By Vehicle\TRUCK\G-Serie\Engine 310\Truck DC 9 [---07>---13]\Radio\AUS Audio system	√	√	√				
Scania\Divided By Vehicle\TRUCK\G-Serie\Engine 310\Truck DC 9 [---07>---13]\Retarder\RET Retarder	√	√	√	√		√	
Scania\Divided By Vehicle\TRUCK\G-Serie\Engine 310\Truck DC 9 [---07>---13]\Suspensions\SMS Supension management system	√	√	√	√			0006, 0007, 0014
Scania\Divided By Vehicle\TRUCK\G-Serie\Engine 310\Truck DC 9 [---07>---13]\Tachograph\DTCO Tachograph	√	√	√				
Scania\Divided By Vehicle\TRUCK\G-Serie\Engine 310\Truck DC 9 [---07>---13]\Tachograph\MTCO Tachograph	√	√	√				
Scania\Divided By Vehicle\TRUCK\G-Serie\Engine 310\Truck DC 9 [---07>---13]\Tire pressure\TPM - Tires Pressure Monitoring System	√	√	√				
Scania\Divided By Vehicle\TRUCK\G-Serie\Engine 310\Truck DC 9 [---07>---13]\Transmission\GMS - Gear management system A4	√	√	√			√	
Scania\Divided By Vehicle\TRUCK\G-Serie\Engine 310\Truck DC 9 [---07>---13]\Transmission\GMS - Gear management system OPC	√	√	√	√		√	0005
Scania\Divided By Vehicle\TRUCK\G-Serie\Engine 310\Truck DC 9 [---07>---13]\Transmission\GMS - Gear management system Opticruise 5	√	√	√	√		√	0009, 0011, 0018
Scania\Divided By Vehicle\TRUCK\G-Serie\Engine 310\Truck DC 9 [---07>---13]\Transmission\GMS - GMS Opticruise 5	√	√	√	√		√	0009, 0011, 0018
Scania\Divided By Vehicle\TRUCK\G-Serie\Engine 310\Truck DC 9 [---07>---13]\Transport information system\RTI - Road Transport Informatics	√	√	√				
Scania\Divided By Vehicle\TRUCK\G-Serie\Engine 310\Truck DC 9 [---07>---13]\Reset service\EMS S8						√	
Scania\Divided By Vehicle\TRUCK\G-Serie\Engine 310\Truck DC 9 [---07>---13]\Reset service\EMS S7						√	
Scania\Divided By Vehicle\TRUCK\G-Serie\Engine 310\Truck DC 9 [---07>---13]\Reset service\EMS S6						√	
Scania\Divided By Vehicle\TRUCK\G-Serie\Engine 320\Truck DC 9 [---07>---13]\ABS\BMS Brake management system-ABS E	√	√	√	√		√	
Scania\Divided By Vehicle\TRUCK\G-Serie\Engine 320\Truck DC 9 [---07>---13]\Aid for keeping lane\LDW Monitor traffic lane	√	√	√				
Scania\Divided By Vehicle\TRUCK\G-Serie\Engine 320\Truck DC 9 [---07>---13]\Air conditioner\CCS Climate control system	√	√	√	√		√	
Scania\Divided By Vehicle\TRUCK\G-Serie\Engine 320\Truck DC 9 [---07>---13]\Airbag\CSS Climate safety system	√	√	√				
Scania\Divided By Vehicle\TRUCK\G-Serie\Engine 320\Truck DC 9 [---07>---13]\Alarm\LAS Locking and alarm system	√	√	√				
Scania\Divided By Vehicle\TRUCK\G-Serie\Engine 320\Truck DC 9 [---07>---13]\Auxiliary heating\ATA Auxiliary heating system air-to-air	√	√	√	√			
Scania\Divided By Vehicle\TRUCK\G-Serie\Engine 320\Truck DC 9 [---07>---13]\Auxiliary heating\WTA Auxiliary heating system water-to-air	√	√	√				
Scania\Divided By Vehicle\TRUCK\G-Serie\Engine 320\Truck DC 9 [---07>---13]\Chassis equipment and design\BWS Preparation system	√	√	√				
Scania\Divided By Vehicle\TRUCK\G-Serie\Engine 320\Truck DC 9 [---07>---13]\Comfort system\CTS Clock and Time System	√	√	√				

Scania\Divided By Vehicle\TRUCK\G-Serie\Engine 320\Truck DC 9 [---07>---13]\Compressed air reserve system\APS Compressed air power supply(Scania protocol)	√	√	√	√			0003
Scania\Divided By Vehicle\TRUCK\G-Serie\Engine 320\Truck DC 9 [---07>---13]\Compressed air reserve system\APS Compressed air power supply(Wabco protocol)	√	√	√	√			
Scania\Divided By Vehicle\TRUCK\G-Serie\Engine 320\Truck DC 9 [---07>---13]\Diesel injection\EEC-Exhaust gas treatment	√	√	√	√		√	
Scania\Divided By Vehicle\TRUCK\G-Serie\Engine 320\Truck DC 9 [---07>---13]\Diesel injection\EMS Engine management system S6-S7	√	√	√	√		√	0002, 0015, 0017
Scania\Divided By Vehicle\TRUCK\G-Serie\Engine 320\Truck DC 9 [---07>---13]\Diesel injection\EMS Engine management system S8(8 Cylindres)	√	√	√	√		√	0001
Scania\Divided By Vehicle\TRUCK\G-Serie\Engine 320\Truck DC 9 [---07>---13]\Diesel injection\EMS Engine management system DC13(6 Cylindres)	√	√	√	√		√	
Scania\Divided By Vehicle\TRUCK\G-Serie\Engine 320\Truck DC 9 [---07>---13]\Distance control\DAS Adaptive Cruise Control	√	√	√				
Scania\Divided By Vehicle\TRUCK\G-Serie\Engine 320\Truck DC 9 [---07>---13]\Distance control\DIS Adaptive Cruise Control	√	√	√				
Scania\Divided By Vehicle\TRUCK\G-Serie\Engine 320\Truck DC 9 [---07>---13]\EBS\BMS Brake management system 5.0 (4x2)	√	√	√	√		√	0004
Scania\Divided By Vehicle\TRUCK\G-Serie\Engine 320\Truck DC 9 [---07>---13]\EBS\BMS Brake management system 5.0 (6x2 - 6x4)	√	√	√	√		√	0004
Scania\Divided By Vehicle\TRUCK\G-Serie\Engine 320\Truck DC 9 [---07>---13]\EBS\BMS Brake management system 5.0 (8x2)	√	√	√	√		√	0004
Scania\Divided By Vehicle\TRUCK\G-Serie\Engine 320\Truck DC 9 [---07>---13]\ECU external light\VIS Visibility system	√	√	√	√		√	
Scania\Divided By Vehicle\TRUCK\G-Serie\Engine 320\Truck DC 9 [---07>---13]\Engine-vehicle adjustment\COO Coordinator module	√	√	√	√		√	
Scania\Divided By Vehicle\TRUCK\G-Serie\Engine 320\Truck DC 9 [---07>---13]\Engine-vehicle adjustment\COO7 (Coordinator)	√	√	√	√		√	
Scania\Divided By Vehicle\TRUCK\G-Serie\Engine 320\Truck DC 9 [---07>---13]\Four-wheel drive\AWD ALL-Wheel Drive	√	√	√				
Scania\Divided By Vehicle\TRUCK\G-Serie\Engine 320\Truck DC 9 [---07>---13]\Instrument panel\NCL Instrument Panel 1	√	√	√	√		√	
Scania\Divided By Vehicle\TRUCK\G-Serie\Engine 320\Truck DC 9 [---07>---13]\Instrument panel\NCL Instrument Panel 2	√	√	√	√		√	
Scania\Divided By Vehicle\TRUCK\G-Serie\Engine 320\Truck DC 9 [---07>---13]\Radio\AUS Audio system	√	√	√				
Scania\Divided By Vehicle\TRUCK\G-Serie\Engine 320\Truck DC 9 [---07>---13]\Retarder\RET Retarder	√	√	√	√		√	
Scania\Divided By Vehicle\TRUCK\G-Serie\Engine 320\Truck DC 9 [---07>---13]\Suspensions\SMS Supension management system	√	√	√	√			0006, 0007, 0014
Scania\Divided By Vehicle\TRUCK\G-Serie\Engine 320\Truck DC 9 [---07>---13]\Tachograph\DTCO Tachograph	√	√	√				
Scania\Divided By Vehicle\TRUCK\G-Serie\Engine 320\Truck DC 9 [---07>---13]\Tachograph\MTCO Tachograph	√	√	√				
Scania\Divided By Vehicle\TRUCK\G-Serie\Engine 320\Truck DC 9 [---07>---13]\Tire pressure\TPM - Tires Pressure Monitoring System	√	√	√				
Scania\Divided By Vehicle\TRUCK\G-Serie\Engine 320\Truck DC 9 [---07>---13]\Transmission\GMS - Gear management system A4	√	√	√			√	
Scania\Divided By Vehicle\TRUCK\G-Serie\Engine 320\Truck DC 9 [---07>---13]\Transmission\GMS - Gear management system OPC	√	√	√	√		√	0005
Scania\Divided By Vehicle\TRUCK\G-Serie\Engine 320\Truck DC 9 [---07>---13]\Transmission\GMS - Gear management system Opticruise 5	√	√	√	√		√	0009, 0011, 0018
Scania\Divided By Vehicle\TRUCK\G-Serie\Engine 320\Truck DC 9 [---07>---13]\Transmission\GMS - GMS Opticruise 5	√	√	√	√		√	0009, 0011, 0018
Scania\Divided By Vehicle\TRUCK\G-Serie\Engine 320\Truck DC 9 [---07>---13]\Transport information system\RTI - Road Transport Informatics	√	√	√				
Scania\Divided By Vehicle\TRUCK\G-Serie\Engine 320\Truck DC 9 [---07>---13]\Reset service\EMS S8						√	
Scania\Divided By Vehicle\TRUCK\G-Serie\Engine 320\Truck DC 9 [---07>---13]\Reset service\EMS S7						√	
Scania\Divided By Vehicle\TRUCK\G-Serie\Engine 320\Truck DC 9 [---07>---13]\Reset service\EMS S6						√	
Scania\Divided By Vehicle\TRUCK\G-Serie\Engine 340\Truck DC 12 HPI [---07>---13]\ABS\BMS Brake management system-ABS E	√	√	√	√		√	
Scania\Divided By Vehicle\TRUCK\G-Serie\Engine 340\Truck DC 12 HPI [---07>---13]\Aid for keeping lane\LDW Monitor traffic lane	√	√	√				
Scania\Divided By Vehicle\TRUCK\G-Serie\Engine 340\Truck DC 12 HPI [---07>---13]\Air conditioner\CCS Climate control system	√	√	√	√		√	
Scania\Divided By Vehicle\TRUCK\G-Serie\Engine 340\Truck DC 12 HPI [---07>---13]\Airbag\CSS Climate safety system	√	√	√				

Scania\Divided By Vehicle\TRUCK\G-Serie\Engine 340\Truck DC 12 HPI [---07>---13]\Alarm\LAS Locking and alarm system	√	√	√				
Scania\Divided By Vehicle\TRUCK\G-Serie\Engine 340\Truck DC 12 HPI [---07>---13]\Auxiliary heating\ATA Auxiliary heating system air-to-air	√	√	√	√			
Scania\Divided By Vehicle\TRUCK\G-Serie\Engine 340\Truck DC 12 HPI [---07>---13]\Auxiliary heating\WTA Auxiliary heating system water-to-air	√	√	√				
Scania\Divided By Vehicle\TRUCK\G-Serie\Engine 340\Truck DC 12 HPI [---07>---13]\Chassis equipment and design\BWS Preparation system	√	√	√				
Scania\Divided By Vehicle\TRUCK\G-Serie\Engine 340\Truck DC 12 HPI [---07>---13]\Comfort system\CTS Clock and Time System	√	√	√				
Scania\Divided By Vehicle\TRUCK\G-Serie\Engine 340\Truck DC 12 HPI [---07>---13]\Compressed air reserve system\APS Compressed air power supply(Scania protocol)	√	√	√	√			0003
Scania\Divided By Vehicle\TRUCK\G-Serie\Engine 340\Truck DC 12 HPI [---07>---13]\Compressed air reserve system\APS Compressed air power supply(Wabco protocol)	√	√	√	√			
Scania\Divided By Vehicle\TRUCK\G-Serie\Engine 340\Truck DC 12 HPI [---07>---13]\Diesel injection\EEC-Exhaust gas treatment	√	√	√	√		√	
Scania\Divided By Vehicle\TRUCK\G-Serie\Engine 340\Truck DC 12 HPI [---07>---13]\Diesel injection\EMS Engine management system S6-S7	√	√	√	√		√	0002, 0015, 0017
Scania\Divided By Vehicle\TRUCK\G-Serie\Engine 340\Truck DC 12 HPI [---07>---13]\Diesel injection\EMS Engine management system S8(8 Cylindres)	√	√	√	√		√	0001
Scania\Divided By Vehicle\TRUCK\G-Serie\Engine 340\Truck DC 12 HPI [---07>---13]\Diesel injection\EMS Engine management system DC13(6 Cylindres)	√	√	√	√		√	
Scania\Divided By Vehicle\TRUCK\G-Serie\Engine 340\Truck DC 12 HPI [---07>---13]\Distance control\DAS Adaptive Cruise Control	√	√	√				
Scania\Divided By Vehicle\TRUCK\G-Serie\Engine 340\Truck DC 12 HPI [---07>---13]\Distance control\DIS Adaptive Cruise Control	√	√	√				
Scania\Divided By Vehicle\TRUCK\G-Serie\Engine 340\Truck DC 12 HPI [---07>---13]\EBS\BMS Brake management system 5.0 (4x2)	√	√	√	√		√	0004
Scania\Divided By Vehicle\TRUCK\G-Serie\Engine 340\Truck DC 12 HPI [---07>---13]\EBS\BMS Brake management system 5.0 (6x2 - 6x4)	√	√	√	√		√	0004
Scania\Divided By Vehicle\TRUCK\G-Serie\Engine 340\Truck DC 12 HPI [---07>---13]\EBS\BMS Brake management system 5.0 (8x2)	√	√	√	√		√	0004
Scania\Divided By Vehicle\TRUCK\G-Serie\Engine 340\Truck DC 12 HPI [---07>---13]\ECU external light\VIS Visibility system	√	√	√	√		√	
Scania\Divided By Vehicle\TRUCK\G-Serie\Engine 340\Truck DC 12 HPI [---07>---13]\Engine-vehicle adjustment\COO Coordinator module	√	√	√	√		√	
Scania\Divided By Vehicle\TRUCK\G-Serie\Engine 340\Truck DC 12 HPI [---07>---13]\Engine-vehicle adjustment\COO7 (Coordinator)	√	√	√	√		√	
Scania\Divided By Vehicle\TRUCK\G-Serie\Engine 340\Truck DC 12 HPI [---07>---13]\Four-wheel drive\AWD ALL-Wheel Drive	√	√	√				
Scania\Divided By Vehicle\TRUCK\G-Serie\Engine 340\Truck DC 12 HPI [---07>---13]\Instrument panel\NCL Instrument Panel 1	√	√	√	√		√	
Scania\Divided By Vehicle\TRUCK\G-Serie\Engine 340\Truck DC 12 HPI [---07>---13]\Instrument panel\NCL Instrument Panel 2	√	√	√	√		√	
Scania\Divided By Vehicle\TRUCK\G-Serie\Engine 340\Truck DC 12 HPI [---07>---13]\Radio\AUS Audio system	√	√	√				
Scania\Divided By Vehicle\TRUCK\G-Serie\Engine 340\Truck DC 12 HPI [---07>---13]\Retarder\RET Retarder	√	√	√	√		√	
Scania\Divided By Vehicle\TRUCK\G-Serie\Engine 340\Truck DC 12 HPI [---07>---13]\Suspensions\SMS Suspension management system	√	√	√	√			0006, 0007, 0014
Scania\Divided By Vehicle\TRUCK\G-Serie\Engine 340\Truck DC 12 HPI [---07>---13]\Tachograph\DTCO Tachograph	√	√	√				
Scania\Divided By Vehicle\TRUCK\G-Serie\Engine 340\Truck DC 12 HPI [---07>---13]\Tachograph\MTCO Tachograph	√	√	√				
Scania\Divided By Vehicle\TRUCK\G-Serie\Engine 340\Truck DC 12 HPI [---07>---13]\Tire pressure\TPM - Tires Pressure Monitoring System	√	√	√				
Scania\Divided By Vehicle\TRUCK\G-Serie\Engine 340\Truck DC 12 HPI [---07>---13]\Transmission\GMS - Gear management system A4	√	√	√			√	
Scania\Divided By Vehicle\TRUCK\G-Serie\Engine 340\Truck DC 12 HPI [---07>---13]\Transmission\GMS - Gear management system OPC	√	√	√	√		√	0005
Scania\Divided By Vehicle\TRUCK\G-Serie\Engine 340\Truck DC 12 HPI [---07>---13]\Transmission\GMS - Gear management system Opticruise 5	√	√	√	√		√	0009, 0011, 0018
Scania\Divided By Vehicle\TRUCK\G-Serie\Engine 340\Truck DC 12 HPI [---07>---13]\Transmission\GMS - GMS Opticruise 5	√	√	√	√		√	0009, 0011, 0018
Scania\Divided By Vehicle\TRUCK\G-Serie\Engine 340\Truck DC 12 HPI [---07>---13]\Transport information system\RTI - Road Transport Informatics	√	√	√				
Scania\Divided By Vehicle\TRUCK\G-Serie\Engine 340\Truck DC 12 HPI [---07>---13]\Reset service\EMS S8						√	
Scania\Divided By Vehicle\TRUCK\G-Serie\Engine 340\Truck DC 12 HPI [---07>---13]\Reset service\EMS S7						√	

Scania\Divided By Vehicle\TRUCK\G-Serie\Engine 340\Truck DC 12 HPI [---07>---13]\Reset service\EMS S6						√	
Scania\Divided By Vehicle\TRUCK\G-Serie\Engine 380\Truck DC 12 HPI EU5 [---08>---13]\ABS\BMS Brake management system-ABS E	√	√	√	√		√	
Scania\Divided By Vehicle\TRUCK\G-Serie\Engine 380\Truck DC 12 HPI EU5 [---08>---13]\Aid for keeping lane\LDW Monitor traffic lane	√	√	√				
Scania\Divided By Vehicle\TRUCK\G-Serie\Engine 380\Truck DC 12 HPI EU5 [---08>---13]\Air conditioner\CCS Climate control system	√	√	√	√		√	
Scania\Divided By Vehicle\TRUCK\G-Serie\Engine 380\Truck DC 12 HPI EU5 [---08>---13]\Airbag\CSS Climate safety system	√	√	√				
Scania\Divided By Vehicle\TRUCK\G-Serie\Engine 380\Truck DC 12 HPI EU5 [---08>---13]\Alarm\LAS Locking and alarm system	√	√	√				
Scania\Divided By Vehicle\TRUCK\G-Serie\Engine 380\Truck DC 12 HPI EU5 [---08>---13]\Auxiliary heating\ATA Auxiliary heating system air-to-air	√	√	√	√			
Scania\Divided By Vehicle\TRUCK\G-Serie\Engine 380\Truck DC 12 HPI EU5 [---08>---13]\Auxiliary heating\WTA Auxiliary heating system water-to-air	√	√	√				
Scania\Divided By Vehicle\TRUCK\G-Serie\Engine 380\Truck DC 12 HPI EU5 [---08>---13]\Chassis equipment and design\BWS Preparation system	√	√	√				
Scania\Divided By Vehicle\TRUCK\G-Serie\Engine 380\Truck DC 12 HPI EU5 [---08>---13]\Comfort system\CTS Clock and Time System	√	√	√				
Scania\Divided By Vehicle\TRUCK\G-Serie\Engine 380\Truck DC 12 HPI EU5 [---08>---13]\Compressed air reserve system\APS Compressed air power supply(Scania protocol)	√	√	√	√			0003
Scania\Divided By Vehicle\TRUCK\G-Serie\Engine 380\Truck DC 12 HPI EU5 [---08>---13]\Compressed air reserve system\APS Compressed air power supply(Wabco protocol)	√	√	√	√			
Scania\Divided By Vehicle\TRUCK\G-Serie\Engine 380\Truck DC 12 HPI EU5 [---08>---13]\Diesel injection\EEC-Exhaust gas treatment	√	√	√	√		√	
Scania\Divided By Vehicle\TRUCK\G-Serie\Engine 380\Truck DC 12 HPI EU5 [---08>---13]\Diesel injection\EMS Engine management system S6-S7	√	√	√	√		√	0002, 0015, 0017
Scania\Divided By Vehicle\TRUCK\G-Serie\Engine 380\Truck DC 12 HPI EU5 [---08>---13]\Diesel injection\EMS Engine management system S8(8 Cylindres)	√	√	√	√		√	0001
Scania\Divided By Vehicle\TRUCK\G-Serie\Engine 380\Truck DC 12 HPI EU5 [---08>---13]\Diesel injection\EMS Engine management system DC13(6 Cylindres)	√	√	√	√		√	
Scania\Divided By Vehicle\TRUCK\G-Serie\Engine 380\Truck DC 12 HPI EU5 [---08>---13]\Distance control\DAS Adaptive Cruise Control	√	√	√				
Scania\Divided By Vehicle\TRUCK\G-Serie\Engine 380\Truck DC 12 HPI EU5 [---08>---13]\Distance control\DIS Adaptive Cruise Control	√	√	√				
Scania\Divided By Vehicle\TRUCK\G-Serie\Engine 380\Truck DC 12 HPI EU5 [---08>---13]\EBS\BMS Brake management system 5.0 (4x2)	√	√	√	√		√	0004
Scania\Divided By Vehicle\TRUCK\G-Serie\Engine 380\Truck DC 12 HPI EU5 [---08>---13]\EBS\BMS Brake management system 5.0 (6x2 - 6x4)	√	√	√	√		√	0004
Scania\Divided By Vehicle\TRUCK\G-Serie\Engine 380\Truck DC 12 HPI EU5 [---08>---13]\EBS\BMS Brake management system 5.0 (8x2)	√	√	√	√		√	0004
Scania\Divided By Vehicle\TRUCK\G-Serie\Engine 380\Truck DC 12 HPI EU5 [---08>---13]\ECU external light\VIS Visibility system	√	√	√	√		√	
Scania\Divided By Vehicle\TRUCK\G-Serie\Engine 380\Truck DC 12 HPI EU5 [---08>---13]\Engine-vehicle adjustment\COO Coordinator module	√	√	√	√		√	
Scania\Divided By Vehicle\TRUCK\G-Serie\Engine 380\Truck DC 12 HPI EU5 [---08>---13]\Engine-vehicle adjustment\COO7 (Coordinator)	√	√	√	√		√	
Scania\Divided By Vehicle\TRUCK\G-Serie\Engine 380\Truck DC 12 HPI EU5 [---08>---13]\Four-wheel drive\AWD ALL-Wheel Drive	√	√	√				
Scania\Divided By Vehicle\TRUCK\G-Serie\Engine 380\Truck DC 12 HPI EU5 [---08>---13]\Instrument panel\NCL Instrument Panel 1	√	√	√	√		√	
Scania\Divided By Vehicle\TRUCK\G-Serie\Engine 380\Truck DC 12 HPI EU5 [---08>---13]\Instrument panel\NCL Instrument Panel 2	√	√	√	√		√	
Scania\Divided By Vehicle\TRUCK\G-Serie\Engine 380\Truck DC 12 HPI EU5 [---08>---13]\Radio\AUS Audio system	√	√	√				
Scania\Divided By Vehicle\TRUCK\G-Serie\Engine 380\Truck DC 12 HPI EU5 [---08>---13]\Retarder\RET Retarder	√	√	√	√		√	
Scania\Divided By Vehicle\TRUCK\G-Serie\Engine 380\Truck DC 12 HPI EU5 [---08>---13]\Suspensions\SMS Supension management system	√	√	√	√			0006, 0007, 0014
Scania\Divided By Vehicle\TRUCK\G-Serie\Engine 380\Truck DC 12 HPI EU5 [---08>---13]\Tachograph\DTCO Tachograph	√	√	√				
Scania\Divided By Vehicle\TRUCK\G-Serie\Engine 380\Truck DC 12 HPI EU5 [---08>---13]\Tachograph\MTCO Tachograph	√	√	√				
Scania\Divided By Vehicle\TRUCK\G-Serie\Engine 380\Truck DC 12 HPI EU5 [---08>---13]\Tire pressure\TPM - Tires Pressure Monitoring System	√	√	√				
Scania\Divided By Vehicle\TRUCK\G-Serie\Engine 380\Truck DC 12 HPI EU5 [---08>---13]\Transmission\GMS - Gear management system A4	√	√	√			√	
Scania\Divided By Vehicle\TRUCK\G-Serie\Engine 380\Truck DC 12 HPI EU5 [---08>---13]\Transmission\GMS - Gear management system OPC	√	√	√	√		√	0005

Scania\Divided By Vehicle\TRUCK\G-Serie\Engine 380\Truck DC 12 HPI EU5 [---08>---13]\Transmission\GMS - Gear management system Opticruise 5	√	√	√	√		√	0009, 0011, 0018
Scania\Divided By Vehicle\TRUCK\G-Serie\Engine 380\Truck DC 12 HPI EU5 [---08>---13]\Transmission\GMS - GMS Opticruise 5	√	√	√	√		√	0009, 0011, 0018
Scania\Divided By Vehicle\TRUCK\G-Serie\Engine 380\Truck DC 12 HPI EU5 [---08>---13]\Transport information system\RTI - Road Transport Informatics	√	√	√				
Scania\Divided By Vehicle\TRUCK\G-Serie\Engine 380\Truck DC 12 HPI EU5 [---08>---13]\Reset service\EMS S8						√	
Scania\Divided By Vehicle\TRUCK\G-Serie\Engine 380\Truck DC 12 HPI EU5 [---08>---13]\Reset service\EMS S7						√	
Scania\Divided By Vehicle\TRUCK\G-Serie\Engine 380\Truck DC 12 HPI EU5 [---08>---13]\Reset service\EMS S6						√	
Scania\Divided By Vehicle\TRUCK\G-Serie\Engine 380\Truck DC 12 HPI [---05>---08]\ABS\BMS Brake management system-ABS E	√	√	√	√		√	
Scania\Divided By Vehicle\TRUCK\G-Serie\Engine 380\Truck DC 12 HPI [---05>---08]\Aid for keeping lane\LDW Monitor traffic lane	√	√	√				
Scania\Divided By Vehicle\TRUCK\G-Serie\Engine 380\Truck DC 12 HPI [---05>---08]\Air conditioner\CCS Climate control system	√	√	√	√		√	
Scania\Divided By Vehicle\TRUCK\G-Serie\Engine 380\Truck DC 12 HPI [---05>---08]\Airbag\CSS Climate safety system	√	√	√				
Scania\Divided By Vehicle\TRUCK\G-Serie\Engine 380\Truck DC 12 HPI [---05>---08]\Alarm\LAS Locking and alarm system	√	√	√				
Scania\Divided By Vehicle\TRUCK\G-Serie\Engine 380\Truck DC 12 HPI [---05>---08]\Auxiliary heating\ATA Auxiliary heating system air-to-air	√	√	√	√			
Scania\Divided By Vehicle\TRUCK\G-Serie\Engine 380\Truck DC 12 HPI [---05>---08]\Auxiliary heating\WTA Auxiliary heating system water-to-air	√	√	√				
Scania\Divided By Vehicle\TRUCK\G-Serie\Engine 380\Truck DC 12 HPI [---05>---08]\Chassis equipment and design\BWS Preparation system	√	√	√				
Scania\Divided By Vehicle\TRUCK\G-Serie\Engine 380\Truck DC 12 HPI [---05>---08]\Comfort system\CTS Clock and Time System	√	√	√				
Scania\Divided By Vehicle\TRUCK\G-Serie\Engine 380\Truck DC 12 HPI [---05>---08]\Compressed air reserve system\APS Compressed air power supply(Scania protocol)	√	√	√	√			0003
Scania\Divided By Vehicle\TRUCK\G-Serie\Engine 380\Truck DC 12 HPI [---05>---08]\Compressed air reserve system\APS Compressed air power supply(Wabco protocol)	√	√	√	√			
Scania\Divided By Vehicle\TRUCK\G-Serie\Engine 380\Truck DC 12 HPI [---05>---08]\Diesel injection\EEC-Exhaust gas treatment	√	√	√	√		√	
Scania\Divided By Vehicle\TRUCK\G-Serie\Engine 380\Truck DC 12 HPI [---05>---08]\Diesel injection\EMS Engine management system S6-S7	√	√	√	√		√	0002, 0015, 0017
Scania\Divided By Vehicle\TRUCK\G-Serie\Engine 380\Truck DC 12 HPI [---05>---08]\Diesel injection\EMS Engine management system S8(8 Cylindes)	√	√	√	√		√	0001
Scania\Divided By Vehicle\TRUCK\G-Serie\Engine 380\Truck DC 12 HPI [---05>---08]\Diesel injection\EMS Engine management system DC13(6 Cylindes)	√	√	√	√		√	
Scania\Divided By Vehicle\TRUCK\G-Serie\Engine 380\Truck DC 12 HPI [---05>---08]\Distance control\DAS Adaptive Cruise Control	√	√	√				
Scania\Divided By Vehicle\TRUCK\G-Serie\Engine 380\Truck DC 12 HPI [---05>---08]\Distance control\DIS Adaptive Cruise Control	√	√	√				
Scania\Divided By Vehicle\TRUCK\G-Serie\Engine 380\Truck DC 12 HPI [---05>---08]\EBS\BMS Brake management system 5.0 (4x2)	√	√	√	√		√	0004
Scania\Divided By Vehicle\TRUCK\G-Serie\Engine 380\Truck DC 12 HPI [---05>---08]\EBS\BMS Brake management system 5.0 (6x2 - 6x4)	√	√	√	√		√	0004
Scania\Divided By Vehicle\TRUCK\G-Serie\Engine 380\Truck DC 12 HPI [---05>---08]\EBS\BMS Brake management system 5.0 (8x2)	√	√	√	√		√	0004
Scania\Divided By Vehicle\TRUCK\G-Serie\Engine 380\Truck DC 12 HPI [---05>---08]\ECU external light\VIS Visibility system	√	√	√	√		√	
Scania\Divided By Vehicle\TRUCK\G-Serie\Engine 380\Truck DC 12 HPI [---05>---08]\Engine-vehicle adjustment\COO Coordinator module	√	√	√	√		√	
Scania\Divided By Vehicle\TRUCK\G-Serie\Engine 380\Truck DC 12 HPI [---05>---08]\Engine-vehicle adjustment\COO7 (Coordinator)	√	√	√	√		√	
Scania\Divided By Vehicle\TRUCK\G-Serie\Engine 380\Truck DC 12 HPI [---05>---08]\Four-wheel drive\AWD ALL-Wheel Drive	√	√	√				
Scania\Divided By Vehicle\TRUCK\G-Serie\Engine 380\Truck DC 12 HPI [---05>---08]\Instrument pane\NCL Instrument Panel 1	√	√	√	√		√	
Scania\Divided By Vehicle\TRUCK\G-Serie\Engine 380\Truck DC 12 HPI [---05>---08]\Instrument pane\NCL Instrument Panel 2	√	√	√	√		√	
Scania\Divided By Vehicle\TRUCK\G-Serie\Engine 380\Truck DC 12 HPI [---05>---08]\Radio\AUS Audio system	√	√	√				
Scania\Divided By Vehicle\TRUCK\G-Serie\Engine 380\Truck DC 12 HPI [---05>---08]\Retarder\RET Retarder	√	√	√	√		√	
Scania\Divided By Vehicle\TRUCK\G-Serie\Engine 380\Truck DC 12 HPI [---05>---08]\Suspensions\SMS Supension management system	√	√	√	√			0006, 0007, 0014

Scania\Divided By Vehicle\TRUCK\G-Serie\Engine 380\Truck DC 12 HPI [---05>---08]\Tachograph\DTCO Tachograph	√	√	√				
Scania\Divided By Vehicle\TRUCK\G-Serie\Engine 380\Truck DC 12 HPI [---05>---08]\Tachograph\MTCO Tachograph	√	√	√				
Scania\Divided By Vehicle\TRUCK\G-Serie\Engine 380\Truck DC 12 HPI [---05>---08]\Tire pressure\TPM - Tires Pressure Monitoring System	√	√	√				
Scania\Divided By Vehicle\TRUCK\G-Serie\Engine 380\Truck DC 12 HPI [---05>---08]\Transmission\GMS - Gear management system A4	√	√	√			√	
Scania\Divided By Vehicle\TRUCK\G-Serie\Engine 380\Truck DC 12 HPI [---05>---08]\Transmission\GMS - Gear management system OPC	√	√	√	√		√	0005
Scania\Divided By Vehicle\TRUCK\G-Serie\Engine 380\Truck DC 12 HPI [---05>---08]\Transmission\GMS - Gear management system Opticruise 5	√	√	√	√		√	0009, 0011, 0018
Scania\Divided By Vehicle\TRUCK\G-Serie\Engine 380\Truck DC 12 HPI [---05>---08]\Transmission\GMS - GMS Opticruise 5	√	√	√	√		√	0009, 0011, 0018
Scania\Divided By Vehicle\TRUCK\G-Serie\Engine 380\Truck DC 12 HPI [---05>---08]\Transport information system\RTI - Road Transport Informatics	√	√	√				
Scania\Divided By Vehicle\TRUCK\G-Serie\Engine 380\Truck DC 12 HPI [---05>---08]\Reset service\EMS S8						√	
Scania\Divided By Vehicle\TRUCK\G-Serie\Engine 380\Truck DC 12 HPI [---05>---08]\Reset service\EMS S7						√	
Scania\Divided By Vehicle\TRUCK\G-Serie\Engine 380\Truck DC 12 HPI [---05>---08]\Reset service\EMS S6						√	
Scania\Divided By Vehicle\TRUCK\G-Serie\Engine 400\Truck DC 9 [---07>---13]\ABS\BMS Brake management system-ABS E	√	√	√	√		√	
Scania\Divided By Vehicle\TRUCK\G-Serie\Engine 400\Truck DC 9 [---07>---13]\Aid for keeping lane\LDW Monitor traffic lane	√	√	√				
Scania\Divided By Vehicle\TRUCK\G-Serie\Engine 400\Truck DC 9 [---07>---13]\Air conditioner\CCS Climate control system	√	√	√	√		√	
Scania\Divided By Vehicle\TRUCK\G-Serie\Engine 400\Truck DC 9 [---07>---13]\Airbag\CSS Climate safety system	√	√	√				
Scania\Divided By Vehicle\TRUCK\G-Serie\Engine 400\Truck DC 9 [---07>---13]\Alarm\LAS Locking and alarm system	√	√	√				
Scania\Divided By Vehicle\TRUCK\G-Serie\Engine 400\Truck DC 9 [---07>---13]\Auxiliary heating\ATA Auxiliary heating system air-to-air	√	√	√	√			
Scania\Divided By Vehicle\TRUCK\G-Serie\Engine 400\Truck DC 9 [---07>---13]\Auxiliary heating\WTA Auxiliary heating system water-to-air	√	√	√				
Scania\Divided By Vehicle\TRUCK\G-Serie\Engine 400\Truck DC 9 [---07>---13]\Chassis equipment and design\BWS Preparation system	√	√	√				
Scania\Divided By Vehicle\TRUCK\G-Serie\Engine 400\Truck DC 9 [---07>---13]\Comfort system\CTS Clock and Time System	√	√	√				
Scania\Divided By Vehicle\TRUCK\G-Serie\Engine 400\Truck DC 9 [---07>---13]\Compressed air reserve system\APS Compressed air power supply(Scania protocol)	√	√	√	√			0003
Scania\Divided By Vehicle\TRUCK\G-Serie\Engine 400\Truck DC 9 [---07>---13]\Compressed air reserve system\APS Compressed air power supply(Wabco protocol)	√	√	√	√			
Scania\Divided By Vehicle\TRUCK\G-Serie\Engine 400\Truck DC 9 [---07>---13]\Diesel injection\EEC-Exhaust gas treatment	√	√	√	√		√	
Scania\Divided By Vehicle\TRUCK\G-Serie\Engine 400\Truck DC 9 [---07>---13]\Diesel injection\EMS Engine management system S6-S7	√	√	√	√		√	0002, 0015, 0017
Scania\Divided By Vehicle\TRUCK\G-Serie\Engine 400\Truck DC 9 [---07>---13]\Diesel injection\EMS Engine management system S8(8 Cylindes)	√	√	√	√		√	0001
Scania\Divided By Vehicle\TRUCK\G-Serie\Engine 400\Truck DC 9 [---07>---13]\Diesel injection\EMS Engine management system DC13(6 Cylindes)	√	√	√	√		√	
Scania\Divided By Vehicle\TRUCK\G-Serie\Engine 400\Truck DC 9 [---07>---13]\Distance control\DAS Adaptive Cruise Control	√	√	√				
Scania\Divided By Vehicle\TRUCK\G-Serie\Engine 400\Truck DC 9 [---07>---13]\Distance control\DIS Adaptive Cruise Control	√	√	√				
Scania\Divided By Vehicle\TRUCK\G-Serie\Engine 400\Truck DC 9 [---07>---13]\EBS\BMS Brake management system 5.0 (4x2)	√	√	√	√		√	0004
Scania\Divided By Vehicle\TRUCK\G-Serie\Engine 400\Truck DC 9 [---07>---13]\EBS\BMS Brake management system 5.0 (6x2 - 6x4)	√	√	√	√		√	0004
Scania\Divided By Vehicle\TRUCK\G-Serie\Engine 400\Truck DC 9 [---07>---13]\EBS\BMS Brake management system 5.0 (8x2)	√	√	√	√		√	0004
Scania\Divided By Vehicle\TRUCK\G-Serie\Engine 400\Truck DC 9 [---07>---13]\ECU external light\VIS Visiblity system	√	√	√	√		√	
Scania\Divided By Vehicle\TRUCK\G-Serie\Engine 400\Truck DC 9 [---07>---13]\Engine-vehicle adjustment\COO Coordinator module	√	√	√	√		√	
Scania\Divided By Vehicle\TRUCK\G-Serie\Engine 400\Truck DC 9 [---07>---13]\Engine-vehicle adjustment\COO7 (Coordinator)	√	√	√	√		√	
Scania\Divided By Vehicle\TRUCK\G-Serie\Engine 400\Truck DC 9 [---07>---13]\Four-wheel drive\AWD ALL-Wheel Drive	√	√	√				

Scania\Divided By Vehicle\TRUCK\G-Serie\Engine 400\Truck DC 9 [---07>---13]\Instrument panel\NCL Instrument Panel 1	√	√	√	√		√	
Scania\Divided By Vehicle\TRUCK\G-Serie\Engine 400\Truck DC 9 [---07>---13]\Instrument panel\NCL Instrument Panel 2	√	√	√	√		√	
Scania\Divided By Vehicle\TRUCK\G-Serie\Engine 400\Truck DC 9 [---07>---13]\Radio\AUS Audio system	√	√	√				
Scania\Divided By Vehicle\TRUCK\G-Serie\Engine 400\Truck DC 9 [---07>---13]\Retarder\RET Retarder	√	√	√	√		√	
Scania\Divided By Vehicle\TRUCK\G-Serie\Engine 400\Truck DC 9 [---07>---13]\Suspensions\SMS Suspension management system	√	√	√	√			0006, 0007, 0014
Scania\Divided By Vehicle\TRUCK\G-Serie\Engine 400\Truck DC 9 [---07>---13]\Tachograph\DTCO Tachograph	√	√	√				
Scania\Divided By Vehicle\TRUCK\G-Serie\Engine 400\Truck DC 9 [---07>---13]\Tachograph\MTCO Tachograph	√	√	√				
Scania\Divided By Vehicle\TRUCK\G-Serie\Engine 400\Truck DC 9 [---07>---13]\Tire pressure\TPM - Tires Pressure Monitoring System	√	√	√				
Scania\Divided By Vehicle\TRUCK\G-Serie\Engine 400\Truck DC 9 [---07>---13]\Transmission\GMS - Gear management system A4	√	√	√			√	
Scania\Divided By Vehicle\TRUCK\G-Serie\Engine 400\Truck DC 9 [---07>---13]\Transmission\GMS - Gear management system OPC	√	√	√	√		√	0005
Scania\Divided By Vehicle\TRUCK\G-Serie\Engine 400\Truck DC 9 [---07>---13]\Transmission\GMS - Gear management system Opticruise 5	√	√	√	√		√	0009, 0011, 0018
Scania\Divided By Vehicle\TRUCK\G-Serie\Engine 400\Truck DC 9 [---07>---13]\Transmission\GMS - GMS Opticruise 5	√	√	√	√		√	0009, 0011, 0018
Scania\Divided By Vehicle\TRUCK\G-Serie\Engine 400\Truck DC 9 [---07>---13]\Transport information system\RTI - Road Transport Informatics	√	√	√				
Scania\Divided By Vehicle\TRUCK\G-Serie\Engine 400\Truck DC 9 [---07>---13]\Reset service\EMS S8						√	
Scania\Divided By Vehicle\TRUCK\G-Serie\Engine 400\Truck DC 9 [---07>---13]\Reset service\EMS S7						√	
Scania\Divided By Vehicle\TRUCK\G-Serie\Engine 400\Truck DC 9 [---07>---13]\Reset service\EMS S6						√	
Scania\Divided By Vehicle\TRUCK\G-Serie\Engine 420\Truck DC 12 HPI [---05>---08]\ABS\BMS Brake management system-ABS E	√	√	√	√		√	
Scania\Divided By Vehicle\TRUCK\G-Serie\Engine 420\Truck DC 12 HPI [---05>---08]\Aid for keeping lane\LDW Monitor traffic lane	√	√	√				
Scania\Divided By Vehicle\TRUCK\G-Serie\Engine 420\Truck DC 12 HPI [---05>---08]\Air conditioner\CCS Climate control system	√	√	√	√		√	
Scania\Divided By Vehicle\TRUCK\G-Serie\Engine 420\Truck DC 12 HPI [---05>---08]\Airbag\CSS Climate safety system	√	√	√				
Scania\Divided By Vehicle\TRUCK\G-Serie\Engine 420\Truck DC 12 HPI [---05>---08]\Alarm\LAS Locking and alarm system	√	√	√				
Scania\Divided By Vehicle\TRUCK\G-Serie\Engine 420\Truck DC 12 HPI [---05>---08]\Auxiliary heating\ATA Auxiliary heating system air-to-air	√	√	√	√			
Scania\Divided By Vehicle\TRUCK\G-Serie\Engine 420\Truck DC 12 HPI [---05>---08]\Auxiliary heating\WTA Auxiliary heating system water-to-air	√	√	√				
Scania\Divided By Vehicle\TRUCK\G-Serie\Engine 420\Truck DC 12 HPI [---05>---08]\Chassis equipment and design\BWS Preparation system	√	√	√				
Scania\Divided By Vehicle\TRUCK\G-Serie\Engine 420\Truck DC 12 HPI [---05>---08]\Comfort system\CTS Clock and Time System	√	√	√				
Scania\Divided By Vehicle\TRUCK\G-Serie\Engine 420\Truck DC 12 HPI [---05>---08]\Compressed air reserve system\APS Compressed air power supply(Scania protocol)	√	√	√	√			0003
Scania\Divided By Vehicle\TRUCK\G-Serie\Engine 420\Truck DC 12 HPI [---05>---08]\Compressed air reserve system\APS Compressed air power supply(Wabco protocol)	√	√	√	√			
Scania\Divided By Vehicle\TRUCK\G-Serie\Engine 420\Truck DC 12 HPI [---05>---08]\Diesel injection\EEC-Exhaust gas treatment	√	√	√	√		√	
Scania\Divided By Vehicle\TRUCK\G-Serie\Engine 420\Truck DC 12 HPI [---05>---08]\Diesel injection\EMS Engine management system S6-S7	√	√	√	√		√	0002, 0015, 0017
Scania\Divided By Vehicle\TRUCK\G-Serie\Engine 420\Truck DC 12 HPI [---05>---08]\Diesel injection\EMS Engine management system S8(8 Cylindes)	√	√	√	√		√	0001
Scania\Divided By Vehicle\TRUCK\G-Serie\Engine 420\Truck DC 12 HPI [---05>---08]\Diesel injection\EMS Engine management system DC13(6 Cylindes)	√	√	√	√		√	
Scania\Divided By Vehicle\TRUCK\G-Serie\Engine 420\Truck DC 12 HPI [---05>---08]\Distance control\DAS Adaptive Cruise Control	√	√	√				
Scania\Divided By Vehicle\TRUCK\G-Serie\Engine 420\Truck DC 12 HPI [---05>---08]\Distance control\DIS Adaptive Cruise Control	√	√	√				
Scania\Divided By Vehicle\TRUCK\G-Serie\Engine 420\Truck DC 12 HPI [---05>---08]\EBS\BMS Brake management system 5.0 (4x2)	√	√	√	√		√	0004
Scania\Divided By Vehicle\TRUCK\G-Serie\Engine 420\Truck DC 12 HPI [---05>---08]\EBS\BMS Brake management system 5.0 (6x2 - 6x4)	√	√	√	√		√	0004

Scania\Divided By Vehicle\TRUCK\G-Serie\Engine 420\Truck DC 12 HPI [---05>---08]\EBS\BMS Brake management system 5.0 (8x2)	√	√	√	√		√	0004
Scania\Divided By Vehicle\TRUCK\G-Serie\Engine 420\Truck DC 12 HPI [---05>---08]\ECU external light\VIS Visibility system	√	√	√	√		√	
Scania\Divided By Vehicle\TRUCK\G-Serie\Engine 420\Truck DC 12 HPI [---05>---08]\Engine-vehicle adjustment\COO Coordinator module	√	√	√	√		√	
Scania\Divided By Vehicle\TRUCK\G-Serie\Engine 420\Truck DC 12 HPI [---05>---08]\Engine-vehicle adjustment\COO7 (Coordinator)	√	√	√	√		√	
Scania\Divided By Vehicle\TRUCK\G-Serie\Engine 420\Truck DC 12 HPI [---05>---08]\Four-wheel drive\AWD ALL-Wheel Drive	√	√	√				
Scania\Divided By Vehicle\TRUCK\G-Serie\Engine 420\Truck DC 12 HPI [---05>---08]\Instrument panel\NCL Instrument Panel 1	√	√	√	√		√	
Scania\Divided By Vehicle\TRUCK\G-Serie\Engine 420\Truck DC 12 HPI [---05>---08]\Instrument panel\NCL Instrument Panel 2	√	√	√	√		√	
Scania\Divided By Vehicle\TRUCK\G-Serie\Engine 420\Truck DC 12 HPI [---05>---08]\Radio\AUS Audio system	√	√	√				
Scania\Divided By Vehicle\TRUCK\G-Serie\Engine 420\Truck DC 12 HPI [---05>---08]\Retarder\RET Retarder	√	√	√	√		√	
Scania\Divided By Vehicle\TRUCK\G-Serie\Engine 420\Truck DC 12 HPI [---05>---08]\Suspensions\SMS Suspension management system	√	√	√	√			0006, 0007, 0014
Scania\Divided By Vehicle\TRUCK\G-Serie\Engine 420\Truck DC 12 HPI [---05>---08]\Tachograph\DTCO Tachograph	√	√	√				
Scania\Divided By Vehicle\TRUCK\G-Serie\Engine 420\Truck DC 12 HPI [---05>---08]\Tachograph\MTCO Tachograph	√	√	√				
Scania\Divided By Vehicle\TRUCK\G-Serie\Engine 420\Truck DC 12 HPI [---05>---08]\Tire pressure\TPM - Tires Pressure Monitoring System	√	√	√				
Scania\Divided By Vehicle\TRUCK\G-Serie\Engine 420\Truck DC 12 HPI [---05>---08]\Transmission\GMS - Gear management system A4	√	√	√			√	
Scania\Divided By Vehicle\TRUCK\G-Serie\Engine 420\Truck DC 12 HPI [---05>---08]\Transmission\GMS - Gear management system OPC	√	√	√	√		√	0005
Scania\Divided By Vehicle\TRUCK\G-Serie\Engine 420\Truck DC 12 HPI [---05>---08]\Transmission\GMS - Gear management system Opticruise 5	√	√	√	√		√	0009, 0011, 0018
Scania\Divided By Vehicle\TRUCK\G-Serie\Engine 420\Truck DC 12 HPI [---05>---08]\Transmission\GMS - GMS Opticruise 5	√	√	√	√		√	0009, 0011, 0018
Scania\Divided By Vehicle\TRUCK\G-Serie\Engine 420\Truck DC 12 HPI [---05>---08]\Transport information system\RTI - Road Transport Informatics	√	√	√				
Scania\Divided By Vehicle\TRUCK\G-Serie\Engine 420\Truck DC 12 HPI [---05>---08]\Reset service\EMS S8						√	
Scania\Divided By Vehicle\TRUCK\G-Serie\Engine 420\Truck DC 12 HPI [---05>---08]\Reset service\EMS S7						√	
Scania\Divided By Vehicle\TRUCK\G-Serie\Engine 420\Truck DC 12 HPI [---05>---08]\Reset service\EMS S6						√	
Scania\Divided By Vehicle\TRUCK\G-Serie\Engine 420\Truck DC 13 XPI EU5 [---08>---13]\ABS\BMS Brake management system-ABS E	√	√	√	√		√	
Scania\Divided By Vehicle\TRUCK\G-Serie\Engine 420\Truck DC 13 XPI EU5 [---08>---13]\Aid for keeping lane\LDW Monitor traffic lane	√	√	√				
Scania\Divided By Vehicle\TRUCK\G-Serie\Engine 420\Truck DC 13 XPI EU5 [---08>---13]\Air conditioner\CCS Climate control system	√	√	√	√		√	
Scania\Divided By Vehicle\TRUCK\G-Serie\Engine 420\Truck DC 13 XPI EU5 [---08>---13]\Airbag\CSS Climate safety system	√	√	√				
Scania\Divided By Vehicle\TRUCK\G-Serie\Engine 420\Truck DC 13 XPI EU5 [---08>---13]\Alarm\LAS Locking and alarm system	√	√	√				
Scania\Divided By Vehicle\TRUCK\G-Serie\Engine 420\Truck DC 13 XPI EU5 [---08>---13]\Auxiliary heating\ATA Auxiliary heating system air-to-air	√	√	√	√			
Scania\Divided By Vehicle\TRUCK\G-Serie\Engine 420\Truck DC 13 XPI EU5 [---08>---13]\Auxiliary heating\WTA Auxiliary heating system water-to-air	√	√	√				
Scania\Divided By Vehicle\TRUCK\G-Serie\Engine 420\Truck DC 13 XPI EU5 [---08>---13]\Chassis equipment and design\BWS Preparation system	√	√	√				
Scania\Divided By Vehicle\TRUCK\G-Serie\Engine 420\Truck DC 13 XPI EU5 [---08>---13]\Comfort system\CTS Clock and Time System	√	√	√				
Scania\Divided By Vehicle\TRUCK\G-Serie\Engine 420\Truck DC 13 XPI EU5 [---08>---13]\Compressed air reserve system\APS Compressed air power supply(Scania protocol)	√	√	√	√			0003
Scania\Divided By Vehicle\TRUCK\G-Serie\Engine 420\Truck DC 13 XPI EU5 [---08>---13]\Compressed air reserve system\APS Compressed air power supply(Wabco protocol)	√	√	√	√			
Scania\Divided By Vehicle\TRUCK\G-Serie\Engine 420\Truck DC 13 XPI EU5 [---08>---13]\Diesel injection\EEC-Exhaust gas treatment	√	√	√	√		√	
Scania\Divided By Vehicle\TRUCK\G-Serie\Engine 420\Truck DC 13 XPI EU5 [---08>---13]\Diesel injection\EMS Engine management system S6-S7	√	√	√	√		√	0002, 0015, 0017
Scania\Divided By Vehicle\TRUCK\G-Serie\Engine 420\Truck DC 13 XPI EU5 [---08>---13]\Diesel injection\EMS Engine management system S8(8 Cylindres)	√	√	√	√		√	0001

Scania\Divided By Vehicle\TRUCK\G-Serie\Engine 420\Truck DC 13 XPI EU5 [---08>---13]\Diesel injection\EMS Engine management system DC13(6 Cylindres)	√	√	√	√		√	
Scania\Divided By Vehicle\TRUCK\G-Serie\Engine 420\Truck DC 13 XPI EU5 [---08>---13]\Distance control\DAS Adaptive Cruise Control	√	√	√				
Scania\Divided By Vehicle\TRUCK\G-Serie\Engine 420\Truck DC 13 XPI EU5 [---08>---13]\Distance control\DIS Adaptive Cruise Control	√	√	√				
Scania\Divided By Vehicle\TRUCK\G-Serie\Engine 420\Truck DC 13 XPI EU5 [---08>---13]\EBS\BMS Brake management system 5.0 (4x2)	√	√	√	√		√	0004
Scania\Divided By Vehicle\TRUCK\G-Serie\Engine 420\Truck DC 13 XPI EU5 [---08>---13]\EBS\BMS Brake management system 5.0 (6x2 - 6x4)	√	√	√	√		√	0004
Scania\Divided By Vehicle\TRUCK\G-Serie\Engine 420\Truck DC 13 XPI EU5 [---08>---13]\EBS\BMS Brake management system 5.0 (8x2)	√	√	√	√		√	0004
Scania\Divided By Vehicle\TRUCK\G-Serie\Engine 420\Truck DC 13 XPI EU5 [---08>---13]\ECU external light\VIS Visibility system	√	√	√	√		√	
Scania\Divided By Vehicle\TRUCK\G-Serie\Engine 420\Truck DC 13 XPI EU5 [---08>---13]\Engine-vehicle adjustment\COO Coordinator module	√	√	√	√		√	
Scania\Divided By Vehicle\TRUCK\G-Serie\Engine 420\Truck DC 13 XPI EU5 [---08>---13]\Engine-vehicle adjustment\COO7 (Coordinator)	√	√	√	√		√	
Scania\Divided By Vehicle\TRUCK\G-Serie\Engine 420\Truck DC 13 XPI EU5 [---08>---13]\Four-wheel drive\AWD ALL-Wheel Drive	√	√	√				
Scania\Divided By Vehicle\TRUCK\G-Serie\Engine 420\Truck DC 13 XPI EU5 [---08>---13]\Instrument panel\NCL Instrument Panel 1	√	√	√	√		√	
Scania\Divided By Vehicle\TRUCK\G-Serie\Engine 420\Truck DC 13 XPI EU5 [---08>---13]\Instrument pane\NCL Instrument Panel 2	√	√	√	√		√	
Scania\Divided By Vehicle\TRUCK\G-Serie\Engine 420\Truck DC 13 XPI EU5 [---08>---13]\Radio\AUS Audio system	√	√	√				
Scania\Divided By Vehicle\TRUCK\G-Serie\Engine 420\Truck DC 13 XPI EU5 [---08>---13]\Retarder\RET Retarder	√	√	√	√		√	
Scania\Divided By Vehicle\TRUCK\G-Serie\Engine 420\Truck DC 13 XPI EU5 [---08>---13]\Suspensions\SMS Supension management system	√	√	√	√			0006, 0007, 0014
Scania\Divided By Vehicle\TRUCK\G-Serie\Engine 420\Truck DC 13 XPI EU5 [---08>---13]\Tachograph\DTCO Tachograph	√	√	√				
Scania\Divided By Vehicle\TRUCK\G-Serie\Engine 420\Truck DC 13 XPI EU5 [---08>---13]\Tachograph\MTCO Tachograph	√	√	√				
Scania\Divided By Vehicle\TRUCK\G-Serie\Engine 420\Truck DC 13 XPI EU5 [---08>---13]\Tire pressure\TPM - Tires Pressure Monitoring System	√	√	√				
Scania\Divided By Vehicle\TRUCK\G-Serie\Engine 420\Truck DC 13 XPI EU5 [---08>---13]\Transmission\GMS - Gear management system A4	√	√	√			√	
Scania\Divided By Vehicle\TRUCK\G-Serie\Engine 420\Truck DC 13 XPI EU5 [---08>---13]\Transmission\GMS - Gear management system OPC	√	√	√	√		√	0005
Scania\Divided By Vehicle\TRUCK\G-Serie\Engine 420\Truck DC 13 XPI EU5 [---08>---13]\Transmission\GMS - Gear management system Opticruise 5	√	√	√	√		√	0009, 0011, 0018
Scania\Divided By Vehicle\TRUCK\G-Serie\Engine 420\Truck DC 13 XPI EU5 [---08>---13]\Transmission\GMS - GMS Opticruise 5	√	√	√	√		√	0009, 0011, 0018
Scania\Divided By Vehicle\TRUCK\G-Serie\Engine 420\Truck DC 13 XPI EU5 [---08>---13]\Transport information system\RTI - Road Transport Informatics	√	√	√				
Scania\Divided By Vehicle\TRUCK\G-Serie\Engine 420\Truck DC 13 XPI EU5 [---08>---13]\Reset service\EMS S8						√	
Scania\Divided By Vehicle\TRUCK\G-Serie\Engine 420\Truck DC 13 XPI EU5 [---08>---13]\Reset service\EMS S7						√	
Scania\Divided By Vehicle\TRUCK\G-Serie\Engine 420\Truck DC 13 XPI EU5 [---08>---13]\Reset service\EMS S6						√	
Scania\Divided By Vehicle\TRUCK\G-Serie\Engine 420\Truck DT 12 HPI [---04>---08]\ABS\BMS Brake management system-ABS E	√	√	√	√		√	
Scania\Divided By Vehicle\TRUCK\G-Serie\Engine 420\Truck DT 12 HPI [---04>---08]\Aid for keeping lane\LDW Monitor traffic lane	√	√	√				
Scania\Divided By Vehicle\TRUCK\G-Serie\Engine 420\Truck DT 12 HPI [---04>---08]\Air conditioner\CCS Climate control system	√	√	√	√		√	
Scania\Divided By Vehicle\TRUCK\G-Serie\Engine 420\Truck DT 12 HPI [---04>---08]\Airbag\CSS Climate safety system	√	√	√				
Scania\Divided By Vehicle\TRUCK\G-Serie\Engine 420\Truck DT 12 HPI [---04>---08]\Alarm\LAS Locking and alarm system	√	√	√				
Scania\Divided By Vehicle\TRUCK\G-Serie\Engine 420\Truck DT 12 HPI [---04>---08]\Auxiliary heating\ATA Auxiliary heating system air-to-air	√	√	√	√			
Scania\Divided By Vehicle\TRUCK\G-Serie\Engine 420\Truck DT 12 HPI [---04>---08]\Auxiliary heating\WTA Auxiliary heating system water-to-air	√	√	√				
Scania\Divided By Vehicle\TRUCK\G-Serie\Engine 420\Truck DT 12 HPI [---04>---08]\Chassis equipment and design\BWS Preparation system	√	√	√				
Scania\Divided By Vehicle\TRUCK\G-Serie\Engine 420\Truck DT 12 HPI [---04>---08]\Comfort system\CTS Clock and Time System	√	√	√				

Scania\Divided By Vehicle\TRUCK\G-Serie\Engine 420\Truck DT 12 HPI [---04>---08]\Compressed air reserve system\APS Compressed air power supply(Scania protocol)	√	√	√	√			0003
Scania\Divided By Vehicle\TRUCK\G-Serie\Engine 420\Truck DT 12 HPI [---04>---08]\Compressed air reserve system\APS Compressed air power supply(Wabco protocol)	√	√	√	√			
Scania\Divided By Vehicle\TRUCK\G-Serie\Engine 420\Truck DT 12 HPI [---04>---08]\Distance control\DAS Adaptive Cruise Control	√	√	√				
Scania\Divided By Vehicle\TRUCK\G-Serie\Engine 420\Truck DT 12 HPI [---04>---08]\Distance control\DIS Adaptive Cruise Control	√	√	√				
Scania\Divided By Vehicle\TRUCK\G-Serie\Engine 420\Truck DT 12 HPI [---04>---08]\EBS\BMS Brake management system 5.0 (4x2)	√	√	√	√		√	0004
Scania\Divided By Vehicle\TRUCK\G-Serie\Engine 420\Truck DT 12 HPI [---04>---08]\EBS\BMS Brake management system 5.0 (6x2 - 6x4)	√	√	√	√		√	0004
Scania\Divided By Vehicle\TRUCK\G-Serie\Engine 420\Truck DT 12 HPI [---04>---08]\EBS\BMS Brake management system 5.0 (8x2)	√	√	√	√		√	0004
Scania\Divided By Vehicle\TRUCK\G-Serie\Engine 420\Truck DT 12 HPI [---04>---08]\ECU external light\VIS Visibility system	√	√	√	√		√	
Scania\Divided By Vehicle\TRUCK\G-Serie\Engine 420\Truck DT 12 HPI [---04>---08]\Engine-vehicle adjustment\COO Coordinator module	√	√	√	√		√	
Scania\Divided By Vehicle\TRUCK\G-Serie\Engine 420\Truck DT 12 HPI [---04>---08]\Engine-vehicle adjustment\COO7 (Coordinator)	√	√	√	√		√	
Scania\Divided By Vehicle\TRUCK\G-Serie\Engine 420\Truck DT 12 HPI [---04>---08]\Four-wheel drive\AWD ALL-Wheel Drive	√	√	√				
Scania\Divided By Vehicle\TRUCK\G-Serie\Engine 420\Truck DT 12 HPI [---04>---08]\Instrument panel\NCL Instrument Panel 1	√	√	√	√		√	
Scania\Divided By Vehicle\TRUCK\G-Serie\Engine 420\Truck DT 12 HPI [---04>---08]\Instrument panel\NCL Instrument Panel 2	√	√	√	√		√	
Scania\Divided By Vehicle\TRUCK\G-Serie\Engine 420\Truck DT 12 HPI [---04>---08]\Radio\AUS Audio system	√	√	√				
Scania\Divided By Vehicle\TRUCK\G-Serie\Engine 420\Truck DT 12 HPI [---04>---08]\Retarder\RET Retarder	√	√	√	√		√	
Scania\Divided By Vehicle\TRUCK\G-Serie\Engine 420\Truck DT 12 HPI [---04>---08]\Suspensions\SMS Suspension management system	√	√	√	√			0006, 0007, 0014
Scania\Divided By Vehicle\TRUCK\G-Serie\Engine 420\Truck DT 12 HPI [---04>---08]\Tachograph\DTCO Tachograph	√	√	√				
Scania\Divided By Vehicle\TRUCK\G-Serie\Engine 420\Truck DT 12 HPI [---04>---08]\Tachograph\WTCO Tachograph	√	√	√				
Scania\Divided By Vehicle\TRUCK\G-Serie\Engine 420\Truck DT 12 HPI [---04>---08]\Tire pressure\TPM - Tires Pressure Monitoring System	√	√	√				
Scania\Divided By Vehicle\TRUCK\G-Serie\Engine 420\Truck DT 12 HPI [---04>---08]\Transmission\GMS - Gear management system A4	√	√	√			√	
Scania\Divided By Vehicle\TRUCK\G-Serie\Engine 420\Truck DT 12 HPI [---04>---08]\Transmission\GMS - Gear management system OPC	√	√	√	√		√	0005
Scania\Divided By Vehicle\TRUCK\G-Serie\Engine 420\Truck DT 12 HPI [---04>---08]\Transmission\GMS - Gear management system Opticruise 5	√	√	√	√		√	0009, 0011, 0018
Scania\Divided By Vehicle\TRUCK\G-Serie\Engine 420\Truck DT 12 HPI [---04>---08]\Transmission\GMS - GMS Opticruise 5	√	√	√	√		√	0009, 0011, 0018
Scania\Divided By Vehicle\TRUCK\G-Serie\Engine 420\Truck DT 12 HPI [---04>---08]\Transport information system\RTI - Road Transport Informatics	√	√	√				
Scania\Divided By Vehicle\TRUCK\G-Serie\Engine 420\Truck DT 12 HPI [---04>---08]\Reset service\EMS S8						√	
Scania\Divided By Vehicle\TRUCK\G-Serie\Engine 420\Truck DT 12 HPI [---04>---08]\Reset service\EMS S7						√	
Scania\Divided By Vehicle\TRUCK\G-Serie\Engine 420\Truck DT 12 HPI [---04>---08]\Reset service\EMS S6						√	
Scania\Divided By Vehicle\TRUCK\G-Serie\Engine 440\Truck DC 9 [---07>---13]\ABS\BMS Brake management system-ABS E	√	√	√	√		√	
Scania\Divided By Vehicle\TRUCK\G-Serie\Engine 440\Truck DC 9 [---07>---13]\Aid for keeping lane\LDW Monitor traffic lane	√	√	√				
Scania\Divided By Vehicle\TRUCK\G-Serie\Engine 440\Truck DC 9 [---07>---13]\Air conditioner\CCS Climate control system	√	√	√	√		√	
Scania\Divided By Vehicle\TRUCK\G-Serie\Engine 440\Truck DC 9 [---07>---13]\Airbag\CSS Climate safety system	√	√	√				
Scania\Divided By Vehicle\TRUCK\G-Serie\Engine 440\Truck DC 9 [---07>---13]\Alarm\LAS Locking and alarm system	√	√	√				
Scania\Divided By Vehicle\TRUCK\G-Serie\Engine 440\Truck DC 9 [---07>---13]\Auxiliary heating\ATA Auxiliary heating system air-to-air	√	√	√	√			
Scania\Divided By Vehicle\TRUCK\G-Serie\Engine 440\Truck DC 9 [---07>---13]\Auxiliary heating\WTA Auxiliary heating system water-to-air	√	√	√				
Scania\Divided By Vehicle\TRUCK\G-Serie\Engine 440\Truck DC 9 [---07>---13]\Chassis equipment and design\BWS Preparation system	√	√	√				

Scania\Divided By Vehicle\TRUCK\G-Serie\Engine 440\Truck DC 9 [---07>---13]\Comfort system\CTS Clock and Time System	√	√	√				
Scania\Divided By Vehicle\TRUCK\G-Serie\Engine 440\Truck DC 9 [---07>---13]\Compressed air reserve system\APS Compressed air power supply(Scania protocol)	√	√	√	√			0003
Scania\Divided By Vehicle\TRUCK\G-Serie\Engine 440\Truck DC 9 [---07>---13]\Compressed air reserve system\APS Compressed air power supply(Wabco protocol)	√	√	√	√			
Scania\Divided By Vehicle\TRUCK\G-Serie\Engine 440\Truck DC 9 [---07>---13]\Diesel injection\EEC-Exhaust gas treatment	√	√	√	√		√	
Scania\Divided By Vehicle\TRUCK\G-Serie\Engine 440\Truck DC 9 [---07>---13]\Diesel injection\EMS Engine management system S6-S7	√	√	√	√		√	0002, 0015, 0017
Scania\Divided By Vehicle\TRUCK\G-Serie\Engine 440\Truck DC 9 [---07>---13]\Diesel injection\EMS Engine management system S8(8 Cylindres)	√	√	√	√		√	0001
Scania\Divided By Vehicle\TRUCK\G-Serie\Engine 440\Truck DC 9 [---07>---13]\Diesel injection\EMS Engine management system DC13(6 Cylindres)	√	√	√	√		√	
Scania\Divided By Vehicle\TRUCK\G-Serie\Engine 440\Truck DC 9 [---07>---13]\Distance control\DAS Adaptive Cruise Control	√	√	√				
Scania\Divided By Vehicle\TRUCK\G-Serie\Engine 440\Truck DC 9 [---07>---13]\Distance control\DIS Adaptive Cruise Control	√	√	√				
Scania\Divided By Vehicle\TRUCK\G-Serie\Engine 440\Truck DC 9 [---07>---13]\EBS\BMS Brake management system 5.0 (4x2)	√	√	√	√		√	0004
Scania\Divided By Vehicle\TRUCK\G-Serie\Engine 440\Truck DC 9 [---07>---13]\EBS\BMS Brake management system 5.0 (6x2 - 6x4)	√	√	√	√		√	0004
Scania\Divided By Vehicle\TRUCK\G-Serie\Engine 440\Truck DC 9 [---07>---13]\EBS\BMS Brake management system 5.0 (8x2)	√	√	√	√		√	0004
Scania\Divided By Vehicle\TRUCK\G-Serie\Engine 440\Truck DC 9 [---07>---13]\ECU external light\VIS Visiblity system	√	√	√	√		√	
Scania\Divided By Vehicle\TRUCK\G-Serie\Engine 440\Truck DC 9 [---07>---13]\Engine-vehicle adjustment\COO Coordinator module	√	√	√	√		√	
Scania\Divided By Vehicle\TRUCK\G-Serie\Engine 440\Truck DC 9 [---07>---13]\Engine-vehicle adjustment\COO7 (Coordinator)	√	√	√	√		√	
Scania\Divided By Vehicle\TRUCK\G-Serie\Engine 440\Truck DC 9 [---07>---13]\Four-wheel drive\AWD ALL-Wheel Drive	√	√	√				
Scania\Divided By Vehicle\TRUCK\G-Serie\Engine 440\Truck DC 9 [---07>---13]\Instrument panel\ICL Instrument Panel 1	√	√	√	√		√	
Scania\Divided By Vehicle\TRUCK\G-Serie\Engine 440\Truck DC 9 [---07>---13]\Instrument panel\ICL Instrument Panel 2	√	√	√	√		√	
Scania\Divided By Vehicle\TRUCK\G-Serie\Engine 440\Truck DC 9 [---07>---13]\Radio\AUS Audio system	√	√	√				
Scania\Divided By Vehicle\TRUCK\G-Serie\Engine 440\Truck DC 9 [---07>---13]\Retarder\RET Retarder	√	√	√	√		√	
Scania\Divided By Vehicle\TRUCK\G-Serie\Engine 440\Truck DC 9 [---07>---13]\Suspensions\SMS Supension management system	√	√	√	√			0006, 0007, 0014
Scania\Divided By Vehicle\TRUCK\G-Serie\Engine 440\Truck DC 9 [---07>---13]\Tachograph\DTCO Tachograph	√	√	√				
Scania\Divided By Vehicle\TRUCK\G-Serie\Engine 440\Truck DC 9 [---07>---13]\Tachograph\MTCO Tachograph	√	√	√				
Scania\Divided By Vehicle\TRUCK\G-Serie\Engine 440\Truck DC 9 [---07>---13]\Tire pressure\TPM - Tires Pressure Monitoring System	√	√	√				
Scania\Divided By Vehicle\TRUCK\G-Serie\Engine 440\Truck DC 9 [---07>---13]\Transmission\GMS - Gear management system A4	√	√	√			√	
Scania\Divided By Vehicle\TRUCK\G-Serie\Engine 440\Truck DC 9 [---07>---13]\Transmission\GMS - Gear management system OPC	√	√	√	√		√	0005
Scania\Divided By Vehicle\TRUCK\G-Serie\Engine 440\Truck DC 9 [---07>---13]\Transmission\GMS - Gear management system Opticruise 5	√	√	√	√		√	0009, 0011, 0018
Scania\Divided By Vehicle\TRUCK\G-Serie\Engine 440\Truck DC 9 [---07>---13]\Transmission\GMS - GMS Opticruise 5	√	√	√	√		√	0009, 0011, 0018
Scania\Divided By Vehicle\TRUCK\G-Serie\Engine 440\Truck DC 9 [---07>---13]\Transport information system\RTI - Road Transport Informatics	√	√	√				
Scania\Divided By Vehicle\TRUCK\G-Serie\Engine 440\Truck DC 9 [---07>---13]\Reset service\EMS S8						√	
Scania\Divided By Vehicle\TRUCK\G-Serie\Engine 440\Truck DC 9 [---07>---13]\Reset service\EMS S7						√	
Scania\Divided By Vehicle\TRUCK\G-Serie\Engine 440\Truck DC 9 [---07>---13]\Reset service\EMS S6						√	
Scania\Divided By Vehicle\TRUCK\G-Serie\Engine 470\Truck DT 12 HPI [---07>---13]\ABS\BMS Brake management system-ABS E	√	√	√	√		√	
Scania\Divided By Vehicle\TRUCK\G-Serie\Engine 470\Truck DT 12 HPI [---07>---13]\Aid for keeping lane\LDW Monitor traffic lane	√	√	√				
Scania\Divided By Vehicle\TRUCK\G-Serie\Engine 470\Truck DT 12 HPI [---07>---13]\Air conditioner\CCS Climate control system	√	√	√	√		√	

Scania\Divided By Vehicle\TRUCK\G-Serie\Engine 470\Truck DT 12 HPI [---07>---13]\Airbag\CSS Climate safety system	√	√	√				
Scania\Divided By Vehicle\TRUCK\G-Serie\Engine 470\Truck DT 12 HPI [---07>---13]\Alarm\LAS Locking and alarm system	√	√	√				
Scania\Divided By Vehicle\TRUCK\G-Serie\Engine 470\Truck DT 12 HPI [---07>---13]\Auxiliary heating\ATA Auxiliary heating system air-to-air	√	√	√	√			
Scania\Divided By Vehicle\TRUCK\G-Serie\Engine 470\Truck DT 12 HPI [---07>---13]\Auxiliary heating\WTA Auxiliary heating system water-to-air	√	√	√				
Scania\Divided By Vehicle\TRUCK\G-Serie\Engine 470\Truck DT 12 HPI [---07>---13]\Chassis equipment and design\BWS Preparation system	√	√	√				
Scania\Divided By Vehicle\TRUCK\G-Serie\Engine 470\Truck DT 12 HPI [---07>---13]\Comfort system\CTS Clock and Time System	√	√	√				
Scania\Divided By Vehicle\TRUCK\G-Serie\Engine 470\Truck DT 12 HPI [---07>---13]\Compressed air reserve system\APS Compressed air power supply(Scania protocol)	√	√	√	√			0003
Scania\Divided By Vehicle\TRUCK\G-Serie\Engine 470\Truck DT 12 HPI [---07>---13]\Compressed air reserve system\APS Compressed air power supply(Wabco protocol)	√	√	√	√			
Scania\Divided By Vehicle\TRUCK\G-Serie\Engine 470\Truck DT 12 HPI [---07>---13]\Distance control\DAS Adaptive Cruise Control	√	√	√				
Scania\Divided By Vehicle\TRUCK\G-Serie\Engine 470\Truck DT 12 HPI [---07>---13]\Distance control\DIS Adaptive Cruise Control	√	√	√				
Scania\Divided By Vehicle\TRUCK\G-Serie\Engine 470\Truck DT 12 HPI [---07>---13]\EBS\BMS Brake management system 5.0 (4x2)	√	√	√	√		√	0004
Scania\Divided By Vehicle\TRUCK\G-Serie\Engine 470\Truck DT 12 HPI [---07>---13]\EBS\BMS Brake management system 5.0 (6x2 - 6x4)	√	√	√	√		√	0004
Scania\Divided By Vehicle\TRUCK\G-Serie\Engine 470\Truck DT 12 HPI [---07>---13]\EBS\BMS Brake management system 5.0 (8x2)	√	√	√	√		√	0004
Scania\Divided By Vehicle\TRUCK\G-Serie\Engine 470\Truck DT 12 HPI [---07>---13]\ECU external light\VIS Visibility system	√	√	√	√		√	
Scania\Divided By Vehicle\TRUCK\G-Serie\Engine 470\Truck DT 12 HPI [---07>---13]\Engine-vehicle adjustment\COO Coordinator module	√	√	√	√		√	
Scania\Divided By Vehicle\TRUCK\G-Serie\Engine 470\Truck DT 12 HPI [---07>---13]\Engine-vehicle adjustment\COO7 (Coordinator)	√	√	√	√		√	
Scania\Divided By Vehicle\TRUCK\G-Serie\Engine 470\Truck DT 12 HPI [---07>---13]\Four-wheel drive\AWD ALL-Wheel Drive	√	√	√				
Scania\Divided By Vehicle\TRUCK\G-Serie\Engine 470\Truck DT 12 HPI [---07>---13]\Instrument panel\NCL Instrument Panel 1	√	√	√	√		√	
Scania\Divided By Vehicle\TRUCK\G-Serie\Engine 470\Truck DT 12 HPI [---07>---13]\Instrument panel\NCL Instrument Panel 2	√	√	√	√		√	
Scania\Divided By Vehicle\TRUCK\G-Serie\Engine 470\Truck DT 12 HPI [---07>---13]\Radio\AUS Audio system	√	√	√				
Scania\Divided By Vehicle\TRUCK\G-Serie\Engine 470\Truck DT 12 HPI [---07>---13]\Retarder\RET Retarder	√	√	√	√		√	
Scania\Divided By Vehicle\TRUCK\G-Serie\Engine 470\Truck DT 12 HPI [---07>---13]\Suspensions\SMS Suspension management system	√	√	√	√			0006, 0007, 0014
Scania\Divided By Vehicle\TRUCK\G-Serie\Engine 470\Truck DT 12 HPI [---07>---13]\Tachograph\DTCO Tachograph	√	√	√				
Scania\Divided By Vehicle\TRUCK\G-Serie\Engine 470\Truck DT 12 HPI [---07>---13]\Tachograph\MTCO Tachograph	√	√	√				
Scania\Divided By Vehicle\TRUCK\G-Serie\Engine 470\Truck DT 12 HPI [---07>---13]\Tire pressure\TPM - Tires Pressure Monitoring System	√	√	√				
Scania\Divided By Vehicle\TRUCK\G-Serie\Engine 470\Truck DT 12 HPI [---07>---13]\Transmission\GMS - Gear management system A4	√	√	√			√	
Scania\Divided By Vehicle\TRUCK\G-Serie\Engine 470\Truck DT 12 HPI [---07>---13]\Transmission\GMS - Gear management system OPC	√	√	√	√		√	0005
Scania\Divided By Vehicle\TRUCK\G-Serie\Engine 470\Truck DT 12 HPI [---07>---13]\Transmission\GMS - Gear management system Opticruise 5	√	√	√	√		√	0009, 0011, 0018
Scania\Divided By Vehicle\TRUCK\G-Serie\Engine 470\Truck DT 12 HPI [---07>---13]\Transmission\GMS - GMS Opticruise 5	√	√	√	√		√	0009, 0011, 0018
Scania\Divided By Vehicle\TRUCK\G-Serie\Engine 470\Truck DT 12 HPI [---07>---13]\Transport information system\RTI - Road Transport Informatics	√	√	√				
Scania\Divided By Vehicle\TRUCK\G-Serie\Engine 470\Truck DT 12 HPI [---07>---13]\Reset service\EMS S8						√	
Scania\Divided By Vehicle\TRUCK\G-Serie\Engine 470\Truck DT 12 HPI [---07>---13]\Reset service\EMS S7						√	
Scania\Divided By Vehicle\TRUCK\G-Serie\Engine 470\Truck DT 12 HPI [---07>---13]\Reset service\EMS S6						√	
Scania\Divided By Vehicle\TRUCK\G-Serie\Engine 480\Truck DC 12 HPI [---07>---13]\ABS\BMS Brake management system-ABS E	√	√	√	√		√	
Scania\Divided By Vehicle\TRUCK\G-Serie\Engine 480\Truck DC 12 HPI [---07>---13]\Aid for keeping lane\LDW Monitor traffic lane	√	√	√				

Scania\Divided By Vehicle\TRUCK\G-Serie\Engine 480\Truck DC 12 HPI [---07>---13]\Air conditioner\CCS Climate control system	√	√	√	√		√	
Scania\Divided By Vehicle\TRUCK\G-Serie\Engine 480\Truck DC 12 HPI [---07>---13]\Airbag\CSS Climate safety system	√	√	√				
Scania\Divided By Vehicle\TRUCK\G-Serie\Engine 480\Truck DC 12 HPI [---07>---13]\Alarm\LAS Locking and alarm system	√	√	√				
Scania\Divided By Vehicle\TRUCK\G-Serie\Engine 480\Truck DC 12 HPI [---07>---13]\Auxiliary heating\ATA Auxiliary heating system air-to-air	√	√	√	√			
Scania\Divided By Vehicle\TRUCK\G-Serie\Engine 480\Truck DC 12 HPI [---07>---13]\Auxiliary heating\WTA Auxiliary heating system water-to-air	√	√	√				
Scania\Divided By Vehicle\TRUCK\G-Serie\Engine 480\Truck DC 12 HPI [---07>---13]\Chassis equipment and design\BWS Preparation system	√	√	√				
Scania\Divided By Vehicle\TRUCK\G-Serie\Engine 480\Truck DC 12 HPI [---07>---13]\Comfort system\CTS Clock and Time System	√	√	√				
Scania\Divided By Vehicle\TRUCK\G-Serie\Engine 480\Truck DC 12 HPI [---07>---13]\Compressed air reserve system\APS Compressed air power supply(Scania protocol)	√	√	√	√			0003
Scania\Divided By Vehicle\TRUCK\G-Serie\Engine 480\Truck DC 12 HPI [---07>---13]\Compressed air reserve system\APS Compressed air power supply(Wabco protocol)	√	√	√	√			
Scania\Divided By Vehicle\TRUCK\G-Serie\Engine 480\Truck DC 12 HPI [---07>---13]\Diesel injection\EEC-Exhaust gas treatment	√	√	√	√		√	
Scania\Divided By Vehicle\TRUCK\G-Serie\Engine 480\Truck DC 12 HPI [---07>---13]\Diesel injection\EMS Engine management system S6-S7	√	√	√	√		√	0002, 0015, 0017
Scania\Divided By Vehicle\TRUCK\G-Serie\Engine 480\Truck DC 12 HPI [---07>---13]\Diesel injection\EMS Engine management system S8(8 Cylindes)	√	√	√	√		√	0001
Scania\Divided By Vehicle\TRUCK\G-Serie\Engine 480\Truck DC 12 HPI [---07>---13]\Diesel injection\EMS Engine management system DC13(6 Cylindes)	√	√	√	√		√	
Scania\Divided By Vehicle\TRUCK\G-Serie\Engine 480\Truck DC 12 HPI [---07>---13]\Distance control\DAS Adaptive Cruise Control	√	√	√				
Scania\Divided By Vehicle\TRUCK\G-Serie\Engine 480\Truck DC 12 HPI [---07>---13]\Distance control\DIS Adaptive Cruise Control	√	√	√				
Scania\Divided By Vehicle\TRUCK\G-Serie\Engine 480\Truck DC 12 HPI [---07>---13]\EBS\BMS Brake management system 5.0 (4x2)	√	√	√	√		√	0004
Scania\Divided By Vehicle\TRUCK\G-Serie\Engine 480\Truck DC 12 HPI [---07>---13]\EBS\BMS Brake management system 5.0 (6x2 - 6x4)	√	√	√	√		√	0004
Scania\Divided By Vehicle\TRUCK\G-Serie\Engine 480\Truck DC 12 HPI [---07>---13]\EBS\BMS Brake management system 5.0 (8x2)	√	√	√	√		√	0004
Scania\Divided By Vehicle\TRUCK\G-Serie\Engine 480\Truck DC 12 HPI [---07>---13]\ECU external light\VIS Visibility system	√	√	√	√		√	
Scania\Divided By Vehicle\TRUCK\G-Serie\Engine 480\Truck DC 12 HPI [---07>---13]\Engine-vehicle adjustment\COO Coordinator module	√	√	√	√		√	
Scania\Divided By Vehicle\TRUCK\G-Serie\Engine 480\Truck DC 12 HPI [---07>---13]\Engine-vehicle adjustment\COO7 (Coordinator)	√	√	√	√		√	
Scania\Divided By Vehicle\TRUCK\G-Serie\Engine 480\Truck DC 12 HPI [---07>---13]\Four-wheel drive\AWD ALL-Wheel Drive	√	√	√				
Scania\Divided By Vehicle\TRUCK\G-Serie\Engine 480\Truck DC 12 HPI [---07>---13]\Instrument panel\NCL Instrument Panel 1	√	√	√	√		√	
Scania\Divided By Vehicle\TRUCK\G-Serie\Engine 480\Truck DC 12 HPI [---07>---13]\Instrument panel\NCL Instrument Panel 2	√	√	√	√		√	
Scania\Divided By Vehicle\TRUCK\G-Serie\Engine 480\Truck DC 12 HPI [---07>---13]\Radio\AUS Audio system	√	√	√				
Scania\Divided By Vehicle\TRUCK\G-Serie\Engine 480\Truck DC 12 HPI [---07>---13]\Retarder\RET Retarder	√	√	√	√		√	
Scania\Divided By Vehicle\TRUCK\G-Serie\Engine 480\Truck DC 12 HPI [---07>---13]\Suspensions\SMS Suspension management system	√	√	√	√			0006, 0007, 0014
Scania\Divided By Vehicle\TRUCK\G-Serie\Engine 480\Truck DC 12 HPI [---07>---13]\Tachograph\DTCO Tachograph	√	√	√				
Scania\Divided By Vehicle\TRUCK\G-Serie\Engine 480\Truck DC 12 HPI [---07>---13]\Tachograph\MTCO Tachograph	√	√	√				
Scania\Divided By Vehicle\TRUCK\G-Serie\Engine 480\Truck DC 12 HPI [---07>---13]\Tire pressure\TPM - Tires Pressure Monitoring System	√	√	√				
Scania\Divided By Vehicle\TRUCK\G-Serie\Engine 480\Truck DC 12 HPI [---07>---13]\Transmission\GMS - Gear management system A4	√	√	√			√	
Scania\Divided By Vehicle\TRUCK\G-Serie\Engine 480\Truck DC 12 HPI [---07>---13]\Transmission\GMS - Gear management system OPC	√	√	√	√		√	0005
Scania\Divided By Vehicle\TRUCK\G-Serie\Engine 480\Truck DC 12 HPI [---07>---13]\Transmission\GMS - Gear management system Opticruise 5	√	√	√	√		√	0009, 0011, 0018
Scania\Divided By Vehicle\TRUCK\G-Serie\Engine 480\Truck DC 12 HPI [---07>---13]\Transmission\GMS - GMS Opticruise 5	√	√	√	√		√	0009, 0011, 0018
Scania\Divided By Vehicle\TRUCK\G-Serie\Engine 480\Truck DC 12 HPI [---07>---13]\Transport information system\RTI - Road Transport Informatics	√	√	√				

Scania\Divided By Vehicle\TRUCK\G-Serie\Engine 480\Truck DC 12 HPI [---07>---13]\Reset service\EMS S8						√	
Scania\Divided By Vehicle\TRUCK\G-Serie\Engine 480\Truck DC 12 HPI [---07>---13]\Reset service\EMS S7						√	
Scania\Divided By Vehicle\TRUCK\G-Serie\Engine 480\Truck DC 12 HPI [---07>---13]\Reset service\EMS S6						√	
Scania\Divided By Vehicle\TRUCK\G-Serie\Engine 480\Truck DT 12 HPI [---08>---13]\ABS\BMS Brake management system-ABS E	√	√	√	√		√	
Scania\Divided By Vehicle\TRUCK\G-Serie\Engine 480\Truck DT 12 HPI [---08>---13]\Aid for keeping lane\LDW Monitor traffic lane	√	√	√				
Scania\Divided By Vehicle\TRUCK\G-Serie\Engine 480\Truck DT 12 HPI [---08>---13]\Air conditioner\CCS Climate control system	√	√	√	√		√	
Scania\Divided By Vehicle\TRUCK\G-Serie\Engine 480\Truck DT 12 HPI [---08>---13]\Airbag\CSS Climate safety system	√	√	√				
Scania\Divided By Vehicle\TRUCK\G-Serie\Engine 480\Truck DT 12 HPI [---08>---13]\Alarm\LAS Locking and alarm system	√	√	√				
Scania\Divided By Vehicle\TRUCK\G-Serie\Engine 480\Truck DT 12 HPI [---08>---13]\Auxiliary heating\ATA Auxiliary heating system air-to-air	√	√	√	√			
Scania\Divided By Vehicle\TRUCK\G-Serie\Engine 480\Truck DT 12 HPI [---08>---13]\Auxiliary heating\WTA Auxiliary heating system water-to-air	√	√	√				
Scania\Divided By Vehicle\TRUCK\G-Serie\Engine 480\Truck DT 12 HPI [---08>---13]\Chassis equipment and design\BWS Preparation system	√	√	√				
Scania\Divided By Vehicle\TRUCK\G-Serie\Engine 480\Truck DT 12 HPI [---08>---13]\Comfort system\CTS Clock and Time System	√	√	√				
Scania\Divided By Vehicle\TRUCK\G-Serie\Engine 480\Truck DT 12 HPI [---08>---13]\Compressed air reserve system\APS Compressed air power supply(Scania protocol)	√	√	√	√			0003
Scania\Divided By Vehicle\TRUCK\G-Serie\Engine 480\Truck DT 12 HPI [---08>---13]\Compressed air reserve system\APS Compressed air power supply(Wabco protocol)	√	√	√	√			
Scania\Divided By Vehicle\TRUCK\G-Serie\Engine 480\Truck DT 12 HPI [---08>---13]\Diesel injection\EEC-Exhaust gas treatment	√	√	√	√		√	
Scania\Divided By Vehicle\TRUCK\G-Serie\Engine 480\Truck DT 12 HPI [---08>---13]\Diesel injection\EMS Engine management system S6-S7	√	√	√	√		√	0002, 0015, 0017
Scania\Divided By Vehicle\TRUCK\G-Serie\Engine 480\Truck DT 12 HPI [---08>---13]\Diesel injection\EMS Engine management system S8(8 Cylindes)	√	√	√	√		√	0001
Scania\Divided By Vehicle\TRUCK\G-Serie\Engine 480\Truck DT 12 HPI [---08>---13]\Diesel injection\EMS Engine management system DC13(6 Cylindes)	√	√	√	√		√	
Scania\Divided By Vehicle\TRUCK\G-Serie\Engine 480\Truck DT 12 HPI [---08>---13]\Distance control\DAS Adaptive Cruise Control	√	√	√				
Scania\Divided By Vehicle\TRUCK\G-Serie\Engine 480\Truck DT 12 HPI [---08>---13]\Distance control\DIS Adaptive Cruise Control	√	√	√				
Scania\Divided By Vehicle\TRUCK\G-Serie\Engine 480\Truck DT 12 HPI [---08>---13]\EBS\BMS Brake management system 5.0 (4x2)	√	√	√	√		√	0004
Scania\Divided By Vehicle\TRUCK\G-Serie\Engine 480\Truck DT 12 HPI [---08>---13]\EBS\BMS Brake management system 5.0 (6x2 - 6x4)	√	√	√	√		√	0004
Scania\Divided By Vehicle\TRUCK\G-Serie\Engine 480\Truck DT 12 HPI [---08>---13]\EBS\BMS Brake management system 5.0 (8x2)	√	√	√	√		√	0004
Scania\Divided By Vehicle\TRUCK\G-Serie\Engine 480\Truck DT 12 HPI [---08>---13]\ECU external light\VIS Visibility system	√	√	√	√		√	
Scania\Divided By Vehicle\TRUCK\G-Serie\Engine 480\Truck DT 12 HPI [---08>---13]\Engine-vehicle adjustment\COO Coordinator module	√	√	√	√		√	
Scania\Divided By Vehicle\TRUCK\G-Serie\Engine 480\Truck DT 12 HPI [---08>---13]\Engine-vehicle adjustment\COO7 (Coordinator)	√	√	√	√		√	
Scania\Divided By Vehicle\TRUCK\G-Serie\Engine 480\Truck DT 12 HPI [---08>---13]\Four-wheel drive\AWD ALL-Wheel Drive	√	√	√				
Scania\Divided By Vehicle\TRUCK\G-Serie\Engine 480\Truck DT 12 HPI [---08>---13]\Instrument panel\NCL Instrument Panel 1	√	√	√	√		√	
Scania\Divided By Vehicle\TRUCK\G-Serie\Engine 480\Truck DT 12 HPI [---08>---13]\Instrument panel\NCL Instrument Panel 2	√	√	√	√		√	
Scania\Divided By Vehicle\TRUCK\G-Serie\Engine 480\Truck DT 12 HPI [---08>---13]\Radio\AUS Audio system	√	√	√				
Scania\Divided By Vehicle\TRUCK\G-Serie\Engine 480\Truck DT 12 HPI [---08>---13]\Retarder\RET Retarder	√	√	√	√		√	
Scania\Divided By Vehicle\TRUCK\G-Serie\Engine 480\Truck DT 12 HPI [---08>---13]\Suspensions\SMS Supension management system	√	√	√	√			0006, 0007, 0014
Scania\Divided By Vehicle\TRUCK\G-Serie\Engine 480\Truck DT 12 HPI [---08>---13]\Tachograph\DTCO Tachograph	√	√	√				
Scania\Divided By Vehicle\TRUCK\G-Serie\Engine 480\Truck DT 12 HPI [---08>---13]\Tachograph\MTCO Tachograph	√	√	√				
Scania\Divided By Vehicle\TRUCK\G-Serie\Engine 480\Truck DT 12 HPI [---08>---13]\Tire pressure\TPM - Tires Pressure Monitoring System	√	√	√				

Scania\Divided By Vehicle\TRUCK\G-Serie\Engine 480\Truck DT 12 HPI [---08>---13]\Transmission\GMS - Gear management system A4	√	√	√			√	
Scania\Divided By Vehicle\TRUCK\G-Serie\Engine 480\Truck DT 12 HPI [---08>---13]\Transmission\GMS - Gear management system OPC	√	√	√	√		√	0005
Scania\Divided By Vehicle\TRUCK\G-Serie\Engine 480\Truck DT 12 HPI [---08>---13]\Transmission\GMS - Gear management system Opticruise 5	√	√	√	√		√	0009, 0011, 0018
Scania\Divided By Vehicle\TRUCK\G-Serie\Engine 480\Truck DT 12 HPI [---08>---13]\Transmission\GMS - GMS Opticruise 5	√	√	√	√		√	0009, 0011, 0018
Scania\Divided By Vehicle\TRUCK\G-Serie\Engine 480\Truck DT 12 HPI [---08>---13]\Transport information system\RTI - Road Transport Informatics	√	√	√				
Scania\Divided By Vehicle\TRUCK\G-Serie\Engine 480\Truck DT 12 HPI [---08>---13]\Reset service\EMS S8						√	
Scania\Divided By Vehicle\TRUCK\G-Serie\Engine 480\Truck DT 12 HPI [---08>---13]\Reset service\EMS S7						√	
Scania\Divided By Vehicle\TRUCK\G-Serie\Engine 480\Truck DT 12 HPI [---08>---13]\Reset service\EMS S6						√	
Scania\Divided By Vehicle\TRUCK\G-Serie Euro 6\ABS\BMS Brake management system-ABS E	√	√	√	√		√	
Scania\Divided By Vehicle\TRUCK\G-Serie Euro 6\Aid for keeping lane\LDW Monitor traffic lane	√	√	√				
Scania\Divided By Vehicle\TRUCK\G-Serie Euro 6\Air conditioner\CCS Climate control system	√	√	√	√		√	
Scania\Divided By Vehicle\TRUCK\G-Serie Euro 6\Airbag\CSS Climate safety system	√	√	√				
Scania\Divided By Vehicle\TRUCK\G-Serie Euro 6\Alarm\LAS Locking and alarm system	√	√	√				
Scania\Divided By Vehicle\TRUCK\G-Serie Euro 6\Auxiliary heating\ATA Auxiliary heating system air-to-air	√	√	√	√			
Scania\Divided By Vehicle\TRUCK\G-Serie Euro 6\Auxiliary heating\WTA Auxiliary heating system water-to-air	√	√	√				
Scania\Divided By Vehicle\TRUCK\G-Serie Euro 6\Chassis equipment and design\BWS Preparation system	√	√	√				
Scania\Divided By Vehicle\TRUCK\G-Serie Euro 6\Comfort system\CTS Clock and Time System	√	√	√				
Scania\Divided By Vehicle\TRUCK\G-Serie Euro 6\Compressed air reserve system\APS Compressed air power supply(Scania protocol)	√	√	√	√			0003
Scania\Divided By Vehicle\TRUCK\G-Serie Euro 6\Compressed air reserve system\APS Compressed air power supply(Wabco protocol)	√	√	√	√			
Scania\Divided By Vehicle\TRUCK\G-Serie Euro 6\Diesel injection\EMS Engine management system S8(8 Cylindes)	√	√	√	√		√	0001
Scania\Divided By Vehicle\TRUCK\G-Serie Euro 6\Diesel injection\EMS Engine management system DC13(6 Cylindes)	√	√	√	√		√	
Scania\Divided By Vehicle\TRUCK\G-Serie Euro 6\Distance control\DAS Adaptive Cruise Control	√	√	√				
Scania\Divided By Vehicle\TRUCK\G-Serie Euro 6\Distance control\DIS Adaptive Cruise Control	√	√	√				
Scania\Divided By Vehicle\TRUCK\G-Serie Euro 6\EBS\BMS Brake management system 5.0 (4x2)	√	√	√	√		√	0004
Scania\Divided By Vehicle\TRUCK\G-Serie Euro 6\EBS\BMS Brake management system 5.0 (6x2 - 6x4)	√	√	√	√		√	0004
Scania\Divided By Vehicle\TRUCK\G-Serie Euro 6\EBS\BMS Brake management system 5.0 (8x2)	√	√	√	√		√	0004
Scania\Divided By Vehicle\TRUCK\G-Serie Euro 6\ECU external light\VIS Visibility system	√	√	√	√		√	
Scania\Divided By Vehicle\TRUCK\G-Serie Euro 6\Engine-vehicle adjustment\COO Coordinator module	√	√	√	√		√	
Scania\Divided By Vehicle\TRUCK\G-Serie Euro 6\Engine-vehicle adjustment\COO7 (Coordinator)	√	√	√	√		√	
Scania\Divided By Vehicle\TRUCK\G-Serie Euro 6\Four-wheel drive\AWD ALL-Wheel Drive	√	√	√				
Scania\Divided By Vehicle\TRUCK\G-Serie Euro 6\Instrument panel\NCL Instrument Panel 1	√	√	√	√		√	
Scania\Divided By Vehicle\TRUCK\G-Serie Euro 6\Instrument panel\NCL Instrument Panel 2	√	√	√	√		√	
Scania\Divided By Vehicle\TRUCK\G-Serie Euro 6\Radio\AUS Audio system	√	√	√				
Scania\Divided By Vehicle\TRUCK\G-Serie Euro 6\Retarder\RET Retarder	√	√	√	√		√	
Scania\Divided By Vehicle\TRUCK\G-Serie Euro 6\Suspensions\SMS Suspension management system	√	√	√	√			0006, 0007, 0014

Scania\Divided By Vehicle\TRUCK\G-Serie Euro 6\Tachograph\DTCO Tachograph	√	√	√				
Scania\Divided By Vehicle\TRUCK\G-Serie Euro 6\Tachograph\MTCO Tachograph	√	√	√				
Scania\Divided By Vehicle\TRUCK\G-Serie Euro 6\Tire pressure\TPM - Tires Pressure Monitoring System	√	√	√				
Scania\Divided By Vehicle\TRUCK\G-Serie Euro 6\Transmission\GMS - Gear management system A4	√	√	√			√	
Scania\Divided By Vehicle\TRUCK\G-Serie Euro 6\Transmission\GMS - Gear management system OPC	√	√	√	√		√	0005
Scania\Divided By Vehicle\TRUCK\G-Serie Euro 6\Transmission\GMS - Gear management system Opticruise 5	√	√	√	√		√	0009, 0011, 0018
Scania\Divided By Vehicle\TRUCK\G-Serie Euro 6\Transmission\GMS - GMS Opticruise 5	√	√	√	√		√	0009, 0011, 0018
Scania\Divided By Vehicle\TRUCK\G-Serie Euro 6\Transport information system\RTI - Road Transport Informatics	√	√	√				
Scania\Divided By Vehicle\TRUCK\G-Serie Euro 6\Reset service\EMS S8						√	
Scania\Divided By Vehicle\TRUCK\G-Serie Euro 6\Reset service\EMS S7						√	
Scania\Divided By Vehicle\TRUCK\G-Serie Euro 6\Reset service\EMS S6						√	
Scania\Divided By Vehicle\TRUCK\I-Series\Engine 230\Truck DC 9 XPI EU5[---08>---13]\ABS\BMS Brake management system-ABS E	√	√	√	√		√	
Scania\Divided By Vehicle\TRUCK\I-Series\Engine 230\Truck DC 9 XPI EU5[---08>---13]\Aid for keeping lane\LDW Monitor traffic lane	√	√	√				
Scania\Divided By Vehicle\TRUCK\I-Series\Engine 230\Truck DC 9 XPI EU5[---08>---13]\Air conditioner\CCS Climate control system	√	√	√	√		√	
Scania\Divided By Vehicle\TRUCK\I-Series\Engine 230\Truck DC 9 XPI EU5[---08>---13]\Airbag\CSS Climate safety system	√	√	√				
Scania\Divided By Vehicle\TRUCK\I-Series\Engine 230\Truck DC 9 XPI EU5[---08>---13]\Alarm\LAS Locking and alarm system	√	√	√				
Scania\Divided By Vehicle\TRUCK\I-Series\Engine 230\Truck DC 9 XPI EU5[---08>---13]\Auxiliary heating\ATA Auxiliary heating system air-to-air	√	√	√	√			
Scania\Divided By Vehicle\TRUCK\I-Series\Engine 230\Truck DC 9 XPI EU5[---08>---13]\Auxiliary heating\WTA Auxiliary heating system water-to-air	√	√	√				
Scania\Divided By Vehicle\TRUCK\I-Series\Engine 230\Truck DC 9 XPI EU5[---08>---13]\Chassis equipment and design\BWS Preparation system	√	√	√				
Scania\Divided By Vehicle\TRUCK\I-Series\Engine 230\Truck DC 9 XPI EU5[---08>---13]\Comfort system\CTS Clock and Time System	√	√	√				
Scania\Divided By Vehicle\TRUCK\I-Series\Engine 230\Truck DC 9 XPI EU5[---08>---13]\Compressed air reserve system\APS Compressed air power supply(Scania protocol)	√	√	√	√			0003
Scania\Divided By Vehicle\TRUCK\I-Series\Engine 230\Truck DC 9 XPI EU5[---08>---13]\Compressed air reserve system\APS Compressed air power supply(Wabco protocol)	√	√	√	√			
Scania\Divided By Vehicle\TRUCK\I-Series\Engine 230\Truck DC 9 XPI EU5[---08>---13]\Diesel injection\EEC-Exhaust gas treatment	√	√	√	√		√	
Scania\Divided By Vehicle\TRUCK\I-Series\Engine 230\Truck DC 9 XPI EU5[---08>---13]\Diesel injection\EMS Engine management system S6-S7	√	√	√	√		√	0002, 0015, 0017
Scania\Divided By Vehicle\TRUCK\I-Series\Engine 230\Truck DC 9 XPI EU5[---08>---13]\Diesel injection\EMS Engine management system S8(8 Cylindes)	√	√	√	√		√	0001
Scania\Divided By Vehicle\TRUCK\I-Series\Engine 230\Truck DC 9 XPI EU5[---08>---13]\Diesel injection\EMS Engine management system DC13(6 Cylindes)	√	√	√	√		√	
Scania\Divided By Vehicle\TRUCK\I-Series\Engine 230\Truck DC 9 XPI EU5[---08>---13]\Distance control\DAS Adaptive Cruise Control	√	√	√				
Scania\Divided By Vehicle\TRUCK\I-Series\Engine 230\Truck DC 9 XPI EU5[---08>---13]\Distance control\DIS Adaptive Cruise Control	√	√	√				
Scania\Divided By Vehicle\TRUCK\I-Series\Engine 230\Truck DC 9 XPI EU5[---08>---13]\EBS\BMS Brake management system 5.0 (4x2)	√	√	√	√		√	0004
Scania\Divided By Vehicle\TRUCK\I-Series\Engine 230\Truck DC 9 XPI EU5[---08>---13]\EBS\BMS Brake management system 5.0 (6x2 - 6x4)	√	√	√	√		√	0004
Scania\Divided By Vehicle\TRUCK\I-Series\Engine 230\Truck DC 9 XPI EU5[---08>---13]\EBS\BMS Brake management system 5.0 (8x2)	√	√	√	√		√	0004
Scania\Divided By Vehicle\TRUCK\I-Series\Engine 230\Truck DC 9 XPI EU5[---08>---13]\ECU external light\VIS Visiblity system	√	√	√	√		√	
Scania\Divided By Vehicle\TRUCK\I-Series\Engine 230\Truck DC 9 XPI EU5[---08>---13]\Engine-vehicle adjustment\COO Coordinator module	√	√	√	√		√	
Scania\Divided By Vehicle\TRUCK\I-Series\Engine 230\Truck DC 9 XPI EU5[---08>---13]\Engine-vehicle adjustment\COO7 (Coordinator)	√	√	√	√		√	
Scania\Divided By Vehicle\TRUCK\I-Series\Engine 230\Truck DC 9 XPI EU5[---08>---13]\Four-wheel drive\AWD ALL-Wheel Drive	√	√	√				

Scania\Divided By Vehicle\TRUCK\P-Serie\Engine 230\Truck DC 9 XPI EU5[---08>---13]\Instrument pane\NCL Instrument Panel 1	√	√	√	√		√	
Scania\Divided By Vehicle\TRUCK\P-Serie\Engine 230\Truck DC 9 XPI EU5[---08>---13]\Instrument pane\NCL Instrument Panel 2	√	√	√	√		√	
Scania\Divided By Vehicle\TRUCK\P-Serie\Engine 230\Truck DC 9 XPI EU5[---08>---13]\Radio\AUS Audio system	√	√	√				
Scania\Divided By Vehicle\TRUCK\P-Serie\Engine 230\Truck DC 9 XPI EU5[---08>---13]\Retarder\RET Retarder	√	√	√	√		√	
Scania\Divided By Vehicle\TRUCK\P-Serie\Engine 230\Truck DC 9 XPI EU5[---08>---13]\Suspensions\SMS Supension management system	√	√	√	√			0006, 0007, 0014
Scania\Divided By Vehicle\TRUCK\P-Serie\Engine 230\Truck DC 9 XPI EU5[---08>---13]\Tachograph\DTCO Tachograph	√	√	√				
Scania\Divided By Vehicle\TRUCK\P-Serie\Engine 230\Truck DC 9 XPI EU5[---08>---13]\Tachograph\MTCO Tachograph	√	√	√				
Scania\Divided By Vehicle\TRUCK\P-Serie\Engine 230\Truck DC 9 XPI EU5[---08>---13]\Tire pressure\TPM - Tires Pressure Monitoring System	√	√	√				
Scania\Divided By Vehicle\TRUCK\P-Serie\Engine 230\Truck DC 9 XPI EU5[---08>---13]\Transmission\GMS - Gear management system A4	√	√	√			√	
Scania\Divided By Vehicle\TRUCK\P-Serie\Engine 230\Truck DC 9 XPI EU5[---08>---13]\Transmission\GMS - Gear management system OPC	√	√	√	√		√	0005
Scania\Divided By Vehicle\TRUCK\P-Serie\Engine 230\Truck DC 9 XPI EU5[---08>---13]\Transmission\GMS - Gear management system Opticruise 5	√	√	√	√		√	0009, 0011, 0018
Scania\Divided By Vehicle\TRUCK\P-Serie\Engine 230\Truck DC 9 XPI EU5[---08>---13]\Transmission\GMS - GMS Opticruise 5	√	√	√	√		√	0009, 0011, 0018
Scania\Divided By Vehicle\TRUCK\P-Serie\Engine 230\Truck DC 9 XPI EU5[---08>---13]\Transport information system\RTI - Road Transport Informatics	√	√	√				
Scania\Divided By Vehicle\TRUCK\P-Serie\Engine 230\Truck DC 9 [---04>---08]\ABS\BMS Brake management system-ABS E	√	√	√	√		√	
Scania\Divided By Vehicle\TRUCK\P-Serie\Engine 230\Truck DC 9 [---04>---08]\Aid for keeping lane\LDW Monitor traffic lane	√	√	√				
Scania\Divided By Vehicle\TRUCK\P-Serie\Engine 230\Truck DC 9 [---04>---08]\Air conditioner\CCS Climate control system	√	√	√	√		√	
Scania\Divided By Vehicle\TRUCK\P-Serie\Engine 230\Truck DC 9 [---04>---08]\Airbag\CSS Climate safety system	√	√	√				
Scania\Divided By Vehicle\TRUCK\P-Serie\Engine 230\Truck DC 9 [---04>---08]\Alarm\LAS Locking and alarm system	√	√	√				
Scania\Divided By Vehicle\TRUCK\P-Serie\Engine 230\Truck DC 9 [---04>---08]\Auxiliary heating\ATA Auxiliary heating system air-to-air	√	√	√	√			
Scania\Divided By Vehicle\TRUCK\P-Serie\Engine 230\Truck DC 9 [---04>---08]\Auxiliary heating\WTA Auxiliary heating system water-to-air	√	√	√				
Scania\Divided By Vehicle\TRUCK\P-Serie\Engine 230\Truck DC 9 [---04>---08]\Chassis equipment and design\BWS Preparation system	√	√	√				
Scania\Divided By Vehicle\TRUCK\P-Serie\Engine 230\Truck DC 9 [---04>---08]\Comfort system\CTS Clock and Time System	√	√	√				
Scania\Divided By Vehicle\TRUCK\P-Serie\Engine 230\Truck DC 9 [---04>---08]\Compressed air reserve system\APS Compressed air power supply(Scania protocol)	√	√	√	√			0003
Scania\Divided By Vehicle\TRUCK\P-Serie\Engine 230\Truck DC 9 [---04>---08]\Compressed air reserve system\APS Compressed air power supply(Wabco protocol)	√	√	√	√			
Scania\Divided By Vehicle\TRUCK\P-Serie\Engine 230\Truck DC 9 [---04>---08]\Diesel injection\EEC-Exhaust gas treatment	√	√	√	√		√	
Scania\Divided By Vehicle\TRUCK\P-Serie\Engine 230\Truck DC 9 [---04>---08]\Diesel injection\EMS Engine management system S6-S7	√	√	√	√		√	0002, 0015, 0017
Scania\Divided By Vehicle\TRUCK\P-Serie\Engine 230\Truck DC 9 [---04>---08]\Diesel injection\EMS Engine management system S8(8 Cylindes)	√	√	√	√		√	0001
Scania\Divided By Vehicle\TRUCK\P-Serie\Engine 230\Truck DC 9 [---04>---08]\Diesel injection\EMS Engine management system DC13(6 Cylindes)	√	√	√	√		√	
Scania\Divided By Vehicle\TRUCK\P-Serie\Engine 230\Truck DC 9 [---04>---08]\Distance control\DAS Adaptive Cruise Control	√	√	√				
Scania\Divided By Vehicle\TRUCK\P-Serie\Engine 230\Truck DC 9 [---04>---08]\Distance control\DIS Adaptive Cruise Control	√	√	√				
Scania\Divided By Vehicle\TRUCK\P-Serie\Engine 230\Truck DC 9 [---04>---08]\EBS\BMS Brake management system 5.0 (4x2)	√	√	√	√		√	0004
Scania\Divided By Vehicle\TRUCK\P-Serie\Engine 230\Truck DC 9 [---04>---08]\EBS\BMS Brake management system 5.0 (6x2 - 6x4)	√	√	√	√		√	0004
Scania\Divided By Vehicle\TRUCK\P-Serie\Engine 230\Truck DC 9 [---04>---08]\EBS\BMS Brake management system 5.0 (8x2)	√	√	√	√		√	0004
Scania\Divided By Vehicle\TRUCK\P-Serie\Engine 230\Truck DC 9 [---04>---08]\ECU external light\VIS Visibility system	√	√	√	√		√	
Scania\Divided By Vehicle\TRUCK\P-Serie\Engine 230\Truck DC 9 [---04>---08]\Engine-vehicle adjustment\COO Coordinator module	√	√	√	√		√	

Scania\Divided By Vehicle\TRUCK\P-Serie\Engine 230\Truck DC 9 [---04>---08]\Engine-vehicle adjustment\COO7 (Coordinator)	√	√	√	√		√	
Scania\Divided By Vehicle\TRUCK\P-Serie\Engine 230\Truck DC 9 [---04>---08]\Four-wheel drive\AWD ALL-Wheel Drive	√	√	√				
Scania\Divided By Vehicle\TRUCK\P-Serie\Engine 230\Truck DC 9 [---04>---08]\Instrument panel\NCL Instrument Panel 1	√	√	√	√		√	
Scania\Divided By Vehicle\TRUCK\P-Serie\Engine 230\Truck DC 9 [---04>---08]\Instrument panel\NCL Instrument Panel 2	√	√	√	√		√	
Scania\Divided By Vehicle\TRUCK\P-Serie\Engine 230\Truck DC 9 [---04>---08]\Radio\AUS Audio system	√	√	√				
Scania\Divided By Vehicle\TRUCK\P-Serie\Engine 230\Truck DC 9 [---04>---08]\Retarder\RET Retarder	√	√	√	√		√	
Scania\Divided By Vehicle\TRUCK\P-Serie\Engine 230\Truck DC 9 [---04>---08]\Suspensions\SMS Suspension management system	√	√	√	√			0006, 0007, 0014
Scania\Divided By Vehicle\TRUCK\P-Serie\Engine 230\Truck DC 9 [---04>---08]\Tachograph\DTCO Tachograph	√	√	√				
Scania\Divided By Vehicle\TRUCK\P-Serie\Engine 230\Truck DC 9 [---04>---08]\Tachograph\MTCO Tachograph	√	√	√				
Scania\Divided By Vehicle\TRUCK\P-Serie\Engine 230\Truck DC 9 [---04>---08]\Tire pressure\TPM - Tires Pressure Monitoring System	√	√	√				
Scania\Divided By Vehicle\TRUCK\P-Serie\Engine 230\Truck DC 9 [---04>---08]\Transmission\GMS - Gear management system A4	√	√	√			√	
Scania\Divided By Vehicle\TRUCK\P-Serie\Engine 230\Truck DC 9 [---04>---08]\Transmission\GMS - Gear management system OPC	√	√	√	√		√	0005
Scania\Divided By Vehicle\TRUCK\P-Serie\Engine 230\Truck DC 9 [---04>---08]\Transmission\GMS - Gear management system Opticruise 5	√	√	√	√		√	0009, 0011, 0018
Scania\Divided By Vehicle\TRUCK\P-Serie\Engine 230\Truck DC 9 [---04>---08]\Transmission\GMS - GMS Opticruise 5	√	√	√	√		√	0009, 0011, 0018
Scania\Divided By Vehicle\TRUCK\P-Serie\Engine 230\Truck DC 9 [---04>---08]\Transport information system\RTI - Road Transport Informatics	√	√	√				
Scania\Divided By Vehicle\TRUCK\P-Serie\Engine 270\Truck DC 9 [---04>---13]\ABS\BMS Brake management system-ABS E	√	√	√	√		√	
Scania\Divided By Vehicle\TRUCK\P-Serie\Engine 270\Truck DC 9 [---04>---13]\Aid for keeping lane\LDW Monitor traffic lane	√	√	√				
Scania\Divided By Vehicle\TRUCK\P-Serie\Engine 270\Truck DC 9 [---04>---13]\Air conditioner\CCS Climate control system	√	√	√	√		√	
Scania\Divided By Vehicle\TRUCK\P-Serie\Engine 270\Truck DC 9 [---04>---13]\Airbag\CSS Climate safety system	√	√	√				
Scania\Divided By Vehicle\TRUCK\P-Serie\Engine 270\Truck DC 9 [---04>---13]\Alarm\LAS Locking and alarm system	√	√	√				
Scania\Divided By Vehicle\TRUCK\P-Serie\Engine 270\Truck DC 9 [---04>---13]\Auxiliary heating\ATA Auxiliary heating system air-to-air	√	√	√	√			
Scania\Divided By Vehicle\TRUCK\P-Serie\Engine 270\Truck DC 9 [---04>---13]\Auxiliary heating\WTA Auxiliary heating system water-to-air	√	√	√				
Scania\Divided By Vehicle\TRUCK\P-Serie\Engine 270\Truck DC 9 [---04>---13]\Chassis equipment and design\BWS Preparation system	√	√	√				
Scania\Divided By Vehicle\TRUCK\P-Serie\Engine 270\Truck DC 9 [---04>---13]\Comfort system\CTS Clock and Time System	√	√	√				
Scania\Divided By Vehicle\TRUCK\P-Serie\Engine 270\Truck DC 9 [---04>---13]\Compressed air reserve system\APS Compressed air power supply(Scania protocol)	√	√	√	√			0003
Scania\Divided By Vehicle\TRUCK\P-Serie\Engine 270\Truck DC 9 [---04>---13]\Compressed air reserve system\APS Compressed air power supply(Wabco protocol)	√	√	√	√			
Scania\Divided By Vehicle\TRUCK\P-Serie\Engine 270\Truck DC 9 [---04>---13]\Diesel injection\EEC-Exhaust gas treatment	√	√	√	√		√	
Scania\Divided By Vehicle\TRUCK\P-Serie\Engine 270\Truck DC 9 [---04>---13]\Diesel injection\EMS Engine management system S6-S7	√	√	√	√		√	0002, 0015, 0017
Scania\Divided By Vehicle\TRUCK\P-Serie\Engine 270\Truck DC 9 [---04>---13]\Diesel injection\EMS Engine management system S8(8 Cylindes)	√	√	√	√		√	0001
Scania\Divided By Vehicle\TRUCK\P-Serie\Engine 270\Truck DC 9 [---04>---13]\Diesel injection\EMS Engine management system DC13(6 Cylindes)	√	√	√	√		√	
Scania\Divided By Vehicle\TRUCK\P-Serie\Engine 270\Truck DC 9 [---04>---13]\Distance control\DAS Adaptive Cruise Control	√	√	√				
Scania\Divided By Vehicle\TRUCK\P-Serie\Engine 270\Truck DC 9 [---04>---13]\Distance control\DIS Adaptive Cruise Control	√	√	√				
Scania\Divided By Vehicle\TRUCK\P-Serie\Engine 270\Truck DC 9 [---04>---13]\EBS\BMS Brake management system 5.0 (4x2)	√	√	√	√		√	0004
Scania\Divided By Vehicle\TRUCK\P-Serie\Engine 270\Truck DC 9 [---04>---13]\EBS\BMS Brake management system 5.0 (6x2 - 6x4)	√	√	√	√		√	0004
Scania\Divided By Vehicle\TRUCK\P-Serie\Engine 270\Truck DC 9 [---04>---13]\EBS\BMS Brake management system 5.0 (8x2)	√	√	√	√		√	0004

Scania\Divided By Vehicle\TRUCK\P-Serie\Engine 270\Truck DC 9 [--04>---13]\ECU external light\VIS Visibility system	√	√	√	√		√	
Scania\Divided By Vehicle\TRUCK\P-Serie\Engine 270\Truck DC 9 [--04>---13]\Engine-vehicle adjustment\COO Coordinator module	√	√	√	√		√	
Scania\Divided By Vehicle\TRUCK\P-Serie\Engine 270\Truck DC 9 [--04>---13]\Engine-vehicle adjustment\COO7 (Coordinator)	√	√	√	√		√	
Scania\Divided By Vehicle\TRUCK\P-Serie\Engine 270\Truck DC 9 [--04>---13]\Four-wheel drive\AWD ALL-Wheel Drive	√	√	√				
Scania\Divided By Vehicle\TRUCK\P-Serie\Engine 270\Truck DC 9 [--04>---13]\Instrument panel\ICL Instrument Panel 1	√	√	√	√		√	
Scania\Divided By Vehicle\TRUCK\P-Serie\Engine 270\Truck DC 9 [--04>---13]\Instrument panel\ICL Instrument Panel 2	√	√	√	√		√	
Scania\Divided By Vehicle\TRUCK\P-Serie\Engine 270\Truck DC 9 [--04>---13]\Radio\AUS Audio system	√	√	√				
Scania\Divided By Vehicle\TRUCK\P-Serie\Engine 270\Truck DC 9 [--04>---13]\Retarder\RET Retarder	√	√	√	√		√	
Scania\Divided By Vehicle\TRUCK\P-Serie\Engine 270\Truck DC 9 [--04>---13]\Suspensions\SMS Suspension management system	√	√	√	√			0006, 0007, 0014
Scania\Divided By Vehicle\TRUCK\P-Serie\Engine 270\Truck DC 9 [--04>---13]\Tachograph\DTCO Tachograph	√	√	√				
Scania\Divided By Vehicle\TRUCK\P-Serie\Engine 270\Truck DC 9 [--04>---13]\Tachograph\MTCO Tachograph	√	√	√				
Scania\Divided By Vehicle\TRUCK\P-Serie\Engine 270\Truck DC 9 [--04>---13]\Tire pressure\TPM - Tires Pressure Monitoring System	√	√	√				
Scania\Divided By Vehicle\TRUCK\P-Serie\Engine 270\Truck DC 9 [--04>---13]\Transmission\GMS - Gear management system A4	√	√	√			√	
Scania\Divided By Vehicle\TRUCK\P-Serie\Engine 270\Truck DC 9 [--04>---13]\Transmission\GMS - Gear management system OPC	√	√	√	√		√	0005
Scania\Divided By Vehicle\TRUCK\P-Serie\Engine 270\Truck DC 9 [--04>---13]\Transmission\GMS - Gear management system Opticruise 5	√	√	√	√		√	0009, 0011, 0018
Scania\Divided By Vehicle\TRUCK\P-Serie\Engine 270\Truck DC 9 [--04>---13]\Transmission\GMS - GMS Opticruise 5	√	√	√	√		√	0009, 0011, 0018
Scania\Divided By Vehicle\TRUCK\P-Serie\Engine 270\Truck DC 9 [--04>---13]\Transport information system\RTI - Road Transport Informatics	√	√	√				
Scania\Divided By Vehicle\TRUCK\P-Serie\Engine 280\Truck DC 9 XPI EU5[---08>---13]\ABS\BMS Brake management system-ABS E	√	√	√	√		√	
Scania\Divided By Vehicle\TRUCK\P-Serie\Engine 280\Truck DC 9 XPI EU5[---08>---13]\Aid for keeping lane\LDW Monitor traffic lane	√	√	√				
Scania\Divided By Vehicle\TRUCK\P-Serie\Engine 280\Truck DC 9 XPI EU5[---08>---13]\Air conditioner\CCS Climate control system	√	√	√	√		√	
Scania\Divided By Vehicle\TRUCK\P-Serie\Engine 280\Truck DC 9 XPI EU5[---08>---13]\Airbag\CSS Climate safety system	√	√	√				
Scania\Divided By Vehicle\TRUCK\P-Serie\Engine 280\Truck DC 9 XPI EU5[---08>---13]\Alarm\LAS Locking and alarm system	√	√	√				
Scania\Divided By Vehicle\TRUCK\P-Serie\Engine 280\Truck DC 9 XPI EU5[---08>---13]\Auxiliary heating\ATA Auxiliary heating system air-to-air	√	√	√	√			
Scania\Divided By Vehicle\TRUCK\P-Serie\Engine 280\Truck DC 9 XPI EU5[---08>---13]\Auxiliary heating\WTA Auxiliary heating system water-to-air	√	√	√				
Scania\Divided By Vehicle\TRUCK\P-Serie\Engine 280\Truck DC 9 XPI EU5[---08>---13]\Chassis equipment and design\BWS Preparation system	√	√	√				
Scania\Divided By Vehicle\TRUCK\P-Serie\Engine 280\Truck DC 9 XPI EU5[---08>---13]\Comfort system\CTS Clock and Time System	√	√	√				
Scania\Divided By Vehicle\TRUCK\P-Serie\Engine 280\Truck DC 9 XPI EU5[---08>---13]\Compressed air reserve system\APS Compressed air power supply(Scania protocol)	√	√	√	√			0003
Scania\Divided By Vehicle\TRUCK\P-Serie\Engine 280\Truck DC 9 XPI EU5[---08>---13]\Compressed air reserve system\APS Compressed air power supply(Wabco protocol)	√	√	√	√			
Scania\Divided By Vehicle\TRUCK\P-Serie\Engine 280\Truck DC 9 XPI EU5[---08>---13]\Diesel injection\EEC-Exhaust gas treatment	√	√	√	√		√	
Scania\Divided By Vehicle\TRUCK\P-Serie\Engine 280\Truck DC 9 XPI EU5[---08>---13]\Diesel injection\EMS Engine management system S6-S7	√	√	√	√		√	0002, 0015, 0017
Scania\Divided By Vehicle\TRUCK\P-Serie\Engine 280\Truck DC 9 XPI EU5[---08>---13]\Diesel injection\EMS Engine management system S8(8 Cylindes)	√	√	√	√		√	0001
Scania\Divided By Vehicle\TRUCK\P-Serie\Engine 280\Truck DC 9 XPI EU5[---08>---13]\Diesel injection\EMS Engine management system DC13(6 Cylindes)	√	√	√	√		√	
Scania\Divided By Vehicle\TRUCK\P-Serie\Engine 280\Truck DC 9 XPI EU5[---08>---13]\Distance control\DAS Adaptive Cruise Control	√	√	√				
Scania\Divided By Vehicle\TRUCK\P-Serie\Engine 280\Truck DC 9 XPI EU5[---08>---13]\Distance control\DIS Adaptive Cruise Control	√	√	√				
Scania\Divided By Vehicle\TRUCK\P-Serie\Engine 280\Truck DC 9 XPI EU5[---08>---13]\EBS\BMS Brake management system 5.0 (4x2)	√	√	√	√		√	0004

Scania\Divided By Vehicle\TRUCK\P-Serie\Engine 280\Truck DC 9 XPI EU5[---08>---13]\EBS\BMS Brake management system 5.0 (6x2 - 6x4)	√	√	√	√		√	0004
Scania\Divided By Vehicle\TRUCK\P-Serie\Engine 280\Truck DC 9 XPI EU5[---08>---13]\EBS\BMS Brake management system 5.0 (8x2)	√	√	√	√		√	0004
Scania\Divided By Vehicle\TRUCK\P-Serie\Engine 280\Truck DC 9 XPI EU5[---08>---13]\ECU external light\VIS Visibility system	√	√	√	√		√	
Scania\Divided By Vehicle\TRUCK\P-Serie\Engine 280\Truck DC 9 XPI EU5[---08>---13]\Engine-vehicle adjustment\COO Coordinator module	√	√	√	√		√	
Scania\Divided By Vehicle\TRUCK\P-Serie\Engine 280\Truck DC 9 XPI EU5[---08>---13]\Engine-vehicle adjustment\COO7 (Coordinator)	√	√	√	√		√	
Scania\Divided By Vehicle\TRUCK\P-Serie\Engine 280\Truck DC 9 XPI EU5[---08>---13]\Four-wheel drive\AWD ALL-Wheel Drive	√	√	√				
Scania\Divided By Vehicle\TRUCK\P-Serie\Engine 280\Truck DC 9 XPI EU5[---08>---13]\Instrument panel\NCL Instrument Panel 1	√	√	√	√		√	
Scania\Divided By Vehicle\TRUCK\P-Serie\Engine 280\Truck DC 9 XPI EU5[---08>---13]\Instrument panel\NCL Instrument Panel 2	√	√	√	√		√	
Scania\Divided By Vehicle\TRUCK\P-Serie\Engine 280\Truck DC 9 XPI EU5[---08>---13]\Radio\AUS Audio system	√	√	√				
Scania\Divided By Vehicle\TRUCK\P-Serie\Engine 280\Truck DC 9 XPI EU5[---08>---13]\Retarder\RET Retarder	√	√	√	√		√	
Scania\Divided By Vehicle\TRUCK\P-Serie\Engine 280\Truck DC 9 XPI EU5[---08>---13]\Suspensions\SMS Supension management system	√	√	√	√			0006, 0007, 0014
Scania\Divided By Vehicle\TRUCK\P-Serie\Engine 280\Truck DC 9 XPI EU5[---08>---13]\Tachograph\DTCO Tachograph	√	√	√				
Scania\Divided By Vehicle\TRUCK\P-Serie\Engine 280\Truck DC 9 XPI EU5[---08>---13]\Tachograph\MTCO Tachograph	√	√	√				
Scania\Divided By Vehicle\TRUCK\P-Serie\Engine 280\Truck DC 9 XPI EU5[---08>---13]\Tire pressure\TPM - Tires Pressure Monitoring System	√	√	√				
Scania\Divided By Vehicle\TRUCK\P-Serie\Engine 280\Truck DC 9 XPI EU5[---08>---13]\Transmission\GMS - Gear management system A4	√	√	√			√	
Scania\Divided By Vehicle\TRUCK\P-Serie\Engine 280\Truck DC 9 XPI EU5[---08>---13]\Transmission\GMS - Gear management system OPC	√	√	√	√		√	0005
Scania\Divided By Vehicle\TRUCK\P-Serie\Engine 280\Truck DC 9 XPI EU5[---08>---13]\Transmission\GMS - Gear management system Opticruise 5	√	√	√	√		√	0009, 0011, 0018
Scania\Divided By Vehicle\TRUCK\P-Serie\Engine 280\Truck DC 9 XPI EU5[---08>---13]\Transmission\GMS - GMS Opticruise 5	√	√	√	√		√	0009, 0011, 0018
Scania\Divided By Vehicle\TRUCK\P-Serie\Engine 280\Truck DC 9 XPI EU5[---08>---13]\Transport information system\RTI - Road Transport Informatics	√	√	√				
Scania\Divided By Vehicle\TRUCK\P-Serie\Engine 310\Truck DC 9 [---04>---13]\ABS\BMS Brake management system-ABS E	√	√	√	√		√	
Scania\Divided By Vehicle\TRUCK\P-Serie\Engine 310\Truck DC 9 [---04>---13]\Aid for keeping lane\LDW Monitor traffic lane	√	√	√				
Scania\Divided By Vehicle\TRUCK\P-Serie\Engine 310\Truck DC 9 [---04>---13]\Air conditioner\CCS Climate control system	√	√	√	√		√	
Scania\Divided By Vehicle\TRUCK\P-Serie\Engine 310\Truck DC 9 [---04>---13]\Airbag\CSS Climate safety system	√	√	√				
Scania\Divided By Vehicle\TRUCK\P-Serie\Engine 310\Truck DC 9 [---04>---13]\Alarm\LAS Locking and alarm system	√	√	√				
Scania\Divided By Vehicle\TRUCK\P-Serie\Engine 310\Truck DC 9 [---04>---13]\Auxiliary heating\ATA Auxiliary heating system air-to-air	√	√	√	√			
Scania\Divided By Vehicle\TRUCK\P-Serie\Engine 310\Truck DC 9 [---04>---13]\Auxiliary heating\WTA Auxiliary heating system water-to-air	√	√	√				
Scania\Divided By Vehicle\TRUCK\P-Serie\Engine 310\Truck DC 9 [---04>---13]\Chassis equipment and design\BWS Preparation system	√	√	√				
Scania\Divided By Vehicle\TRUCK\P-Serie\Engine 310\Truck DC 9 [---04>---13]\Comfort system\CTS Clock and Time System	√	√	√				
Scania\Divided By Vehicle\TRUCK\P-Serie\Engine 310\Truck DC 9 [---04>---13]\Compressed air reserve system\APS Compressed air power supply(Scania protocol)	√	√	√	√			0003
Scania\Divided By Vehicle\TRUCK\P-Serie\Engine 310\Truck DC 9 [---04>---13]\Compressed air reserve system\APS Compressed air power supply(Wabco protocol)	√	√	√	√			
Scania\Divided By Vehicle\TRUCK\P-Serie\Engine 310\Truck DC 9 [---04>---13]\Diesel injection\EEC-Exhaust gas treatment	√	√	√	√		√	
Scania\Divided By Vehicle\TRUCK\P-Serie\Engine 310\Truck DC 9 [---04>---13]\Diesel injection\EMS Engine management system S6-S7	√	√	√	√		√	0002, 0015, 0017
Scania\Divided By Vehicle\TRUCK\P-Serie\Engine 310\Truck DC 9 [---04>---13]\Diesel injection\EMS Engine management system S8(8 Cylindes)	√	√	√	√		√	0001
Scania\Divided By Vehicle\TRUCK\P-Serie\Engine 310\Truck DC 9 [---04>---13]\Diesel injection\EMS Engine management system DC13(6 Cylindes)	√	√	√	√		√	
Scania\Divided By Vehicle\TRUCK\P-Serie\Engine 310\Truck DC 9 [---04>---13]\Distance control\DAS Adaptive Cruise Control	√	√	√				

Scania\Divided By Vehicle\TRUCK\P-Serie\Engine 310\Truck DC 9 [--04>---13]\Distance control\DIS Adaptive Cruise Control	√	√	√				
Scania\Divided By Vehicle\TRUCK\P-Serie\Engine 310\Truck DC 9 [--04>---13]\EBS\BMS Brake management system 5.0 (4x2)	√	√	√	√		√	0004
Scania\Divided By Vehicle\TRUCK\P-Serie\Engine 310\Truck DC 9 [--04>---13]\EBS\BMS Brake management system 5.0 (6x2 - 6x4)	√	√	√	√		√	0004
Scania\Divided By Vehicle\TRUCK\P-Serie\Engine 310\Truck DC 9 [--04>---13]\EBS\BMS Brake management system 5.0 (8x2)	√	√	√	√		√	0004
Scania\Divided By Vehicle\TRUCK\P-Serie\Engine 310\Truck DC 9 [--04>---13]\ECU external light\VIS Visibility system	√	√	√	√		√	
Scania\Divided By Vehicle\TRUCK\P-Serie\Engine 310\Truck DC 9 [--04>---13]\Engine-vehicle adjustment\COO Coordinator module	√	√	√	√		√	
Scania\Divided By Vehicle\TRUCK\P-Serie\Engine 310\Truck DC 9 [--04>---13]\Engine-vehicle adjustment\COO7 (Coordinator)	√	√	√	√		√	
Scania\Divided By Vehicle\TRUCK\P-Serie\Engine 310\Truck DC 9 [--04>---13]\Four-wheel drive\AWD ALL-Wheel Drive	√	√	√				
Scania\Divided By Vehicle\TRUCK\P-Serie\Engine 310\Truck DC 9 [--04>---13]\Instrument panel\ICL Instrument Panel 1	√	√	√	√		√	
Scania\Divided By Vehicle\TRUCK\P-Serie\Engine 310\Truck DC 9 [--04>---13]\Instrument panel\ICL Instrument Panel 2	√	√	√	√		√	
Scania\Divided By Vehicle\TRUCK\P-Serie\Engine 310\Truck DC 9 [--04>---13]\Radio\AUS Audio system	√	√	√				
Scania\Divided By Vehicle\TRUCK\P-Serie\Engine 310\Truck DC 9 [--04>---13]\Retarder\RET Retarder	√	√	√	√		√	
Scania\Divided By Vehicle\TRUCK\P-Serie\Engine 310\Truck DC 9 [--04>---13]\Suspensions\SMS Suspension management system	√	√	√	√			0006, 0007, 0014
Scania\Divided By Vehicle\TRUCK\P-Serie\Engine 310\Truck DC 9 [--04>---13]\Tachograph\DTCO Tachograph	√	√	√				
Scania\Divided By Vehicle\TRUCK\P-Serie\Engine 310\Truck DC 9 [--04>---13]\Tachograph\MTCO Tachograph	√	√	√				
Scania\Divided By Vehicle\TRUCK\P-Serie\Engine 310\Truck DC 9 [--04>---13]\Tire pressure\TPM - Tires Pressure Monitoring System	√	√	√				
Scania\Divided By Vehicle\TRUCK\P-Serie\Engine 310\Truck DC 9 [--04>---13]\Transmission\GMS - Gear management system A4	√	√	√			√	
Scania\Divided By Vehicle\TRUCK\P-Serie\Engine 310\Truck DC 9 [--04>---13]\Transmission\GMS - Gear management system OPC	√	√	√	√		√	0005
Scania\Divided By Vehicle\TRUCK\P-Serie\Engine 310\Truck DC 9 [--04>---13]\Transmission\GMS - Gear management system Opticruise 5	√	√	√	√		√	0009, 0011, 0018
Scania\Divided By Vehicle\TRUCK\P-Serie\Engine 310\Truck DC 9 [--04>---13]\Transmission\GMS - GMS Opticruise 5	√	√	√	√		√	0009, 0011, 0018
Scania\Divided By Vehicle\TRUCK\P-Serie\Engine 310\Truck DC 9 [--04>---13]\Transport information system\RTI - Road Transport Informatics	√	√	√				
Scania\Divided By Vehicle\TRUCK\P-Serie\Engine 320\Truck DC 9 XPI EU5[---08>---13]\ABS\BMS Brake management system-ABS E	√	√	√	√		√	
Scania\Divided By Vehicle\TRUCK\P-Serie\Engine 320\Truck DC 9 XPI EU5[---08>---13]\Aid for keeping lane\LDW Monitor traffic lane	√	√	√				
Scania\Divided By Vehicle\TRUCK\P-Serie\Engine 320\Truck DC 9 XPI EU5[---08>---13]\Air conditioner\CCS Climate control system	√	√	√	√		√	
Scania\Divided By Vehicle\TRUCK\P-Serie\Engine 320\Truck DC 9 XPI EU5[---08>---13]\Airbag\CSS Climate safety system	√	√	√				
Scania\Divided By Vehicle\TRUCK\P-Serie\Engine 320\Truck DC 9 XPI EU5[---08>---13]\Alarm\LAS Locking and alarm system	√	√	√				
Scania\Divided By Vehicle\TRUCK\P-Serie\Engine 320\Truck DC 9 XPI EU5[---08>---13]\Auxiliary heating\ATA Auxiliary heating system air-to-air	√	√	√	√			
Scania\Divided By Vehicle\TRUCK\P-Serie\Engine 320\Truck DC 9 XPI EU5[---08>---13]\Auxiliary heating\WTA Auxiliary heating system water-to-air	√	√	√				
Scania\Divided By Vehicle\TRUCK\P-Serie\Engine 320\Truck DC 9 XPI EU5[---08>---13]\Chassis equipment and design\BWS Preparation system	√	√	√				
Scania\Divided By Vehicle\TRUCK\P-Serie\Engine 320\Truck DC 9 XPI EU5[---08>---13]\Comfort system\CTS Clock and Time System	√	√	√				
Scania\Divided By Vehicle\TRUCK\P-Serie\Engine 320\Truck DC 9 XPI EU5[---08>---13]\Compressed air reserve system\APS Compressed air power supply(Scania protocol)	√	√	√	√			0003
Scania\Divided By Vehicle\TRUCK\P-Serie\Engine 320\Truck DC 9 XPI EU5[---08>---13]\Compressed air reserve system\APS Compressed air power supply(Wabco protocol)	√	√	√	√			
Scania\Divided By Vehicle\TRUCK\P-Serie\Engine 320\Truck DC 9 XPI EU5[---08>---13]\Diesel injection\EEC-Exhaust gas treatment	√	√	√	√		√	
Scania\Divided By Vehicle\TRUCK\P-Serie\Engine 320\Truck DC 9 XPI EU5[---08>---13]\Diesel injection\EMS Engine management system S6-S7	√	√	√	√		√	0002, 0015, 0017
Scania\Divided By Vehicle\TRUCK\P-Serie\Engine 320\Truck DC 9 XPI EU5[---08>---13]\Diesel injection\EMS Engine management system S8(8 Cylindes)	√	√	√	√		√	0001

Scania\Divided By Vehicle\TRUCK\P-Serie\Engine 320\Truck DC 9 XPI EU5[---08>---13]\Diesel injection\EMS Engine management system DC13(6 Cylindres)	√	√	√	√		√	
Scania\Divided By Vehicle\TRUCK\P-Serie\Engine 320\Truck DC 9 XPI EU5[---08>---13]\Distance control\DAS Adaptive Cruise Control	√	√	√				
Scania\Divided By Vehicle\TRUCK\P-Serie\Engine 320\Truck DC 9 XPI EU5[---08>---13]\Distance control\DIS Adaptive Cruise Control	√	√	√				
Scania\Divided By Vehicle\TRUCK\P-Serie\Engine 320\Truck DC 9 XPI EU5[---08>---13]\EBS\BMS Brake management system 5.0 (4x2)	√	√	√	√		√	0004
Scania\Divided By Vehicle\TRUCK\P-Serie\Engine 320\Truck DC 9 XPI EU5[---08>---13]\EBS\BMS Brake management system 5.0 (6x2 - 6x4)	√	√	√	√		√	0004
Scania\Divided By Vehicle\TRUCK\P-Serie\Engine 320\Truck DC 9 XPI EU5[---08>---13]\EBS\BMS Brake management system 5.0 (8x2)	√	√	√	√		√	0004
Scania\Divided By Vehicle\TRUCK\P-Serie\Engine 320\Truck DC 9 XPI EU5[---08>---13]\ECU external light\VIS Visibility system	√	√	√	√		√	
Scania\Divided By Vehicle\TRUCK\P-Serie\Engine 320\Truck DC 9 XPI EU5[---08>---13]\Engine-vehicle adjustment\COO Coordinator module	√	√	√	√		√	
Scania\Divided By Vehicle\TRUCK\P-Serie\Engine 320\Truck DC 9 XPI EU5[---08>---13]\Engine-vehicle adjustment\COO7 (Coordinator)	√	√	√	√		√	
Scania\Divided By Vehicle\TRUCK\P-Serie\Engine 320\Truck DC 9 XPI EU5[---08>---13]\Four-wheel drive\AWD ALL-Wheel Drive	√	√	√				
Scania\Divided By Vehicle\TRUCK\P-Serie\Engine 320\Truck DC 9 XPI EU5[---08>---13]\Instrument panel\NCL Instrument Panel 1	√	√	√	√		√	
Scania\Divided By Vehicle\TRUCK\P-Serie\Engine 320\Truck DC 9 XPI EU5[---08>---13]\Instrument panel\NCL Instrument Panel 2	√	√	√	√		√	
Scania\Divided By Vehicle\TRUCK\P-Serie\Engine 320\Truck DC 9 XPI EU5[---08>---13]\Radio\AUS Audio system	√	√	√				
Scania\Divided By Vehicle\TRUCK\P-Serie\Engine 320\Truck DC 9 XPI EU5[---08>---13]\Retarder\RET Retarder	√	√	√	√		√	
Scania\Divided By Vehicle\TRUCK\P-Serie\Engine 320\Truck DC 9 XPI EU5[---08>---13]\Suspensions\SMS Supension management system	√	√	√	√			0006, 0007, 0014
Scania\Divided By Vehicle\TRUCK\P-Serie\Engine 320\Truck DC 9 XPI EU5[---08>---13]\Tachograph\DTCO Tachograph	√	√	√				
Scania\Divided By Vehicle\TRUCK\P-Serie\Engine 320\Truck DC 9 XPI EU5[---08>---13]\Tachograph\MTCO Tachograph	√	√	√				
Scania\Divided By Vehicle\TRUCK\P-Serie\Engine 320\Truck DC 9 XPI EU5[---08>---13]\Tire pressure\TPM - Tires Pressure Monitoring System	√	√	√				
Scania\Divided By Vehicle\TRUCK\P-Serie\Engine 320\Truck DC 9 XPI EU5[---08>---13]\Transmission\GMS - Gear management system A4	√	√	√			√	
Scania\Divided By Vehicle\TRUCK\P-Serie\Engine 320\Truck DC 9 XPI EU5[---08>---13]\Transmission\GMS - Gear management system OPC	√	√	√	√		√	0005
Scania\Divided By Vehicle\TRUCK\P-Serie\Engine 320\Truck DC 9 XPI EU5[---08>---13]\Transmission\GMS - Gear management system Opticruise 5	√	√	√	√		√	0009, 0011, 0018
Scania\Divided By Vehicle\TRUCK\P-Serie\Engine 320\Truck DC 9 XPI EU5[---08>---13]\Transmission\GMS - GMS Opticruise 5	√	√	√	√		√	0009, 0011, 0018
Scania\Divided By Vehicle\TRUCK\P-Serie\Engine 320\Truck DC 9 XPI EU5[---08>---13]\Transport information system\RTI - Road Transport Informatics	√	√	√				
Scania\Divided By Vehicle\TRUCK\P-Serie\Engine 340\Truck DC 12 HPI [---05>---13]\ABS\BMS Brake management system-ABS E	√	√	√	√		√	
Scania\Divided By Vehicle\TRUCK\P-Serie\Engine 340\Truck DC 12 HPI [---05>---13]\Aid for keeping lane\LDW Monitor traffic lane	√	√	√				
Scania\Divided By Vehicle\TRUCK\P-Serie\Engine 340\Truck DC 12 HPI [---05>---13]\Air conditioner\CCS Climate control system	√	√	√	√		√	
Scania\Divided By Vehicle\TRUCK\P-Serie\Engine 340\Truck DC 12 HPI [---05>---13]\Airbag\CSS Climate safety system	√	√	√				
Scania\Divided By Vehicle\TRUCK\P-Serie\Engine 340\Truck DC 12 HPI [---05>---13]\Alarm\LAS Locking and alarm system	√	√	√				
Scania\Divided By Vehicle\TRUCK\P-Serie\Engine 340\Truck DC 12 HPI [---05>---13]\Auxiliary heating\ATA Auxiliary heating system air-to-air	√	√	√	√			
Scania\Divided By Vehicle\TRUCK\P-Serie\Engine 340\Truck DC 12 HPI [---05>---13]\Auxiliary heating\WTA Auxiliary heating system water-to-air	√	√	√				
Scania\Divided By Vehicle\TRUCK\P-Serie\Engine 340\Truck DC 12 HPI [---05>---13]\Chassis equipment and design\BWS Preparation system	√	√	√				
Scania\Divided By Vehicle\TRUCK\P-Serie\Engine 340\Truck DC 12 HPI [---05>---13]\Comfort system\CTS Clock and Time System	√	√	√				
Scania\Divided By Vehicle\TRUCK\P-Serie\Engine 340\Truck DC 12 HPI [---05>---13]\Compressed air reserve system\APS Compressed air power supply(Scania protocol)	√	√	√	√			0003
Scania\Divided By Vehicle\TRUCK\P-Serie\Engine 340\Truck DC 12 HPI [---05>---13]\Compressed air reserve system\APS Compressed air power supply(Wabco protocol)	√	√	√	√			
Scania\Divided By Vehicle\TRUCK\P-Serie\Engine 340\Truck DC 12 HPI [---05>---13]\Diesel injection\EEC-Exhaust gas treatment	√	√	√	√		√	

Scania\Divided By Vehicle\TRUCK\P-Serie\Engine 340\Truck DC 12 HPI [--05>---13]\Diesel injection\EMS Engine management system S6-S7	√	√	√	√		√	0002, 0015, 0017
Scania\Divided By Vehicle\TRUCK\P-Serie\Engine 340\Truck DC 12 HPI [--05>---13]\Diesel injection\EMS Engine management system S8(8 Cylindes)	√	√	√	√		√	0001
Scania\Divided By Vehicle\TRUCK\P-Serie\Engine 340\Truck DC 12 HPI [--05>---13]\Diesel injection\EMS Engine management system DC13(6 Cylindes)	√	√	√	√		√	
Scania\Divided By Vehicle\TRUCK\P-Serie\Engine 340\Truck DC 12 HPI [--05>---13]\Distance control\DAS Adaptive Cruise Control	√	√	√				
Scania\Divided By Vehicle\TRUCK\P-Serie\Engine 340\Truck DC 12 HPI [--05>---13]\Distance control\DIS Adaptive Cruise Control	√	√	√				
Scania\Divided By Vehicle\TRUCK\P-Serie\Engine 340\Truck DC 12 HPI [--05>---13]\EBS\BMS Brake management system 5.0 (4x2)	√	√	√	√		√	0004
Scania\Divided By Vehicle\TRUCK\P-Serie\Engine 340\Truck DC 12 HPI [--05>---13]\EBS\BMS Brake management system 5.0 (6x2 - 6x4)	√	√	√	√		√	0004
Scania\Divided By Vehicle\TRUCK\P-Serie\Engine 340\Truck DC 12 HPI [--05>---13]\EBS\BMS Brake management system 5.0 (8x2)	√	√	√	√		√	0004
Scania\Divided By Vehicle\TRUCK\P-Serie\Engine 340\Truck DC 12 HPI [--05>---13]\ECU external light\VIS Visibility system	√	√	√	√		√	
Scania\Divided By Vehicle\TRUCK\P-Serie\Engine 340\Truck DC 12 HPI [--05>---13]\Engine-vehicle adjustment\COO Coordinator module	√	√	√	√		√	
Scania\Divided By Vehicle\TRUCK\P-Serie\Engine 340\Truck DC 12 HPI [--05>---13]\Engine-vehicle adjustment\COO7 (Coordinator)	√	√	√	√		√	
Scania\Divided By Vehicle\TRUCK\P-Serie\Engine 340\Truck DC 12 HPI [--05>---13]\Four-wheel drive\AWD ALL-Wheel Drive	√	√	√				
Scania\Divided By Vehicle\TRUCK\P-Serie\Engine 340\Truck DC 12 HPI [--05>---13]\Instrument panel\NCL Instrument Panel 1	√	√	√	√		√	
Scania\Divided By Vehicle\TRUCK\P-Serie\Engine 340\Truck DC 12 HPI [--05>---13]\Instrument pane\NCL Instrument Panel 2	√	√	√	√		√	
Scania\Divided By Vehicle\TRUCK\P-Serie\Engine 340\Truck DC 12 HPI [--05>---13]\Radio\AUS Audio system	√	√	√				
Scania\Divided By Vehicle\TRUCK\P-Serie\Engine 340\Truck DC 12 HPI [--05>---13]\Retarder\RET Retarder	√	√	√	√		√	
Scania\Divided By Vehicle\TRUCK\P-Serie\Engine 340\Truck DC 12 HPI [--05>---13]\Suspensions\SMS Supension management system	√	√	√	√			0006, 0007, 0014
Scania\Divided By Vehicle\TRUCK\P-Serie\Engine 340\Truck DC 12 HPI [--05>---13]\Tachograph\DTCO Tachograph	√	√	√				
Scania\Divided By Vehicle\TRUCK\P-Serie\Engine 340\Truck DC 12 HPI [--05>---13]\Tachograph\MTCO Tachograph	√	√	√				
Scania\Divided By Vehicle\TRUCK\P-Serie\Engine 340\Truck DC 12 HPI [--05>---13]\Tire pressure\TPM - Tires Pressure Monitoring System	√	√	√				
Scania\Divided By Vehicle\TRUCK\P-Serie\Engine 340\Truck DC 12 HPI [--05>---13]\Transmission\GMS - Gear management system A4	√	√	√			√	
Scania\Divided By Vehicle\TRUCK\P-Serie\Engine 340\Truck DC 12 HPI [--05>---13]\Transmission\GMS - Gear management system OPC	√	√	√	√		√	0005
Scania\Divided By Vehicle\TRUCK\P-Serie\Engine 340\Truck DC 12 HPI [--05>---13]\Transmission\GMS - Gear management system Opticruise 5	√	√	√	√		√	0009, 0011, 0018
Scania\Divided By Vehicle\TRUCK\P-Serie\Engine 340\Truck DC 12 HPI [--05>---13]\Transmission\GMS - GMS Opticruise 5	√	√	√	√		√	0009, 0011, 0018
Scania\Divided By Vehicle\TRUCK\P-Serie\Engine 340\Truck DC 12 HPI [--05>---13]\Transport information system\RTI - Road Transport Informatics	√	√	√				
Scania\Divided By Vehicle\TRUCK\P-Serie\Engine 360\Truck DC 13 XPI EU5[---08>---13]\ABS\BMS Brake management system-ABS E	√	√	√	√		√	
Scania\Divided By Vehicle\TRUCK\P-Serie\Engine 360\Truck DC 13 XPI EU5[---08>---13]\Aid for keeping lane\LDW Monitor traffic lane	√	√	√				
Scania\Divided By Vehicle\TRUCK\P-Serie\Engine 360\Truck DC 13 XPI EU5[---08>---13]\Air conditioner\CCS Climate control system	√	√	√	√		√	
Scania\Divided By Vehicle\TRUCK\P-Serie\Engine 360\Truck DC 13 XPI EU5[---08>---13]\Airbag\CSS Climate safety system	√	√	√				
Scania\Divided By Vehicle\TRUCK\P-Serie\Engine 360\Truck DC 13 XPI EU5[---08>---13]\Alarm\LAS Locking and alarm system	√	√	√				
Scania\Divided By Vehicle\TRUCK\P-Serie\Engine 360\Truck DC 13 XPI EU5[---08>---13]\Auxiliary heating\ATA Auxiliary heating system air-to-air	√	√	√	√			
Scania\Divided By Vehicle\TRUCK\P-Serie\Engine 360\Truck DC 13 XPI EU5[---08>---13]\Auxiliary heating\WTA Auxiliary heating system water-to-air	√	√	√				
Scania\Divided By Vehicle\TRUCK\P-Serie\Engine 360\Truck DC 13 XPI EU5[---08>---13]\Chassis equipment and design\BWS Preparation system	√	√	√				
Scania\Divided By Vehicle\TRUCK\P-Serie\Engine 360\Truck DC 13 XPI EU5[---08>---13]\Comfort system\CTS Clock and Time System	√	√	√				
Scania\Divided By Vehicle\TRUCK\P-Serie\Engine 360\Truck DC 13 XPI EU5[---08>---13]\Compressed air reserve system\APS Compressed air power supply(Scania protocol)	√	√	√	√			0003

Scania\Divided By Vehicle\TRUCK\P-Serie\Engine 360\Truck DC 13 XPI EU5[---08>---13]\Compressed air reserve system\APS Compressed air power supply(Wabco protocol)	√	√	√	√			
Scania\Divided By Vehicle\TRUCK\P-Serie\Engine 360\Truck DC 13 XPI EU5[---08>---13]\Diesel injection\EEC-Exhaust gas treatment	√	√	√	√		√	
Scania\Divided By Vehicle\TRUCK\P-Serie\Engine 360\Truck DC 13 XPI EU5[---08>---13]\Diesel injection\EMS Engine management system S6-S7	√	√	√	√		√	0002, 0015, 0017
Scania\Divided By Vehicle\TRUCK\P-Serie\Engine 360\Truck DC 13 XPI EU5[---08>---13]\Diesel injection\EMS Engine management system S8(8 Cylindes)	√	√	√	√		√	0001
Scania\Divided By Vehicle\TRUCK\P-Serie\Engine 360\Truck DC 13 XPI EU5[---08>---13]\Diesel injection\EMS Engine management system DC13(6 Cylindes)	√	√	√	√		√	
Scania\Divided By Vehicle\TRUCK\P-Serie\Engine 360\Truck DC 13 XPI EU5[---08>---13]\Distance control\DAS Adaptive Cruise Control	√	√	√				
Scania\Divided By Vehicle\TRUCK\P-Serie\Engine 360\Truck DC 13 XPI EU5[---08>---13]\Distance control\DIS Adaptive Cruise Control	√	√	√				
Scania\Divided By Vehicle\TRUCK\P-Serie\Engine 360\Truck DC 13 XPI EU5[---08>---13]\EBS\BMS Brake management system 5.0 (4x2)	√	√	√	√		√	0004
Scania\Divided By Vehicle\TRUCK\P-Serie\Engine 360\Truck DC 13 XPI EU5[---08>---13]\EBS\BMS Brake management system 5.0 (6x2 - 6x4)	√	√	√	√		√	0004
Scania\Divided By Vehicle\TRUCK\P-Serie\Engine 360\Truck DC 13 XPI EU5[---08>---13]\EBS\BMS Brake management system 5.0 (8x2)	√	√	√	√		√	0004
Scania\Divided By Vehicle\TRUCK\P-Serie\Engine 360\Truck DC 13 XPI EU5[---08>---13]\ECU external light\VIS Visibility system	√	√	√	√		√	
Scania\Divided By Vehicle\TRUCK\P-Serie\Engine 360\Truck DC 13 XPI EU5[---08>---13]\Engine-vehicle adjustment\COO Coordinator module	√	√	√	√		√	
Scania\Divided By Vehicle\TRUCK\P-Serie\Engine 360\Truck DC 13 XPI EU5[---08>---13]\Engine-vehicle adjustment\COO7 (Coordinator)	√	√	√	√		√	
Scania\Divided By Vehicle\TRUCK\P-Serie\Engine 360\Truck DC 13 XPI EU5[---08>---13]\Four-wheel drive\AWD ALL-Wheel Drive	√	√	√				
Scania\Divided By Vehicle\TRUCK\P-Serie\Engine 360\Truck DC 13 XPI EU5[---08>---13]\Instrument panel\ICL Instrument Panel 1	√	√	√	√		√	
Scania\Divided By Vehicle\TRUCK\P-Serie\Engine 360\Truck DC 13 XPI EU5[---08>---13]\Instrument panel\ICL Instrument Panel 2	√	√	√	√		√	
Scania\Divided By Vehicle\TRUCK\P-Serie\Engine 360\Truck DC 13 XPI EU5[---08>---13]\Radio\AUS Audio system	√	√	√				
Scania\Divided By Vehicle\TRUCK\P-Serie\Engine 360\Truck DC 13 XPI EU5[---08>---13]\Retarder\RET Retarder	√	√	√	√		√	
Scania\Divided By Vehicle\TRUCK\P-Serie\Engine 360\Truck DC 13 XPI EU5[---08>---13]\Suspensions\SMS Suspension management system	√	√	√	√			0006, 0007, 0014
Scania\Divided By Vehicle\TRUCK\P-Serie\Engine 360\Truck DC 13 XPI EU5[---08>---13]\Tachograph\DTCO Tachograph	√	√	√				
Scania\Divided By Vehicle\TRUCK\P-Serie\Engine 360\Truck DC 13 XPI EU5[---08>---13]\Tachograph\MTCO Tachograph	√	√	√				
Scania\Divided By Vehicle\TRUCK\P-Serie\Engine 360\Truck DC 13 XPI EU5[---08>---13]\Tire pressure\TPM - Tires Pressure Monitoring System	√	√	√				
Scania\Divided By Vehicle\TRUCK\P-Serie\Engine 360\Truck DC 13 XPI EU5[---08>---13]\Transmission\GMS - Gear management system A4	√	√	√			√	
Scania\Divided By Vehicle\TRUCK\P-Serie\Engine 360\Truck DC 13 XPI EU5[---08>---13]\Transmission\GMS - Gear management system OPC	√	√	√	√		√	0005
Scania\Divided By Vehicle\TRUCK\P-Serie\Engine 360\Truck DC 13 XPI EU5[---08>---13]\Transmission\GMS - Gear management system Opticruise 5	√	√	√	√		√	0009, 0011, 0018
Scania\Divided By Vehicle\TRUCK\P-Serie\Engine 360\Truck DC 13 XPI EU5[---08>---13]\Transmission\GMS - GMS Opticruise 5	√	√	√	√		√	0009, 0011, 0018
Scania\Divided By Vehicle\TRUCK\P-Serie\Engine 360\Truck DC 13 XPI EU5[---08>---13]\Transport information system\RTI - Road Transport Informatics	√	√	√				
Scania\Divided By Vehicle\TRUCK\P-Serie\Engine 380\Truck DC 12 HPI EU5[---08>---13]\ABS\BMS Brake management system-ABS E	√	√	√	√		√	
Scania\Divided By Vehicle\TRUCK\P-Serie\Engine 380\Truck DC 12 HPI EU5[---08>---13]\Aid for keeping lane\LDW Monitor traffic lane	√	√	√				
Scania\Divided By Vehicle\TRUCK\P-Serie\Engine 380\Truck DC 12 HPI EU5[---08>---13]\Air conditioner\CCS Climate control system	√	√	√	√		√	
Scania\Divided By Vehicle\TRUCK\P-Serie\Engine 380\Truck DC 12 HPI EU5[---08>---13]\Airbag\CSS Climate safety system	√	√	√				
Scania\Divided By Vehicle\TRUCK\P-Serie\Engine 380\Truck DC 12 HPI EU5[---08>---13]\Alarm\LAS Locking and alarm system	√	√	√				
Scania\Divided By Vehicle\TRUCK\P-Serie\Engine 380\Truck DC 12 HPI EU5[---08>---13]\Auxiliary heating\ATA Auxiliary heating system air-to-air	√	√	√	√			
Scania\Divided By Vehicle\TRUCK\P-Serie\Engine 380\Truck DC 12 HPI EU5[---08>---13]\Auxiliary heating\WTA Auxiliary heating system water-to-air	√	√	√				
Scania\Divided By Vehicle\TRUCK\P-Serie\Engine 380\Truck DC 12 HPI EU5[---08>---13]\Chassis equipment and design\BWS Preparation system	√	√	√				

Scania\Divided By Vehicle\TRUCK\P-Serie\Engine 380\Truck DC 12 HPI EU5[---08>---13]\Comfort system\CTS Clock and Time System	√	√	√				
Scania\Divided By Vehicle\TRUCK\P-Serie\Engine 380\Truck DC 12 HPI EU5[---08>---13]\Compressed air reserve system\APS Compressed air power supply(Scania protocol)	√	√	√	√			0003
Scania\Divided By Vehicle\TRUCK\P-Serie\Engine 380\Truck DC 12 HPI EU5[---08>---13]\Compressed air reserve system\APS Compressed air power supply(Wabco protocol)	√	√	√	√			
Scania\Divided By Vehicle\TRUCK\P-Serie\Engine 380\Truck DC 12 HPI EU5[---08>---13]\Diesel injection\EEC-Exhaust gas treatment	√	√	√	√		√	
Scania\Divided By Vehicle\TRUCK\P-Serie\Engine 380\Truck DC 12 HPI EU5[---08>---13]\Diesel injection\EMS Engine management system S6-S7	√	√	√	√		√	0002, 0015, 0017
Scania\Divided By Vehicle\TRUCK\P-Serie\Engine 380\Truck DC 12 HPI EU5[---08>---13]\Diesel injection\EMS Engine management system S8(8 Cylindes)	√	√	√	√		√	0001
Scania\Divided By Vehicle\TRUCK\P-Serie\Engine 380\Truck DC 12 HPI EU5[---08>---13]\Diesel injection\EMS Engine management system DC13(6 Cylindes)	√	√	√	√		√	
Scania\Divided By Vehicle\TRUCK\P-Serie\Engine 380\Truck DC 12 HPI EU5[---08>---13]\Distance control\DAS Adaptive Cruise Control	√	√	√				
Scania\Divided By Vehicle\TRUCK\P-Serie\Engine 380\Truck DC 12 HPI EU5[---08>---13]\Distance control\DIS Adaptive Cruise Control	√	√	√				
Scania\Divided By Vehicle\TRUCK\P-Serie\Engine 380\Truck DC 12 HPI EU5[---08>---13]\EBS\BMS Brake management system 5.0 (4x2)	√	√	√	√		√	0004
Scania\Divided By Vehicle\TRUCK\P-Serie\Engine 380\Truck DC 12 HPI EU5[---08>---13]\EBS\BMS Brake management system 5.0 (6x2 - 6x4)	√	√	√	√		√	0004
Scania\Divided By Vehicle\TRUCK\P-Serie\Engine 380\Truck DC 12 HPI EU5[---08>---13]\EBS\BMS Brake management system 5.0 (8x2)	√	√	√	√		√	0004
Scania\Divided By Vehicle\TRUCK\P-Serie\Engine 380\Truck DC 12 HPI EU5[---08>---13]\ECU external light\VIS Visibility system	√	√	√	√		√	
Scania\Divided By Vehicle\TRUCK\P-Serie\Engine 380\Truck DC 12 HPI EU5[---08>---13]\Engine-vehicle adjustment\COO Coordinator module	√	√	√	√		√	
Scania\Divided By Vehicle\TRUCK\P-Serie\Engine 380\Truck DC 12 HPI EU5[---08>---13]\Engine-vehicle adjustment\COO7 (Coordinator)	√	√	√	√		√	
Scania\Divided By Vehicle\TRUCK\P-Serie\Engine 380\Truck DC 12 HPI EU5[---08>---13]\Four-wheel drive\AWD ALL-Wheel Drive	√	√	√				
Scania\Divided By Vehicle\TRUCK\P-Serie\Engine 380\Truck DC 12 HPI EU5[---08>---13]\Instrument panel\NCL Instrument Panel 1	√	√	√	√		√	
Scania\Divided By Vehicle\TRUCK\P-Serie\Engine 380\Truck DC 12 HPI EU5[---08>---13]\Instrument panel\NCL Instrument Panel 2	√	√	√	√		√	
Scania\Divided By Vehicle\TRUCK\P-Serie\Engine 380\Truck DC 12 HPI EU5[---08>---13]\Radio\AUS Audio system	√	√	√				
Scania\Divided By Vehicle\TRUCK\P-Serie\Engine 380\Truck DC 12 HPI EU5[---08>---13]\Retarder\RET Retarder	√	√	√	√		√	
Scania\Divided By Vehicle\TRUCK\P-Serie\Engine 380\Truck DC 12 HPI EU5[---08>---13]\Suspensions\SMS Supension management system	√	√	√	√			0006, 0007, 0014
Scania\Divided By Vehicle\TRUCK\P-Serie\Engine 380\Truck DC 12 HPI EU5[---08>---13]\Tachograph\DTCO Tachograph	√	√	√				
Scania\Divided By Vehicle\TRUCK\P-Serie\Engine 380\Truck DC 12 HPI EU5[---08>---13]\Tachograph\MTCO Tachograph	√	√	√				
Scania\Divided By Vehicle\TRUCK\P-Serie\Engine 380\Truck DC 12 HPI EU5[---08>---13]\Tire pressure\TPM - Tires Pressure Monitoring System	√	√	√				
Scania\Divided By Vehicle\TRUCK\P-Serie\Engine 380\Truck DC 12 HPI EU5[---08>---13]\Transmission\GMS - Gear management system A4	√	√	√			√	
Scania\Divided By Vehicle\TRUCK\P-Serie\Engine 380\Truck DC 12 HPI EU5[---08>---13]\Transmission\GMS - Gear management system OPC	√	√	√	√		√	0005
Scania\Divided By Vehicle\TRUCK\P-Serie\Engine 380\Truck DC 12 HPI EU5[---08>---13]\Transmission\GMS - Gear management system Opticruise 5	√	√	√	√		√	0009, 0011, 0018
Scania\Divided By Vehicle\TRUCK\P-Serie\Engine 380\Truck DC 12 HPI EU5[---08>---13]\Transmission\GMS - GMS Opticruise 5	√	√	√	√		√	0009, 0011, 0018
Scania\Divided By Vehicle\TRUCK\P-Serie\Engine 380\Truck DC 12 HPI EU5[---08>---13]\Transport information system\RTI - Road Transport Informatics	√	√	√				
Scania\Divided By Vehicle\TRUCK\P-Serie\Engine 380\Truck DC 12 HPI [---04>---08]\ABS\BMS Brake management system-ABS E	√	√	√	√		√	
Scania\Divided By Vehicle\TRUCK\P-Serie\Engine 380\Truck DC 12 HPI [---04>---08]\Aid for keeping lane\LDW Monitor traffic lane	√	√	√				
Scania\Divided By Vehicle\TRUCK\P-Serie\Engine 380\Truck DC 12 HPI [---04>---08]\Air conditioner\CCS Climate control system	√	√	√	√		√	
Scania\Divided By Vehicle\TRUCK\P-Serie\Engine 380\Truck DC 12 HPI [---04>---08]\Airbag\CSS Climate safety system	√	√	√				
Scania\Divided By Vehicle\TRUCK\P-Serie\Engine 380\Truck DC 12 HPI [---04>---08]\Alarm\LAS Locking and alarm system	√	√	√				
Scania\Divided By Vehicle\TRUCK\P-Serie\Engine 380\Truck DC 12 HPI [---04>---08]\Auxiliary heating\ATA Auxiliary heating system air-to-air	√	√	√	√			

Scania\Divided By Vehicle\TRUCK\I-Series\Engine 380\Truck DC 12 HPI [--04>----08]\Auxiliary heating\WTA Auxiliary heating system water-to-air	√	√	√				
Scania\Divided By Vehicle\TRUCK\I-Series\Engine 380\Truck DC 12 HPI [--04>----08]\Chassis equipment and design\BWS Preparation system	√	√	√				
Scania\Divided By Vehicle\TRUCK\I-Series\Engine 380\Truck DC 12 HPI [--04>----08]\Comfort system\CTS Clock and Time System	√	√	√				
Scania\Divided By Vehicle\TRUCK\I-Series\Engine 380\Truck DC 12 HPI [--04>----08]\Compressed air reserve system\APS Compressed air power supply(Scania protocol)	√	√	√	√			0003
Scania\Divided By Vehicle\TRUCK\I-Series\Engine 380\Truck DC 12 HPI [--04>----08]\Compressed air reserve system\APS Compressed air power supply(Wabco protocol)	√	√	√	√			
Scania\Divided By Vehicle\TRUCK\I-Series\Engine 380\Truck DC 12 HPI [--04>----08]\Diesel injection\EEC-Exhaust gas treatment	√	√	√	√		√	
Scania\Divided By Vehicle\TRUCK\I-Series\Engine 380\Truck DC 12 HPI [--04>----08]\Diesel injection\EMS Engine management system S6-S7	√	√	√	√		√	0002, 0015, 0017
Scania\Divided By Vehicle\TRUCK\I-Series\Engine 380\Truck DC 12 HPI [--04>----08]\Diesel injection\EMS Engine management system S8(8 Cylindres)	√	√	√	√		√	0001
Scania\Divided By Vehicle\TRUCK\I-Series\Engine 380\Truck DC 12 HPI [--04>----08]\Diesel injection\EMS Engine management system DC13(6 Cylindres)	√	√	√	√		√	
Scania\Divided By Vehicle\TRUCK\I-Series\Engine 380\Truck DC 12 HPI [--04>----08]\Distance control\DAS Adaptive Cruise Control	√	√	√				
Scania\Divided By Vehicle\TRUCK\I-Series\Engine 380\Truck DC 12 HPI [--04>----08]\Distance control\DIS Adaptive Cruise Control	√	√	√				
Scania\Divided By Vehicle\TRUCK\I-Series\Engine 380\Truck DC 12 HPI [--04>----08]\EBS\BMS Brake management system 5.0 (4x2)	√	√	√	√		√	0004
Scania\Divided By Vehicle\TRUCK\I-Series\Engine 380\Truck DC 12 HPI [--04>----08]\EBS\BMS Brake management system 5.0 (6x2 - 6x4)	√	√	√	√		√	0004
Scania\Divided By Vehicle\TRUCK\I-Series\Engine 380\Truck DC 12 HPI [--04>----08]\EBS\BMS Brake management system 5.0 (8x2)	√	√	√	√		√	0004
Scania\Divided By Vehicle\TRUCK\I-Series\Engine 380\Truck DC 12 HPI [--04>----08]\ECU external light\VIS Visibility system	√	√	√	√		√	
Scania\Divided By Vehicle\TRUCK\I-Series\Engine 380\Truck DC 12 HPI [--04>----08]\Engine-vehicle adjustment\COO Coordinator module	√	√	√	√		√	
Scania\Divided By Vehicle\TRUCK\I-Series\Engine 380\Truck DC 12 HPI [--04>----08]\Engine-vehicle adjustment\COO7 (Coordinator)	√	√	√	√		√	
Scania\Divided By Vehicle\TRUCK\I-Series\Engine 380\Truck DC 12 HPI [--04>----08]\Four-wheel drive\AWD ALL-Wheel Drive	√	√	√				
Scania\Divided By Vehicle\TRUCK\I-Series\Engine 380\Truck DC 12 HPI [--04>----08]\Instrument panel\NCL Instrument Panel 1	√	√	√	√		√	
Scania\Divided By Vehicle\TRUCK\I-Series\Engine 380\Truck DC 12 HPI [--04>----08]\Instrument panel\NCL Instrument Panel 2	√	√	√	√		√	
Scania\Divided By Vehicle\TRUCK\I-Series\Engine 380\Truck DC 12 HPI [--04>----08]\Radio\AUS Audio system	√	√	√				
Scania\Divided By Vehicle\TRUCK\I-Series\Engine 380\Truck DC 12 HPI [--04>----08]\Retarder\RET Retarder	√	√	√	√		√	
Scania\Divided By Vehicle\TRUCK\I-Series\Engine 380\Truck DC 12 HPI [--04>----08]\Suspensions\SMS Suspension management system	√	√	√	√			0006, 0007, 0014
Scania\Divided By Vehicle\TRUCK\I-Series\Engine 380\Truck DC 12 HPI [--04>----08]\Tachograph\DTCO Tachograph	√	√	√				
Scania\Divided By Vehicle\TRUCK\I-Series\Engine 380\Truck DC 12 HPI [--04>----08]\Tachograph\MTCO Tachograph	√	√	√				
Scania\Divided By Vehicle\TRUCK\I-Series\Engine 380\Truck DC 12 HPI [--04>----08]\Tire pressure\TPM - Tires Pressure Monitoring System	√	√	√				
Scania\Divided By Vehicle\TRUCK\I-Series\Engine 380\Truck DC 12 HPI [--04>----08]\Transmission\GMS - Gear management system A4	√	√	√			√	
Scania\Divided By Vehicle\TRUCK\I-Series\Engine 380\Truck DC 12 HPI [--04>----08]\Transmission\GMS - Gear management system OPC	√	√	√	√		√	0005
Scania\Divided By Vehicle\TRUCK\I-Series\Engine 380\Truck DC 12 HPI [--04>----08]\Transmission\GMS - Gear management system Opticruise 5	√	√	√	√		√	0009, 0011, 0018
Scania\Divided By Vehicle\TRUCK\I-Series\Engine 380\Truck DC 12 HPI [--04>----08]\Transmission\GMS - GMS Opticruise 5	√	√	√	√		√	0009, 0011, 0018
Scania\Divided By Vehicle\TRUCK\I-Series\Engine 380\Truck DC 12 HPI [--04>----08]\Transport information system\RTI - Road Transport Informatics	√	√	√				
Scania\Divided By Vehicle\TRUCK\I-Series\Engine 400\Truck DC 13 XPI EU5[---08>----13]\ABS\BMS Brake management system-ABS E	√	√	√	√		√	
Scania\Divided By Vehicle\TRUCK\I-Series\Engine 400\Truck DC 13 XPI EU5[---08>----13]\Aid for keeping lane\LDW Monitor traffic lane	√	√	√				
Scania\Divided By Vehicle\TRUCK\I-Series\Engine 400\Truck DC 13 XPI EU5[---08>----13]\Air conditioner\CCS Climate control system	√	√	√	√		√	
Scania\Divided By Vehicle\TRUCK\I-Series\Engine 400\Truck DC 13 XPI EU5[---08>----13]\Airbag\CSS Climate safety system	√	√	√				

Scania\Divided By Vehicle\TRUCK\P-Serie\Engine 400\Truck DC 13 XPI EU5[---08>---13]\Alarm\LAS Locking and alarm system	√	√	√				
Scania\Divided By Vehicle\TRUCK\P-Serie\Engine 400\Truck DC 13 XPI EU5[---08>---13]\Auxiliary heating\ATA Auxiliary heating system air-to-air	√	√	√	√			
Scania\Divided By Vehicle\TRUCK\P-Serie\Engine 400\Truck DC 13 XPI EU5[---08>---13]\Auxiliary heating\WTA Auxiliary heating system water-to-air	√	√	√				
Scania\Divided By Vehicle\TRUCK\P-Serie\Engine 400\Truck DC 13 XPI EU5[---08>---13]\Chassis equipment and design\BWS Preparation system	√	√	√				
Scania\Divided By Vehicle\TRUCK\P-Serie\Engine 400\Truck DC 13 XPI EU5[---08>---13]\Comfort system\CTS Clock and Time System	√	√	√				
Scania\Divided By Vehicle\TRUCK\P-Serie\Engine 400\Truck DC 13 XPI EU5[---08>---13]\Compressed air reserve system\APS Compressed air power supply(Scania protocol)	√	√	√	√			0003
Scania\Divided By Vehicle\TRUCK\P-Serie\Engine 400\Truck DC 13 XPI EU5[---08>---13]\Compressed air reserve system\APS Compressed air power supply(Wabco protocol)	√	√	√	√			
Scania\Divided By Vehicle\TRUCK\P-Serie\Engine 400\Truck DC 13 XPI EU5[---08>---13]\Diesel injection\EEC-Exhaust gas treatment	√	√	√	√		√	
Scania\Divided By Vehicle\TRUCK\P-Serie\Engine 400\Truck DC 13 XPI EU5[---08>---13]\Diesel injection\EMS Engine management system S6-S7	√	√	√	√		√	0002, 0015, 0017
Scania\Divided By Vehicle\TRUCK\P-Serie\Engine 400\Truck DC 13 XPI EU5[---08>---13]\Diesel injection\EMS Engine management system S8(8 Cylindes)	√	√	√	√		√	0001
Scania\Divided By Vehicle\TRUCK\P-Serie\Engine 400\Truck DC 13 XPI EU5[---08>---13]\Diesel injection\EMS Engine management system DC13(6 Cylindes)	√	√	√	√		√	
Scania\Divided By Vehicle\TRUCK\P-Serie\Engine 400\Truck DC 13 XPI EU5[---08>---13]\Distance control\DAS Adaptive Cruise Control	√	√	√				
Scania\Divided By Vehicle\TRUCK\P-Serie\Engine 400\Truck DC 13 XPI EU5[---08>---13]\Distance control\DIS Adaptive Cruise Control	√	√	√				
Scania\Divided By Vehicle\TRUCK\P-Serie\Engine 400\Truck DC 13 XPI EU5[---08>---13]\EBS\BMS Brake management system 5.0 (4x2)	√	√	√	√		√	0004
Scania\Divided By Vehicle\TRUCK\P-Serie\Engine 400\Truck DC 13 XPI EU5[---08>---13]\EBS\BMS Brake management system 5.0 (6x2 - 6x4)	√	√	√	√		√	0004
Scania\Divided By Vehicle\TRUCK\P-Serie\Engine 400\Truck DC 13 XPI EU5[---08>---13]\EBS\BMS Brake management system 5.0 (8x2)	√	√	√	√		√	0004
Scania\Divided By Vehicle\TRUCK\P-Serie\Engine 400\Truck DC 13 XPI EU5[---08>---13]\ECU external light\VIS Visibility system	√	√	√	√		√	
Scania\Divided By Vehicle\TRUCK\P-Serie\Engine 400\Truck DC 13 XPI EU5[---08>---13]\Engine-vehicle adjustment\COO Coordinator module	√	√	√	√		√	
Scania\Divided By Vehicle\TRUCK\P-Serie\Engine 400\Truck DC 13 XPI EU5[---08>---13]\Engine-vehicle adjustment\COO7 (Coordinator)	√	√	√	√		√	
Scania\Divided By Vehicle\TRUCK\P-Serie\Engine 400\Truck DC 13 XPI EU5[---08>---13]\Four-wheel drive\AWD ALL-Wheel Drive	√	√	√				
Scania\Divided By Vehicle\TRUCK\P-Serie\Engine 400\Truck DC 13 XPI EU5[---08>---13]\Instrument panel\ICL Instrument Panel 1	√	√	√	√		√	
Scania\Divided By Vehicle\TRUCK\P-Serie\Engine 400\Truck DC 13 XPI EU5[---08>---13]\Instrument panel\ICL Instrument Panel 2	√	√	√	√		√	
Scania\Divided By Vehicle\TRUCK\P-Serie\Engine 400\Truck DC 13 XPI EU5[---08>---13]\Radio\AUS Audio system	√	√	√				
Scania\Divided By Vehicle\TRUCK\P-Serie\Engine 400\Truck DC 13 XPI EU5[---08>---13]\Retarder\RET Retarder	√	√	√	√		√	
Scania\Divided By Vehicle\TRUCK\P-Serie\Engine 400\Truck DC 13 XPI EU5[---08>---13]\Suspensions\SMS Supension management system	√	√	√	√			0006, 0007, 0014
Scania\Divided By Vehicle\TRUCK\P-Serie\Engine 400\Truck DC 13 XPI EU5[---08>---13]\Tachograph\DTCO Tachograph	√	√	√				
Scania\Divided By Vehicle\TRUCK\P-Serie\Engine 400\Truck DC 13 XPI EU5[---08>---13]\Tachograph\MTCO Tachograph	√	√	√				
Scania\Divided By Vehicle\TRUCK\P-Serie\Engine 400\Truck DC 13 XPI EU5[---08>---13]\Tire pressure\TPM - Tires Pressure Monitoring System	√	√	√				
Scania\Divided By Vehicle\TRUCK\P-Serie\Engine 400\Truck DC 13 XPI EU5[---08>---13]\Transmission\GMS - Gear management system A4	√	√	√			√	
Scania\Divided By Vehicle\TRUCK\P-Serie\Engine 400\Truck DC 13 XPI EU5[---08>---13]\Transmission\GMS - Gear management system OPC	√	√	√	√		√	0005
Scania\Divided By Vehicle\TRUCK\P-Serie\Engine 400\Truck DC 13 XPI EU5[---08>---13]\Transmission\GMS - Gear management system Opticruise 5	√	√	√	√		√	0009, 0011, 0018
Scania\Divided By Vehicle\TRUCK\P-Serie\Engine 400\Truck DC 13 XPI EU5[---08>---13]\Transmission\GMS - GMS Opticruise 5	√	√	√	√		√	0009, 0011, 0018
Scania\Divided By Vehicle\TRUCK\P-Serie\Engine 400\Truck DC 13 XPI EU5[---08>---13]\Transport information system\RTI - Road Transport Informatics	√	√	√				
Scania\Divided By Vehicle\TRUCK\P-Serie\Engine 410\Truck DC 13 XPI EU5[---08>---13]\ABS\BMS Brake management system-ABS E	√	√	√	√		√	
Scania\Divided By Vehicle\TRUCK\P-Serie\Engine 410\Truck DC 13 XPI EU5[---08>---13]\Aid for keeping lane\LDW Monitor traffic lane	√	√	√				

Scania\Divided By Vehicle\TRUCK\P-Serie\Engine 410\Truck DC 13 XPI EU5[---08>---13]\Air conditioner\CCS Climate control system	√	√	√	√		√	
Scania\Divided By Vehicle\TRUCK\P-Serie\Engine 410\Truck DC 13 XPI EU5[---08>---13]\Airbag\CSS Climate safety system	√	√	√				
Scania\Divided By Vehicle\TRUCK\P-Serie\Engine 410\Truck DC 13 XPI EU5[---08>---13]\Alarm\LAS Locking and alarm system	√	√	√				
Scania\Divided By Vehicle\TRUCK\P-Serie\Engine 410\Truck DC 13 XPI EU5[---08>---13]\Auxiliary heating\ATA Auxiliary heating system air-to-air	√	√	√	√			
Scania\Divided By Vehicle\TRUCK\P-Serie\Engine 410\Truck DC 13 XPI EU5[---08>---13]\Auxiliary heating\WTA Auxiliary heating system water-to-air	√	√	√				
Scania\Divided By Vehicle\TRUCK\P-Serie\Engine 410\Truck DC 13 XPI EU5[---08>---13]\Chassis equipment and design\BWS Preparation system	√	√	√				
Scania\Divided By Vehicle\TRUCK\P-Serie\Engine 410\Truck DC 13 XPI EU5[---08>---13]\Comfort system\CTS Clock and Time System	√	√	√				
Scania\Divided By Vehicle\TRUCK\P-Serie\Engine 410\Truck DC 13 XPI EU5[---08>---13]\Compressed air reserve system\APS Compressed air power supply(Scania protocol)	√	√	√	√			0003
Scania\Divided By Vehicle\TRUCK\P-Serie\Engine 410\Truck DC 13 XPI EU5[---08>---13]\Compressed air reserve system\APS Compressed air power supply(Wabco protocol)	√	√	√	√			
Scania\Divided By Vehicle\TRUCK\P-Serie\Engine 410\Truck DC 13 XPI EU5[---08>---13]\Diesel injection\EEC-Exhaust gas treatment	√	√	√	√		√	
Scania\Divided By Vehicle\TRUCK\P-Serie\Engine 410\Truck DC 13 XPI EU5[---08>---13]\Diesel injection\EMS Engine management system S6-S7	√	√	√	√		√	0002, 0015, 0017
Scania\Divided By Vehicle\TRUCK\P-Serie\Engine 410\Truck DC 13 XPI EU5[---08>---13]\Diesel injection\EMS Engine management system S8(8 Cylindes)	√	√	√	√		√	0001
Scania\Divided By Vehicle\TRUCK\P-Serie\Engine 410\Truck DC 13 XPI EU5[---08>---13]\Diesel injection\EMS Engine management system DC13(6 Cylindes)	√	√	√	√		√	
Scania\Divided By Vehicle\TRUCK\P-Serie\Engine 410\Truck DC 13 XPI EU5[---08>---13]\Distance control\DAS Adaptive Cruise Control	√	√	√				
Scania\Divided By Vehicle\TRUCK\P-Serie\Engine 410\Truck DC 13 XPI EU5[---08>---13]\Distance control\DIS Adaptive Cruise Control	√	√	√				
Scania\Divided By Vehicle\TRUCK\P-Serie\Engine 410\Truck DC 13 XPI EU5[---08>---13]\EBS\BMS Brake management system 5.0 (4x2)	√	√	√	√		√	0004
Scania\Divided By Vehicle\TRUCK\P-Serie\Engine 410\Truck DC 13 XPI EU5[---08>---13]\EBS\BMS Brake management system 5.0 (6x2 - 6x4)	√	√	√	√		√	0004
Scania\Divided By Vehicle\TRUCK\P-Serie\Engine 410\Truck DC 13 XPI EU5[---08>---13]\EBS\BMS Brake management system 5.0 (8x2)	√	√	√	√		√	0004
Scania\Divided By Vehicle\TRUCK\P-Serie\Engine 410\Truck DC 13 XPI EU5[---08>---13]\ECU external light\VIS Visibility system	√	√	√	√		√	
Scania\Divided By Vehicle\TRUCK\P-Serie\Engine 410\Truck DC 13 XPI EU5[---08>---13]\Engine-vehicle adjustment\COO Coordinator module	√	√	√	√		√	
Scania\Divided By Vehicle\TRUCK\P-Serie\Engine 410\Truck DC 13 XPI EU5[---08>---13]\Engine-vehicle adjustment\COO7 (Coordinator)	√	√	√	√		√	
Scania\Divided By Vehicle\TRUCK\P-Serie\Engine 410\Truck DC 13 XPI EU5[---08>---13]\Four-wheel drive\AWD ALL-Wheel Drive	√	√	√				
Scania\Divided By Vehicle\TRUCK\P-Serie\Engine 410\Truck DC 13 XPI EU5[---08>---13]\Instrument panel\ICL Instrument Panel 1	√	√	√	√		√	
Scania\Divided By Vehicle\TRUCK\P-Serie\Engine 410\Truck DC 13 XPI EU5[---08>---13]\Instrument panel\ICL Instrument Panel 2	√	√	√	√		√	
Scania\Divided By Vehicle\TRUCK\P-Serie\Engine 410\Truck DC 13 XPI EU5[---08>---13]\Radio\AUS Audio system	√	√	√				
Scania\Divided By Vehicle\TRUCK\P-Serie\Engine 410\Truck DC 13 XPI EU5[---08>---13]\Retarder\RET Retarder	√	√	√	√		√	
Scania\Divided By Vehicle\TRUCK\P-Serie\Engine 410\Truck DC 13 XPI EU5[---08>---13]\Suspensions\SMS Suspension management system	√	√	√	√			0006, 0007, 0014
Scania\Divided By Vehicle\TRUCK\P-Serie\Engine 410\Truck DC 13 XPI EU5[---08>---13]\Tachograph\DTCO Tachograph	√	√	√				
Scania\Divided By Vehicle\TRUCK\P-Serie\Engine 410\Truck DC 13 XPI EU5[---08>---13]\Tachograph\MTCO Tachograph	√	√	√				
Scania\Divided By Vehicle\TRUCK\P-Serie\Engine 410\Truck DC 13 XPI EU5[---08>---13]\Tire pressure\TPM - Tires Pressure Monitoring System	√	√	√				
Scania\Divided By Vehicle\TRUCK\P-Serie\Engine 410\Truck DC 13 XPI EU5[---08>---13]\Transmission\GMS - Gear management system A4	√	√	√			√	
Scania\Divided By Vehicle\TRUCK\P-Serie\Engine 410\Truck DC 13 XPI EU5[---08>---13]\Transmission\GMS - Gear management system OPC	√	√	√	√		√	0005
Scania\Divided By Vehicle\TRUCK\P-Serie\Engine 410\Truck DC 13 XPI EU5[---08>---13]\Transmission\GMS - Gear management system Opticruise 5	√	√	√	√		√	0009, 0011, 0018
Scania\Divided By Vehicle\TRUCK\P-Serie\Engine 410\Truck DC 13 XPI EU5[---08>---13]\Transmission\GMS - GMS Opticruise 5	√	√	√	√		√	0009, 0011, 0018
Scania\Divided By Vehicle\TRUCK\P-Serie\Engine 410\Truck DC 13 XPI EU5[---08>---13]\Transport information system\RTI - Road Transport Informatics	√	√	√				

Scania\Divided By Vehicle\TRUCK\P-Serie\Engine 420\Truck DC 12 HPI ---04>---13\ABS\BMS Brake management system-ABS E	√	√	√	√		√	
Scania\Divided By Vehicle\TRUCK\P-Serie\Engine 420\Truck DC 12 HPI ---04>---13\Aid for keeping lane\LDW Monitor traffic lane	√	√	√				
Scania\Divided By Vehicle\TRUCK\P-Serie\Engine 420\Truck DC 12 HPI ---04>---13\Air conditioner\CCS Climate control system	√	√	√	√		√	
Scania\Divided By Vehicle\TRUCK\P-Serie\Engine 420\Truck DC 12 HPI ---04>---13\Airbag\CSS Climate safety system	√	√	√				
Scania\Divided By Vehicle\TRUCK\P-Serie\Engine 420\Truck DC 12 HPI ---04>---13\Alarm\LAS Locking and alarm system	√	√	√				
Scania\Divided By Vehicle\TRUCK\P-Serie\Engine 420\Truck DC 12 HPI ---04>---13\Auxiliary heating\ATA Auxiliary heating system air-to-air	√	√	√	√			
Scania\Divided By Vehicle\TRUCK\P-Serie\Engine 420\Truck DC 12 HPI ---04>---13\Auxiliary heating\WTA Auxiliary heating system water-to-air	√	√	√				
Scania\Divided By Vehicle\TRUCK\P-Serie\Engine 420\Truck DC 12 HPI ---04>---13\Chassis equipment and design\BWS Preparation system	√	√	√				
Scania\Divided By Vehicle\TRUCK\P-Serie\Engine 420\Truck DC 12 HPI ---04>---13\Comfort system\CTS Clock and Time System	√	√	√				
Scania\Divided By Vehicle\TRUCK\P-Serie\Engine 420\Truck DC 12 HPI ---04>---13\Compressed air reserve system\APS Compressed air power supply(Scania protocol)	√	√	√	√			0003
Scania\Divided By Vehicle\TRUCK\P-Serie\Engine 420\Truck DC 12 HPI ---04>---13\Compressed air reserve system\APS Compressed air power supply(Wabco protocol)	√	√	√	√			
Scania\Divided By Vehicle\TRUCK\P-Serie\Engine 420\Truck DC 12 HPI ---04>---13\Diesel injection\EEC-Exhaust gas treatment	√	√	√	√		√	
Scania\Divided By Vehicle\TRUCK\P-Serie\Engine 420\Truck DC 12 HPI ---04>---13\Diesel injection\EMS Engine management system S6-S7	√	√	√	√		√	0002, 0015, 0017
Scania\Divided By Vehicle\TRUCK\P-Serie\Engine 420\Truck DC 12 HPI ---04>---13\Diesel injection\EMS Engine management system S8(8 Cylindes)	√	√	√	√		√	0001
Scania\Divided By Vehicle\TRUCK\P-Serie\Engine 420\Truck DC 12 HPI ---04>---13\Diesel injection\EMS Engine management system DC13(6 Cylindes)	√	√	√	√		√	
Scania\Divided By Vehicle\TRUCK\P-Serie\Engine 420\Truck DC 12 HPI ---04>---13\Distance control\DAS Adaptive Cruise Control	√	√	√				
Scania\Divided By Vehicle\TRUCK\P-Serie\Engine 420\Truck DC 12 HPI ---04>---13\Distance control\DIS Adaptive Cruise Control	√	√	√				
Scania\Divided By Vehicle\TRUCK\P-Serie\Engine 420\Truck DC 12 HPI ---04>---13\EBS\BMS Brake management system 5.0 (4x2)	√	√	√	√		√	0004
Scania\Divided By Vehicle\TRUCK\P-Serie\Engine 420\Truck DC 12 HPI ---04>---13\EBS\BMS Brake management system 5.0 (6x2 - 6x4)	√	√	√	√		√	0004
Scania\Divided By Vehicle\TRUCK\P-Serie\Engine 420\Truck DC 12 HPI ---04>---13\EBS\BMS Brake management system 5.0 (8x2)	√	√	√	√		√	0004
Scania\Divided By Vehicle\TRUCK\P-Serie\Engine 420\Truck DC 12 HPI ---04>---13\ECU external light\VIS Visibility system	√	√	√	√		√	
Scania\Divided By Vehicle\TRUCK\P-Serie\Engine 420\Truck DC 12 HPI ---04>---13\Engine-vehicle adjustment\COO Coordinator module	√	√	√	√		√	
Scania\Divided By Vehicle\TRUCK\P-Serie\Engine 420\Truck DC 12 HPI ---04>---13\Engine-vehicle adjustment\COO7 (Coordinator)	√	√	√	√		√	
Scania\Divided By Vehicle\TRUCK\P-Serie\Engine 420\Truck DC 12 HPI ---04>---13\Four-wheel drive\AWD ALL-Wheel Drive	√	√	√				
Scania\Divided By Vehicle\TRUCK\P-Serie\Engine 420\Truck DC 12 HPI ---04>---13\Instrument pane\NCL Instrument Panel 1	√	√	√	√		√	
Scania\Divided By Vehicle\TRUCK\P-Serie\Engine 420\Truck DC 12 HPI ---04>---13\Instrument pane\NCL Instrument Panel 2	√	√	√	√		√	
Scania\Divided By Vehicle\TRUCK\P-Serie\Engine 420\Truck DC 12 HPI ---04>---13\Radio\AUS Audio system	√	√	√				
Scania\Divided By Vehicle\TRUCK\P-Serie\Engine 420\Truck DC 12 HPI ---04>---13\Retarder\RET Retarder	√	√	√	√		√	
Scania\Divided By Vehicle\TRUCK\P-Serie\Engine 420\Truck DC 12 HPI ---04>---13\Suspensions\SMS Supension management system	√	√	√	√			0006, 0007, 0014
Scania\Divided By Vehicle\TRUCK\P-Serie\Engine 420\Truck DC 12 HPI ---04>---13\Tachograph\DTCO Tachograph	√	√	√				
Scania\Divided By Vehicle\TRUCK\P-Serie\Engine 420\Truck DC 12 HPI ---04>---13\Tachograph\MTCO Tachograph	√	√	√				
Scania\Divided By Vehicle\TRUCK\P-Serie\Engine 420\Truck DC 12 HPI ---04>---13\Tire pressure\TPM - Tires Pressure Monitoring System	√	√	√				
Scania\Divided By Vehicle\TRUCK\P-Serie\Engine 420\Truck DC 12 HPI ---04>---13\Transmission\GMS - Gear management system A4	√	√	√			√	
Scania\Divided By Vehicle\TRUCK\P-Serie\Engine 420\Truck DC 12 HPI ---04>---13\Transmission\GMS - Gear management system OPC	√	√	√	√		√	0005
Scania\Divided By Vehicle\TRUCK\P-Serie\Engine 420\Truck DC 12 HPI ---04>---13\Transmission\GMS - Gear management system Opticruise 5	√	√	√	√		√	0009, 0011, 0018

Scania\Divided By Vehicle\TRUCK\P-Serie\Engine 420\Truck DC 12 HPI [--04>----13]\Transmission\GMS - GMS Opticruise 5	√	√	√	√		√	0009, 0011, 0018
Scania\Divided By Vehicle\TRUCK\P-Serie\Engine 420\Truck DC 12 HPI [--04>----13]\Transport information system\RTI - Road Transport Informatics	√	√	√				
Scania\Divided By Vehicle\TRUCK\P-Serie\Engine 420\Truck DC 12 HPI [--04>----08]\ABS\BMS Brake management system-ABS E	√	√	√	√		√	
Scania\Divided By Vehicle\TRUCK\P-Serie\Engine 420\Truck DC 12 HPI [--04>----08]\Aid for keeping lane\LDW Monitor traffic lane	√	√	√				
Scania\Divided By Vehicle\TRUCK\P-Serie\Engine 420\Truck DC 12 HPI [--04>----08]\Air conditioner\CCS Climate control system	√	√	√	√		√	
Scania\Divided By Vehicle\TRUCK\P-Serie\Engine 420\Truck DC 12 HPI [--04>----08]\Airbag\CSS Climate safety system	√	√	√				
Scania\Divided By Vehicle\TRUCK\P-Serie\Engine 420\Truck DC 12 HPI [--04>----08]\Alarm\LAS Locking and alarm system	√	√	√				
Scania\Divided By Vehicle\TRUCK\P-Serie\Engine 420\Truck DC 12 HPI [--04>----08]\Auxiliary heating\ATA Auxiliary heating system air-to-air	√	√	√	√			
Scania\Divided By Vehicle\TRUCK\P-Serie\Engine 420\Truck DC 12 HPI [--04>----08]\Auxiliary heating\WTA Auxiliary heating system water-to-air	√	√	√				
Scania\Divided By Vehicle\TRUCK\P-Serie\Engine 420\Truck DC 12 HPI [--04>----08]\Chassis equipment and design\BWS Preparation system	√	√	√				
Scania\Divided By Vehicle\TRUCK\P-Serie\Engine 420\Truck DC 12 HPI [--04>----08]\Comfort system\CTS Clock and Time System	√	√	√				
Scania\Divided By Vehicle\TRUCK\P-Serie\Engine 420\Truck DC 12 HPI [--04>----08]\Compressed air reserve system\APS Compressed air power supply(Scania protocol)	√	√	√	√			0003
Scania\Divided By Vehicle\TRUCK\P-Serie\Engine 420\Truck DC 12 HPI [--04>----08]\Compressed air reserve system\APS Compressed air power supply(Wabco protocol)	√	√	√	√			
Scania\Divided By Vehicle\TRUCK\P-Serie\Engine 420\Truck DC 12 HPI [--04>----08]\Diesel injection\EEC-Exhaust gas treatment	√	√	√	√		√	
Scania\Divided By Vehicle\TRUCK\P-Serie\Engine 420\Truck DC 12 HPI [--04>----08]\Diesel injection\EMS Engine management system S6-S7	√	√	√	√		√	0002, 0015, 0017
Scania\Divided By Vehicle\TRUCK\P-Serie\Engine 420\Truck DC 12 HPI [--04>----08]\Diesel injection\EMS Engine management system S8(8 Cylindes)	√	√	√	√		√	0001
Scania\Divided By Vehicle\TRUCK\P-Serie\Engine 420\Truck DC 12 HPI [--04>----08]\Diesel injection\EMS Engine management system DC13(6 Cylindes)	√	√	√	√		√	
Scania\Divided By Vehicle\TRUCK\P-Serie\Engine 420\Truck DC 12 HPI [--04>----08]\Distance control\DAS Adaptive Cruise Control	√	√	√				
Scania\Divided By Vehicle\TRUCK\P-Serie\Engine 420\Truck DC 12 HPI [--04>----08]\Distance control\DIS Adaptive Cruise Control	√	√	√				
Scania\Divided By Vehicle\TRUCK\P-Serie\Engine 420\Truck DC 12 HPI [--04>----08]\EBS\BMS Brake management system 5.0 (4x2)	√	√	√	√		√	0004
Scania\Divided By Vehicle\TRUCK\P-Serie\Engine 420\Truck DC 12 HPI [--04>----08]\EBS\BMS Brake management system 5.0 (6x2 - 6x4)	√	√	√	√		√	0004
Scania\Divided By Vehicle\TRUCK\P-Serie\Engine 420\Truck DC 12 HPI [--04>----08]\EBS\BMS Brake management system 5.0 (8x2)	√	√	√	√		√	0004
Scania\Divided By Vehicle\TRUCK\P-Serie\Engine 420\Truck DC 12 HPI [--04>----08]\ECU external light\VIS Visibility system	√	√	√	√		√	
Scania\Divided By Vehicle\TRUCK\P-Serie\Engine 420\Truck DC 12 HPI [--04>----08]\Engine-vehicle adjustment\COO Coordinator module	√	√	√	√		√	
Scania\Divided By Vehicle\TRUCK\P-Serie\Engine 420\Truck DC 12 HPI [--04>----08]\Engine-vehicle adjustment\COO7 (Coordinator)	√	√	√	√		√	
Scania\Divided By Vehicle\TRUCK\P-Serie\Engine 420\Truck DC 12 HPI [--04>----08]\Four-wheel drive\AWD ALL-Wheel Drive	√	√	√				
Scania\Divided By Vehicle\TRUCK\P-Serie\Engine 420\Truck DC 12 HPI [--04>----08]\Instrument pane\NCL Instrument Panel 1	√	√	√	√		√	
Scania\Divided By Vehicle\TRUCK\P-Serie\Engine 420\Truck DC 12 HPI [--04>----08]\Instrument pane\NCL Instrument Panel 2	√	√	√	√		√	
Scania\Divided By Vehicle\TRUCK\P-Serie\Engine 420\Truck DC 12 HPI [--04>----08]\Radio\AUS Audio system	√	√	√				
Scania\Divided By Vehicle\TRUCK\P-Serie\Engine 420\Truck DC 12 HPI [--04>----08]\Retarder\RET Retarder	√	√	√	√		√	
Scania\Divided By Vehicle\TRUCK\P-Serie\Engine 420\Truck DC 12 HPI [--04>----08]\Suspensions\SMS Supension management system	√	√	√	√			0006, 0007, 0014
Scania\Divided By Vehicle\TRUCK\P-Serie\Engine 420\Truck DC 12 HPI [--04>----08]\Tachograph\DTCO Tachograph	√	√	√				
Scania\Divided By Vehicle\TRUCK\P-Serie\Engine 420\Truck DC 12 HPI [--04>----08]\Tachograph\MTCO Tachograph	√	√	√				
Scania\Divided By Vehicle\TRUCK\P-Serie\Engine 420\Truck DC 12 HPI [--04>----08]\Tire pressure\TPM - Tires Pressure Monitoring System	√	√	√				
Scania\Divided By Vehicle\TRUCK\P-Serie\Engine 420\Truck DC 12 HPI [--04>----08]\Transmission\GMS - Gear management system A4	√	√	√			√	

Scania\Divided By Vehicle\TRUCK\I-Series\Engine 420\Truck DC 12 HPI [--04>---08]\Transmission\GMS - Gear management system OPC	√	√	√	√		√	0005
Scania\Divided By Vehicle\TRUCK\I-Series\Engine 420\Truck DC 12 HPI [--04>---08]\Transmission\GMS - Gear management system Opticruise 5	√	√	√	√		√	0009, 0011, 0018
Scania\Divided By Vehicle\TRUCK\I-Series\Engine 420\Truck DC 12 HPI [--04>---08]\Transmission\GMS - GMS Opticruise 5	√	√	√	√		√	0009, 0011, 0018
Scania\Divided By Vehicle\TRUCK\I-Series\Engine 420\Truck DC 12 HPI [--04>---08]\Transport information system\RTI - Road Transport Informatics	√	√	√				
Scania\Divided By Vehicle\TRUCK\I-Series\Engine 470\Truck DC 13 XPI EU5[---08>---13]\ABS\BMS Brake management system-ABS E	√	√	√	√		√	
Scania\Divided By Vehicle\TRUCK\I-Series\Engine 470\Truck DC 13 XPI EU5[---08>---13]\Aid for keeping lane\LDW Monitor traffic lane	√	√	√				
Scania\Divided By Vehicle\TRUCK\I-Series\Engine 470\Truck DC 13 XPI EU5[---08>---13]\Air conditioner\CCS Climate control system	√	√	√	√		√	
Scania\Divided By Vehicle\TRUCK\I-Series\Engine 470\Truck DC 13 XPI EU5[---08>---13]\Airbag\CSS Climate safety system	√	√	√				
Scania\Divided By Vehicle\TRUCK\I-Series\Engine 470\Truck DC 13 XPI EU5[---08>---13]\Alarm\LAS Locking and alarm system	√	√	√				
Scania\Divided By Vehicle\TRUCK\I-Series\Engine 470\Truck DC 13 XPI EU5[---08>---13]\Auxiliary heating\ATA Auxiliary heating system air-to-air	√	√	√	√			
Scania\Divided By Vehicle\TRUCK\I-Series\Engine 470\Truck DC 13 XPI EU5[---08>---13]\Auxiliary heating\WTA Auxiliary heating system water-to-air	√	√	√				
Scania\Divided By Vehicle\TRUCK\I-Series\Engine 470\Truck DC 13 XPI EU5[---08>---13]\Chassis equipment and design\BWS Preparation system	√	√	√				
Scania\Divided By Vehicle\TRUCK\I-Series\Engine 470\Truck DC 13 XPI EU5[---08>---13]\Comfort system\CTS Clock and Time System	√	√	√				
Scania\Divided By Vehicle\TRUCK\I-Series\Engine 470\Truck DC 13 XPI EU5[---08>---13]\Compressed air reserve system\APS Compressed air power supply(Scania protocol)	√	√	√	√			0003
Scania\Divided By Vehicle\TRUCK\I-Series\Engine 470\Truck DC 13 XPI EU5[---08>---13]\Compressed air reserve system\APS Compressed air power supply(Wabco protocol)	√	√	√	√			
Scania\Divided By Vehicle\TRUCK\I-Series\Engine 470\Truck DC 13 XPI EU5[---08>---13]\Diesel injection\EEC-Exhaust gas treatment	√	√	√	√		√	
Scania\Divided By Vehicle\TRUCK\I-Series\Engine 470\Truck DC 13 XPI EU5[---08>---13]\Diesel injection\EMS Engine management system S6-S7	√	√	√	√		√	0002, 0015, 0017
Scania\Divided By Vehicle\TRUCK\I-Series\Engine 470\Truck DC 13 XPI EU5[---08>---13]\Diesel injection\EMS Engine management system S8(8 Cylindres)	√	√	√	√		√	0001
Scania\Divided By Vehicle\TRUCK\I-Series\Engine 470\Truck DC 13 XPI EU5[---08>---13]\Diesel injection\EMS Engine management system DC13(6 Cylindres)	√	√	√	√		√	
Scania\Divided By Vehicle\TRUCK\I-Series\Engine 470\Truck DC 13 XPI EU5[---08>---13]\Distance control\DAS Adaptive Cruise Control	√	√	√				
Scania\Divided By Vehicle\TRUCK\I-Series\Engine 470\Truck DC 13 XPI EU5[---08>---13]\Distance control\DIS Adaptive Cruise Control	√	√	√				
Scania\Divided By Vehicle\TRUCK\I-Series\Engine 470\Truck DC 13 XPI EU5[---08>---13]\EBS\BMS Brake management system 5.0 (4x2)	√	√	√	√		√	0004
Scania\Divided By Vehicle\TRUCK\I-Series\Engine 470\Truck DC 13 XPI EU5[---08>---13]\EBS\BMS Brake management system 5.0 (6x2 - 6x4)	√	√	√	√		√	0004
Scania\Divided By Vehicle\TRUCK\I-Series\Engine 470\Truck DC 13 XPI EU5[---08>---13]\EBS\BMS Brake management system 5.0 (8x2)	√	√	√	√		√	0004
Scania\Divided By Vehicle\TRUCK\I-Series\Engine 470\Truck DC 13 XPI EU5[---08>---13]\ECU external light\VIS Visibility system	√	√	√	√		√	
Scania\Divided By Vehicle\TRUCK\I-Series\Engine 470\Truck DC 13 XPI EU5[---08>---13]\Engine-vehicle adjustment\COO Coordinator module	√	√	√	√		√	
Scania\Divided By Vehicle\TRUCK\I-Series\Engine 470\Truck DC 13 XPI EU5[---08>---13]\Engine-vehicle adjustment\COO7 (Coordinator)	√	√	√	√		√	
Scania\Divided By Vehicle\TRUCK\I-Series\Engine 470\Truck DC 13 XPI EU5[---08>---13]\Four-wheel drive\AWD ALL-Wheel Drive	√	√	√				
Scania\Divided By Vehicle\TRUCK\I-Series\Engine 470\Truck DC 13 XPI EU5[---08>---13]\Instrument panel\ICL Instrument Panel 1	√	√	√	√		√	
Scania\Divided By Vehicle\TRUCK\I-Series\Engine 470\Truck DC 13 XPI EU5[---08>---13]\Instrument panel\ICL Instrument Panel 2	√	√	√	√		√	
Scania\Divided By Vehicle\TRUCK\I-Series\Engine 470\Truck DC 13 XPI EU5[---08>---13]\Radio\AUS Audio system	√	√	√				
Scania\Divided By Vehicle\TRUCK\I-Series\Engine 470\Truck DC 13 XPI EU5[---08>---13]\Retarder\RET Retarder	√	√	√	√		√	
Scania\Divided By Vehicle\TRUCK\I-Series\Engine 470\Truck DC 13 XPI EU5[---08>---13]\Suspensions\SMS Suspension management system	√	√	√	√			0006, 0007, 0014
Scania\Divided By Vehicle\TRUCK\I-Series\Engine 470\Truck DC 13 XPI EU5[---08>---13]\Tachograph\DTCO Tachograph	√	√	√				
Scania\Divided By Vehicle\TRUCK\I-Series\Engine 470\Truck DC 13 XPI EU5[---08>---13]\Tachograph\MTCO Tachograph	√	√	√				

Scania\Divided By Vehicle\TRUCK\P-Serie\Engine 470\Truck DC 13 XPI EU5[---08>---13]\Tire pressure\TPM - Tires Pressure Monitoring System	√	√	√				
Scania\Divided By Vehicle\TRUCK\P-Serie\Engine 470\Truck DC 13 XPI EU5[---08>---13]\Transmission\GMS - Gear management system A4	√	√	√			√	
Scania\Divided By Vehicle\TRUCK\P-Serie\Engine 470\Truck DC 13 XPI EU5[---08>---13]\Transmission\GMS - Gear management system OPC	√	√	√	√		√	0005
Scania\Divided By Vehicle\TRUCK\P-Serie\Engine 470\Truck DC 13 XPI EU5[---08>---13]\Transmission\GMS - Gear management system Opticruise 5	√	√	√	√		√	0009, 0011, 0018
Scania\Divided By Vehicle\TRUCK\P-Serie\Engine 470\Truck DC 13 XPI EU5[---08>---13]\Transmission\GMS - GMS Opticruise 5	√	√	√	√		√	0009, 0011, 0018
Scania\Divided By Vehicle\TRUCK\P-Serie\Engine 470\Truck DC 13 XPI EU5[---08>---13]\Transport information system\RTI - Road Transport Informatics	√	√	√				
Scania\Divided By Vehicle\TRUCK\P-Serie\Engine 470\Truck DT 12 HPI [---04>---08]\ABS\BMS Brake management system-ABS E	√	√	√	√		√	
Scania\Divided By Vehicle\TRUCK\P-Serie\Engine 470\Truck DT 12 HPI [---04>---08]\Aid for keeping lane\LDW Monitor traffic lane	√	√	√				
Scania\Divided By Vehicle\TRUCK\P-Serie\Engine 470\Truck DT 12 HPI [---04>---08]\Air conditioner\CCS Climate control system	√	√	√	√		√	
Scania\Divided By Vehicle\TRUCK\P-Serie\Engine 470\Truck DT 12 HPI [---04>---08]\Airbag\CSS Climate safety system	√	√	√				
Scania\Divided By Vehicle\TRUCK\P-Serie\Engine 470\Truck DT 12 HPI [---04>---08]\Alarm\LAS Locking and alarm system	√	√	√				
Scania\Divided By Vehicle\TRUCK\P-Serie\Engine 470\Truck DT 12 HPI [---04>---08]\Auxiliary heating\ATA Auxiliary heating system air-to-air	√	√	√	√			
Scania\Divided By Vehicle\TRUCK\P-Serie\Engine 470\Truck DT 12 HPI [---04>---08]\Auxiliary heating\WTA Auxiliary heating system water-to-air	√	√	√				
Scania\Divided By Vehicle\TRUCK\P-Serie\Engine 470\Truck DT 12 HPI [---04>---08]\Chassis equipment and design\BWS Preparation system	√	√	√				
Scania\Divided By Vehicle\TRUCK\P-Serie\Engine 470\Truck DT 12 HPI [---04>---08]\Comfort system\CTS Clock and Time System	√	√	√				
Scania\Divided By Vehicle\TRUCK\P-Serie\Engine 470\Truck DT 12 HPI [---04>---08]\Compressed air reserve system\APS Compressed air power supply(Scania protocol)	√	√	√	√			0003
Scania\Divided By Vehicle\TRUCK\P-Serie\Engine 470\Truck DT 12 HPI [---04>---08]\Compressed air reserve system\APS Compressed air power supply(Wabco protocol)	√	√	√	√			
Scania\Divided By Vehicle\TRUCK\P-Serie\Engine 470\Truck DT 12 HPI [---04>---08]\Diesel injection\EEC-Exhaust gas treatment	√	√	√	√		√	
Scania\Divided By Vehicle\TRUCK\P-Serie\Engine 470\Truck DT 12 HPI [---04>---08]\Diesel injection\EMS Engine management system S6-S7	√	√	√	√		√	0002, 0015, 0017
Scania\Divided By Vehicle\TRUCK\P-Serie\Engine 470\Truck DT 12 HPI [---04>---08]\Diesel injection\EMS Engine management system S8(8 Cylindes)	√	√	√	√		√	0001
Scania\Divided By Vehicle\TRUCK\P-Serie\Engine 470\Truck DT 12 HPI [---04>---08]\Diesel injection\EMS Engine management system DC13(6 Cylindes)	√	√	√	√		√	
Scania\Divided By Vehicle\TRUCK\P-Serie\Engine 470\Truck DT 12 HPI [---04>---08]\Distance control\DAS Adaptive Cruise Control	√	√	√				
Scania\Divided By Vehicle\TRUCK\P-Serie\Engine 470\Truck DT 12 HPI [---04>---08]\Distance control\DIS Adaptive Cruise Control	√	√	√				
Scania\Divided By Vehicle\TRUCK\P-Serie\Engine 470\Truck DT 12 HPI [---04>---08]\EBS\BMS Brake management system 5.0 (4x2)	√	√	√	√		√	0004
Scania\Divided By Vehicle\TRUCK\P-Serie\Engine 470\Truck DT 12 HPI [---04>---08]\EBS\BMS Brake management system 5.0 (6x2 - 6x4)	√	√	√	√		√	0004
Scania\Divided By Vehicle\TRUCK\P-Serie\Engine 470\Truck DT 12 HPI [---04>---08]\EBS\BMS Brake management system 5.0 (8x2)	√	√	√	√		√	0004
Scania\Divided By Vehicle\TRUCK\P-Serie\Engine 470\Truck DT 12 HPI [---04>---08]\ECU external light\VIS Visibility system	√	√	√	√		√	
Scania\Divided By Vehicle\TRUCK\P-Serie\Engine 470\Truck DT 12 HPI [---04>---08]\Engine-vehicle adjustment\COO Coordinator module	√	√	√	√		√	
Scania\Divided By Vehicle\TRUCK\P-Serie\Engine 470\Truck DT 12 HPI [---04>---08]\Engine-vehicle adjustment\COO7 (Coordinator)	√	√	√	√		√	
Scania\Divided By Vehicle\TRUCK\P-Serie\Engine 470\Truck DT 12 HPI [---04>---08]\Four-wheel drive\AWD ALL-Wheel Drive	√	√	√				
Scania\Divided By Vehicle\TRUCK\P-Serie\Engine 470\Truck DT 12 HPI [---04>---08]\Instrument panel\NCL Instrument Panel 1	√	√	√	√		√	
Scania\Divided By Vehicle\TRUCK\P-Serie\Engine 470\Truck DT 12 HPI [---04>---08]\Instrument panel\NCL Instrument Panel 2	√	√	√	√		√	
Scania\Divided By Vehicle\TRUCK\P-Serie\Engine 470\Truck DT 12 HPI [---04>---08]\Radio\AUS Audio system	√	√	√				
Scania\Divided By Vehicle\TRUCK\P-Serie\Engine 470\Truck DT 12 HPI [---04>---08]\Retarder\RET Retarder	√	√	√	√		√	
Scania\Divided By Vehicle\TRUCK\P-Serie\Engine 470\Truck DT 12 HPI [---04>---08]\Suspensions\SMS Supension management system	√	√	√	√			0006, 0007, 0014

Scania\Divided By Vehicle\TRUCK\P-Serie\Engine 470\Truck DT 12 HPI [---04>---08]\Tachograph\DTCO Tachograph	√	√	√				
Scania\Divided By Vehicle\TRUCK\P-Serie\Engine 470\Truck DT 12 HPI [---04>---08]\Tachograph\MTCO Tachograph	√	√	√				
Scania\Divided By Vehicle\TRUCK\P-Serie\Engine 470\Truck DT 12 HPI [---04>---08]\Tire pressure\TPM - Tires Pressure Monitoring System	√	√	√				
Scania\Divided By Vehicle\TRUCK\P-Serie\Engine 470\Truck DT 12 HPI [---04>---08]\Transmission\GMS - Gear management system A4	√	√	√			√	
Scania\Divided By Vehicle\TRUCK\P-Serie\Engine 470\Truck DT 12 HPI [---04>---08]\Transmission\GMS - Gear management system OPC	√	√	√	√		√	0005
Scania\Divided By Vehicle\TRUCK\P-Serie\Engine 470\Truck DT 12 HPI [---04>---08]\Transmission\GMS - Gear management system Opticruise 5	√	√	√	√		√	0009, 0011, 0018
Scania\Divided By Vehicle\TRUCK\P-Serie\Engine 470\Truck DT 12 HPI [---04>---08]\Transmission\GMS - GMS Opticruise 5	√	√	√	√		√	0009, 0011, 0018
Scania\Divided By Vehicle\TRUCK\P-Serie\Engine 470\Truck DT 12 HPI [---04>---08]\Transport information system\RTI - Road Transport Informatics	√	√	√				
Scania\Divided By Vehicle\TRUCK\P-Serie\Engine 480\Truck DC 13 XPI EU5 [---08>---13]\ABS\BMS Brake management system-ABS E	√	√	√	√		√	
Scania\Divided By Vehicle\TRUCK\P-Serie\Engine 480\Truck DC 13 XPI EU5 [---08>---13]\Aid for keeping lane\LDW Monitor traffic lane	√	√	√				
Scania\Divided By Vehicle\TRUCK\P-Serie\Engine 480\Truck DC 13 XPI EU5 [---08>---13]\Air conditioner\CCS Climate control system	√	√	√	√		√	
Scania\Divided By Vehicle\TRUCK\P-Serie\Engine 480\Truck DC 13 XPI EU5 [---08>---13]\Airbag\CSS Climate safety system	√	√	√				
Scania\Divided By Vehicle\TRUCK\P-Serie\Engine 480\Truck DC 13 XPI EU5 [---08>---13]\Alarm\LAS Locking and alarm system	√	√	√				
Scania\Divided By Vehicle\TRUCK\P-Serie\Engine 480\Truck DC 13 XPI EU5 [---08>---13]\Auxiliary heating\ATA Auxiliary heating system air-to-air	√	√	√	√			
Scania\Divided By Vehicle\TRUCK\P-Serie\Engine 480\Truck DC 13 XPI EU5 [---08>---13]\Auxiliary heating\WTA Auxiliary heating system water-to-air	√	√	√				
Scania\Divided By Vehicle\TRUCK\P-Serie\Engine 480\Truck DC 13 XPI EU5 [---08>---13]\Chassis equipment and design\BWS Preparation system	√	√	√				
Scania\Divided By Vehicle\TRUCK\P-Serie\Engine 480\Truck DC 13 XPI EU5 [---08>---13]\Comfort system\CTS Clock and Time System	√	√	√				
Scania\Divided By Vehicle\TRUCK\P-Serie\Engine 480\Truck DC 13 XPI EU5 [---08>---13]\Compressed air reserve system\APS Compressed air power supply(Scania protocol)	√	√	√	√			0003
Scania\Divided By Vehicle\TRUCK\P-Serie\Engine 480\Truck DC 13 XPI EU5 [---08>---13]\Compressed air reserve system\APS Compressed air power supply(Wabco protocol)	√	√	√	√			
Scania\Divided By Vehicle\TRUCK\P-Serie\Engine 480\Truck DC 13 XPI EU5 [---08>---13]\Diesel injection\EEC-Exhaust gas treatment	√	√	√	√		√	
Scania\Divided By Vehicle\TRUCK\P-Serie\Engine 480\Truck DC 13 XPI EU5 [---08>---13]\Diesel injection\EMS Engine management system S6-S7	√	√	√	√		√	0002, 0015, 0017
Scania\Divided By Vehicle\TRUCK\P-Serie\Engine 480\Truck DC 13 XPI EU5 [---08>---13]\Diesel injection\EMS Engine management system S8(8 Cylindres)	√	√	√	√		√	0001
Scania\Divided By Vehicle\TRUCK\P-Serie\Engine 480\Truck DC 13 XPI EU5 [---08>---13]\Diesel injection\EMS Engine management system DC13(6 Cylindres)	√	√	√	√		√	
Scania\Divided By Vehicle\TRUCK\P-Serie\Engine 480\Truck DC 13 XPI EU5 [---08>---13]\Distance control\DAS Adaptive Cruise Control	√	√	√				
Scania\Divided By Vehicle\TRUCK\P-Serie\Engine 480\Truck DC 13 XPI EU5 [---08>---13]\Distance control\DIS Adaptive Cruise Control	√	√	√				
Scania\Divided By Vehicle\TRUCK\P-Serie\Engine 480\Truck DC 13 XPI EU5 [---08>---13]\EBS\BMS Brake management system 5.0 (4x2)	√	√	√	√		√	0004
Scania\Divided By Vehicle\TRUCK\P-Serie\Engine 480\Truck DC 13 XPI EU5 [---08>---13]\EBS\BMS Brake management system 5.0 (6x2 - 6x4)	√	√	√	√		√	0004
Scania\Divided By Vehicle\TRUCK\P-Serie\Engine 480\Truck DC 13 XPI EU5 [---08>---13]\EBS\BMS Brake management system 5.0 (8x2)	√	√	√	√		√	0004
Scania\Divided By Vehicle\TRUCK\P-Serie\Engine 480\Truck DC 13 XPI EU5 [---08>---13]\ECU external light\VIS Visibility system	√	√	√	√		√	
Scania\Divided By Vehicle\TRUCK\P-Serie\Engine 480\Truck DC 13 XPI EU5 [---08>---13]\Engine-vehicle adjustment\COO Coordinator module	√	√	√	√		√	
Scania\Divided By Vehicle\TRUCK\P-Serie\Engine 480\Truck DC 13 XPI EU5 [---08>---13]\Engine-vehicle adjustment\COO7 (Coordinator)	√	√	√	√		√	
Scania\Divided By Vehicle\TRUCK\P-Serie\Engine 480\Truck DC 13 XPI EU5 [---08>---13]\Four-wheel drive\AWD ALL-Wheel Drive	√	√	√				
Scania\Divided By Vehicle\TRUCK\P-Serie\Engine 480\Truck DC 13 XPI EU5 [---08>---13]\Instrument panel\ICL Instrument Panel 1	√	√	√	√		√	
Scania\Divided By Vehicle\TRUCK\P-Serie\Engine 480\Truck DC 13 XPI EU5 [---08>---13]\Instrument panel\ICL Instrument Panel 2	√	√	√	√		√	
Scania\Divided By Vehicle\TRUCK\P-Serie\Engine 480\Truck DC 13 XPI EU5 [---08>---13]\Radio\AUS Audio system	√	√	√				

Scania\Divided By Vehicle\TRUCK\P-Serie\Engine 480\Truck DC 13 XPI EU5[---08>---13]\Retarder\RET Retarder	√	√	√	√		√	
Scania\Divided By Vehicle\TRUCK\P-Serie\Engine 480\Truck DC 13 XPI EU5[---08>---13]\Suspensions\SMS Suspension management system	√	√	√	√			0006, 0007, 0014
Scania\Divided By Vehicle\TRUCK\P-Serie\Engine 480\Truck DC 13 XPI EU5[---08>---13]\Tachograph\DTCO Tachograph	√	√	√				
Scania\Divided By Vehicle\TRUCK\P-Serie\Engine 480\Truck DC 13 XPI EU5[---08>---13]\Tachograph\MTCO Tachograph	√	√	√				
Scania\Divided By Vehicle\TRUCK\P-Serie\Engine 480\Truck DC 13 XPI EU5[---08>---13]\Tire pressure\TPM - Tires Pressure Monitoring System	√	√	√				
Scania\Divided By Vehicle\TRUCK\P-Serie\Engine 480\Truck DC 13 XPI EU5[---08>---13]\Transmission\GMS - Gear management system A4	√	√	√			√	
Scania\Divided By Vehicle\TRUCK\P-Serie\Engine 480\Truck DC 13 XPI EU5[---08>---13]\Transmission\GMS - Gear management system OPC	√	√	√	√		√	0005
Scania\Divided By Vehicle\TRUCK\P-Serie\Engine 480\Truck DC 13 XPI EU5[---08>---13]\Transmission\GMS - Gear management system Opticruise 5	√	√	√	√		√	0009, 0011, 0018
Scania\Divided By Vehicle\TRUCK\P-Serie\Engine 480\Truck DC 13 XPI EU5[---08>---13]\Transmission\GMS - GMS Opticruise 5	√	√	√	√		√	0009, 0011, 0018
Scania\Divided By Vehicle\TRUCK\P-Serie\Engine 480\Truck DC 13 XPI EU5[---08>---13]\Transport information system\RTI - Road Transport Informatics	√	√	√				
Scania\Divided By Vehicle\TRUCK\P-Serie\Engine 480\Truck DT 12 HPI [---04>---13]\ABS\BMS Brake management system-ABS E	√	√	√	√		√	
Scania\Divided By Vehicle\TRUCK\P-Serie\Engine 480\Truck DT 12 HPI [---04>---13]\Aid for keeping lane\LDW Monitor traffic lane	√	√	√				
Scania\Divided By Vehicle\TRUCK\P-Serie\Engine 480\Truck DT 12 HPI [---04>---13]\Air conditioner\CCS Climate control system	√	√	√	√		√	
Scania\Divided By Vehicle\TRUCK\P-Serie\Engine 480\Truck DT 12 HPI [---04>---13]\Airbag\CSS Climate safety system	√	√	√				
Scania\Divided By Vehicle\TRUCK\P-Serie\Engine 480\Truck DT 12 HPI [---04>---13]\Alarm\LAS Locking and alarm system	√	√	√				
Scania\Divided By Vehicle\TRUCK\P-Serie\Engine 480\Truck DT 12 HPI [---04>---13]\Auxiliary heating\ATA Auxiliary heating system air-to-air	√	√	√	√			
Scania\Divided By Vehicle\TRUCK\P-Serie\Engine 480\Truck DT 12 HPI [---04>---13]\Auxiliary heating\WTA Auxiliary heating system water-to-air	√	√	√				
Scania\Divided By Vehicle\TRUCK\P-Serie\Engine 480\Truck DT 12 HPI [---04>---13]\Chassis equipment and design\BWS Preparation system	√	√	√				
Scania\Divided By Vehicle\TRUCK\P-Serie\Engine 480\Truck DT 12 HPI [---04>---13]\Comfort system\CTS Clock and Time System	√	√	√				
Scania\Divided By Vehicle\TRUCK\P-Serie\Engine 480\Truck DT 12 HPI [---04>---13]\Compressed air reserve system\APS Compressed air power supply(Scania protocol)	√	√	√	√			0003
Scania\Divided By Vehicle\TRUCK\P-Serie\Engine 480\Truck DT 12 HPI [---04>---13]\Compressed air reserve system\APS Compressed air power supply(Wabco protocol)	√	√	√	√			
Scania\Divided By Vehicle\TRUCK\P-Serie\Engine 480\Truck DT 12 HPI [---04>---13]\Diesel injection\EEC-Exhaust gas treatment	√	√	√	√		√	
Scania\Divided By Vehicle\TRUCK\P-Serie\Engine 480\Truck DT 12 HPI [---04>---13]\Diesel injection\EMS Engine management system S6-S7	√	√	√	√		√	0002, 0015, 0017
Scania\Divided By Vehicle\TRUCK\P-Serie\Engine 480\Truck DT 12 HPI [---04>---13]\Diesel injection\EMS Engine management system S8(8 Cylindes)	√	√	√	√		√	0001
Scania\Divided By Vehicle\TRUCK\P-Serie\Engine 480\Truck DT 12 HPI [---04>---13]\Diesel injection\EMS Engine management system DC13(6 Cylindes)	√	√	√	√		√	
Scania\Divided By Vehicle\TRUCK\P-Serie\Engine 480\Truck DT 12 HPI [---04>---13]\Distance control\DAS Adaptive Cruise Control	√	√	√				
Scania\Divided By Vehicle\TRUCK\P-Serie\Engine 480\Truck DT 12 HPI [---04>---13]\Distance control\DIS Adaptive Cruise Control	√	√	√				
Scania\Divided By Vehicle\TRUCK\P-Serie\Engine 480\Truck DT 12 HPI [---04>---13]\EBS\BMS Brake management system 5.0 (4x2)	√	√	√	√		√	0004
Scania\Divided By Vehicle\TRUCK\P-Serie\Engine 480\Truck DT 12 HPI [---04>---13]\EBS\BMS Brake management system 5.0 (6x2 - 6x4)	√	√	√	√		√	0004
Scania\Divided By Vehicle\TRUCK\P-Serie\Engine 480\Truck DT 12 HPI [---04>---13]\EBS\BMS Brake management system 5.0 (8x2)	√	√	√	√		√	0004
Scania\Divided By Vehicle\TRUCK\P-Serie\Engine 480\Truck DT 12 HPI [---04>---13]\ECU external light\VIS Visibility system	√	√	√	√		√	
Scania\Divided By Vehicle\TRUCK\P-Serie\Engine 480\Truck DT 12 HPI [---04>---13]\Engine-vehicle adjustment\COO Coordinator module	√	√	√	√		√	
Scania\Divided By Vehicle\TRUCK\P-Serie\Engine 480\Truck DT 12 HPI [---04>---13]\Engine-vehicle adjustment\COO7 (Coordinator)	√	√	√	√		√	
Scania\Divided By Vehicle\TRUCK\P-Serie\Engine 480\Truck DT 12 HPI [---04>---13]\Four-wheel drive\AWD ALL-Wheel Drive	√	√	√				
Scania\Divided By Vehicle\TRUCK\P-Serie\Engine 480\Truck DT 12 HPI [---04>---13]\Instrument panel\ICL Instrument Panel 1	√	√	√	√		√	

Scania\Divided By Vehicle\TRUCK\P-Serie\Engine 480\Truck DT 12 HPI [---04>---13]\Instrument pane\NCL Instrument Panel 2	√	√	√	√		√	
Scania\Divided By Vehicle\TRUCK\P-Serie\Engine 480\Truck DT 12 HPI [---04>---13]\Radio\AUS Audio system	√	√	√				
Scania\Divided By Vehicle\TRUCK\P-Serie\Engine 480\Truck DT 12 HPI [---04>---13]\Retarder\RET Retarder	√	√	√	√		√	
Scania\Divided By Vehicle\TRUCK\P-Serie\Engine 480\Truck DT 12 HPI [---04>---13]\Suspensions\SMS Supension management system	√	√	√	√			0006, 0007, 0014
Scania\Divided By Vehicle\TRUCK\P-Serie\Engine 480\Truck DT 12 HPI [---04>---13]\Tachograph\DTCO Tachograph	√	√	√				
Scania\Divided By Vehicle\TRUCK\P-Serie\Engine 480\Truck DT 12 HPI [---04>---13]\Tachograph\MTCO Tachograph	√	√	√				
Scania\Divided By Vehicle\TRUCK\P-Serie\Engine 480\Truck DT 12 HPI [---04>---13]\Tire pressure\TPM - Tires Pressure Monitoring System	√	√	√				
Scania\Divided By Vehicle\TRUCK\P-Serie\Engine 480\Truck DT 12 HPI [---04>---13]\Transmission\GMS - Gear management system A4	√	√	√			√	
Scania\Divided By Vehicle\TRUCK\P-Serie\Engine 480\Truck DT 12 HPI [---04>---13]\Transmission\GMS - Gear management system OPC	√	√	√	√		√	0005
Scania\Divided By Vehicle\TRUCK\P-Serie\Engine 480\Truck DT 12 HPI [---04>---13]\Transmission\GMS - Gear management system Opticruise 5	√	√	√	√		√	0009, 0011, 0018
Scania\Divided By Vehicle\TRUCK\P-Serie\Engine 480\Truck DT 12 HPI [---04>---13]\Transmission\GMS - GMS Opticruise 5	√	√	√	√		√	0009, 0011, 0018
Scania\Divided By Vehicle\TRUCK\P-Serie\Engine 480\Truck DT 12 HPI [---04>---13]\Transport information system\RTI - Road Transport Informatics	√	√	√				
Scania\Divided By Vehicle\TRUCK\P-Serie\Engine 480\Truck DT 12 [---06>---13]\ABS\BMS Brake management system-ABS E	√	√	√	√		√	
Scania\Divided By Vehicle\TRUCK\P-Serie\Engine 480\Truck DT 12 [---06>---13]\Aid for keeping lane\LDW Monitor traffic lane	√	√	√				
Scania\Divided By Vehicle\TRUCK\P-Serie\Engine 480\Truck DT 12 [---06>---13]\Air conditioner\CCS Climate control system	√	√	√	√		√	
Scania\Divided By Vehicle\TRUCK\P-Serie\Engine 480\Truck DT 12 [---06>---13]\Airbag\CSS Climate safety system	√	√	√				
Scania\Divided By Vehicle\TRUCK\P-Serie\Engine 480\Truck DT 12 [---06>---13]\Alarm\LAS Locking and alarm system	√	√	√				
Scania\Divided By Vehicle\TRUCK\P-Serie\Engine 480\Truck DT 12 [---06>---13]\Auxiliary heating\ATA Auxiliary heating system air-to-air	√	√	√	√			
Scania\Divided By Vehicle\TRUCK\P-Serie\Engine 480\Truck DT 12 [---06>---13]\Auxiliary heating\WTA Auxiliary heating system water-to-air	√	√	√				
Scania\Divided By Vehicle\TRUCK\P-Serie\Engine 480\Truck DT 12 [---06>---13]\Chassis equipment and design\BWS Preparation system	√	√	√				
Scania\Divided By Vehicle\TRUCK\P-Serie\Engine 480\Truck DT 12 [---06>---13]\Comfort system\CTS Clock and Time System	√	√	√				
Scania\Divided By Vehicle\TRUCK\P-Serie\Engine 480\Truck DT 12 [---06>---13]\Compressed air reserve system\APS Compressed air power supply(Scania protocol)	√	√	√	√			0003
Scania\Divided By Vehicle\TRUCK\P-Serie\Engine 480\Truck DT 12 [---06>---13]\Compressed air reserve system\APS Compressed air power supply(Wabco protocol)	√	√	√	√			
Scania\Divided By Vehicle\TRUCK\P-Serie\Engine 480\Truck DT 12 [---06>---13]\Diesel injection\EEC-Exhaust gas treatment	√	√	√	√		√	
Scania\Divided By Vehicle\TRUCK\P-Serie\Engine 480\Truck DT 12 [---06>---13]\Diesel injection\EMS Engine management system S6-S7	√	√	√	√		√	0002, 0015, 0017
Scania\Divided By Vehicle\TRUCK\P-Serie\Engine 480\Truck DT 12 [---06>---13]\Diesel injection\EMS Engine management system S8(8 Cylindes)	√	√	√	√		√	0001
Scania\Divided By Vehicle\TRUCK\P-Serie\Engine 480\Truck DT 12 [---06>---13]\Diesel injection\EMS Engine management system DC13(6 Cylindes)	√	√	√	√		√	
Scania\Divided By Vehicle\TRUCK\P-Serie\Engine 480\Truck DT 12 [---06>---13]\Distance control\DAS Adaptive Cruise Control	√	√	√				
Scania\Divided By Vehicle\TRUCK\P-Serie\Engine 480\Truck DT 12 [---06>---13]\Distance control\DIS Adaptive Cruise Control	√	√	√				
Scania\Divided By Vehicle\TRUCK\P-Serie\Engine 480\Truck DT 12 [---06>---13]\EBS\BMS Brake management system 5.0 (4x2)	√	√	√	√		√	0004
Scania\Divided By Vehicle\TRUCK\P-Serie\Engine 480\Truck DT 12 [---06>---13]\EBS\BMS Brake management system 5.0 (6x2 - 6x4)	√	√	√	√		√	0004
Scania\Divided By Vehicle\TRUCK\P-Serie\Engine 480\Truck DT 12 [---06>---13]\EBS\BMS Brake management system 5.0 (8x2)	√	√	√	√		√	0004
Scania\Divided By Vehicle\TRUCK\P-Serie\Engine 480\Truck DT 12 [---06>---13]\ECU external light\VIS Visbility system	√	√	√	√		√	
Scania\Divided By Vehicle\TRUCK\P-Serie\Engine 480\Truck DT 12 [---06>---13]\Engine-vehicle adjustment\COO Coordinator module	√	√	√	√		√	
Scania\Divided By Vehicle\TRUCK\P-Serie\Engine 480\Truck DT 12 [---06>---13]\Engine-vehicle adjustment\COO7 (Coordinator)	√	√	√	√		√	

Scania\Divided By Vehicle\TRUCK\I-Series\Engine 480\Truck DT 12 <---06>---13 \Four-wheel drive\AWD ALL-Wheel Drive	√	√	√				
Scania\Divided By Vehicle\TRUCK\I-Series\Engine 480\Truck DT 12 <---06>---13 \Instrument panel\NCL Instrument Panel 1	√	√	√	√		√	
Scania\Divided By Vehicle\TRUCK\I-Series\Engine 480\Truck DT 12 <---06>---13 \Instrument panel\NCL Instrument Panel 2	√	√	√	√		√	
Scania\Divided By Vehicle\TRUCK\I-Series\Engine 480\Truck DT 12 <---06>---13 \Radio\AUS Audio system	√	√	√				
Scania\Divided By Vehicle\TRUCK\I-Series\Engine 480\Truck DT 12 <---06>---13 \Retarder\RET Retarder	√	√	√	√		√	
Scania\Divided By Vehicle\TRUCK\I-Series\Engine 480\Truck DT 12 <---06>---13 \Suspensions\SMS Suspension management system	√	√	√	√			0006, 0007, 0014
Scania\Divided By Vehicle\TRUCK\I-Series\Engine 480\Truck DT 12 <---06>---13 \Tachograph\DTCO Tachograph	√	√	√				
Scania\Divided By Vehicle\TRUCK\I-Series\Engine 480\Truck DT 12 <---06>---13 \Tachograph\MTCO Tachograph	√	√	√				
Scania\Divided By Vehicle\TRUCK\I-Series\Engine 480\Truck DT 12 <---06>---13 \Tire pressure\TPM - Tires Pressure Monitoring System	√	√	√				
Scania\Divided By Vehicle\TRUCK\I-Series\Engine 480\Truck DT 12 <---06>---13 \Transmission\GMS - Gear management system A4	√	√	√			√	
Scania\Divided By Vehicle\TRUCK\I-Series\Engine 480\Truck DT 12 <---06>---13 \Transmission\GMS - Gear management system OPC	√	√	√	√		√	0005
Scania\Divided By Vehicle\TRUCK\I-Series\Engine 480\Truck DT 12 <---06>---13 \Transmission\GMS - Gear management system Opticruise 5	√	√	√	√		√	0009, 0011, 0018
Scania\Divided By Vehicle\TRUCK\I-Series\Engine 480\Truck DT 12 <---06>---13 \Transmission\GMS - GMS Opticruise 5	√	√	√	√		√	0009, 0011, 0018
Scania\Divided By Vehicle\TRUCK\I-Series\Engine 480\Truck DT 12 <---06>---13 \Transport information system\RTI - Road Transport Informatics	√	√	√				
Scania\Divided By Vehicle\TRUCK\I-Series Euro 6\ABS\BMS Brake management system-ABS E	√	√	√	√		√	
Scania\Divided By Vehicle\TRUCK\I-Series Euro 6\Aid for keeping lane\LDW Monitor traffic lane	√	√	√				
Scania\Divided By Vehicle\TRUCK\I-Series Euro 6\Air conditioner\CCS Climate control system	√	√	√	√		√	
Scania\Divided By Vehicle\TRUCK\I-Series Euro 6\Airbag\CSS Climate safety system	√	√	√				
Scania\Divided By Vehicle\TRUCK\I-Series Euro 6\Alarm\LAS Locking and alarm system	√	√	√				
Scania\Divided By Vehicle\TRUCK\I-Series Euro 6\Auxiliary heating\ATA Auxiliary heating system air-to-air	√	√	√	√			
Scania\Divided By Vehicle\TRUCK\I-Series Euro 6\Auxiliary heating\WTA Auxiliary heating system water-to-air	√	√	√				
Scania\Divided By Vehicle\TRUCK\I-Series Euro 6\Chassis equipment and design\BWS Preparation system	√	√	√				
Scania\Divided By Vehicle\TRUCK\I-Series Euro 6\Comfort system\CTS Clock and Time System	√	√	√				
Scania\Divided By Vehicle\TRUCK\I-Series Euro 6\Compressed air reserve system\APS Compressed air power supply(Scania protocol)	√	√	√	√			0003
Scania\Divided By Vehicle\TRUCK\I-Series Euro 6\Compressed air reserve system\APS Compressed air power supply(Wabco protocol)	√	√	√	√			
Scania\Divided By Vehicle\TRUCK\I-Series Euro 6\Diesel injection\EMS Engine management system S8(8 Cylindres)	√	√	√	√		√	0001
Scania\Divided By Vehicle\TRUCK\I-Series Euro 6\Diesel injection\EMS Engine management system DC13(6 Cylindres)	√	√	√	√		√	
Scania\Divided By Vehicle\TRUCK\I-Series Euro 6\Distance control\DAS Adaptive Cruise Control	√	√	√				
Scania\Divided By Vehicle\TRUCK\I-Series Euro 6\Distance control\DIS Adaptive Cruise Control	√	√	√				
Scania\Divided By Vehicle\TRUCK\I-Series Euro 6\EBS\BMS Brake management system 5.0 (4x2)	√	√	√	√		√	0004
Scania\Divided By Vehicle\TRUCK\I-Series Euro 6\EBS\BMS Brake management system 5.0 (6x2 - 6x4)	√	√	√	√		√	0004
Scania\Divided By Vehicle\TRUCK\I-Series Euro 6\EBS\BMS Brake management system 5.0 (8x2)	√	√	√	√		√	0004
Scania\Divided By Vehicle\TRUCK\I-Series Euro 6\ECU external light\VIS Visibility system	√	√	√	√		√	
Scania\Divided By Vehicle\TRUCK\I-Series Euro 6\Engine-vehicle adjustment\COO Coordinator module	√	√	√	√		√	
Scania\Divided By Vehicle\TRUCK\I-Series Euro 6\Engine-vehicle adjustment\COO7 (Coordinator)	√	√	√	√		√	

Scania\Divided By Vehicle\TRUCK\I-Series Euro 6\Four-wheel drive\AWD ALL-Wheel Drive	√	√	√				
Scania\Divided By Vehicle\TRUCK\I-Series Euro 6\Instrument panel\NCL Instrument Panel 1	√	√	√	√		√	
Scania\Divided By Vehicle\TRUCK\I-Series Euro 6\Instrument panel\NCL Instrument Panel 2	√	√	√	√		√	
Scania\Divided By Vehicle\TRUCK\I-Series Euro 6\Radio\AUS Audio system	√	√	√				
Scania\Divided By Vehicle\TRUCK\I-Series Euro 6\Retarder\RET Retarder	√	√	√	√		√	
Scania\Divided By Vehicle\TRUCK\I-Series Euro 6\Suspensions\SMS Suspension management system	√	√	√	√			0006, 0007, 0014
Scania\Divided By Vehicle\TRUCK\I-Series Euro 6\Tachograph\DTCO Tachograph	√	√	√				
Scania\Divided By Vehicle\TRUCK\I-Series Euro 6\Tachograph\MTCO Tachograph	√	√	√				
Scania\Divided By Vehicle\TRUCK\I-Series Euro 6\Tire pressure\TPM - Tires Pressure Monitoring System	√	√	√				
Scania\Divided By Vehicle\TRUCK\I-Series Euro 6\Transmission\GMS - Gear management system A4	√	√	√			√	
Scania\Divided By Vehicle\TRUCK\I-Series Euro 6\Transmission\GMS - Gear management system OPC	√	√	√	√		√	0005
Scania\Divided By Vehicle\TRUCK\I-Series Euro 6\Transmission\GMS - Gear management system Opticruise 5	√	√	√	√		√	0009, 0011, 0018
Scania\Divided By Vehicle\TRUCK\I-Series Euro 6\Transmission\GMS - GMS Opticruise 5	√	√	√	√		√	0009, 0011, 0018
Scania\Divided By Vehicle\TRUCK\I-Series Euro 6\Transport information system\RTI - Road Transport Informatics	√	√	√				
Scania\Divided By Vehicle\TRUCK\I-Series\Engine 230\TRUCK DC 9 [---04>---08]\ABS\BMS Brake management system-ABS E	√	√	√	√		√	
Scania\Divided By Vehicle\TRUCK\I-Series\Engine 230\TRUCK DC 9 [---04>---08]\Aid for keeping lane\LDW Monitor traffic lane	√	√	√				
Scania\Divided By Vehicle\TRUCK\I-Series\Engine 230\TRUCK DC 9 [---04>---08]\Air conditioner\CCS Climate control system	√	√	√	√		√	
Scania\Divided By Vehicle\TRUCK\I-Series\Engine 230\TRUCK DC 9 [---04>---08]\Airbag\CSS Climate safety system	√	√	√				
Scania\Divided By Vehicle\TRUCK\I-Series\Engine 230\TRUCK DC 9 [---04>---08]\Alarm\LAS Locking and alarm system	√	√	√				
Scania\Divided By Vehicle\TRUCK\I-Series\Engine 230\TRUCK DC 9 [---04>---08]\Auxiliary heating\ATA Auxiliary heating system air-to-air	√	√	√	√			
Scania\Divided By Vehicle\TRUCK\I-Series\Engine 230\TRUCK DC 9 [---04>---08]\Auxiliary heating\WTA Auxiliary heating system water-to-air	√	√	√				
Scania\Divided By Vehicle\TRUCK\I-Series\Engine 230\TRUCK DC 9 [---04>---08]\Chassis equipment and design\BWS Preparation system	√	√	√				
Scania\Divided By Vehicle\TRUCK\I-Series\Engine 230\TRUCK DC 9 [---04>---08]\Comfort system\CTS Clock and Time System	√	√	√				
Scania\Divided By Vehicle\TRUCK\I-Series\Engine 230\TRUCK DC 9 [---04>---08]\Compressed air reserve system\APS Compressed air power supply(Scania protocol)	√	√	√	√			0003
Scania\Divided By Vehicle\TRUCK\I-Series\Engine 230\TRUCK DC 9 [---04>---08]\Compressed air reserve system\APS Compressed air power supply(Wabco protocol)	√	√	√	√			
Scania\Divided By Vehicle\TRUCK\I-Series\Engine 230\TRUCK DC 9 [---04>---08]\Diesel injection\EEC-Exhaust gas treatment	√	√	√	√		√	
Scania\Divided By Vehicle\TRUCK\I-Series\Engine 230\TRUCK DC 9 [---04>---08]\Diesel injection\EMS Engine management system S6-S7	√	√	√	√		√	0002, 0015, 0017
Scania\Divided By Vehicle\TRUCK\I-Series\Engine 230\TRUCK DC 9 [---04>---08]\Diesel injection\EMS Engine management system S8(8 Cylindres)	√	√	√	√		√	0001
Scania\Divided By Vehicle\TRUCK\I-Series\Engine 230\TRUCK DC 9 [---04>---08]\Diesel injection\EMS Engine management system DC13(6 Cylindres)	√	√	√	√		√	
Scania\Divided By Vehicle\TRUCK\I-Series\Engine 230\TRUCK DC 9 [---04>---08]\Distance control\DAS Adaptive Cruise Control	√	√	√				
Scania\Divided By Vehicle\TRUCK\I-Series\Engine 230\TRUCK DC 9 [---04>---08]\Distance control\DIS Adaptive Cruise Control	√	√	√				
Scania\Divided By Vehicle\TRUCK\I-Series\Engine 230\TRUCK DC 9 [---04>---08]\EBS\BMS Brake management system 5.0 (4x2)	√	√	√	√		√	0004
Scania\Divided By Vehicle\TRUCK\I-Series\Engine 230\TRUCK DC 9 [---04>---08]\EBS\BMS Brake management system 5.0 (6x2 - 6x4)	√	√	√	√		√	0004
Scania\Divided By Vehicle\TRUCK\I-Series\Engine 230\TRUCK DC 9 [---04>---08]\EBS\BMS Brake management system 5.0 (8x2)	√	√	√	√		√	0004
Scania\Divided By Vehicle\TRUCK\I-Series\Engine 230\TRUCK DC 9 [---04>---08]\ECU external light\VIS Visibility system	√	√	√	√		√	

Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 230\TRUCK DC 9 [---04>---08]\Engine-vehicle adjustment\COO Coordinator module	√	√	√	√		√	
Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 230\TRUCK DC 9 [---04>---08]\Engine-vehicle adjustment\COO7 (Coordinator)	√	√	√	√		√	
Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 230\TRUCK DC 9 [---04>---08]\Four-wheel drive\AWD ALL-Wheel Drive	√	√	√				
Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 230\TRUCK DC 9 [---04>---08]\Instrument panel\NCL Instrument Panel 1	√	√	√	√		√	
Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 230\TRUCK DC 9 [---04>---08]\Instrument panel\NCL Instrument Panel 2	√	√	√	√		√	
Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 230\TRUCK DC 9 [---04>---08]\Radio\AUS Audio system	√	√	√				
Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 230\TRUCK DC 9 [---04>---08]\Retarder\RET Retarder	√	√	√	√		√	
Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 230\TRUCK DC 9 [---04>---08]\Suspensions\SMS Suspension management system	√	√	√	√			0006, 0007, 0014
Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 230\TRUCK DC 9 [---04>---08]\Tachograph\DTCO Tachograph	√	√	√				
Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 230\TRUCK DC 9 [---04>---08]\Tachograph\MTCO Tachograph	√	√	√				
Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 230\TRUCK DC 9 [---04>---08]\Tire pressure\TPM - Tires Pressure Monitoring System	√	√	√				
Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 230\TRUCK DC 9 [---04>---08]\Transmission\GMS - Gear management system A4	√	√	√			√	
Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 230\TRUCK DC 9 [---04>---08]\Transmission\GMS - Gear management system OPC	√	√	√	√		√	0005
Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 230\TRUCK DC 9 [---04>---08]\Transmission\GMS - Gear management system Opticruise 5	√	√	√	√		√	0009, 0011, 0018
Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 230\TRUCK DC 9 [---04>---08]\Transmission\GMS - GMS Opticruise 5	√	√	√	√		√	0009, 0011, 0018
Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 230\TRUCK DC 9 [---04>---08]\Transport information system\RTI - Road Transport Informatics	√	√	√				
Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 270\TRUCK DC 9 [---04>---08]\ABS\BMS Brake management system-ABS E	√	√	√	√		√	
Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 270\TRUCK DC 9 [---04>---08]\Aid for keeping lane\LDW Monitor traffic lane	√	√	√				
Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 270\TRUCK DC 9 [---04>---08]\Air conditioner\CCS Climate control system	√	√	√	√		√	
Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 270\TRUCK DC 9 [---04>---08]\Airbag\CSS Climate safety system	√	√	√				
Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 270\TRUCK DC 9 [---04>---08]\Alarm\LAS Locking and alarm system	√	√	√				
Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 270\TRUCK DC 9 [---04>---08]\Auxiliary heating\ATA Auxiliary heating system air-to-air	√	√	√	√			
Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 270\TRUCK DC 9 [---04>---08]\Auxiliary heating\WTA Auxiliary heating system water-to-air	√	√	√				
Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 270\TRUCK DC 9 [---04>---08]\Chassis equipment and design\BWS Preparation system	√	√	√				
Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 270\TRUCK DC 9 [---04>---08]\Comfort system\CTS Clock and Time System	√	√	√				
Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 270\TRUCK DC 9 [---04>---08]\Compressed air reserve system\APS Compressed air power supply(Scania protocol)	√	√	√	√			0003
Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 270\TRUCK DC 9 [---04>---08]\Compressed air reserve system\APS Compressed air power supply(Wabco protocol)	√	√	√	√			
Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 270\TRUCK DC 9 [---04>---08]\Diesel injection\EEC-Exhaust gas treatment	√	√	√	√		√	
Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 270\TRUCK DC 9 [---04>---08]\Diesel injection\EMS Engine management system S6-S7	√	√	√	√		√	0002, 0015, 0017
Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 270\TRUCK DC 9 [---04>---08]\Diesel injection\EMS Engine management system S8(8 Cylindres)	√	√	√	√		√	0001
Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 270\TRUCK DC 9 [---04>---08]\Diesel injection\EMS Engine management system DC13(6 Cylindres)	√	√	√	√		√	
Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 270\TRUCK DC 9 [---04>---08]\Distance control\DAS Adaptive Cruise Control	√	√	√				
Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 270\TRUCK DC 9 [---04>---08]\Distance control\DIS Adaptive Cruise Control	√	√	√				
Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 270\TRUCK DC 9 [---04>---08]\EBS\BMS Brake management system 5.0 (4x2)	√	√	√	√		√	0004
Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 270\TRUCK DC 9 [---04>---08]\EBS\BMS Brake management system 5.0 (6x2 - 6x4)	√	√	√	√		√	0004

Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 270\TRUCK DC 9 [---04>---08]\EBS\BMS Brake management system 5.0 (8x2)	√	√	√	√		√	0004
Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 270\TRUCK DC 9 [---04>---08]\ECU external light\VIS Visibility system	√	√	√	√		√	
Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 270\TRUCK DC 9 [---04>---08]\Engine-vehicle adjustment\COO Coordinator module	√	√	√	√		√	
Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 270\TRUCK DC 9 [---04>---08]\Engine-vehicle adjustment\COO7 (Coordinator)	√	√	√	√		√	
Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 270\TRUCK DC 9 [---04>---08]\Four-wheel drive\AWD ALL-Wheel Drive	√	√	√				
Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 270\TRUCK DC 9 [---04>---08]\Instrument panel\NCL Instrument Panel 1	√	√	√	√		√	
Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 270\TRUCK DC 9 [---04>---08]\Instrument panel\NCL Instrument Panel 2	√	√	√	√		√	
Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 270\TRUCK DC 9 [---04>---08]\Radio\AUS Audio system	√	√	√				
Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 270\TRUCK DC 9 [---04>---08]\Retarder\RET Retarder	√	√	√	√		√	
Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 270\TRUCK DC 9 [---04>---08]\Suspensions\SMS Suspension management system	√	√	√	√			0006, 0007, 0014
Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 270\TRUCK DC 9 [---04>---08]\Tachograph\DTCO Tachograph	√	√	√				
Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 270\TRUCK DC 9 [---04>---08]\Tachograph\MTCO Tachograph	√	√	√				
Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 270\TRUCK DC 9 [---04>---08]\Tire pressure\TPM - Tires Pressure Monitoring System	√	√	√				
Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 270\TRUCK DC 9 [---04>---08]\Transmission\GMS - Gear management system A4	√	√	√			√	
Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 270\TRUCK DC 9 [---04>---08]\Transmission\GMS - Gear management system OPC	√	√	√	√		√	0005
Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 270\TRUCK DC 9 [---04>---08]\Transmission\GMS - Gear management system Opticruise 5	√	√	√	√		√	0009, 0011, 0018
Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 270\TRUCK DC 9 [---04>---08]\Transmission\GMS - GMS Opticruise 5	√	√	√	√		√	0009, 0011, 0018
Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 270\TRUCK DC 9 [---04>---08]\Transport information system\RTI - Road Transport Informatics	√	√	√				
Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 280\TRUCK DC 9 [---08>---13]\ABS\BMS Brake management system-ABS E	√	√	√	√		√	
Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 280\TRUCK DC 9 [---08>---13]\Aid for keeping lane\LDW Monitor traffic lane	√	√	√				
Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 280\TRUCK DC 9 [---08>---13]\Air conditioner\CCS Climate control system	√	√	√	√		√	
Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 280\TRUCK DC 9 [---08>---13]\Airbag\CSS Climate safety system	√	√	√				
Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 280\TRUCK DC 9 [---08>---13]\Alarm\LAS Locking and alarm system	√	√	√				
Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 280\TRUCK DC 9 [---08>---13]\Auxiliary heating\ATA Auxiliary heating system air-to-air	√	√	√	√			
Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 280\TRUCK DC 9 [---08>---13]\Auxiliary heating\WTA Auxiliary heating system water-to-air	√	√	√				
Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 280\TRUCK DC 9 [---08>---13]\Chassis equipment and design\BWS Preparation system	√	√	√				
Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 280\TRUCK DC 9 [---08>---13]\Comfort system\CTS Clock and Time System	√	√	√				
Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 280\TRUCK DC 9 [---08>---13]\Compressed air reserve system\APS Compressed air power supply(Scania protocol)	√	√	√	√			0003
Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 280\TRUCK DC 9 [---08>---13]\Compressed air reserve system\APS Compressed air power supply(Wabco protocol)	√	√	√	√			
Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 280\TRUCK DC 9 [---08>---13]\Diesel injection\EEC-Exhaust gas treatment	√	√	√	√		√	
Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 280\TRUCK DC 9 [---08>---13]\Diesel injection\EMS Engine management system S6-S7	√	√	√	√		√	0002, 0015, 0017
Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 280\TRUCK DC 9 [---08>---13]\Diesel injection\EMS Engine management system S8(8 Cylindres)	√	√	√	√		√	0001
Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 280\TRUCK DC 9 [---08>---13]\Diesel injection\EMS Engine management system DC13(6 Cylindres)	√	√	√	√		√	
Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 280\TRUCK DC 9 [---08>---13]\Distance control\DAS Adaptive Cruise Control	√	√	√				
Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 280\TRUCK DC 9 [---08>---13]\Distance control\DIS Adaptive Cruise Control	√	√	√				

Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 280\TRUCK DC 9 [---08>---13]\EBS\BMS Brake management system 5.0 (4x2)	√	√	√	√		√	0004
Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 280\TRUCK DC 9 [---08>---13]\EBS\BMS Brake management system 5.0 (6x2 - 6x4)	√	√	√	√		√	0004
Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 280\TRUCK DC 9 [---08>---13]\EBS\BMS Brake management system 5.0 (8x2)	√	√	√	√		√	0004
Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 280\TRUCK DC 9 [---08>---13]\ECU external light\VIS Visibility system	√	√	√	√		√	
Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 280\TRUCK DC 9 [---08>---13]\Engine-vehicle adjustment\COO Coordinator module	√	√	√	√		√	
Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 280\TRUCK DC 9 [---08>---13]\Engine-vehicle adjustment\COO7 (Coordinator)	√	√	√	√		√	
Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 280\TRUCK DC 9 [---08>---13]\Four-wheel drive\AWD ALL-Wheel Drive	√	√	√				
Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 280\TRUCK DC 9 [---08>---13]\Instrument panel\NCL Instrument Panel 1	√	√	√	√		√	
Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 280\TRUCK DC 9 [---08>---13]\Instrument panel\NCL Instrument Panel 2	√	√	√	√		√	
Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 280\TRUCK DC 9 [---08>---13]\Radio\AUS Audio system	√	√	√				
Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 280\TRUCK DC 9 [---08>---13]\Retarder\RET Retarder	√	√	√	√		√	
Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 280\TRUCK DC 9 [---08>---13]\Suspensions\SMS Suspension management system	√	√	√	√			0006, 0007, 0014
Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 280\TRUCK DC 9 [---08>---13]\Tachograph\DTCO Tachograph	√	√	√				
Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 280\TRUCK DC 9 [---08>---13]\Tachograph\MTCO Tachograph	√	√	√				
Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 280\TRUCK DC 9 [---08>---13]\Tire pressure\TPM - Tires Pressure Monitoring System	√	√	√				
Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 280\TRUCK DC 9 [---08>---13]\Transmission\GMS - Gear management system A4	√	√	√			√	
Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 280\TRUCK DC 9 [---08>---13]\Transmission\GMS - Gear management system OPC	√	√	√	√		√	0005
Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 280\TRUCK DC 9 [---08>---13]\Transmission\GMS - Gear management system Opticruise 5	√	√	√	√		√	0009, 0011, 0018
Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 280\TRUCK DC 9 [---08>---13]\Transmission\GMS - GMS Opticruise 5	√	√	√	√		√	0009, 0011, 0018
Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 280\TRUCK DC 9 [---08>---13]\Transport information system\RTI - Road Transport Informatics	√	√	√				
Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 310\TRUCK DC 9 [---04>---13]\ABS\BMS Brake management system-ABS E	√	√	√	√		√	
Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 310\TRUCK DC 9 [---04>---13]\Aid for keeping lane\LDW Monitor traffic lane	√	√	√				
Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 310\TRUCK DC 9 [---04>---13]\Air conditioner\CCS Climate control system	√	√	√	√		√	
Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 310\TRUCK DC 9 [---04>---13]\Airbag\CSS Climate safety system	√	√	√				
Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 310\TRUCK DC 9 [---04>---13]\Alarm\LAS Locking and alarm system	√	√	√				
Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 310\TRUCK DC 9 [---04>---13]\Auxiliary heating\ATA Auxiliary heating system air-to-air	√	√	√	√			
Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 310\TRUCK DC 9 [---04>---13]\Auxiliary heating\WTA Auxiliary heating system water-to-air	√	√	√				
Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 310\TRUCK DC 9 [---04>---13]\Chassis equipment and design\BWS Preparation system	√	√	√				
Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 310\TRUCK DC 9 [---04>---13]\Comfort system\CTS Clock and Time System	√	√	√				
Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 310\TRUCK DC 9 [---04>---13]\Compressed air reserve system\APS Compressed air power supply(Scania protocol)	√	√	√	√			0003
Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 310\TRUCK DC 9 [---04>---13]\Compressed air reserve system\APS Compressed air power supply(Wabco protocol)	√	√	√	√			
Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 310\TRUCK DC 9 [---04>---13]\Diesel injection\EEC-Exhaust gas treatment	√	√	√	√		√	
Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 310\TRUCK DC 9 [---04>---13]\Diesel injection\EMS Engine management system S6-S7	√	√	√	√		√	0002, 0015, 0017
Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 310\TRUCK DC 9 [---04>---13]\Diesel injection\EMS Engine management system S8(8 Cylindres)	√	√	√	√		√	0001
Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 310\TRUCK DC 9 [---04>---13]\Diesel injection\EMS Engine management system DC13(6 Cylindres)	√	√	√	√		√	

Scania\Divided By Vehicle\TRUCK\R-Series\Engine 310\TRUCK DC 9 [---04>---13]\Distance control\DAS Adaptive Cruise Control	√	√	√				
Scania\Divided By Vehicle\TRUCK\R-Series\Engine 310\TRUCK DC 9 [---04>---13]\Distance control\DIS Adaptive Cruise Control	√	√	√				
Scania\Divided By Vehicle\TRUCK\R-Series\Engine 310\TRUCK DC 9 [---04>---13]\EBS\BMS Brake management system 5.0 (4x2)	√	√	√	√		√	0004
Scania\Divided By Vehicle\TRUCK\R-Series\Engine 310\TRUCK DC 9 [---04>---13]\EBS\BMS Brake management system 5.0 (6x2 - 6x4)	√	√	√	√		√	0004
Scania\Divided By Vehicle\TRUCK\R-Series\Engine 310\TRUCK DC 9 [---04>---13]\EBS\BMS Brake management system 5.0 (8x2)	√	√	√	√		√	0004
Scania\Divided By Vehicle\TRUCK\R-Series\Engine 310\TRUCK DC 9 [---04>---13]\ECU external light\VIS Visibility system	√	√	√	√		√	
Scania\Divided By Vehicle\TRUCK\R-Series\Engine 310\TRUCK DC 9 [---04>---13]\Engine-vehicle adjustment\COO Coordinator module	√	√	√	√		√	
Scania\Divided By Vehicle\TRUCK\R-Series\Engine 310\TRUCK DC 9 [---04>---13]\Engine-vehicle adjustment\COO7 (Coordinator)	√	√	√	√		√	
Scania\Divided By Vehicle\TRUCK\R-Series\Engine 310\TRUCK DC 9 [---04>---13]\Four-wheel drive\AWD ALL-Wheel Drive	√	√	√				
Scania\Divided By Vehicle\TRUCK\R-Series\Engine 310\TRUCK DC 9 [---04>---13]\Instrument panel\NCL Instrument Panel 1	√	√	√	√		√	
Scania\Divided By Vehicle\TRUCK\R-Series\Engine 310\TRUCK DC 9 [---04>---13]\Instrument panel\NCL Instrument Panel 2	√	√	√	√		√	
Scania\Divided By Vehicle\TRUCK\R-Series\Engine 310\TRUCK DC 9 [---04>---13]\Radio\AUS Audio system	√	√	√				
Scania\Divided By Vehicle\TRUCK\R-Series\Engine 310\TRUCK DC 9 [---04>---13]\Retarder\RET Retarder	√	√	√	√		√	
Scania\Divided By Vehicle\TRUCK\R-Series\Engine 310\TRUCK DC 9 [---04>---13]\Suspensions\SMS Suspension management system	√	√	√	√			0006, 0007, 0014
Scania\Divided By Vehicle\TRUCK\R-Series\Engine 310\TRUCK DC 9 [---04>---13]\Tachograph\DTCO Tachograph	√	√	√				
Scania\Divided By Vehicle\TRUCK\R-Series\Engine 310\TRUCK DC 9 [---04>---13]\Tachograph\MTCO Tachograph	√	√	√				
Scania\Divided By Vehicle\TRUCK\R-Series\Engine 310\TRUCK DC 9 [---04>---13]\Tire pressure\TPM - Tires Pressure Monitoring System	√	√	√				
Scania\Divided By Vehicle\TRUCK\R-Series\Engine 310\TRUCK DC 9 [---04>---13]\Transmission\GMS - Gear management system A4	√	√	√			√	
Scania\Divided By Vehicle\TRUCK\R-Series\Engine 310\TRUCK DC 9 [---04>---13]\Transmission\GMS - Gear management system OPC	√	√	√	√		√	0005
Scania\Divided By Vehicle\TRUCK\R-Series\Engine 310\TRUCK DC 9 [---04>---13]\Transmission\GMS - Gear management system Opticruise 5	√	√	√	√		√	0009, 0011, 0018
Scania\Divided By Vehicle\TRUCK\R-Series\Engine 310\TRUCK DC 9 [---04>---13]\Transmission\GMS - GMS Opticruise 5	√	√	√	√		√	0009, 0011, 0018
Scania\Divided By Vehicle\TRUCK\R-Series\Engine 310\TRUCK DC 9 [---04>---13]\Transport information system\RTI - Road Transport Informatics	√	√	√				
Scania\Divided By Vehicle\TRUCK\R-Series\Engine 320\TRUCK DC 9 XPI EU5 [---08>---13]\ABS\BMS Brake management system-ABS E	√	√	√	√		√	
Scania\Divided By Vehicle\TRUCK\R-Series\Engine 320\TRUCK DC 9 XPI EU5 [---08>---13]\Aid for keeping lane\LDW Monitor traffic lane	√	√	√				
Scania\Divided By Vehicle\TRUCK\R-Series\Engine 320\TRUCK DC 9 XPI EU5 [---08>---13]\Air conditioner\CCS Climate control system	√	√	√	√		√	
Scania\Divided By Vehicle\TRUCK\R-Series\Engine 320\TRUCK DC 9 XPI EU5 [---08>---13]\Airbag\CSS Climate safety system	√	√	√				
Scania\Divided By Vehicle\TRUCK\R-Series\Engine 320\TRUCK DC 9 XPI EU5 [---08>---13]\Alarm\LAS Locking and alarm system	√	√	√				
Scania\Divided By Vehicle\TRUCK\R-Series\Engine 320\TRUCK DC 9 XPI EU5 [---08>---13]\Auxiliary heating\ATA Auxiliary heating system air-to-air	√	√	√	√			
Scania\Divided By Vehicle\TRUCK\R-Series\Engine 320\TRUCK DC 9 XPI EU5 [---08>---13]\Auxiliary heating\WTA Auxiliary heating system water-to-air	√	√	√				
Scania\Divided By Vehicle\TRUCK\R-Series\Engine 320\TRUCK DC 9 XPI EU5 [---08>---13]\Chassis equipment and design\BWS Preparation system	√	√	√				
Scania\Divided By Vehicle\TRUCK\R-Series\Engine 320\TRUCK DC 9 XPI EU5 [---08>---13]\Comfort system\CTS Clock and Time System	√	√	√				
Scania\Divided By Vehicle\TRUCK\R-Series\Engine 320\TRUCK DC 9 XPI EU5 [---08>---13]\Compressed air reserve system\APS Compressed air power supply(Scania protocol)	√	√	√	√			0003
Scania\Divided By Vehicle\TRUCK\R-Series\Engine 320\TRUCK DC 9 XPI EU5 [---08>---13]\Compressed air reserve system\APS Compressed air power supply(Wabco protocol)	√	√	√	√			
Scania\Divided By Vehicle\TRUCK\R-Series\Engine 320\TRUCK DC 9 XPI EU5 [---08>---13]\Diesel injection\IEEC-Exhaust gas treatment	√	√	√	√		√	
Scania\Divided By Vehicle\TRUCK\R-Series\Engine 320\TRUCK DC 9 XPI EU5 [---08>---13]\Diesel injection\EMS Engine management system S6-S7	√	√	√	√		√	0002, 0015, 0017

Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 320\TRUCK DC 9 XPI EU5 [---08>---13]\Diesel injection\EMS Engine management system S8(8 Cylindes)	√	√	√	√		√	0001
Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 320\TRUCK DC 9 XPI EU5 [---08>---13]\Diesel injection\EMS Engine management system DC13(6 Cylindes)	√	√	√	√		√	
Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 320\TRUCK DC 9 XPI EU5 [---08>---13]\Distance control\DAS Adaptive Cruise Control	√	√	√				
Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 320\TRUCK DC 9 XPI EU5 [---08>---13]\Distance control\DIS Adaptive Cruise Control	√	√	√				
Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 320\TRUCK DC 9 XPI EU5 [---08>---13]\EBS\BMS Brake management system 5.0 (4x2)	√	√	√	√		√	0004
Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 320\TRUCK DC 9 XPI EU5 [---08>---13]\EBS\BMS Brake management system 5.0 (6x2 - 6x4)	√	√	√	√		√	0004
Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 320\TRUCK DC 9 XPI EU5 [---08>---13]\EBS\BMS Brake management system 5.0 (8x2)	√	√	√	√		√	0004
Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 320\TRUCK DC 9 XPI EU5 [---08>---13]\ECU external light\VIS Visibility system	√	√	√	√		√	
Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 320\TRUCK DC 9 XPI EU5 [---08>---13]\Engine-vehicle adjustment\COO Coordinator module	√	√	√	√		√	
Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 320\TRUCK DC 9 XPI EU5 [---08>---13]\Engine-vehicle adjustment\COO7 (Coordinator)	√	√	√	√		√	
Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 320\TRUCK DC 9 XPI EU5 [---08>---13]\Four-wheel drive\AWD ALL-Wheel Drive	√	√	√				
Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 320\TRUCK DC 9 XPI EU5 [---08>---13]\Instrument panel\NCL Instrument Panel 1	√	√	√	√		√	
Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 320\TRUCK DC 9 XPI EU5 [---08>---13]\Instrument panel\NCL Instrument Panel 2	√	√	√	√		√	
Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 320\TRUCK DC 9 XPI EU5 [---08>---13]\Radio\AUS Audio system	√	√	√				
Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 320\TRUCK DC 9 XPI EU5 [---08>---13]\Retarder\RET Retarder	√	√	√	√		√	
Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 320\TRUCK DC 9 XPI EU5 [---08>---13]\Suspensions\SMS Supension management system	√	√	√	√			0006, 0007, 0014
Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 320\TRUCK DC 9 XPI EU5 [---08>---13]\Tachograph\DTCO Tachograph	√	√	√				
Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 320\TRUCK DC 9 XPI EU5 [---08>---13]\Tachograph\MTCO Tachograph	√	√	√				
Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 320\TRUCK DC 9 XPI EU5 [---08>---13]\Tire pressure\TPM - Tires Pressure Monitoring System	√	√	√				
Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 320\TRUCK DC 9 XPI EU5 [---08>---13]\Transmission\GMS - Gear management system A4	√	√	√			√	
Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 320\TRUCK DC 9 XPI EU5 [---08>---13]\Transmission\GMS - Gear management system OPC	√	√	√	√		√	0005
Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 320\TRUCK DC 9 XPI EU5 [---08>---13]\Transmission\GMS - Gear management system Opticruise 5	√	√	√	√		√	0009, 0011, 0018
Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 320\TRUCK DC 9 XPI EU5 [---08>---13]\Transmission\GMS - GMS Opticruise 5	√	√	√	√		√	0009, 0011, 0018
Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 320\TRUCK DC 9 XPI EU5 [---08>---13]\Transport information system\RTI - Road Transport Informatics	√	√	√				
Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 340\TRUCK DC 11 [---05>---08]\ABS\BMS Brake management system-ABS E	√	√	√	√		√	
Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 340\TRUCK DC 11 [---05>---08]\Aid for keeping lane\LDW Monitor traffic lane	√	√	√				
Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 340\TRUCK DC 11 [---05>---08]\Air conditioner\CCS Climate control system	√	√	√	√		√	
Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 340\TRUCK DC 11 [---05>---08]\Airbag\CSS Climate safety system	√	√	√				
Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 340\TRUCK DC 11 [---05>---08]\Alarm\LAS Locking and alarm system	√	√	√				
Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 340\TRUCK DC 11 [---05>---08]\Auxiliary heating\ATA Auxiliary heating system air-to-air	√	√	√	√			
Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 340\TRUCK DC 11 [---05>---08]\Auxiliary heating\WTA Auxiliary heating system water-to-air	√	√	√				
Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 340\TRUCK DC 11 [---05>---08]\Chassis equipment and design\BWS Preparation system	√	√	√				
Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 340\TRUCK DC 11 [---05>---08]\Comfort system\CTS Clock and Time System	√	√	√				
Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 340\TRUCK DC 11 [---05>---08]\Compressed air reserve system\APS Compressed air power supply(Scania protocol)	√	√	√	√			0003
Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 340\TRUCK DC 11 [---05>---08]\Compressed air reserve system\APS Compressed air power supply(Wabco protocol)	√	√	√	√			

Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 340\TRUCK DC 11 [---05>---08]\Diesel injection\EEC-Exhaust gas treatment	√	√	√	√		√	
Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 340\TRUCK DC 11 [---05>---08]\Diesel injection\EMS Engine management system S6-S7	√	√	√	√		√	0002, 0015, 0017
Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 340\TRUCK DC 11 [---05>---08]\Diesel injection\EMS Engine management system S8(8 Cylindes)	√	√	√	√		√	0001
Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 340\TRUCK DC 11 [---05>---08]\Diesel injection\EMS Engine management system DC13(6 Cylindes)	√	√	√	√		√	
Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 340\TRUCK DC 11 [---05>---08]\Distance control\DAS Adaptive Cruise Control	√	√	√				
Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 340\TRUCK DC 11 [---05>---08]\Distance control\DIS Adaptive Cruise Control	√	√	√				
Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 340\TRUCK DC 11 [---05>---08]\EBS\BMS Brake management system 5.0 (4x2)	√	√	√	√		√	0004
Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 340\TRUCK DC 11 [---05>---08]\EBS\BMS Brake management system 5.0 (6x2 - 6x4)	√	√	√	√		√	0004
Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 340\TRUCK DC 11 [---05>---08]\EBS\BMS Brake management system 5.0 (8x2)	√	√	√	√		√	0004
Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 340\TRUCK DC 11 [---05>---08]\ECU external light\VIS Visibility system	√	√	√	√		√	
Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 340\TRUCK DC 11 [---05>---08]\Engine-vehicle adjustment\COO Coordinator module	√	√	√	√		√	
Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 340\TRUCK DC 11 [---05>---08]\Engine-vehicle adjustment\COO7 (Coordinator)	√	√	√	√		√	
Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 340\TRUCK DC 11 [---05>---08]\Four-wheel drive\AWD ALL-Wheel Drive	√	√	√				
Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 340\TRUCK DC 11 [---05>---08]\Instrument pane\NCL Instrument Panel 1	√	√	√	√		√	
Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 340\TRUCK DC 11 [---05>---08]\Instrument pane\NCL Instrument Panel 2	√	√	√	√		√	
Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 340\TRUCK DC 11 [---05>---08]\Radio\AUS Audio system	√	√	√				
Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 340\TRUCK DC 11 [---05>---08]\Retarder\RET Retarder	√	√	√	√		√	
Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 340\TRUCK DC 11 [---05>---08]\Suspensions\SMS Supension management system	√	√	√	√			0006, 0007, 0014
Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 340\TRUCK DC 11 [---05>---08]\Tachograph\DTCO Tachograph	√	√	√				
Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 340\TRUCK DC 11 [---05>---08]\Tachograph\WTCO Tachograph	√	√	√				
Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 340\TRUCK DC 11 [---05>---08]\Tire pressure\TPM - Tires Pressure Monitoring System	√	√	√				
Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 340\TRUCK DC 11 [---05>---08]\Transmission\GMS - Gear management system A4	√	√	√			√	
Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 340\TRUCK DC 11 [---05>---08]\Transmission\GMS - Gear management system OPC	√	√	√	√		√	0005
Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 340\TRUCK DC 11 [---05>---08]\Transmission\GMS - Gear management system Opticruise 5	√	√	√	√		√	0009, 0011, 0018
Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 340\TRUCK DC 11 [---05>---08]\Transmission\GMS - GMS Opticruise 5	√	√	√	√		√	0009, 0011, 0018
Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 340\TRUCK DC 11 [---05>---08]\Transport information system\RTI - Road Transport Informatics	√	√	√				
Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 340\TRUCK DC 12 HPI [---05>---08]\ABS\BMS Brake management system-ABS E	√	√	√	√		√	
Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 340\TRUCK DC 12 HPI [---05>---08]\Aid for keeping lane\LDW Monitor traffic lane	√	√	√				
Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 340\TRUCK DC 12 HPI [---05>---08]\Air conditioner\CCS Climate control system	√	√	√	√		√	
Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 340\TRUCK DC 12 HPI [---05>---08]\Airbag\CSS Climate safety system	√	√	√				
Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 340\TRUCK DC 12 HPI [---05>---08]\Alarm\LAS Locking and alarm system	√	√	√				
Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 340\TRUCK DC 12 HPI [---05>---08]\Auxiliary heating\ATA Auxiliary heating system air-to-air	√	√	√	√			
Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 340\TRUCK DC 12 HPI [---05>---08]\Auxiliary heating\WTA Auxiliary heating system water-to-air	√	√	√				
Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 340\TRUCK DC 12 HPI [---05>---08]\Chassis equipment and design\BWS Preparation system	√	√	√				
Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 340\TRUCK DC 12 HPI [---05>---08]\Comfort system\CTS Clock and Time System	√	√	√				

Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 340\TRUCK DC 12 HPI [---05>---08]\Compressed air reserve system\APS Compressed air power supply(Scania protocol)	√	√	√	√			0003
Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 340\TRUCK DC 12 HPI [---05>---08]\Compressed air reserve system\APS Compressed air power supply(Wabco protocol)	√	√	√	√			
Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 340\TRUCK DC 12 HPI [---05>---08]\Diesel injection\EEC-Exhaust gas treatment	√	√	√	√		√	
Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 340\TRUCK DC 12 HPI [---05>---08]\Diesel injection\EMS Engine management system S6-S7	√	√	√	√		√	0002, 0015, 0017
Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 340\TRUCK DC 12 HPI [---05>---08]\Diesel injection\EMS Engine management system S8(8 Cylindes)	√	√	√	√		√	0001
Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 340\TRUCK DC 12 HPI [---05>---08]\Diesel injection\EMS Engine management system DC13(6 Cylindes)	√	√	√	√		√	
Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 340\TRUCK DC 12 HPI [---05>---08]\Distance control\DAS Adaptive Cruise Control	√	√	√				
Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 340\TRUCK DC 12 HPI [---05>---08]\Distance control\DIS Adaptive Cruise Control	√	√	√				
Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 340\TRUCK DC 12 HPI [---05>---08]\EBS\BMS Brake management system 5.0 (4x2)	√	√	√	√		√	0004
Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 340\TRUCK DC 12 HPI [---05>---08]\EBS\BMS Brake management system 5.0 (6x2 - 6x4)	√	√	√	√		√	0004
Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 340\TRUCK DC 12 HPI [---05>---08]\EBS\BMS Brake management system 5.0 (8x2)	√	√	√	√		√	0004
Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 340\TRUCK DC 12 HPI [---05>---08]\ECU external light\VIS Visibility system	√	√	√	√		√	
Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 340\TRUCK DC 12 HPI [---05>---08]\Engine-vehicle adjustment\COO Coordinator module	√	√	√	√		√	
Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 340\TRUCK DC 12 HPI [---05>---08]\Engine-vehicle adjustment\COO7 (Coordinator)	√	√	√	√		√	
Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 340\TRUCK DC 12 HPI [---05>---08]\Four-wheel drive\AWD ALL-Wheel Drive	√	√	√				
Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 340\TRUCK DC 12 HPI [---05>---08]\Instrument panel\ICL Instrument Panel 1	√	√	√	√		√	
Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 340\TRUCK DC 12 HPI [---05>---08]\Instrument panel\ICL Instrument Panel 2	√	√	√	√		√	
Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 340\TRUCK DC 12 HPI [---05>---08]\Radio\AUS Audio system	√	√	√				
Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 340\TRUCK DC 12 HPI [---05>---08]\Retarder\RET Retarder	√	√	√	√		√	
Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 340\TRUCK DC 12 HPI [---05>---08]\Suspensions\SMS Supension management system	√	√	√	√			0006, 0007, 0014
Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 340\TRUCK DC 12 HPI [---05>---08]\Tachograph\DTCO Tachograph	√	√	√				
Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 340\TRUCK DC 12 HPI [---05>---08]\Tachograph\MTCO Tachograph	√	√	√				
Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 340\TRUCK DC 12 HPI [---05>---08]\Tire pressure\TPM - Tires Pressure Monitoring System	√	√	√				
Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 340\TRUCK DC 12 HPI [---05>---08]\Transmission\GMS - Gear management system A4	√	√	√			√	
Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 340\TRUCK DC 12 HPI [---05>---08]\Transmission\GMS - Gear management system OPC	√	√	√	√		√	0005
Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 340\TRUCK DC 12 HPI [---05>---08]\Transmission\GMS - Gear management system Opticruise 5	√	√	√	√		√	0009, 0011, 0018
Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 340\TRUCK DC 12 HPI [---05>---08]\Transmission\GMS - GMS Opticruise 5	√	√	√	√		√	0009, 0011, 0018
Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 340\TRUCK DC 12 HPI [---05>---08]\Transport information system\RTI - Road Transport Informatics	√	√	√				
Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 360\TRUCK DC 13 XPI EU5 [---08>---13]\ABS\BMS Brake management system-ABS E	√	√	√	√		√	
Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 360\TRUCK DC 13 XPI EU5 [---08>---13]\Aid for keeping lane\LDW Monitor traffic lane	√	√	√				
Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 360\TRUCK DC 13 XPI EU5 [---08>---13]\Air conditioner\CCS Climate control system	√	√	√	√		√	
Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 360\TRUCK DC 13 XPI EU5 [---08>---13]\Airbag\CSS Climate safety system	√	√	√				
Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 360\TRUCK DC 13 XPI EU5 [---08>---13]\Alarm\LAS Locking and alarm system	√	√	√				
Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 360\TRUCK DC 13 XPI EU5 [---08>---13]\Auxiliary heating\ATA Auxiliary heating system air-to-air	√	√	√	√			
Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 360\TRUCK DC 13 XPI EU5 [---08>---13]\Auxiliary heating\WTA Auxiliary heating system water-to-air	√	√	√				

Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 360\TRUCK DC 13 XPI EU5 [---08>---13]\Chassis equipment and design\BWS Preparation system	√	√	√				
Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 360\TRUCK DC 13 XPI EU5 [---08>---13]\Comfort system\CTS Clock and Time System	√	√	√				
Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 360\TRUCK DC 13 XPI EU5 [---08>---13]\Compressed air reserve system\APS Compressed air power supply(Scania protocol)	√	√	√	√			0003
Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 360\TRUCK DC 13 XPI EU5 [---08>---13]\Compressed air reserve system\APS Compressed air power supply(Wabco protocol)	√	√	√	√			
Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 360\TRUCK DC 13 XPI EU5 [---08>---13]\Diesel injection\EEC-Exhaust gas treatment	√	√	√	√		√	
Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 360\TRUCK DC 13 XPI EU5 [---08>---13]\Diesel injection\EMS Engine management system S6-S7	√	√	√	√		√	0002, 0015, 0017
Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 360\TRUCK DC 13 XPI EU5 [---08>---13]\Diesel injection\EMS Engine management system S8(8 Cylindes)	√	√	√	√		√	0001
Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 360\TRUCK DC 13 XPI EU5 [---08>---13]\Diesel injection\EMS Engine management system DC13(6 Cylindes)	√	√	√	√		√	
Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 360\TRUCK DC 13 XPI EU5 [---08>---13]\Distance control\DAS Adaptive Cruise Control	√	√	√				
Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 360\TRUCK DC 13 XPI EU5 [---08>---13]\Distance control\DIS Adaptive Cruise Control	√	√	√				
Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 360\TRUCK DC 13 XPI EU5 [---08>---13]\EBS\BMS Brake management system 5.0 (4x2)	√	√	√	√		√	0004
Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 360\TRUCK DC 13 XPI EU5 [---08>---13]\EBS\BMS Brake management system 5.0 (6x2 - 6x4)	√	√	√	√		√	0004
Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 360\TRUCK DC 13 XPI EU5 [---08>---13]\EBS\BMS Brake management system 5.0 (8x2)	√	√	√	√		√	0004
Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 360\TRUCK DC 13 XPI EU5 [---08>---13]\ECU external light\VIS Visibility system	√	√	√	√		√	
Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 360\TRUCK DC 13 XPI EU5 [---08>---13]\Engine-vehicle adjustment\COO Coordinator module	√	√	√	√		√	
Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 360\TRUCK DC 13 XPI EU5 [---08>---13]\Engine-vehicle adjustment\COO7 (Coordinator)	√	√	√	√		√	
Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 360\TRUCK DC 13 XPI EU5 [---08>---13]\Four-wheel drive\AWD ALL-Wheel Drive	√	√	√				
Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 360\TRUCK DC 13 XPI EU5 [---08>---13]\Instrument pane\NCL Instrument Panel 1	√	√	√	√		√	
Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 360\TRUCK DC 13 XPI EU5 [---08>---13]\Instrument pane\NCL Instrument Panel 2	√	√	√	√		√	
Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 360\TRUCK DC 13 XPI EU5 [---08>---13]\Radio\AUS Audio system	√	√	√				
Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 360\TRUCK DC 13 XPI EU5 [---08>---13]\Retarder\RET Retarder	√	√	√	√		√	
Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 360\TRUCK DC 13 XPI EU5 [---08>---13]\Suspensions\SMS Supension management system	√	√	√	√			0006, 0007, 0014
Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 360\TRUCK DC 13 XPI EU5 [---08>---13]\Tachograph\DTCO Tachograph	√	√	√				
Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 360\TRUCK DC 13 XPI EU5 [---08>---13]\Tachograph\MTCO Tachograph	√	√	√				
Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 360\TRUCK DC 13 XPI EU5 [---08>---13]\Tire pressure\TPM - Tires Pressure Monitoring System	√	√	√				
Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 360\TRUCK DC 13 XPI EU5 [---08>---13]\Transmission\GMS - Gear management system A4	√	√	√			√	
Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 360\TRUCK DC 13 XPI EU5 [---08>---13]\Transmission\GMS - Gear management system OPC	√	√	√	√		√	0005
Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 360\TRUCK DC 13 XPI EU5 [---08>---13]\Transmission\GMS - Gear management system Opticruise 5	√	√	√	√		√	0009, 0011, 0018
Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 360\TRUCK DC 13 XPI EU5 [---08>---13]\Transmission\GMS - GMS Opticruise 5	√	√	√	√		√	0009, 0011, 0018
Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 360\TRUCK DC 13 XPI EU5 [---08>---13]\Transport information system\RTI - Road Transport Informatics	√	√	√				
Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 380\TRUCK DC 11 [---04>---08]\ABS\BMS Brake management system-ABS E	√	√	√	√		√	
Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 380\TRUCK DC 11 [---04>---08]\Aid for keeping lane\LDW Monitor traffic lane	√	√	√				
Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 380\TRUCK DC 11 [---04>---08]\Air conditioner\CCS Climate control system	√	√	√	√		√	
Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 380\TRUCK DC 11 [---04>---08]\Airbag\CSS Climate safety system	√	√	√				
Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 380\TRUCK DC 11 [---04>---08]\Alarm\LAS Locking and alarm system	√	√	√				

Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 380\TRUCK DC 11 [---04>---08]\Auxiliary heating\ATA Auxiliary heating system air-to-air	√	√	√	√			
Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 380\TRUCK DC 11 [---04>---08]\Auxiliary heating\WTA Auxiliary heating system water-to-air	√	√	√				
Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 380\TRUCK DC 11 [---04>---08]\Chassis equipment and design\BWS Preparation system	√	√	√				
Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 380\TRUCK DC 11 [---04>---08]\Comfort system\CTS Clock and Time System	√	√	√				
Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 380\TRUCK DC 11 [---04>---08]\Compressed air reserve system\APS Compressed air power supply(Scania protocol)	√	√	√	√			0003
Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 380\TRUCK DC 11 [---04>---08]\Compressed air reserve system\APS Compressed air power supply(Wabco protocol)	√	√	√	√			
Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 380\TRUCK DC 11 [---04>---08]\Diesel injection\EEC-Exhaust gas treatment	√	√	√	√		√	
Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 380\TRUCK DC 11 [---04>---08]\Diesel injection\EMS Engine management system S6-S7	√	√	√	√		√	0002, 0015, 0017
Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 380\TRUCK DC 11 [---04>---08]\Diesel injection\EMS Engine management system S8(8 Cylindes)	√	√	√	√		√	0001
Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 380\TRUCK DC 11 [---04>---08]\Diesel injection\EMS Engine management system DC13(6 Cylindes)	√	√	√	√		√	
Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 380\TRUCK DC 11 [---04>---08]\Distance control\DAS Adaptive Cruise Control	√	√	√				
Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 380\TRUCK DC 11 [---04>---08]\Distance control\DIS Adaptive Cruise Control	√	√	√				
Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 380\TRUCK DC 11 [---04>---08]\EBS\BMS Brake management system 5.0 (4x2)	√	√	√	√		√	0004
Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 380\TRUCK DC 11 [---04>---08]\EBS\BMS Brake management system 5.0 (6x2 - 6x4)	√	√	√	√		√	0004
Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 380\TRUCK DC 11 [---04>---08]\EBS\BMS Brake management system 5.0 (8x2)	√	√	√	√		√	0004
Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 380\TRUCK DC 11 [---04>---08]\ECU external light\VIS Visibility system	√	√	√	√		√	
Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 380\TRUCK DC 11 [---04>---08]\Engine-vehicle adjustment\COO Coordinator module	√	√	√	√		√	
Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 380\TRUCK DC 11 [---04>---08]\Engine-vehicle adjustment\COO7 (Coordinator)	√	√	√	√		√	
Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 380\TRUCK DC 11 [---04>---08]\Four-wheel drive\AWD ALL-Wheel Drive	√	√	√				
Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 380\TRUCK DC 11 [---04>---08]\Instrument pane\NCL Instrument Panel 1	√	√	√	√		√	
Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 380\TRUCK DC 11 [---04>---08]\Instrument pane\NCL Instrument Panel 2	√	√	√	√		√	
Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 380\TRUCK DC 11 [---04>---08]\Radio\AUS Audio system	√	√	√				
Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 380\TRUCK DC 11 [---04>---08]\Retarder\RET Retarder	√	√	√	√		√	
Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 380\TRUCK DC 11 [---04>---08]\Suspensions\SMS Supension management system	√	√	√	√			0006, 0007, 0014
Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 380\TRUCK DC 11 [---04>---08]\Tachograph\DTCO Tachograph	√	√	√				
Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 380\TRUCK DC 11 [---04>---08]\Tachograph\MTCO Tachograph	√	√	√				
Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 380\TRUCK DC 11 [---04>---08]\Tire pressure\TPM - Tires Pressure Monitoring System	√	√	√				
Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 380\TRUCK DC 11 [---04>---08]\Transmission\GMS - Gear management system A4	√	√	√			√	
Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 380\TRUCK DC 11 [---04>---08]\Transmission\GMS - Gear management system OPC	√	√	√	√		√	0005
Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 380\TRUCK DC 11 [---04>---08]\Transmission\GMS - Gear management system Opticruise 5	√	√	√	√		√	0009, 0011, 0018
Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 380\TRUCK DC 11 [---04>---08]\Transmission\GMS - GMS Opticruise 5	√	√	√	√		√	0009, 0011, 0018
Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 380\TRUCK DC 11 [---04>---08]\Transport information system\RTI - Road Transport Informatics	√	√	√				
Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 380\TRUCK DC 12 HPI EU5 [---08>---13]\ABS\BMS Brake management system-ABS E	√	√	√	√		√	
Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 380\TRUCK DC 12 HPI EU5 [---08>---13]\Aid for keeping lane\LDW Monitor traffic lane	√	√	√				
Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 380\TRUCK DC 12 HPI EU5 [---08>---13]\Air conditioner\CCS Climate control system	√	√	√	√		√	

Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 380\TRUCK DC 12 HPI EU5 [---08>---13]\Airbag\CSS Climate safety system	√	√	√				
Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 380\TRUCK DC 12 HPI EU5 [---08>---13]\Alarm\LAS Locking and alarm system	√	√	√				
Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 380\TRUCK DC 12 HPI EU5 [---08>---13]\Auxiliary heating\ATA Auxiliary heating system air-to-air	√	√	√	√			
Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 380\TRUCK DC 12 HPI EU5 [---08>---13]\Auxiliary heating\WTA Auxiliary heating system water-to-air	√	√	√				
Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 380\TRUCK DC 12 HPI EU5 [---08>---13]\Chassis equipment and design\BWS Preparation system	√	√	√				
Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 380\TRUCK DC 12 HPI EU5 [---08>---13]\Comfort system\CTS Clock and Time System	√	√	√				
Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 380\TRUCK DC 12 HPI EU5 [---08>---13]\Compressed air reserve system\APS Compressed air power supply(Scania protocol)	√	√	√	√			0003
Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 380\TRUCK DC 12 HPI EU5 [---08>---13]\Compressed air reserve system\APS Compressed air power supply(Wabco protocol)	√	√	√	√			
Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 380\TRUCK DC 12 HPI EU5 [---08>---13]\Diesel injection\EEC-Exhaust gas treatment	√	√	√	√		√	
Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 380\TRUCK DC 12 HPI EU5 [---08>---13]\Diesel injection\EMS Engine management system S6-S7	√	√	√	√		√	0002, 0015, 0017
Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 380\TRUCK DC 12 HPI EU5 [---08>---13]\Diesel injection\EMS Engine management system S8(8 Cylindes)	√	√	√	√		√	0001
Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 380\TRUCK DC 12 HPI EU5 [---08>---13]\Diesel injection\EMS Engine management system DC13(6 Cylindes)	√	√	√	√		√	
Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 380\TRUCK DC 12 HPI EU5 [---08>---13]\Distance control\DAS Adaptive Cruise Control	√	√	√				
Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 380\TRUCK DC 12 HPI EU5 [---08>---13]\Distance control\DIS Adaptive Cruise Control	√	√	√				
Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 380\TRUCK DC 12 HPI EU5 [---08>---13]\EBS\BMS Brake management system 5.0 (4x2)	√	√	√	√		√	0004
Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 380\TRUCK DC 12 HPI EU5 [---08>---13]\EBS\BMS Brake management system 5.0 (6x2 - 6x4)	√	√	√	√		√	0004
Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 380\TRUCK DC 12 HPI EU5 [---08>---13]\EBS\BMS Brake management system 5.0 (8x2)	√	√	√	√		√	0004
Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 380\TRUCK DC 12 HPI EU5 [---08>---13]\ECU external light\VIS Visibility system	√	√	√	√		√	
Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 380\TRUCK DC 12 HPI EU5 [---08>---13]\Engine-vehicle adjustment\COO Coordinator module	√	√	√	√		√	
Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 380\TRUCK DC 12 HPI EU5 [---08>---13]\Engine-vehicle adjustment\COO7 (Coordinator)	√	√	√	√		√	
Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 380\TRUCK DC 12 HPI EU5 [---08>---13]\Four-wheel drive\AWD ALL-Wheel Drive	√	√	√				
Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 380\TRUCK DC 12 HPI EU5 [---08>---13]\Instrument pane\NCL Instrument Panel 1	√	√	√	√		√	
Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 380\TRUCK DC 12 HPI EU5 [---08>---13]\Instrument pane\NCL Instrument Panel 2	√	√	√	√		√	
Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 380\TRUCK DC 12 HPI EU5 [---08>---13]\Radio\AUS Audio system	√	√	√				
Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 380\TRUCK DC 12 HPI EU5 [---08>---13]\Retarder\RET Retarder	√	√	√	√		√	
Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 380\TRUCK DC 12 HPI EU5 [---08>---13]\Suspensions\SMS Supension management system	√	√	√	√			0006, 0007, 0014
Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 380\TRUCK DC 12 HPI EU5 [---08>---13]\Tachograph\DTCO Tachograph	√	√	√				
Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 380\TRUCK DC 12 HPI EU5 [---08>---13]\Tachograph\MTCO Tachograph	√	√	√				
Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 380\TRUCK DC 12 HPI EU5 [---08>---13]\Tire pressure\TPM - Tires Pressure Monitoring System	√	√	√				
Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 380\TRUCK DC 12 HPI EU5 [---08>---13]\Transmission\GMS - Gear management system A4	√	√	√			√	
Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 380\TRUCK DC 12 HPI EU5 [---08>---13]\Transmission\GMS - Gear management system OPC	√	√	√	√		√	0005
Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 380\TRUCK DC 12 HPI EU5 [---08>---13]\Transmission\GMS - Gear management system Opticruise 5	√	√	√	√		√	0009, 0011, 0018
Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 380\TRUCK DC 12 HPI EU5 [---08>---13]\Transmission\GMS - GMS Opticruise 5	√	√	√	√		√	0009, 0011, 0018
Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 380\TRUCK DC 12 HPI EU5 [---08>---13]\Transport information system\RTI - Road Transport Informatics	√	√	√				
Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 380\TRUCK DC 12 HPI [---04>---08]\ABS\BMS Brake management system-ABS E	√	√	√	√		√	

Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 380\TRUCK DC 12 HPI [---04>---08]\Aid for keeping lane\LDW Monitor traffic lane	√	√	√				
Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 380\TRUCK DC 12 HPI [---04>---08]\Air conditioner\CCS Climate control system	√	√	√	√		√	
Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 380\TRUCK DC 12 HPI [---04>---08]\Airbag\CSS Climate safety system	√	√	√				
Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 380\TRUCK DC 12 HPI [---04>---08]\Alarm\LAS Locking and alarm system	√	√	√				
Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 380\TRUCK DC 12 HPI [---04>---08]\Auxiliary heating\ATA Auxiliary heating system air-to-air	√	√	√	√			
Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 380\TRUCK DC 12 HPI [---04>---08]\Auxiliary heating\WTA Auxiliary heating system water-to-air	√	√	√				
Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 380\TRUCK DC 12 HPI [---04>---08]\Chassis equipment and design\BWS Preparation system	√	√	√				
Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 380\TRUCK DC 12 HPI [---04>---08]\Comfort system\CTS Clock and Time System	√	√	√				
Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 380\TRUCK DC 12 HPI [---04>---08]\Compressed air reserve system\APS Compressed air power supply(Scania protocol)	√	√	√	√			0003
Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 380\TRUCK DC 12 HPI [---04>---08]\Compressed air reserve system\APS Compressed air power supply(Wabco protocol)	√	√	√	√			
Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 380\TRUCK DC 12 HPI [---04>---08]\Diesel injection\EEC-Exhaust gas treatment	√	√	√	√		√	
Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 380\TRUCK DC 12 HPI [---04>---08]\Diesel injection\EMS Engine management system S6-S7	√	√	√	√		√	0002, 0015, 0017
Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 380\TRUCK DC 12 HPI [---04>---08]\Diesel injection\EMS Engine management system S8(8 Cylindes)	√	√	√	√		√	0001
Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 380\TRUCK DC 12 HPI [---04>---08]\Diesel injection\EMS Engine management system DC13(6 Cylindes)	√	√	√	√		√	
Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 380\TRUCK DC 12 HPI [---04>---08]\Distance control\DAS Adaptive Cruise Control	√	√	√				
Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 380\TRUCK DC 12 HPI [---04>---08]\Distance control\DIS Adaptive Cruise Control	√	√	√				
Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 380\TRUCK DC 12 HPI [---04>---08]\EBS\BMS Brake management system 5.0 (4x2)	√	√	√	√		√	0004
Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 380\TRUCK DC 12 HPI [---04>---08]\EBS\BMS Brake management system 5.0 (6x2 - 6x4)	√	√	√	√		√	0004
Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 380\TRUCK DC 12 HPI [---04>---08]\EBS\BMS Brake management system 5.0 (8x2)	√	√	√	√		√	0004
Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 380\TRUCK DC 12 HPI [---04>---08]\ECU external light\VIS Visibility system	√	√	√	√		√	
Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 380\TRUCK DC 12 HPI [---04>---08]\Engine-vehicle adjustment\COO Coordinator module	√	√	√	√		√	
Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 380\TRUCK DC 12 HPI [---04>---08]\Engine-vehicle adjustment\COO7 (Coordinator)	√	√	√	√		√	
Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 380\TRUCK DC 12 HPI [---04>---08]\Four-wheel drive\AWD ALL-Wheel Drive	√	√	√				
Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 380\TRUCK DC 12 HPI [---04>---08]\Instrument panel\NCL Instrument Panel 1	√	√	√	√		√	
Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 380\TRUCK DC 12 HPI [---04>---08]\Instrument panel\NCL Instrument Panel 2	√	√	√	√		√	
Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 380\TRUCK DC 12 HPI [---04>---08]\Radio\AUS Audio system	√	√	√				
Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 380\TRUCK DC 12 HPI [---04>---08]\Retarder\RET Retarder	√	√	√	√		√	
Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 380\TRUCK DC 12 HPI [---04>---08]\Suspensions\SMS Supension management system	√	√	√	√			0006, 0007, 0014
Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 380\TRUCK DC 12 HPI [---04>---08]\Tachograph\DTCO Tachograph	√	√	√				
Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 380\TRUCK DC 12 HPI [---04>---08]\Tachograph\MTCO Tachograph	√	√	√				
Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 380\TRUCK DC 12 HPI [---04>---08]\Tire pressure\TPM - Tires Pressure Monitoring System	√	√	√				
Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 380\TRUCK DC 12 HPI [---04>---08]\Transmission\GMS - Gear management system A4	√	√	√			√	
Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 380\TRUCK DC 12 HPI [---04>---08]\Transmission\GMS - Gear management system OPC	√	√	√	√		√	0005
Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 380\TRUCK DC 12 HPI [---04>---08]\Transmission\GMS - Gear management system Opticruise 5	√	√	√	√		√	0009, 0011, 0018
Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 380\TRUCK DC 12 HPI [---04>---08]\Transmission\GMS - GMS Opticruise 5	√	√	√	√		√	0009, 0011, 0018

Scania\Divided By Vehicle\TRUCK\R-Series\Engine 380\TRUCK DC 12 HPI [---04>---08]\Transport information system\RTI - Road Transport Informatics	√	√	√				
Scania\Divided By Vehicle\TRUCK\R-Series\Engine 400\TRUCK DC 13 XPI EU5 [---08>---13]\ABS\BMS Brake management system-ABS E	√	√	√	√		√	
Scania\Divided By Vehicle\TRUCK\R-Series\Engine 400\TRUCK DC 13 XPI EU5 [---08>---13]\Aid for keeping lane\LDW Monitor traffic lane	√	√	√				
Scania\Divided By Vehicle\TRUCK\R-Series\Engine 400\TRUCK DC 13 XPI EU5 [---08>---13]\Air conditioner\CCS Climate control system	√	√	√	√		√	
Scania\Divided By Vehicle\TRUCK\R-Series\Engine 400\TRUCK DC 13 XPI EU5 [---08>---13]\Airbag\CSS Climate safety system	√	√	√				
Scania\Divided By Vehicle\TRUCK\R-Series\Engine 400\TRUCK DC 13 XPI EU5 [---08>---13]\Alarm\LAS Locking and alarm system	√	√	√				
Scania\Divided By Vehicle\TRUCK\R-Series\Engine 400\TRUCK DC 13 XPI EU5 [---08>---13]\Auxiliary heating\ATA Auxiliary heating system air-to-air	√	√	√	√			
Scania\Divided By Vehicle\TRUCK\R-Series\Engine 400\TRUCK DC 13 XPI EU5 [---08>---13]\Auxiliary heating\WTA Auxiliary heating system water-to-air	√	√	√				
Scania\Divided By Vehicle\TRUCK\R-Series\Engine 400\TRUCK DC 13 XPI EU5 [---08>---13]\Chassis equipment and design\BWS Preparation system	√	√	√				
Scania\Divided By Vehicle\TRUCK\R-Series\Engine 400\TRUCK DC 13 XPI EU5 [---08>---13]\Comfort system\CTS Clock and Time System	√	√	√				
Scania\Divided By Vehicle\TRUCK\R-Series\Engine 400\TRUCK DC 13 XPI EU5 [---08>---13]\Compressed air reserve system\APS Compressed air power supply(Scania protocol)	√	√	√	√			0003
Scania\Divided By Vehicle\TRUCK\R-Series\Engine 400\TRUCK DC 13 XPI EU5 [---08>---13]\Compressed air reserve system\APS Compressed air power supply(Wabco protocol)	√	√	√	√			
Scania\Divided By Vehicle\TRUCK\R-Series\Engine 400\TRUCK DC 13 XPI EU5 [---08>---13]\Diesel injection\EEC-Exhaust gas treatment	√	√	√	√		√	
Scania\Divided By Vehicle\TRUCK\R-Series\Engine 400\TRUCK DC 13 XPI EU5 [---08>---13]\Diesel injection\EMS Engine management system S6-S7	√	√	√	√		√	0002, 0015, 0017
Scania\Divided By Vehicle\TRUCK\R-Series\Engine 400\TRUCK DC 13 XPI EU5 [---08>---13]\Diesel injection\EMS Engine management system S8(8 Cylindres)	√	√	√	√		√	0001
Scania\Divided By Vehicle\TRUCK\R-Series\Engine 400\TRUCK DC 13 XPI EU5 [---08>---13]\Diesel injection\EMS Engine management system DC13(6 Cylindres)	√	√	√	√		√	
Scania\Divided By Vehicle\TRUCK\R-Series\Engine 400\TRUCK DC 13 XPI EU5 [---08>---13]\Distance control\DAS Adaptive Cruise Control	√	√	√				
Scania\Divided By Vehicle\TRUCK\R-Series\Engine 400\TRUCK DC 13 XPI EU5 [---08>---13]\Distance control\DIS Adaptive Cruise Control	√	√	√				
Scania\Divided By Vehicle\TRUCK\R-Series\Engine 400\TRUCK DC 13 XPI EU5 [---08>---13]\EBS\BMS Brake management system 5.0 (4x2)	√	√	√	√		√	0004
Scania\Divided By Vehicle\TRUCK\R-Series\Engine 400\TRUCK DC 13 XPI EU5 [---08>---13]\EBS\BMS Brake management system 5.0 (6x2 - 6x4)	√	√	√	√		√	0004
Scania\Divided By Vehicle\TRUCK\R-Series\Engine 400\TRUCK DC 13 XPI EU5 [---08>---13]\EBS\BMS Brake management system 5.0 (8x2)	√	√	√	√		√	0004
Scania\Divided By Vehicle\TRUCK\R-Series\Engine 400\TRUCK DC 13 XPI EU5 [---08>---13]\ECU external light\VIS Visibility system	√	√	√	√		√	
Scania\Divided By Vehicle\TRUCK\R-Series\Engine 400\TRUCK DC 13 XPI EU5 [---08>---13]\Engine-vehicle adjustment\COO Coordinator module	√	√	√	√		√	
Scania\Divided By Vehicle\TRUCK\R-Series\Engine 400\TRUCK DC 13 XPI EU5 [---08>---13]\Engine-vehicle adjustment\COO7 (Coordinator)	√	√	√	√		√	
Scania\Divided By Vehicle\TRUCK\R-Series\Engine 400\TRUCK DC 13 XPI EU5 [---08>---13]\Four-wheel drive\AWD ALL-Wheel Drive	√	√	√				
Scania\Divided By Vehicle\TRUCK\R-Series\Engine 400\TRUCK DC 13 XPI EU5 [---08>---13]\Instrument panel\NCL Instrument Panel 1	√	√	√	√		√	
Scania\Divided By Vehicle\TRUCK\R-Series\Engine 400\TRUCK DC 13 XPI EU5 [---08>---13]\Instrument panel\NCL Instrument Panel 2	√	√	√	√		√	
Scania\Divided By Vehicle\TRUCK\R-Series\Engine 400\TRUCK DC 13 XPI EU5 [---08>---13]\Radio\AUS Audio system	√	√	√				
Scania\Divided By Vehicle\TRUCK\R-Series\Engine 400\TRUCK DC 13 XPI EU5 [---08>---13]\Retarder\RET Retarder	√	√	√	√		√	
Scania\Divided By Vehicle\TRUCK\R-Series\Engine 400\TRUCK DC 13 XPI EU5 [---08>---13]\Suspensions\SMS Suspension management system	√	√	√	√			0006, 0007, 0014
Scania\Divided By Vehicle\TRUCK\R-Series\Engine 400\TRUCK DC 13 XPI EU5 [---08>---13]\Tachograph\DTCO Tachograph	√	√	√				
Scania\Divided By Vehicle\TRUCK\R-Series\Engine 400\TRUCK DC 13 XPI EU5 [---08>---13]\Tachograph\MTCO Tachograph	√	√	√				
Scania\Divided By Vehicle\TRUCK\R-Series\Engine 400\TRUCK DC 13 XPI EU5 [---08>---13]\Tire pressure\TPM - Tires Pressure Monitoring System	√	√	√				
Scania\Divided By Vehicle\TRUCK\R-Series\Engine 400\TRUCK DC 13 XPI EU5 [---08>---13]\Transmission\GMS - Gear management system A4	√	√	√			√	
Scania\Divided By Vehicle\TRUCK\R-Series\Engine 400\TRUCK DC 13 XPI EU5 [---08>---13]\Transmission\GMS - Gear management system OPC	√	√	√	√		√	0005

Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 400\TRUCK DC 13 XPI EU5 [---08>---13]\Transmission\GMS - Gear management system Opticruise 5	√	√	√	√		√	0009, 0011, 0018
Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 400\TRUCK DC 13 XPI EU5 [---08>---13]\Transmission\GMS - GMS Opticruise 5	√	√	√	√		√	0009, 0011, 0018
Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 400\TRUCK DC 13 XPI EU5 [---08>---13]\Transport information system\RTI - Road Transport Informatics	√	√	√				
Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 420\TRUCK DC 12 HPI [---04>---08]\ABS\BMS Brake management system-ABS E	√	√	√	√		√	
Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 420\TRUCK DC 12 HPI [---04>---08]\Aid for keeping lane\LDW Monitor traffic lane	√	√	√				
Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 420\TRUCK DC 12 HPI [---04>---08]\Air conditioner\CCS Climate control system	√	√	√	√		√	
Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 420\TRUCK DC 12 HPI [---04>---08]\Airbag\CSS Climate safety system	√	√	√				
Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 420\TRUCK DC 12 HPI [---04>---08]\Alarm\LAS Locking and alarm system	√	√	√				
Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 420\TRUCK DC 12 HPI [---04>---08]\Auxiliary heating\ATA Auxiliary heating system air-to-air	√	√	√	√			
Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 420\TRUCK DC 12 HPI [---04>---08]\Auxiliary heating\WTA Auxiliary heating system water-to-air	√	√	√				
Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 420\TRUCK DC 12 HPI [---04>---08]\Chassis equipment and design\BWS Preparation system	√	√	√				
Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 420\TRUCK DC 12 HPI [---04>---08]\Comfort system\CTS Clock and Time System	√	√	√				
Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 420\TRUCK DC 12 HPI [---04>---08]\Compressed air reserve system\APS Compressed air power supply(Scania protocol)	√	√	√	√			0003
Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 420\TRUCK DC 12 HPI [---04>---08]\Compressed air reserve system\APS Compressed air power supply(Wabco protocol)	√	√	√	√			
Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 420\TRUCK DC 12 HPI [---04>---08]\Diesel injection\EEC-Exhaust gas treatment	√	√	√	√		√	
Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 420\TRUCK DC 12 HPI [---04>---08]\Diesel injection\EMS Engine management system S6-S7	√	√	√	√		√	0002, 0015, 0017
Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 420\TRUCK DC 12 HPI [---04>---08]\Diesel injection\EMS Engine management system S8(8 Cylindes)	√	√	√	√		√	0001
Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 420\TRUCK DC 12 HPI [---04>---08]\Diesel injection\EMS Engine management system DC13(6 Cylindes)	√	√	√	√		√	
Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 420\TRUCK DC 12 HPI [---04>---08]\Distance control\DAS Adaptive Cruise Control	√	√	√				
Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 420\TRUCK DC 12 HPI [---04>---08]\Distance control\DIS Adaptive Cruise Control	√	√	√				
Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 420\TRUCK DC 12 HPI [---04>---08]\EBS\BMS Brake management system 5.0 (4x2)	√	√	√	√		√	0004
Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 420\TRUCK DC 12 HPI [---04>---08]\EBS\BMS Brake management system 5.0 (6x2 - 6x4)	√	√	√	√		√	0004
Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 420\TRUCK DC 12 HPI [---04>---08]\EBS\BMS Brake management system 5.0 (8x2)	√	√	√	√		√	0004
Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 420\TRUCK DC 12 HPI [---04>---08]\ECU external light\VIS Visibility system	√	√	√	√		√	
Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 420\TRUCK DC 12 HPI [---04>---08]\Engine-vehicle adjustment\COO Coordinator module	√	√	√	√		√	
Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 420\TRUCK DC 12 HPI [---04>---08]\Engine-vehicle adjustment\COO7 (Coordinator)	√	√	√	√		√	
Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 420\TRUCK DC 12 HPI [---04>---08]\Four-wheel drive\AWD ALL-Wheel Drive	√	√	√				
Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 420\TRUCK DC 12 HPI [---04>---08]\Instrument panel\ICL Instrument Panel 1	√	√	√	√		√	
Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 420\TRUCK DC 12 HPI [---04>---08]\Instrument panel\ICL Instrument Panel 2	√	√	√	√		√	
Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 420\TRUCK DC 12 HPI [---04>---08]\Radio\AUS Audio system	√	√	√				
Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 420\TRUCK DC 12 HPI [---04>---08]\Retarder\RET Retarder	√	√	√	√		√	
Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 420\TRUCK DC 12 HPI [---04>---08]\Suspensions\SMS Suspension management system	√	√	√	√			0006, 0007, 0014
Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 420\TRUCK DC 12 HPI [---04>---08]\Tachograph\DTCO Tachograph	√	√	√				
Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 420\TRUCK DC 12 HPI [---04>---08]\Tachograph\MTCO Tachograph	√	√	√				
Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 420\TRUCK DC 12 HPI [---04>---08]\Tire pressure\TPM - Tires Pressure Monitoring System	√	√	√				

Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 420\TRUCK DC 12 HPI [---04>---08]\Transmission\GMS - Gear management system A4	√	√	√			√	
Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 420\TRUCK DC 12 HPI [---04>---08]\Transmission\GMS - Gear management system OPC	√	√	√	√		√	0005
Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 420\TRUCK DC 12 HPI [---04>---08]\Transmission\GMS - Gear management system Opticruise 5	√	√	√	√		√	0009, 0011, 0018
Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 420\TRUCK DC 12 HPI [---04>---08]\Transmission\GMS - GMS Opticruise 5	√	√	√	√		√	0009, 0011, 0018
Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 420\TRUCK DC 12 HPI [---04>---08]\Transport information system\RTI - Road Transport Informatics	√	√	√				
Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 420\TRUCK DC 13 XPI EU5 [---08>---13]\ABS\BMS Brake management system-ABS E	√	√	√	√		√	
Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 420\TRUCK DC 13 XPI EU5 [---08>---13]\Aid for keeping lane\LDW Monitor traffic lane	√	√	√				
Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 420\TRUCK DC 13 XPI EU5 [---08>---13]\Air conditioner\CCS Climate control system	√	√	√	√		√	
Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 420\TRUCK DC 13 XPI EU5 [---08>---13]\Airbag\CSS Climate safety system	√	√	√				
Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 420\TRUCK DC 13 XPI EU5 [---08>---13]\Alarm\LAS Locking and alarm system	√	√	√				
Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 420\TRUCK DC 13 XPI EU5 [---08>---13]\Auxiliary heating\ATA Auxiliary heating system air-to-air	√	√	√	√			
Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 420\TRUCK DC 13 XPI EU5 [---08>---13]\Auxiliary heating\WTA Auxiliary heating system water-to-air	√	√	√				
Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 420\TRUCK DC 13 XPI EU5 [---08>---13]\Chassis equipment and design\BWS Preparation system	√	√	√				
Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 420\TRUCK DC 13 XPI EU5 [---08>---13]\Comfort system\CTS Clock and Time System	√	√	√				
Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 420\TRUCK DC 13 XPI EU5 [---08>---13]\Compressed air reserve system\APS Compressed air power supply(Scania protocol)	√	√	√	√			0003
Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 420\TRUCK DC 13 XPI EU5 [---08>---13]\Compressed air reserve system\APS Compressed air power supply(Wabco protocol)	√	√	√	√			
Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 420\TRUCK DC 13 XPI EU5 [---08>---13]\Diesel injection\EEC-Exhaust gas treatment	√	√	√	√		√	
Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 420\TRUCK DC 13 XPI EU5 [---08>---13]\Diesel injection\EMS Engine management system S6-S7	√	√	√	√		√	0002, 0015, 0017
Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 420\TRUCK DC 13 XPI EU5 [---08>---13]\Diesel injection\EMS Engine management system S8(8 Cylindes)	√	√	√	√		√	0001
Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 420\TRUCK DC 13 XPI EU5 [---08>---13]\Diesel injection\EMS Engine management system DC13(6 Cylindes)	√	√	√	√		√	
Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 420\TRUCK DC 13 XPI EU5 [---08>---13]\Distance control\DAS Adaptive Cruise Control	√	√	√				
Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 420\TRUCK DC 13 XPI EU5 [---08>---13]\Distance control\DIS Adaptive Cruise Control	√	√	√				
Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 420\TRUCK DC 13 XPI EU5 [---08>---13]\EBS\BMS Brake management system 5.0 (4x2)	√	√	√	√		√	0004
Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 420\TRUCK DC 13 XPI EU5 [---08>---13]\EBS\BMS Brake management system 5.0 (6x2 - 6x4)	√	√	√	√		√	0004
Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 420\TRUCK DC 13 XPI EU5 [---08>---13]\EBS\BMS Brake management system 5.0 (8x2)	√	√	√	√		√	0004
Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 420\TRUCK DC 13 XPI EU5 [---08>---13]\ECU external light\VIS Visibility system	√	√	√	√		√	
Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 420\TRUCK DC 13 XPI EU5 [---08>---13]\Engine-vehicle adjustment\COO Coordinator module	√	√	√	√		√	
Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 420\TRUCK DC 13 XPI EU5 [---08>---13]\Engine-vehicle adjustment\COO7 (Coordinator)	√	√	√	√		√	
Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 420\TRUCK DC 13 XPI EU5 [---08>---13]\Four-wheel drive\AWD ALL-Wheel Drive	√	√	√				
Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 420\TRUCK DC 13 XPI EU5 [---08>---13]\Instrument pane\NCL Instrument Panel 1	√	√	√	√		√	
Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 420\TRUCK DC 13 XPI EU5 [---08>---13]\Instrument pane\NCL Instrument Panel 2	√	√	√	√		√	
Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 420\TRUCK DC 13 XPI EU5 [---08>---13]\Radio\AUS Audio system	√	√	√				
Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 420\TRUCK DC 13 XPI EU5 [---08>---13]\Retarder\RET Retarder	√	√	√	√		√	
Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 420\TRUCK DC 13 XPI EU5 [---08>---13]\Suspensions\SMS Supension management system	√	√	√	√			0006, 0007, 0014
Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 420\TRUCK DC 13 XPI EU5 [---08>---13]\Tachograph\DTCO Tachograph	√	√	√				

Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 420\TRUCK DC 13 XPI EU5 [---08>---13]\Tachograph\MTCO Tachograph	√	√	√				
Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 420\TRUCK DC 13 XPI EU5 [---08>---13]\Tire pressure\TPM - Tires Pressure Monitoring System	√	√	√				
Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 420\TRUCK DC 13 XPI EU5 [---08>---13]\Transmission\GMS - Gear management system A4	√	√	√			√	
Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 420\TRUCK DC 13 XPI EU5 [---08>---13]\Transmission\GMS - Gear management system OPC	√	√	√	√		√	0005
Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 420\TRUCK DC 13 XPI EU5 [---08>---13]\Transmission\GMS - Gear management system Opticruise 5	√	√	√	√		√	0009, 0011, 0018
Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 420\TRUCK DC 13 XPI EU5 [---08>---13]\Transmission\GMS - GMS Opticruise 5	√	√	√	√		√	0009, 0011, 0018
Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 420\TRUCK DC 13 XPI EU5 [---08>---13]\Transport information system\RTI - Road Transport Informatics	√	√	√				
Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 420\TRUCK DT 12 HPI [---04>---08]\ABS\BMS Brake management system-ABS E	√	√	√	√		√	
Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 420\TRUCK DT 12 HPI [---04>---08]\Aid for keeping lane\LDW Monitor traffic lane	√	√	√				
Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 420\TRUCK DT 12 HPI [---04>---08]\Air conditioner\CCS Climate control system	√	√	√	√		√	
Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 420\TRUCK DT 12 HPI [---04>---08]\Airbag\CSS Climate safety system	√	√	√				
Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 420\TRUCK DT 12 HPI [---04>---08]\Alarm\LAS Locking and alarm system	√	√	√				
Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 420\TRUCK DT 12 HPI [---04>---08]\Auxiliary heating\ATA Auxiliary heating system air-to-air	√	√	√	√			
Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 420\TRUCK DT 12 HPI [---04>---08]\Auxiliary heating\WTA Auxiliary heating system water-to-air	√	√	√				
Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 420\TRUCK DT 12 HPI [---04>---08]\Chassis equipment and design\BWS Preparation system	√	√	√				
Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 420\TRUCK DT 12 HPI [---04>---08]\Comfort system\CTS Clock and Time System	√	√	√				
Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 420\TRUCK DT 12 HPI [---04>---08]\Compressed air reserve system\APS Compressed air power supply(Scania protocol)	√	√	√	√			0003
Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 420\TRUCK DT 12 HPI [---04>---08]\Compressed air reserve system\APS Compressed air power supply(Wabco protocol)	√	√	√	√			
Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 420\TRUCK DT 12 HPI [---04>---08]\Diesel injection\EEC-Exhaust gas treatment	√	√	√	√		√	
Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 420\TRUCK DT 12 HPI [---04>---08]\Diesel injection\EMS Engine management system S6-S7	√	√	√	√		√	0002, 0015, 0017
Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 420\TRUCK DT 12 HPI [---04>---08]\Diesel injection\EMS Engine management system S8(8 Cylindes)	√	√	√	√		√	0001
Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 420\TRUCK DT 12 HPI [---04>---08]\Diesel injection\EMS Engine management system DC13(6 Cylindes)	√	√	√	√		√	
Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 420\TRUCK DT 12 HPI [---04>---08]\Distance control\DAS Adaptive Cruise Control	√	√	√				
Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 420\TRUCK DT 12 HPI [---04>---08]\Distance control\DIS Adaptive Cruise Control	√	√	√				
Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 420\TRUCK DT 12 HPI [---04>---08]\EBS\BMS Brake management system 5.0 (4x2)	√	√	√	√		√	0004
Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 420\TRUCK DT 12 HPI [---04>---08]\EBS\BMS Brake management system 5.0 (6x2 - 6x4)	√	√	√	√		√	0004
Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 420\TRUCK DT 12 HPI [---04>---08]\EBS\BMS Brake management system 5.0 (8x2)	√	√	√	√		√	0004
Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 420\TRUCK DT 12 HPI [---04>---08]\ECU external light\VIS Visibility system	√	√	√	√		√	
Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 420\TRUCK DT 12 HPI [---04>---08]\Engine-vehicle adjustment\COO Coordinator module	√	√	√	√		√	
Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 420\TRUCK DT 12 HPI [---04>---08]\Engine-vehicle adjustment\COO7 (Coordinator)	√	√	√	√		√	
Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 420\TRUCK DT 12 HPI [---04>---08]\Four-wheel drive\AWD ALL-Wheel Drive	√	√	√				
Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 420\TRUCK DT 12 HPI [---04>---08]\Instrument panel\NCL Instrument Panel 1	√	√	√	√		√	
Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 420\TRUCK DT 12 HPI [---04>---08]\Instrument panel\NCL Instrument Panel 2	√	√	√	√		√	
Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 420\TRUCK DT 12 HPI [---04>---08]\Radio\AUS Audio system	√	√	√				
Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 420\TRUCK DT 12 HPI [---04>---08]\Retarder\RET Retarder	√	√	√	√		√	

Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 420\TRUCK DT 12 HPI [---04>---08]\Suspensions\SMS Suspension management system	√	√	√	√			0006, 0007, 0014
Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 420\TRUCK DT 12 HPI [---04>---08]\Tachograph\DTCO Tachograph	√	√	√				
Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 420\TRUCK DT 12 HPI [---04>---08]\Tachograph\MTCO Tachograph	√	√	√				
Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 420\TRUCK DT 12 HPI [---04>---08]\Tire pressure\TPM - Tires Pressure Monitoring System	√	√	√				
Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 420\TRUCK DT 12 HPI [---04>---08]\Transmission\GMS - Gear management system A4	√	√	√			√	
Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 420\TRUCK DT 12 HPI [---04>---08]\Transmission\GMS - Gear management system OPC	√	√	√	√		√	0005
Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 420\TRUCK DT 12 HPI [---04>---08]\Transmission\GMS - Gear management system Opticruise 5	√	√	√	√		√	0009, 0011, 0018
Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 420\TRUCK DT 12 HPI [---04>---08]\Transmission\GMS - GMS Opticruise 5	√	√	√	√		√	0009, 0011, 0018
Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 420\TRUCK DT 12 HPI [---04>---08]\Transport information system\RTI - Road Transport Informatics	√	√	√				
Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 440\TRUCK DC 13 XPI EU5 [---08>---13]\ABS\BMS Brake management system-ABS E	√	√	√	√		√	
Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 440\TRUCK DC 13 XPI EU5 [---08>---13]\Aid for keeping lane\LDW Monitor traffic lane	√	√	√				
Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 440\TRUCK DC 13 XPI EU5 [---08>---13]\Air conditioner\CCS Climate control system	√	√	√	√		√	
Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 440\TRUCK DC 13 XPI EU5 [---08>---13]\Airbag\CSS Climate safety system	√	√	√				
Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 440\TRUCK DC 13 XPI EU5 [---08>---13]\Alarm\LAS Locking and alarm system	√	√	√				
Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 440\TRUCK DC 13 XPI EU5 [---08>---13]\Auxiliary heating\ATA Auxiliary heating system air-to-air	√	√	√	√			
Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 440\TRUCK DC 13 XPI EU5 [---08>---13]\Auxiliary heating\WTA Auxiliary heating system water-to-air	√	√	√				
Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 440\TRUCK DC 13 XPI EU5 [---08>---13]\Chassis equipment and design\BWS Preparation system	√	√	√				
Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 440\TRUCK DC 13 XPI EU5 [---08>---13]\Comfort system\CTS Clock and Time System	√	√	√				
Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 440\TRUCK DC 13 XPI EU5 [---08>---13]\Compressed air reserve system\APS Compressed air power supply(Scania protocol)	√	√	√	√			0003
Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 440\TRUCK DC 13 XPI EU5 [---08>---13]\Compressed air reserve system\APS Compressed air power supply(Wabco protocol)	√	√	√	√			
Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 440\TRUCK DC 13 XPI EU5 [---08>---13]\Diesel injection\EEC-Exhaust gas treatment	√	√	√	√		√	
Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 440\TRUCK DC 13 XPI EU5 [---08>---13]\Diesel injection\EMS Engine management system S6-S7	√	√	√	√		√	0002, 0015, 0017
Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 440\TRUCK DC 13 XPI EU5 [---08>---13]\Diesel injection\EMS Engine management system S8(8 Cylindes)	√	√	√	√		√	0001
Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 440\TRUCK DC 13 XPI EU5 [---08>---13]\Diesel injection\EMS Engine management system DC13(6 Cylindes)	√	√	√	√		√	
Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 440\TRUCK DC 13 XPI EU5 [---08>---13]\Distance control\DAS Adaptive Cruise Control	√	√	√				
Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 440\TRUCK DC 13 XPI EU5 [---08>---13]\Distance control\DIS Adaptive Cruise Control	√	√	√				
Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 440\TRUCK DC 13 XPI EU5 [---08>---13]\EBS\BMS Brake management system 5.0 (4x2)	√	√	√	√		√	0004
Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 440\TRUCK DC 13 XPI EU5 [---08>---13]\EBS\BMS Brake management system 5.0 (6x2 - 6x4)	√	√	√	√		√	0004
Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 440\TRUCK DC 13 XPI EU5 [---08>---13]\EBS\BMS Brake management system 5.0 (8x2)	√	√	√	√		√	0004
Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 440\TRUCK DC 13 XPI EU5 [---08>---13]\ECU external light\VIS Visibility system	√	√	√	√		√	
Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 440\TRUCK DC 13 XPI EU5 [---08>---13]\Engine-vehicle adjustment\COO Coordinator module	√	√	√	√		√	
Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 440\TRUCK DC 13 XPI EU5 [---08>---13]\Engine-vehicle adjustment\COO7 (Coordinator)	√	√	√	√		√	
Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 440\TRUCK DC 13 XPI EU5 [---08>---13]\Four-wheel drive\AWD ALL-Wheel Drive	√	√	√				
Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 440\TRUCK DC 13 XPI EU5 [---08>---13]\Instrument pane\NCL Instrument Panel 1	√	√	√	√		√	
Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 440\TRUCK DC 13 XPI EU5 [---08>---13]\Instrument pane\NCL Instrument Panel 2	√	√	√	√		√	

Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 440\TRUCK DC 13 XPI EU5 [---08>---13]\Radio\AUS Audio system	√	√	√				
Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 440\TRUCK DC 13 XPI EU5 [---08>---13]\Retarder\RET Retarder	√	√	√	√		√	
Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 440\TRUCK DC 13 XPI EU5 [---08>---13]\Suspensions\SMS Supension management system	√	√	√	√			0006, 0007, 0014
Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 440\TRUCK DC 13 XPI EU5 [---08>---13]\Tachograph\DTCO Tachograph	√	√	√				
Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 440\TRUCK DC 13 XPI EU5 [---08>---13]\Tachograph\MTCO Tachograph	√	√	√				
Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 440\TRUCK DC 13 XPI EU5 [---08>---13]\Tire pressure\TPM - Tires Pressure Monitoring System	√	√	√				
Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 440\TRUCK DC 13 XPI EU5 [---08>---13]\Transmission\GMS - Gear management system A4	√	√	√			√	
Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 440\TRUCK DC 13 XPI EU5 [---08>---13]\Transmission\GMS - Gear management system OPC	√	√	√	√		√	0005
Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 440\TRUCK DC 13 XPI EU5 [---08>---13]\Transmission\GMS - Gear management system Opticruise 5	√	√	√	√		√	0009, 0011, 0018
Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 440\TRUCK DC 13 XPI EU5 [---08>---13]\Transmission\GMS - GMS Opticruise 5	√	√	√	√		√	0009, 0011, 0018
Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 440\TRUCK DC 13 XPI EU5 [---08>---13]\Transport information system\RTI - Road Transport Informatics	√	√	√				
Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 470\TRUCK DT 12 HPI [---04>---08]\ABS\BMS Brake management system-ABS E	√	√	√	√		√	
Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 470\TRUCK DT 12 HPI [---04>---08]\Aid for keeping lane\LDW Monitor traffic lane	√	√	√				
Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 470\TRUCK DT 12 HPI [---04>---08]\Air conditioner\CCS Climate control system	√	√	√	√		√	
Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 470\TRUCK DT 12 HPI [---04>---08]\Airbag\CSS Climate safety system	√	√	√				
Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 470\TRUCK DT 12 HPI [---04>---08]\Alarm\LAS Locking and alarm system	√	√	√				
Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 470\TRUCK DT 12 HPI [---04>---08]\Auxiliary heating\ATA Auxiliary heating system air-to-air	√	√	√	√			
Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 470\TRUCK DT 12 HPI [---04>---08]\Auxiliary heating\WTA Auxiliary heating system water-to-air	√	√	√				
Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 470\TRUCK DT 12 HPI [---04>---08]\Chassis equipment and design\BWS Preparation system	√	√	√				
Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 470\TRUCK DT 12 HPI [---04>---08]\Comfort system\CTS Clock and Time System	√	√	√				
Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 470\TRUCK DT 12 HPI [---04>---08]\Compressed air reserve system\APS Compressed air power supply(Scania protocol)	√	√	√	√			0003
Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 470\TRUCK DT 12 HPI [---04>---08]\Compressed air reserve system\APS Compressed air power supply(Wabco protocol)	√	√	√	√			
Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 470\TRUCK DT 12 HPI [---04>---08]\Diesel injection\EEC-Exhaust gas treatment	√	√	√	√		√	
Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 470\TRUCK DT 12 HPI [---04>---08]\Diesel injection\EMS Engine management system S6-S7	√	√	√	√		√	0002, 0015, 0017
Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 470\TRUCK DT 12 HPI [---04>---08]\Diesel injection\EMS Engine management system S8(8 Cylindes)	√	√	√	√		√	0001
Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 470\TRUCK DT 12 HPI [---04>---08]\Diesel injection\EMS Engine management system DC13(6 Cylindes)	√	√	√	√		√	
Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 470\TRUCK DT 12 HPI [---04>---08]\Distance control\DAS Adaptive Cruise Control	√	√	√				
Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 470\TRUCK DT 12 HPI [---04>---08]\Distance control\DIS Adaptive Cruise Control	√	√	√				
Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 470\TRUCK DT 12 HPI [---04>---08]\EBS\BMS Brake management system 5.0 (4x2)	√	√	√	√		√	0004
Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 470\TRUCK DT 12 HPI [---04>---08]\EBS\BMS Brake management system 5.0 (6x2 - 6x4)	√	√	√	√		√	0004
Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 470\TRUCK DT 12 HPI [---04>---08]\EBS\BMS Brake management system 5.0 (8x2)	√	√	√	√		√	0004
Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 470\TRUCK DT 12 HPI [---04>---08]\ECU external light\VIS Visibility system	√	√	√	√		√	
Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 470\TRUCK DT 12 HPI [---04>---08]\Engine-vehicle adjustment\COO Coordinator module	√	√	√	√		√	
Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 470\TRUCK DT 12 HPI [---04>---08]\Engine-vehicle adjustment\COO7 (Coordinator)	√	√	√	√		√	
Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 470\TRUCK DT 12 HPI [---04>---08]\Four-wheel drive\AWD ALL-Wheel Drive	√	√	√				

Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 470\TRUCK DT 12 HPI [---04>---08]\Instrument panel\NCL Instrument Panel 1	√	√	√	√		√	
Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 470\TRUCK DT 12 HPI [---04>---08]\Instrument panel\NCL Instrument Panel 2	√	√	√	√		√	
Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 470\TRUCK DT 12 HPI [---04>---08]\Radio\AUS Audio system	√	√	√				
Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 470\TRUCK DT 12 HPI [---04>---08]\Retarder\RET Retarder	√	√	√	√		√	
Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 470\TRUCK DT 12 HPI [---04>---08]\Suspensions\SMS Suspension management system	√	√	√	√			0006, 0007, 0014
Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 470\TRUCK DT 12 HPI [---04>---08]\Tachograph\DTCO Tachograph	√	√	√				
Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 470\TRUCK DT 12 HPI [---04>---08]\Tachograph\MTCO Tachograph	√	√	√				
Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 470\TRUCK DT 12 HPI [---04>---08]\Tire pressure\TPM - Tires Pressure Monitoring System	√	√	√				
Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 470\TRUCK DT 12 HPI [---04>---08]\Transmission\GMS - Gear management system A4	√	√	√			√	
Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 470\TRUCK DT 12 HPI [---04>---08]\Transmission\GMS - Gear management system OPC	√	√	√	√		√	0005
Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 470\TRUCK DT 12 HPI [---04>---08]\Transmission\GMS - Gear management system Opticruise 5	√	√	√	√		√	0009, 0011, 0018
Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 470\TRUCK DT 12 HPI [---04>---08]\Transmission\GMS - GMS Opticruise 5	√	√	√	√		√	0009, 0011, 0018
Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 470\TRUCK DT 12 HPI [---04>---08]\Transport information system\RTI - Road Transport Informatics	√	√	√				
Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 480\TRUCK DC 13 XPI EU5 [---08>---13]\ABS\BMS Brake management system-ABS E	√	√	√	√		√	
Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 480\TRUCK DC 13 XPI EU5 [---08>---13]\Aid for keeping lane\LDW Monitor traffic lane	√	√	√				
Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 480\TRUCK DC 13 XPI EU5 [---08>---13]\Air conditioner\CCS Climate control system	√	√	√	√		√	
Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 480\TRUCK DC 13 XPI EU5 [---08>---13]\Airbag\CSS Climate safety system	√	√	√				
Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 480\TRUCK DC 13 XPI EU5 [---08>---13]\Alarm\LAS Locking and alarm system	√	√	√				
Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 480\TRUCK DC 13 XPI EU5 [---08>---13]\Auxiliary heating\ATA Auxiliary heating system air-to-air	√	√	√	√			
Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 480\TRUCK DC 13 XPI EU5 [---08>---13]\Auxiliary heating\WTA Auxiliary heating system water-to-air	√	√	√				
Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 480\TRUCK DC 13 XPI EU5 [---08>---13]\Chassis equipment and design\BWS Preparation system	√	√	√				
Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 480\TRUCK DC 13 XPI EU5 [---08>---13]\Comfort system\CTS Clock and Time System	√	√	√				
Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 480\TRUCK DC 13 XPI EU5 [---08>---13]\Compressed air reserve system\APS Compressed air power supply(Scania protocol)	√	√	√	√			0003
Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 480\TRUCK DC 13 XPI EU5 [---08>---13]\Compressed air reserve system\APS Compressed air power supply(Wabco protocol)	√	√	√	√			
Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 480\TRUCK DC 13 XPI EU5 [---08>---13]\Diesel injection\EEC-Exhaust gas treatment	√	√	√	√		√	
Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 480\TRUCK DC 13 XPI EU5 [---08>---13]\Diesel injection\EMS Engine management system S6-S7	√	√	√	√		√	0002, 0015, 0017
Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 480\TRUCK DC 13 XPI EU5 [---08>---13]\Diesel injection\EMS Engine management system S8(8 Cylindes)	√	√	√	√		√	0001
Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 480\TRUCK DC 13 XPI EU5 [---08>---13]\Diesel injection\EMS Engine management system DC13(6 Cylindes)	√	√	√	√		√	
Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 480\TRUCK DC 13 XPI EU5 [---08>---13]\Distance control\DAS Adaptive Cruise Control	√	√	√				
Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 480\TRUCK DC 13 XPI EU5 [---08>---13]\Distance control\DIS Adaptive Cruise Control	√	√	√				
Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 480\TRUCK DC 13 XPI EU5 [---08>---13]\EBS\BMS Brake management system 5.0 (4x2)	√	√	√	√		√	0004
Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 480\TRUCK DC 13 XPI EU5 [---08>---13]\EBS\BMS Brake management system 5.0 (6x2 - 6x4)	√	√	√	√		√	0004
Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 480\TRUCK DC 13 XPI EU5 [---08>---13]\EBS\BMS Brake management system 5.0 (8x2)	√	√	√	√		√	0004
Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 480\TRUCK DC 13 XPI EU5 [---08>---13]\ECU external light\VIS Visibility system	√	√	√	√		√	
Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 480\TRUCK DC 13 XPI EU5 [---08>---13]\Engine-vehicle adjustment\COO Coordinator module	√	√	√	√		√	

Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 480\TRUCK DC 13 XPI EU5 [---08>---13]\Engine-vehicle adjustment\COO7 (Coordinator)	√	√	√	√		√	
Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 480\TRUCK DC 13 XPI EU5 [---08>---13]\Four-wheel drive\AWD ALL-Wheel Drive	√	√	√				
Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 480\TRUCK DC 13 XPI EU5 [---08>---13]\Instrument pane\NCL Instrument Panel 1	√	√	√	√		√	
Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 480\TRUCK DC 13 XPI EU5 [---08>---13]\Instrument pane\NCL Instrument Panel 2	√	√	√	√		√	
Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 480\TRUCK DC 13 XPI EU5 [---08>---13]\Radio\AUS Audio system	√	√	√				
Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 480\TRUCK DC 13 XPI EU5 [---08>---13]\Retarder\RET Retarder	√	√	√	√		√	
Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 480\TRUCK DC 13 XPI EU5 [---08>---13]\Suspensions\SMS Supension management system	√	√	√	√			0006, 0007, 0014
Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 480\TRUCK DC 13 XPI EU5 [---08>---13]\Tachograph\DTCO Tachograph	√	√	√				
Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 480\TRUCK DC 13 XPI EU5 [---08>---13]\Tachograph\MTCO Tachograph	√	√	√				
Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 480\TRUCK DC 13 XPI EU5 [---08>---13]\Tire pressure\TPM - Tires Pressure Monitoring System	√	√	√				
Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 480\TRUCK DC 13 XPI EU5 [---08>---13]\Transmission\GMS - Gear management system A4	√	√	√			√	
Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 480\TRUCK DC 13 XPI EU5 [---08>---13]\Transmission\GMS - Gear management system OPC	√	√	√	√		√	0005
Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 480\TRUCK DC 13 XPI EU5 [---08>---13]\Transmission\GMS - Gear management system Opticruise 5	√	√	√	√		√	0009, 0011, 0018
Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 480\TRUCK DC 13 XPI EU5 [---08>---13]\Transmission\GMS - GMS Opticruise 5	√	√	√	√		√	0009, 0011, 0018
Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 480\TRUCK DC 13 XPI EU5 [---08>---13]\Transport information system\RTI - Road Transport Informatics	√	√	√				
Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 480\TRUCK DC 13 [---04>---08]\ABS\BMS Brake management system-ABS E	√	√	√	√		√	
Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 480\TRUCK DC 13 [---04>---08]\Aid for keeping lane\LDW Monitor traffic lane	√	√	√				
Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 480\TRUCK DC 13 [---04>---08]\Air conditioner\CCS Climate control system	√	√	√	√		√	
Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 480\TRUCK DC 13 [---04>---08]\Airbag\CSS Climate safety system	√	√	√				
Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 480\TRUCK DC 13 [---04>---08]\Alarm\LAS Locking and alarm system	√	√	√				
Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 480\TRUCK DC 13 [---04>---08]\Auxiliary heating\ATA Auxiliary heating system air-to-air	√	√	√	√			
Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 480\TRUCK DC 13 [---04>---08]\Auxiliary heating\WTA Auxiliary heating system water-to-air	√	√	√				
Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 480\TRUCK DC 13 [---04>---08]\Chassis equipment and design\BWS Preparation system	√	√	√				
Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 480\TRUCK DC 13 [---04>---08]\Comfort system\CTS Clock and Time System	√	√	√				
Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 480\TRUCK DC 13 [---04>---08]\Compressed air reserve system\APS Compressed air power supply(Scania protocol)	√	√	√	√			0003
Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 480\TRUCK DC 13 [---04>---08]\Compressed air reserve system\APS Compressed air power supply(Wabco protocol)	√	√	√	√			
Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 480\TRUCK DC 13 [---04>---08]\Diesel injection\EEC-Exhaust gas treatment	√	√	√	√		√	
Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 480\TRUCK DC 13 [---04>---08]\Diesel injection\EMS Engine management system S6-S7	√	√	√	√		√	0002, 0015, 0017
Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 480\TRUCK DC 13 [---04>---08]\Diesel injection\EMS Engine management system S8(8 Cylindes)	√	√	√	√		√	0001
Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 480\TRUCK DC 13 [---04>---08]\Diesel injection\EMS Engine management system DC13(6 Cylindes)	√	√	√	√		√	
Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 480\TRUCK DC 13 [---04>---08]\Distance control\DAS Adaptive Cruise Control	√	√	√				
Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 480\TRUCK DC 13 [---04>---08]\Distance control\DIS Adaptive Cruise Control	√	√	√				
Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 480\TRUCK DC 13 [---04>---08]\EBS\BMS Brake management system 5.0 (4x2)	√	√	√	√		√	0004
Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 480\TRUCK DC 13 [---04>---08]\EBS\BMS Brake management system 5.0 (6x2 - 6x4)	√	√	√	√		√	0004
Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 480\TRUCK DC 13 [---04>---08]\EBS\BMS Brake management system 5.0 (8x2)	√	√	√	√		√	0004

Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 480\TRUCK DC 13 [---04>---08]\ECU external light\VIS Visibility system	√	√	√	√		√	
Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 480\TRUCK DC 13 [---04>---08]\Engine-vehicle adjustment\COO Coordinator module	√	√	√	√		√	
Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 480\TRUCK DC 13 [---04>---08]\Engine-vehicle adjustment\COO7 (Coordinator)	√	√	√	√		√	
Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 480\TRUCK DC 13 [---04>---08]\Four-wheel drive\AWD ALL-Wheel Drive	√	√	√				
Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 480\TRUCK DC 13 [---04>---08]\Instrument panel\NCL Instrument Panel 1	√	√	√	√		√	
Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 480\TRUCK DC 13 [---04>---08]\Instrument panel\NCL Instrument Panel 2	√	√	√	√		√	
Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 480\TRUCK DC 13 [---04>---08]\Radio\AUS Audio system	√	√	√				
Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 480\TRUCK DC 13 [---04>---08]\Retarder\RET Retarder	√	√	√	√		√	
Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 480\TRUCK DC 13 [---04>---08]\Suspensions\SMS Suspension management system	√	√	√	√			0006, 0007, 0014
Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 480\TRUCK DC 13 [---04>---08]\Tachograph\DTCO Tachograph	√	√	√				
Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 480\TRUCK DC 13 [---04>---08]\Tachograph\MTCO Tachograph	√	√	√				
Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 480\TRUCK DC 13 [---04>---08]\Tire pressure\TPM - Tires Pressure Monitoring System	√	√	√				
Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 480\TRUCK DC 13 [---04>---08]\Transmission\GMS - Gear management system A4	√	√	√			√	
Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 480\TRUCK DC 13 [---04>---08]\Transmission\GMS - Gear management system OPC	√	√	√	√		√	0005
Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 480\TRUCK DC 13 [---04>---08]\Transmission\GMS - Gear management system Opticruise 5	√	√	√	√		√	0009, 0011, 0018
Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 480\TRUCK DC 13 [---04>---08]\Transmission\GMS - GMS Opticruise 5	√	√	√	√		√	0009, 0011, 0018
Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 480\TRUCK DC 13 [---04>---08]\Transport information system\RTI - Road Transport Informatics	√	√	√				
Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 480\TRUCK DT 12 HPI [---04>---08]\ABS\BMS Brake management system-ABS E	√	√	√	√		√	
Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 480\TRUCK DT 12 HPI [---04>---08]\Aid for keeping lane\LDW Monitor traffic lane	√	√	√				
Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 480\TRUCK DT 12 HPI [---04>---08]\Air conditioner\CCS Climate control system	√	√	√	√		√	
Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 480\TRUCK DT 12 HPI [---04>---08]\Airbag\CSS Climate safety system	√	√	√				
Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 480\TRUCK DT 12 HPI [---04>---08]\Alarm\LAS Locking and alarm system	√	√	√				
Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 480\TRUCK DT 12 HPI [---04>---08]\Auxiliary heating\ATA Auxiliary heating system air-to-air	√	√	√	√			
Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 480\TRUCK DT 12 HPI [---04>---08]\Auxiliary heating\WTA Auxiliary heating system water-to-air	√	√	√				
Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 480\TRUCK DT 12 HPI [---04>---08]\Chassis equipment and design\BWS Preparation system	√	√	√				
Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 480\TRUCK DT 12 HPI [---04>---08]\Comfort system\CTS Clock and Time System	√	√	√				
Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 480\TRUCK DT 12 HPI [---04>---08]\Compressed air reserve system\APS Compressed air power supply(Scania protocol)	√	√	√	√			0003
Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 480\TRUCK DT 12 HPI [---04>---08]\Compressed air reserve system\APS Compressed air power supply(Wabco protocol)	√	√	√	√			
Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 480\TRUCK DT 12 HPI [---04>---08]\Diesel injection\EEC-Exhaust gas treatment	√	√	√	√		√	
Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 480\TRUCK DT 12 HPI [---04>---08]\Diesel injection\EMS Engine management system S6-S7	√	√	√	√		√	0002, 0015, 0017
Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 480\TRUCK DT 12 HPI [---04>---08]\Diesel injection\EMS Engine management system S8(8 Cylindes)	√	√	√	√		√	0001
Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 480\TRUCK DT 12 HPI [---04>---08]\Diesel injection\EMS Engine management system DC13(6 Cylindes)	√	√	√	√		√	
Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 480\TRUCK DT 12 HPI [---04>---08]\Distance control\DAS Adaptive Cruise Control	√	√	√				
Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 480\TRUCK DT 12 HPI [---04>---08]\Distance control\DIS Adaptive Cruise Control	√	√	√				
Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 480\TRUCK DT 12 HPI [---04>---08]\EBS\BMS Brake management system 5.0 (4x2)	√	√	√	√		√	0004

Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 480\TRUCK DT 12 HPI [---04>---08]\EBS\BMS Brake management system 5.0 (6x2 - 6x4)	√	√	√	√		√	0004
Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 480\TRUCK DT 12 HPI [---04>---08]\EBS\BMS Brake management system 5.0 (8x2)	√	√	√	√		√	0004
Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 480\TRUCK DT 12 HPI [---04>---08]\ECU external light\VIS Visibility system	√	√	√	√		√	
Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 480\TRUCK DT 12 HPI [---04>---08]\Engine-vehicle adjustment\COO Coordinator module	√	√	√	√		√	
Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 480\TRUCK DT 12 HPI [---04>---08]\Engine-vehicle adjustment\COO7 (Coordinator)	√	√	√	√		√	
Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 480\TRUCK DT 12 HPI [---04>---08]\Four-wheel drive\AWD ALL-Wheel Drive	√	√	√				
Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 480\TRUCK DT 12 HPI [---04>---08]\Instrument panel\NCL Instrument Panel 1	√	√	√	√		√	
Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 480\TRUCK DT 12 HPI [---04>---08]\Instrument panel\NCL Instrument Panel 2	√	√	√	√		√	
Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 480\TRUCK DT 12 HPI [---04>---08]\Radio\AUS Audio system	√	√	√				
Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 480\TRUCK DT 12 HPI [---04>---08]\Retarder\RET Retarder	√	√	√	√		√	
Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 480\TRUCK DT 12 HPI [---04>---08]\Suspensions\SMS Suspension management system	√	√	√	√			0006, 0007, 0014
Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 480\TRUCK DT 12 HPI [---04>---08]\Tachograph\DTCO Tachograph	√	√	√				
Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 480\TRUCK DT 12 HPI [---04>---08]\Tachograph\MTCO Tachograph	√	√	√				
Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 480\TRUCK DT 12 HPI [---04>---08]\Tire pressure\TPM - Tires Pressure Monitoring System	√	√	√				
Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 480\TRUCK DT 12 HPI [---04>---08]\Transmission\GMS - Gear management system A4	√	√	√			√	
Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 480\TRUCK DT 12 HPI [---04>---08]\Transmission\GMS - Gear management system OPC	√	√	√	√		√	0005
Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 480\TRUCK DT 12 HPI [---04>---08]\Transmission\GMS - Gear management system Opticruise 5	√	√	√	√		√	0009, 0011, 0018
Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 480\TRUCK DT 12 HPI [---04>---08]\Transmission\GMS - GMS Opticruise 5	√	√	√	√		√	0009, 0011, 0018
Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 480\TRUCK DT 12 HPI [---04>---08]\Transport information system\RTI - Road Transport Informatics	√	√	√				
Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 500\TRUCK DC 16 EU5 [---08>---13]\ABS\BMS Brake management system-ABS E	√	√	√	√		√	
Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 500\TRUCK DC 16 EU5 [---08>---13]\Aid for keeping lane\LDW Monitor traffic lane	√	√	√				
Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 500\TRUCK DC 16 EU5 [---08>---13]\Air conditioner\CCS Climate control system	√	√	√	√		√	
Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 500\TRUCK DC 16 EU5 [---08>---13]\Airbag\CSS Climate safety system	√	√	√				
Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 500\TRUCK DC 16 EU5 [---08>---13]\Alarm\LAS Locking and alarm system	√	√	√				
Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 500\TRUCK DC 16 EU5 [---08>---13]\Auxiliary heating\ATA Auxiliary heating system air-to-air	√	√	√	√			
Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 500\TRUCK DC 16 EU5 [---08>---13]\Auxiliary heating\WTA Auxiliary heating system water-to-air	√	√	√				
Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 500\TRUCK DC 16 EU5 [---08>---13]\Chassis equipment and design\BWS Preparation system	√	√	√				
Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 500\TRUCK DC 16 EU5 [---08>---13]\Comfort system\CTS Clock and Time System	√	√	√				
Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 500\TRUCK DC 16 EU5 [---08>---13]\Compressed air reserve system\APS Compressed air power supply(Scania protocol)	√	√	√	√			0003
Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 500\TRUCK DC 16 EU5 [---08>---13]\Compressed air reserve system\APS Compressed air power supply(Wabco protocol)	√	√	√	√			
Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 500\TRUCK DC 16 EU5 [---08>---13]\Diesel injection\EEC-Exhaust gas treatment	√	√	√	√		√	
Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 500\TRUCK DC 16 EU5 [---08>---13]\Diesel injection\EMS Engine management system S6-S7	√	√	√	√		√	0002, 0015, 0017
Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 500\TRUCK DC 16 EU5 [---08>---13]\Diesel injection\EMS Engine management system S8(8 Cylindes)	√	√	√	√		√	0001
Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 500\TRUCK DC 16 EU5 [---08>---13]\Diesel injection\EMS Engine management system DC13(6 Cylindes)	√	√	√	√		√	
Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 500\TRUCK DC 16 EU5 [---08>---13]\Distance control\DAS Adaptive Cruise Control	√	√	√				

Scania\Divided By Vehicle\TRUCK\R-Series\Engine 500\TRUCK DC 16 EU5 [---08>---13]\Distance control\DIS Adaptive Cruise Control	√	√	√				
Scania\Divided By Vehicle\TRUCK\R-Series\Engine 500\TRUCK DC 16 EU5 [---08>---13]\EBS\BMS Brake management system 5.0 (4x2)	√	√	√	√		√	0004
Scania\Divided By Vehicle\TRUCK\R-Series\Engine 500\TRUCK DC 16 EU5 [---08>---13]\EBS\BMS Brake management system 5.0 (6x2 - 6x4)	√	√	√	√		√	0004
Scania\Divided By Vehicle\TRUCK\R-Series\Engine 500\TRUCK DC 16 EU5 [---08>---13]\EBS\BMS Brake management system 5.0 (8x2)	√	√	√	√		√	0004
Scania\Divided By Vehicle\TRUCK\R-Series\Engine 500\TRUCK DC 16 EU5 [---08>---13]\ECU external light\VIS Visibility system	√	√	√	√		√	
Scania\Divided By Vehicle\TRUCK\R-Series\Engine 500\TRUCK DC 16 EU5 [---08>---13]\Engine-vehicle adjustment\COO Coordinator module	√	√	√	√		√	
Scania\Divided By Vehicle\TRUCK\R-Series\Engine 500\TRUCK DC 16 EU5 [---08>---13]\Engine-vehicle adjustment\COO7 (Coordinator)	√	√	√	√		√	
Scania\Divided By Vehicle\TRUCK\R-Series\Engine 500\TRUCK DC 16 EU5 [---08>---13]\Four-wheel drive\AWD ALL-Wheel Drive	√	√	√				
Scania\Divided By Vehicle\TRUCK\R-Series\Engine 500\TRUCK DC 16 EU5 [---08>---13]\Instrument panel\ICL Instrument Panel 1	√	√	√	√		√	
Scania\Divided By Vehicle\TRUCK\R-Series\Engine 500\TRUCK DC 16 EU5 [---08>---13]\Instrument panel\ICL Instrument Panel 2	√	√	√	√		√	
Scania\Divided By Vehicle\TRUCK\R-Series\Engine 500\TRUCK DC 16 EU5 [---08>---13]\Radio\AUS Audio system	√	√	√				
Scania\Divided By Vehicle\TRUCK\R-Series\Engine 500\TRUCK DC 16 EU5 [---08>---13]\Retarder\RET Retarder	√	√	√	√		√	
Scania\Divided By Vehicle\TRUCK\R-Series\Engine 500\TRUCK DC 16 EU5 [---08>---13]\Suspensions\SMS Suspension management system	√	√	√	√			0006, 0007, 0014
Scania\Divided By Vehicle\TRUCK\R-Series\Engine 500\TRUCK DC 16 EU5 [---08>---13]\Tachograph\DTCO Tachograph	√	√	√				
Scania\Divided By Vehicle\TRUCK\R-Series\Engine 500\TRUCK DC 16 EU5 [---08>---13]\Tachograph\MTCO Tachograph	√	√	√				
Scania\Divided By Vehicle\TRUCK\R-Series\Engine 500\TRUCK DC 16 EU5 [---08>---13]\Tire pressure\TPM - Tires Pressure Monitoring System	√	√	√				
Scania\Divided By Vehicle\TRUCK\R-Series\Engine 500\TRUCK DC 16 EU5 [---08>---13]\Transmission\GMS - Gear management system A4	√	√	√			√	
Scania\Divided By Vehicle\TRUCK\R-Series\Engine 500\TRUCK DC 16 EU5 [---08>---13]\Transmission\GMS - Gear management system OPC	√	√	√	√		√	0005
Scania\Divided By Vehicle\TRUCK\R-Series\Engine 500\TRUCK DC 16 EU5 [---08>---13]\Transmission\GMS - Gear management system Opticruise 5	√	√	√	√		√	0009, 0011, 0018
Scania\Divided By Vehicle\TRUCK\R-Series\Engine 500\TRUCK DC 16 EU5 [---08>---13]\Transmission\GMS - GMS Opticruise 5	√	√	√	√		√	0009, 0011, 0018
Scania\Divided By Vehicle\TRUCK\R-Series\Engine 500\TRUCK DC 16 EU5 [---08>---13]\Transport information system\RTI - Road Transport Informatics	√	√	√				
Scania\Divided By Vehicle\TRUCK\R-Series\Engine 500\TRUCK DC 16 [---04>---13]\ABS\BMS Brake management system-ABS E	√	√	√	√		√	
Scania\Divided By Vehicle\TRUCK\R-Series\Engine 500\TRUCK DC 16 [---04>---13]\Aid for keeping lane\LDW Monitor traffic lane	√	√	√				
Scania\Divided By Vehicle\TRUCK\R-Series\Engine 500\TRUCK DC 16 [---04>---13]\Air conditioner\CCS Climate control system	√	√	√	√		√	
Scania\Divided By Vehicle\TRUCK\R-Series\Engine 500\TRUCK DC 16 [---04>---13]\Airbag\CSS Climate safety system	√	√	√				
Scania\Divided By Vehicle\TRUCK\R-Series\Engine 500\TRUCK DC 16 [---04>---13]\Alarm\LAS Locking and alarm system	√	√	√				
Scania\Divided By Vehicle\TRUCK\R-Series\Engine 500\TRUCK DC 16 [---04>---13]\Auxiliary heating\ATA Auxiliary heating system air-to-air	√	√	√	√			
Scania\Divided By Vehicle\TRUCK\R-Series\Engine 500\TRUCK DC 16 [---04>---13]\Auxiliary heating\WTA Auxiliary heating system water-to-air	√	√	√				
Scania\Divided By Vehicle\TRUCK\R-Series\Engine 500\TRUCK DC 16 [---04>---13]\Chassis equipment and design\BWS Preparation system	√	√	√				
Scania\Divided By Vehicle\TRUCK\R-Series\Engine 500\TRUCK DC 16 [---04>---13]\Comfort system\CTS Clock and Time System	√	√	√				
Scania\Divided By Vehicle\TRUCK\R-Series\Engine 500\TRUCK DC 16 [---04>---13]\Compressed air reserve system\APS Compressed air power supply(Scania protocol)	√	√	√	√			0003
Scania\Divided By Vehicle\TRUCK\R-Series\Engine 500\TRUCK DC 16 [---04>---13]\Compressed air reserve system\APS Compressed air power supply(Wabco protocol)	√	√	√	√			
Scania\Divided By Vehicle\TRUCK\R-Series\Engine 500\TRUCK DC 16 [---04>---13]\Diesel injection\EEC-Exhaust gas treatment	√	√	√	√		√	
Scania\Divided By Vehicle\TRUCK\R-Series\Engine 500\TRUCK DC 16 [---04>---13]\Diesel injection\EMS Engine management system S6-S7	√	√	√	√		√	0002, 0015, 0017
Scania\Divided By Vehicle\TRUCK\R-Series\Engine 500\TRUCK DC 16 [---04>---13]\Diesel injection\EMS Engine management system S8(8 Cylindres)	√	√	√	√		√	0001

Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 500\TRUCK DC 16 [---04>---13]\Diesel injection\EMS Engine management system DC13(6 Cylindes)	√	√	√	√		√	
Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 500\TRUCK DC 16 [---04>---13]\Distance control\DAS Adaptive Cruise Control	√	√	√				
Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 500\TRUCK DC 16 [---04>---13]\Distance control\DIS Adaptive Cruise Control	√	√	√				
Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 500\TRUCK DC 16 [---04>---13]\EBS\BMS Brake management system 5.0 (4x2)	√	√	√	√		√	0004
Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 500\TRUCK DC 16 [---04>---13]\EBS\BMS Brake management system 5.0 (6x2 - 6x4)	√	√	√	√		√	0004
Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 500\TRUCK DC 16 [---04>---13]\EBS\BMS Brake management system 5.0 (8x2)	√	√	√	√		√	0004
Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 500\TRUCK DC 16 [---04>---13]\ECU external light\VIS Visibility system	√	√	√	√		√	
Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 500\TRUCK DC 16 [---04>---13]\Engine-vehicle adjustment\COO Coordinator module	√	√	√	√		√	
Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 500\TRUCK DC 16 [---04>---13]\Engine-vehicle adjustment\COO7 (Coordinator)	√	√	√	√		√	
Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 500\TRUCK DC 16 [---04>---13]\Four-wheel drive\AWD ALL-Wheel Drive	√	√	√				
Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 500\TRUCK DC 16 [---04>---13]\Instrument panel\NCL Instrument Panel 1	√	√	√	√		√	
Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 500\TRUCK DC 16 [---04>---13]\Instrument panel\NCL Instrument Panel 2	√	√	√	√		√	
Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 500\TRUCK DC 16 [---04>---13]\Radio\AUS Audio system	√	√	√				
Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 500\TRUCK DC 16 [---04>---13]\Retarder\RET Retarder	√	√	√	√		√	
Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 500\TRUCK DC 16 [---04>---13]\Suspensions\SMS Supension management system	√	√	√	√			0006, 0007, 0014
Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 500\TRUCK DC 16 [---04>---13]\Tachograph\DTCO Tachograph	√	√	√				
Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 500\TRUCK DC 16 [---04>---13]\Tachograph\MTCO Tachograph	√	√	√				
Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 500\TRUCK DC 16 [---04>---13]\Tire pressure\TPM - Tires Pressure Monitoring System	√	√	√				
Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 500\TRUCK DC 16 [---04>---13]\Transmission\GMS - Gear management system A4	√	√	√			√	
Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 500\TRUCK DC 16 [---04>---13]\Transmission\GMS - Gear management system OPC	√	√	√	√		√	0005
Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 500\TRUCK DC 16 [---04>---13]\Transmission\GMS - Gear management system Opticruise 5	√	√	√	√		√	0009, 0011, 0018
Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 500\TRUCK DC 16 [---04>---13]\Transmission\GMS - GMS Opticruise 5	√	√	√	√		√	0009, 0011, 0018
Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 500\TRUCK DC 16 [---04>---13]\Transport information system\RTI - Road Transport Informatics	√	√	√				
Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 530\TRUCK DSC 14 [---04>---13]\ABS\BMS Brake management system-ABS E	√	√	√	√		√	
Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 530\TRUCK DSC 14 [---04>---13]\Aid for keeping lane\LDW Monitor traffic lane	√	√	√				
Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 530\TRUCK DSC 14 [---04>---13]\Air conditioner\CCS Climate control system	√	√	√	√		√	
Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 530\TRUCK DSC 14 [---04>---13]\Airbag\CSS Climate safety system	√	√	√				
Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 530\TRUCK DSC 14 [---04>---13]\Alarm\LAS Locking and alarm system	√	√	√				
Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 530\TRUCK DSC 14 [---04>---13]\Auxiliary heating\ATA Auxiliary heating system air-to-air	√	√	√	√			
Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 530\TRUCK DSC 14 [---04>---13]\Auxiliary heating\WTA Auxiliary heating system water-to-air	√	√	√				
Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 530\TRUCK DSC 14 [---04>---13]\Chassis equipment and design\BWS Preparation system	√	√	√				
Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 530\TRUCK DSC 14 [---04>---13]\Comfort system\CTS Clock and Time System	√	√	√				
Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 530\TRUCK DSC 14 [---04>---13]\Compressed air reserve system\APS Compressed air power supply(Scania protocol)	√	√	√	√			0003
Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 530\TRUCK DSC 14 [---04>---13]\Compressed air reserve system\APS Compressed air power supply(Wabco protocol)	√	√	√	√			
Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 530\TRUCK DSC 14 [---04>---13]\Diesel injection\EEC-Exhaust gas treatment	√	√	√	√		√	

Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 530\TRUCK DSC 14 [---04>----13]\Diesel injection\EMS Engine management system S6-S7	√	√	√	√		√	0002, 0015, 0017
Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 530\TRUCK DSC 14 [---04>----13]\Diesel injection\EMS Engine management system S8(8 Cylindres)	√	√	√	√		√	0001
Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 530\TRUCK DSC 14 [---04>----13]\Diesel injection\EMS Engine management system DC13(6 Cylindres)	√	√	√	√		√	
Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 530\TRUCK DSC 14 [---04>----13]\Distance control\DAS Adaptive Cruise Control	√	√	√				
Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 530\TRUCK DSC 14 [---04>----13]\Distance control\DIS Adaptive Cruise Control	√	√	√				
Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 530\TRUCK DSC 14 [---04>----13]\EBS\BMS Brake management system 5.0 (4x2)	√	√	√	√		√	0004
Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 530\TRUCK DSC 14 [---04>----13]\EBS\BMS Brake management system 5.0 (6x2 - 6x4)	√	√	√	√		√	0004
Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 530\TRUCK DSC 14 [---04>----13]\EBS\BMS Brake management system 5.0 (8x2)	√	√	√	√		√	0004
Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 530\TRUCK DSC 14 [---04>----13]\ECU external light\VIS Visibility system	√	√	√	√		√	
Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 530\TRUCK DSC 14 [---04>----13]\Engine-vehicle adjustment\COO Coordinator module	√	√	√	√		√	
Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 530\TRUCK DSC 14 [---04>----13]\Engine-vehicle adjustment\COO7 (Coordinator)	√	√	√	√		√	
Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 530\TRUCK DSC 14 [---04>----13]\Four-wheel drive\AWD ALL-Wheel Drive	√	√	√				
Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 530\TRUCK DSC 14 [---04>----13]\Instrument pane\NCL Instrument Panel 1	√	√	√	√		√	
Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 530\TRUCK DSC 14 [---04>----13]\Instrument pane\NCL Instrument Panel 2	√	√	√	√		√	
Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 530\TRUCK DSC 14 [---04>----13]\Radio\AUS Audio system	√	√	√				
Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 530\TRUCK DSC 14 [---04>----13]\Retarder\RET Retarder	√	√	√	√		√	
Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 530\TRUCK DSC 14 [---04>----13]\Suspensions\SMS Supension management system	√	√	√	√			0006, 0007, 0014
Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 530\TRUCK DSC 14 [---04>----13]\Tachograph\DTCO Tachograph	√	√	√				
Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 530\TRUCK DSC 14 [---04>----13]\Tachograph\MTCO Tachograph	√	√	√				
Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 530\TRUCK DSC 14 [---04>----13]\Tire pressure\TPM - Tires Pressure Monitoring System	√	√	√				
Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 530\TRUCK DSC 14 [---04>----13]\Transmission\GMS - Gear management system A4	√	√	√			√	
Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 530\TRUCK DSC 14 [---04>----13]\Transmission\GMS - Gear management system OPC	√	√	√	√		√	0005
Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 530\TRUCK DSC 14 [---04>----13]\Transmission\GMS - Gear management system Opticruise 5	√	√	√	√		√	0009, 0011, 0018
Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 530\TRUCK DSC 14 [---04>----13]\Transmission\GMS - GMS Opticruise 5	√	√	√	√		√	0009, 0011, 0018
Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 530\TRUCK DSC 14 [---04>----13]\Transport information system\RTI - Road Transport Informatics	√	√	√				
Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 560\TRUCK DC 16 EU5 [---08>----13]\ABS\BMS Brake management system-ABS E	√	√	√	√		√	
Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 560\TRUCK DC 16 EU5 [---08>----13]\Aid for keeping lane\LDW Monitor traffic lane	√	√	√				
Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 560\TRUCK DC 16 EU5 [---08>----13]\Air conditioner\CCS Climate control system	√	√	√	√		√	
Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 560\TRUCK DC 16 EU5 [---08>----13]\Airbag\CSS Climate safety system	√	√	√				
Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 560\TRUCK DC 16 EU5 [---08>----13]\Alarm\LAS Locking and alarm system	√	√	√				
Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 560\TRUCK DC 16 EU5 [---08>----13]\Auxiliary heating\ATA Auxiliary heating system air-to-air	√	√	√	√			
Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 560\TRUCK DC 16 EU5 [---08>----13]\Auxiliary heating\WTA Auxiliary heating system water-to-air	√	√	√				
Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 560\TRUCK DC 16 EU5 [---08>----13]\Chassis equipment and design\BWS Preparation system	√	√	√				
Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 560\TRUCK DC 16 EU5 [---08>----13]\Comfort system\CTS Clock and Time System	√	√	√				
Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 560\TRUCK DC 16 EU5 [---08>----13]\Compressed air reserve system\APS Compressed air power supply(Scania protocol)	√	√	√	√			0003

Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 560\TRUCK DC 16 EU5 [---08>---13]\Compressed air reserve system\APS Compressed air power supply(Wabco protocol)	√	√	√	√			
Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 560\TRUCK DC 16 EU5 [---08>---13]\Diesel injection\EEC-Exhaust gas treatment	√	√	√	√		√	
Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 560\TRUCK DC 16 EU5 [---08>---13]\Diesel injection\EMS Engine management system S6-S7	√	√	√	√		√	0002, 0015, 0017
Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 560\TRUCK DC 16 EU5 [---08>---13]\Diesel injection\EMS Engine management system S8(8 Cylindes)	√	√	√	√		√	0001
Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 560\TRUCK DC 16 EU5 [---08>---13]\Diesel injection\EMS Engine management system DC13(6 Cylindes)	√	√	√	√		√	
Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 560\TRUCK DC 16 EU5 [---08>---13]\Distance control\DAS Adaptive Cruise Control	√	√	√				
Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 560\TRUCK DC 16 EU5 [---08>---13]\Distance control\DIS Adaptive Cruise Control	√	√	√				
Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 560\TRUCK DC 16 EU5 [---08>---13]\EBS\BMS Brake management system 5.0 (4x2)	√	√	√	√		√	0004
Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 560\TRUCK DC 16 EU5 [---08>---13]\EBS\BMS Brake management system 5.0 (6x2 - 6x4)	√	√	√	√		√	0004
Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 560\TRUCK DC 16 EU5 [---08>---13]\EBS\BMS Brake management system 5.0 (8x2)	√	√	√	√		√	0004
Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 560\TRUCK DC 16 EU5 [---08>---13]\ECU external light\VIS Visibility system	√	√	√	√		√	
Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 560\TRUCK DC 16 EU5 [---08>---13]\Engine-vehicle adjustment\COO Coordinator module	√	√	√	√		√	
Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 560\TRUCK DC 16 EU5 [---08>---13]\Engine-vehicle adjustment\COO7 (Coordinator)	√	√	√	√		√	
Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 560\TRUCK DC 16 EU5 [---08>---13]\Four-wheel drive\AWD ALL-Wheel Drive	√	√	√				
Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 560\TRUCK DC 16 EU5 [---08>---13]\Instrument panel\NCL Instrument Panel 1	√	√	√	√		√	
Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 560\TRUCK DC 16 EU5 [---08>---13]\Instrument panel\NCL Instrument Panel 2	√	√	√	√		√	
Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 560\TRUCK DC 16 EU5 [---08>---13]\Radio\AUS Audio system	√	√	√				
Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 560\TRUCK DC 16 EU5 [---08>---13]\Retarder\RET Retarder	√	√	√	√		√	
Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 560\TRUCK DC 16 EU5 [---08>---13]\Suspensions\SMS Supension management system	√	√	√	√			0006, 0007, 0014
Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 560\TRUCK DC 16 EU5 [---08>---13]\Tachograph\DTCO Tachograph	√	√	√				
Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 560\TRUCK DC 16 EU5 [---08>---13]\Tachograph\MTCO Tachograph	√	√	√				
Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 560\TRUCK DC 16 EU5 [---08>---13]\Tire pressure\TPM - Tires Pressure Monitoring System	√	√	√				
Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 560\TRUCK DC 16 EU5 [---08>---13]\Transmission\GMS - Gear management system A4	√	√	√			√	
Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 560\TRUCK DC 16 EU5 [---08>---13]\Transmission\GMS - Gear management system OPC	√	√	√	√		√	0005
Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 560\TRUCK DC 16 EU5 [---08>---13]\Transmission\GMS - Gear management system Opticruise 5	√	√	√	√		√	0009, 0011, 0018
Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 560\TRUCK DC 16 EU5 [---08>---13]\Transmission\GMS - GMS Opticruise 5	√	√	√	√		√	0009, 0011, 0018
Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 560\TRUCK DC 16 EU5 [---08>---13]\Transport information system\RTI - Road Transport Informatics	√	√	√				
Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 560\TRUCK DC 16 [---06>---13]\ABS\BMS Brake management system-ABS E	√	√	√	√		√	
Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 560\TRUCK DC 16 [---06>---13]\Aid for keeping lane\LDW Monitor traffic lane	√	√	√				
Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 560\TRUCK DC 16 [---06>---13]\Air conditioner\CCS Climate control system	√	√	√	√		√	
Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 560\TRUCK DC 16 [---06>---13]\Airbag\CSS Climate safety system	√	√	√				
Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 560\TRUCK DC 16 [---06>---13]\Alarm\LAS Locking and alarm system	√	√	√				
Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 560\TRUCK DC 16 [---06>---13]\Auxiliary heating\ATA Auxiliary heating system air-to-air	√	√	√	√			
Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 560\TRUCK DC 16 [---06>---13]\Auxiliary heating\WTA Auxiliary heating system water-to-air	√	√	√				
Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 560\TRUCK DC 16 [---06>---13]\Chassis equipment and design\BWS Preparation system	√	√	√				

Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 560\TRUCK DC 16 [---06>---13]\Comfort system\CTS Clock and Time System	√	√	√				
Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 560\TRUCK DC 16 [---06>---13]\Compressed air reserve system\APS Compressed air power supply(Scania protocol)	√	√	√	√			0003
Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 560\TRUCK DC 16 [---06>---13]\Compressed air reserve system\APS Compressed air power supply(Wabco protocol)	√	√	√	√			
Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 560\TRUCK DC 16 [---06>---13]\Diesel injection\EEC-Exhaust gas treatment	√	√	√	√		√	
Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 560\TRUCK DC 16 [---06>---13]\Diesel injection\EMS Engine management system S6-S7	√	√	√	√		√	0002, 0015, 0017
Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 560\TRUCK DC 16 [---06>---13]\Diesel injection\EMS Engine management system S8(8 Cylindes)	√	√	√	√		√	0001
Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 560\TRUCK DC 16 [---06>---13]\Diesel injection\EMS Engine management system DC13(6 Cylindes)	√	√	√	√		√	
Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 560\TRUCK DC 16 [---06>---13]\Distance control\DAS Adaptive Cruise Control	√	√	√				
Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 560\TRUCK DC 16 [---06>---13]\Distance control\DIS Adaptive Cruise Control	√	√	√				
Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 560\TRUCK DC 16 [---06>---13]\EBS\BMS Brake management system 5.0 (4x2)	√	√	√	√		√	0004
Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 560\TRUCK DC 16 [---06>---13]\EBS\BMS Brake management system 5.0 (6x2 - 6x4)	√	√	√	√		√	0004
Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 560\TRUCK DC 16 [---06>---13]\EBS\BMS Brake management system 5.0 (8x2)	√	√	√	√		√	0004
Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 560\TRUCK DC 16 [---06>---13]\ECU external light\VIS Visibility system	√	√	√	√		√	
Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 560\TRUCK DC 16 [---06>---13]\Engine-vehicle adjustment\COO Coordinator module	√	√	√	√		√	
Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 560\TRUCK DC 16 [---06>---13]\Engine-vehicle adjustment\COO7 (Coordinator)	√	√	√	√		√	
Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 560\TRUCK DC 16 [---06>---13]\Four-wheel drive\AWD ALL-Wheel Drive	√	√	√				
Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 560\TRUCK DC 16 [---06>---13]\Instrument panel\NCL Instrument Panel 1	√	√	√	√		√	
Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 560\TRUCK DC 16 [---06>---13]\Instrument panel\NCL Instrument Panel 2	√	√	√	√		√	
Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 560\TRUCK DC 16 [---06>---13]\Radio\AUS Audio system	√	√	√				
Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 560\TRUCK DC 16 [---06>---13]\Retarder\RET Retarder	√	√	√	√		√	
Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 560\TRUCK DC 16 [---06>---13]\Suspensions\SMS Supension management system	√	√	√	√			0006, 0007, 0014
Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 560\TRUCK DC 16 [---06>---13]\Tachograph\DTCO Tachograph	√	√	√				
Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 560\TRUCK DC 16 [---06>---13]\Tachograph\MTCO Tachograph	√	√	√				
Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 560\TRUCK DC 16 [---06>---13]\Tire pressure\TPM - Tires Pressure Monitoring System	√	√	√				
Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 560\TRUCK DC 16 [---06>---13]\Transmission\GMS - Gear management system A4	√	√	√			√	
Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 560\TRUCK DC 16 [---06>---13]\Transmission\GMS - Gear management system OPC	√	√	√	√		√	0005
Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 560\TRUCK DC 16 [---06>---13]\Transmission\GMS - Gear management system Opticruise 5	√	√	√	√		√	0009, 0011, 0018
Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 560\TRUCK DC 16 [---06>---13]\Transmission\GMS - GMS Opticruise 5	√	√	√	√		√	0009, 0011, 0018
Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 560\TRUCK DC 16 [---06>---13]\Transport information system\RTI - Road Transport Informatics	√	√	√				
Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 580\TRUCK DC 16 [---06>---13]\ABS\BMS Brake management system-ABS E	√	√	√	√		√	
Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 580\TRUCK DC 16 [---06>---13]\Aid for keeping lane\LDW Monitor traffic lane	√	√	√				
Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 580\TRUCK DC 16 [---06>---13]\Air conditioner\CCS Climate control system	√	√	√	√		√	
Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 580\TRUCK DC 16 [---06>---13]\Airbag\CSS Climate safety system	√	√	√				
Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 580\TRUCK DC 16 [---06>---13]\Alarm\LAS Locking and alarm system	√	√	√				
Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 580\TRUCK DC 16 [---06>---13]\Auxiliary heating\ATA Auxiliary heating system air-to-air	√	√	√	√			

Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 580\TRUCK DC 16 [---06>---13]\Auxiliary heating\WTA Auxiliary heating system water-to-air	√	√	√				
Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 580\TRUCK DC 16 [---06>---13]\Chassis equipment and design\BWS Preparation system	√	√	√				
Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 580\TRUCK DC 16 [---06>---13]\Comfort system\CTS Clock and Time System	√	√	√				
Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 580\TRUCK DC 16 [---06>---13]\Compressed air reserve system\APS Compressed air power supply(Scania protocol)	√	√	√	√			0003
Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 580\TRUCK DC 16 [---06>---13]\Compressed air reserve system\APS Compressed air power supply(Wabco protocol)	√	√	√	√			
Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 580\TRUCK DC 16 [---06>---13]\Diesel injection\EEC-Exhaust gas treatment	√	√	√	√		√	
Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 580\TRUCK DC 16 [---06>---13]\Diesel injection\EMS Engine management system S6-S7	√	√	√	√		√	0002, 0015, 0017
Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 580\TRUCK DC 16 [---06>---13]\Diesel injection\EMS Engine management system S8(8 Cylindes)	√	√	√	√		√	0001
Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 580\TRUCK DC 16 [---06>---13]\Diesel injection\EMS Engine management system DC13(6 Cylindes)	√	√	√	√		√	
Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 580\TRUCK DC 16 [---06>---13]\Distance control\DAS Adaptive Cruise Control	√	√	√				
Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 580\TRUCK DC 16 [---06>---13]\Distance control\DIS Adaptive Cruise Control	√	√	√				
Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 580\TRUCK DC 16 [---06>---13]\EBS\BMS Brake management system 5.0 (4x2)	√	√	√	√		√	0004
Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 580\TRUCK DC 16 [---06>---13]\EBS\BMS Brake management system 5.0 (6x2 - 6x4)	√	√	√	√		√	0004
Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 580\TRUCK DC 16 [---06>---13]\EBS\BMS Brake management system 5.0 (8x2)	√	√	√	√		√	0004
Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 580\TRUCK DC 16 [---06>---13]\ECU external light\VIS Visibility system	√	√	√	√		√	
Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 580\TRUCK DC 16 [---06>---13]\Engine-vehicle adjustment\COO Coordinator module	√	√	√	√		√	
Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 580\TRUCK DC 16 [---06>---13]\Engine-vehicle adjustment\COO7 (Coordinator)	√	√	√	√		√	
Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 580\TRUCK DC 16 [---06>---13]\Four-wheel drive\AWD ALL-Wheel Drive	√	√	√				
Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 580\TRUCK DC 16 [---06>---13]\Instrument panel\NCL Instrument Panel 1	√	√	√	√		√	
Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 580\TRUCK DC 16 [---06>---13]\Instrument panel\NCL Instrument Panel 2	√	√	√	√		√	
Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 580\TRUCK DC 16 [---06>---13]\Radio\AUS Audio system	√	√	√				
Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 580\TRUCK DC 16 [---06>---13]\Retarder\RET Retarder	√	√	√	√		√	
Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 580\TRUCK DC 16 [---06>---13]\Suspensions\SMS Suspension management system	√	√	√	√			0006, 0007, 0014
Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 580\TRUCK DC 16 [---06>---13]\Tachograph\DTCO Tachograph	√	√	√				
Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 580\TRUCK DC 16 [---06>---13]\Tachograph\MTCO Tachograph	√	√	√				
Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 580\TRUCK DC 16 [---06>---13]\Tire pressure\TPM - Tires Pressure Monitoring System	√	√	√				
Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 580\TRUCK DC 16 [---06>---13]\Transmission\GMS - Gear management system A4	√	√	√			√	
Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 580\TRUCK DC 16 [---06>---13]\Transmission\GMS - Gear management system OPC	√	√	√	√		√	0005
Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 580\TRUCK DC 16 [---06>---13]\Transmission\GMS - Gear management system Opticruise 5	√	√	√	√		√	0009, 0011, 0018
Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 580\TRUCK DC 16 [---06>---13]\Transmission\GMS - GMS Opticruise 5	√	√	√	√		√	0009, 0011, 0018
Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 580\TRUCK DC 16 [---06>---13]\Transport information system\RTI - Road Transport Informatics	√	√	√				
Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 620\TRUCK DC 16 EU5 [---08>---13]\ABS\BMS Brake management system-ABS E	√	√	√	√		√	
Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 620\TRUCK DC 16 EU5 [---08>---13]\Aid for keeping lane\LDW Monitor traffic lane	√	√	√				
Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 620\TRUCK DC 16 EU5 [---08>---13]\Air conditioner\CCS Climate control system	√	√	√	√		√	
Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 620\TRUCK DC 16 EU5 [---08>---13]\Airbag\CSS Climate safety system	√	√	√				

Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 620\TRUCK DC 16 EU5 [---08>----13]\Alarm\LAS Locking and alarm system	√	√	√				
Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 620\TRUCK DC 16 EU5 [---08>----13]\Auxiliary heating\ATA Auxiliary heating system air-to-air	√	√	√	√			
Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 620\TRUCK DC 16 EU5 [---08>----13]\Auxiliary heating\WTA Auxiliary heating system water-to-air	√	√	√				
Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 620\TRUCK DC 16 EU5 [---08>----13]\Chassis equipment and design\BWS Preparation system	√	√	√				
Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 620\TRUCK DC 16 EU5 [---08>----13]\Comfort system\CTS Clock and Time System	√	√	√				
Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 620\TRUCK DC 16 EU5 [---08>----13]\Compressed air reserve system\APS Compressed air power supply(Scania protocol)	√	√	√	√			0003
Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 620\TRUCK DC 16 EU5 [---08>----13]\Compressed air reserve system\APS Compressed air power supply(Wabco protocol)	√	√	√	√			
Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 620\TRUCK DC 16 EU5 [---08>----13]\Diesel injection\EEC-Exhaust gas treatment	√	√	√	√		√	
Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 620\TRUCK DC 16 EU5 [---08>----13]\Diesel injection\EMS Engine management system S6-S7	√	√	√	√		√	0002, 0015, 0017
Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 620\TRUCK DC 16 EU5 [---08>----13]\Diesel injection\EMS Engine management system S8(8 Cylindes)	√	√	√	√		√	0001
Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 620\TRUCK DC 16 EU5 [---08>----13]\Diesel injection\EMS Engine management system DC13(6 Cylindes)	√	√	√	√		√	
Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 620\TRUCK DC 16 EU5 [---08>----13]\Distance control\DAS Adaptive Cruise Control	√	√	√				
Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 620\TRUCK DC 16 EU5 [---08>----13]\Distance control\DIS Adaptive Cruise Control	√	√	√				
Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 620\TRUCK DC 16 EU5 [---08>----13]\EBS\BMS Brake management system 5.0 (4x2)	√	√	√	√		√	0004
Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 620\TRUCK DC 16 EU5 [---08>----13]\EBS\BMS Brake management system 5.0 (6x2 - 6x4)	√	√	√	√		√	0004
Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 620\TRUCK DC 16 EU5 [---08>----13]\EBS\BMS Brake management system 5.0 (8x2)	√	√	√	√		√	0004
Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 620\TRUCK DC 16 EU5 [---08>----13]\ECU external light\VIS Visibility system	√	√	√	√		√	
Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 620\TRUCK DC 16 EU5 [---08>----13]\Engine-vehicle adjustment\COO Coordinator module	√	√	√	√		√	
Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 620\TRUCK DC 16 EU5 [---08>----13]\Engine-vehicle adjustment\COO7 (Coordinator)	√	√	√	√		√	
Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 620\TRUCK DC 16 EU5 [---08>----13]\Four-wheel drive\AWD ALL-Wheel Drive	√	√	√				
Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 620\TRUCK DC 16 EU5 [---08>----13]\Instrument panel\NCL Instrument Panel 1	√	√	√	√		√	
Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 620\TRUCK DC 16 EU5 [---08>----13]\Instrument panel\NCL Instrument Panel 2	√	√	√	√		√	
Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 620\TRUCK DC 16 EU5 [---08>----13]\Radio\AUS Audio system	√	√	√				
Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 620\TRUCK DC 16 EU5 [---08>----13]\Retarder\RET Retarder	√	√	√	√		√	
Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 620\TRUCK DC 16 EU5 [---08>----13]\Suspensions\SMS Supension management system	√	√	√	√			0006, 0007, 0014
Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 620\TRUCK DC 16 EU5 [---08>----13]\Tachograph\DTCO Tachograph	√	√	√				
Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 620\TRUCK DC 16 EU5 [---08>----13]\Tachograph\MTCO Tachograph	√	√	√				
Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 620\TRUCK DC 16 EU5 [---08>----13]\Tire pressure\TPM - Tires Pressure Monitoring System	√	√	√				
Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 620\TRUCK DC 16 EU5 [---08>----13]\Transmission\GMS - Gear management system A4	√	√	√			√	
Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 620\TRUCK DC 16 EU5 [---08>----13]\Transmission\GMS - Gear management system OPC	√	√	√	√		√	0005
Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 620\TRUCK DC 16 EU5 [---08>----13]\Transmission\GMS - Gear management system Opticruise 5	√	√	√	√		√	0009, 0011, 0018
Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 620\TRUCK DC 16 EU5 [---08>----13]\Transmission\GMS - GMS Opticruise 5	√	√	√	√		√	0009, 0011, 0018
Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 620\TRUCK DC 16 EU5 [---08>----13]\Transport information system\RTI - Road Transport Informatics	√	√	√				
Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 620\TRUCK DC 16 [---06>----13]\ABS\BMS Brake management system-ABS E	√	√	√	√		√	
Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 620\TRUCK DC 16 [---06>----13]\Aid for keeping lane\LDW Monitor traffic lane	√	√	√				

Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 620\TRUCK DC 16 [---06>---13]\Air conditioner\CCS Climate control system	√	√	√	√		√	
Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 620\TRUCK DC 16 [---06>---13]\Airbag\CSS Climate safety system	√	√	√				
Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 620\TRUCK DC 16 [---06>---13]\Alarm\LAS Locking and alarm system	√	√	√				
Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 620\TRUCK DC 16 [---06>---13]\Auxiliary heating\ATA Auxiliary heating system air-to-air	√	√	√	√			
Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 620\TRUCK DC 16 [---06>---13]\Auxiliary heating\WTA Auxiliary heating system water-to-air	√	√	√				
Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 620\TRUCK DC 16 [---06>---13]\Chassis equipment and design\BWS Preparation system	√	√	√				
Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 620\TRUCK DC 16 [---06>---13]\Comfort system\CTS Clock and Time System	√	√	√				
Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 620\TRUCK DC 16 [---06>---13]\Compressed air reserve system\APS Compressed air power supply(Scania protocol)	√	√	√	√			0003
Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 620\TRUCK DC 16 [---06>---13]\Compressed air reserve system\APS Compressed air power supply(Wabco protocol)	√	√	√	√			
Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 620\TRUCK DC 16 [---06>---13]\Diesel injection\EEC-Exhaust gas treatment	√	√	√	√		√	
Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 620\TRUCK DC 16 [---06>---13]\Diesel injection\EMS Engine management system S6-S7	√	√	√	√		√	0002, 0015, 0017
Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 620\TRUCK DC 16 [---06>---13]\Diesel injection\EMS Engine management system S8(8 Cylindes)	√	√	√	√		√	0001
Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 620\TRUCK DC 16 [---06>---13]\Diesel injection\EMS Engine management system DC13(6 Cylindes)	√	√	√	√		√	
Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 620\TRUCK DC 16 [---06>---13]\Distance control\DAS Adaptive Cruise Control	√	√	√				
Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 620\TRUCK DC 16 [---06>---13]\Distance control\DIS Adaptive Cruise Control	√	√	√				
Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 620\TRUCK DC 16 [---06>---13]\EBS\BMS Brake management system 5.0 (4x2)	√	√	√	√		√	0004
Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 620\TRUCK DC 16 [---06>---13]\EBS\BMS Brake management system 5.0 (6x2 - 6x4)	√	√	√	√		√	0004
Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 620\TRUCK DC 16 [---06>---13]\EBS\BMS Brake management system 5.0 (8x2)	√	√	√	√		√	0004
Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 620\TRUCK DC 16 [---06>---13]\ECU external light\VIS Visibility system	√	√	√	√		√	
Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 620\TRUCK DC 16 [---06>---13]\Engine-vehicle adjustment\COO Coordinator module	√	√	√	√		√	
Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 620\TRUCK DC 16 [---06>---13]\Engine-vehicle adjustment\COO7 (Coordinator)	√	√	√	√		√	
Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 620\TRUCK DC 16 [---06>---13]\Four-wheel drive\AWD ALL-Wheel Drive	√	√	√				
Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 620\TRUCK DC 16 [---06>---13]\Instrument panel\ICL Instrument Panel 1	√	√	√	√		√	
Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 620\TRUCK DC 16 [---06>---13]\Instrument panel\ICL Instrument Panel 2	√	√	√	√		√	
Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 620\TRUCK DC 16 [---06>---13]\Radio\AUS Audio system	√	√	√				
Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 620\TRUCK DC 16 [---06>---13]\Retarder\RET Retarder	√	√	√	√		√	
Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 620\TRUCK DC 16 [---06>---13]\Suspensions\SMS Suspension management system	√	√	√	√			0006, 0007, 0014
Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 620\TRUCK DC 16 [---06>---13]\Tachograph\DTCO Tachograph	√	√	√				
Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 620\TRUCK DC 16 [---06>---13]\Tachograph\MTCO Tachograph	√	√	√				
Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 620\TRUCK DC 16 [---06>---13]\Tire pressure\TPM - Tires Pressure Monitoring System	√	√	√				
Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 620\TRUCK DC 16 [---06>---13]\Transmission\GMS - Gear management system A4	√	√	√			√	
Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 620\TRUCK DC 16 [---06>---13]\Transmission\GMS - Gear management system OPC	√	√	√	√		√	0005
Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 620\TRUCK DC 16 [---06>---13]\Transmission\GMS - Gear management system Opticruise 5	√	√	√	√		√	0009, 0011, 0018
Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 620\TRUCK DC 16 [---06>---13]\Transmission\GMS - GMS Opticruise 5	√	√	√	√		√	0009, 0011, 0018
Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 620\TRUCK DC 16 [---06>---13]\Transport information system\RTI - Road Transport Informatics	√	√	√				

Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 730\TRUCK DC 16 [---10>---13]\ABS\BMS Brake management system-ABS E	√	√	√	√		√	
Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 730\TRUCK DC 16 [---10>---13]\Aid for keeping lane\LDW Monitor traffic lane	√	√	√				
Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 730\TRUCK DC 16 [---10>---13]\Air conditioner\CCS Climate control system	√	√	√	√		√	
Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 730\TRUCK DC 16 [---10>---13]\Airbag\CSS Climate safety system	√	√	√				
Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 730\TRUCK DC 16 [---10>---13]\Alarm\LAS Locking and alarm system	√	√	√				
Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 730\TRUCK DC 16 [---10>---13]\Auxiliary heating\ATA Auxiliary heating system air-to-air	√	√	√	√			
Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 730\TRUCK DC 16 [---10>---13]\Auxiliary heating\WTA Auxiliary heating system water-to-air	√	√	√				
Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 730\TRUCK DC 16 [---10>---13]\Chassis equipment and design\BWS Preparation system	√	√	√				
Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 730\TRUCK DC 16 [---10>---13]\Comfort system\CTS Clock and Time System	√	√	√				
Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 730\TRUCK DC 16 [---10>---13]\Compressed air reserve system\APS Compressed air power supply(Scania protocol)	√	√	√	√			0003
Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 730\TRUCK DC 16 [---10>---13]\Compressed air reserve system\APS Compressed air power supply(Wabco protocol)	√	√	√	√			
Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 730\TRUCK DC 16 [---10>---13]\Diesel injection\EEC-Exhaust gas treatment	√	√	√	√		√	
Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 730\TRUCK DC 16 [---10>---13]\Diesel injection\EMS Engine management system S6-S7	√	√	√	√		√	0002, 0015, 0017
Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 730\TRUCK DC 16 [---10>---13]\Diesel injection\EMS Engine management system S8(8 Cylindes)	√	√	√	√		√	0001
Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 730\TRUCK DC 16 [---10>---13]\Diesel injection\EMS Engine management system DC13(6 Cylindes)	√	√	√	√		√	
Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 730\TRUCK DC 16 [---10>---13]\Distance control\DAS Adaptive Cruise Control	√	√	√				
Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 730\TRUCK DC 16 [---10>---13]\Distance control\DIS Adaptive Cruise Control	√	√	√				
Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 730\TRUCK DC 16 [---10>---13]\EBS\BMS Brake management system 5.0 (4x2)	√	√	√	√		√	0004
Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 730\TRUCK DC 16 [---10>---13]\EBS\BMS Brake management system 5.0 (6x2 - 6x4)	√	√	√	√		√	0004
Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 730\TRUCK DC 16 [---10>---13]\EBS\BMS Brake management system 5.0 (8x2)	√	√	√	√		√	0004
Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 730\TRUCK DC 16 [---10>---13]\ECU external light\VIS Visibility system	√	√	√	√		√	
Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 730\TRUCK DC 16 [---10>---13]\Engine-vehicle adjustment\COO Coordinator module	√	√	√	√		√	
Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 730\TRUCK DC 16 [---10>---13]\Engine-vehicle adjustment\COO7 (Coordinator)	√	√	√	√		√	
Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 730\TRUCK DC 16 [---10>---13]\Four-wheel drive\AWD ALL-Wheel Drive	√	√	√				
Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 730\TRUCK DC 16 [---10>---13]\Instrument panel\NCL Instrument Panel 1	√	√	√	√		√	
Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 730\TRUCK DC 16 [---10>---13]\Instrument panel\NCL Instrument Panel 2	√	√	√	√		√	
Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 730\TRUCK DC 16 [---10>---13]\Radio\AUS Audio system	√	√	√				
Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 730\TRUCK DC 16 [---10>---13]\Retarder\RET Retarder	√	√	√	√		√	
Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 730\TRUCK DC 16 [---10>---13]\Suspensions\SMS Suspension management system	√	√	√	√			0006, 0007, 0014
Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 730\TRUCK DC 16 [---10>---13]\Tachograph\DTCO Tachograph	√	√	√				
Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 730\TRUCK DC 16 [---10>---13]\Tachograph\WTCO Tachograph	√	√	√				
Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 730\TRUCK DC 16 [---10>---13]\Tire pressure\TPM - Tires Pressure Monitoring System	√	√	√				
Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 730\TRUCK DC 16 [---10>---13]\Transmission\GMS - Gear management system A4	√	√	√			√	
Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 730\TRUCK DC 16 [---10>---13]\Transmission\GMS - Gear management system OPC	√	√	√	√		√	0005
Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 730\TRUCK DC 16 [---10>---13]\Transmission\GMS - Gear management system Opticruise 5	√	√	√	√		√	0009, 0011, 0018

Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 730\TRUCK DC 16 [---10>---13]\Transmission\GMS - GMS Opticruise 5	√	√	√	√		√	0009, 0011, 0018
Scania\Divided By Vehicle\TRUCK\R-Serie\Engine 730\TRUCK DC 16 [---10>---13]\Transport information system\RTI - Road Transport Informatics	√	√	√				
Scania\Divided By Vehicle\TRUCK\R-Serie Euro 6\ABS\BMS Brake management system-ABS E	√	√	√	√		√	
Scania\Divided By Vehicle\TRUCK\R-Serie Euro 6\Aid for keeping lane\LDW Monitor traffic lane	√	√	√				
Scania\Divided By Vehicle\TRUCK\R-Serie Euro 6\Air conditioner\CCS Climate control system	√	√	√	√		√	
Scania\Divided By Vehicle\TRUCK\R-Serie Euro 6\Airbag\CSS Climate safety system	√	√	√				
Scania\Divided By Vehicle\TRUCK\R-Serie Euro 6\Alarm\LAS Locking and alarm system	√	√	√				
Scania\Divided By Vehicle\TRUCK\R-Serie Euro 6\Auxiliary heating\ATA Auxiliary heating system air-to-air	√	√	√	√			
Scania\Divided By Vehicle\TRUCK\R-Serie Euro 6\Auxiliary heating\WTA Auxiliary heating system water-to-air	√	√	√				
Scania\Divided By Vehicle\TRUCK\R-Serie Euro 6\Chassis equipment and design\BWS Preparation system	√	√	√				
Scania\Divided By Vehicle\TRUCK\R-Serie Euro 6\Comfort system\CTS Clock and Time System	√	√	√				
Scania\Divided By Vehicle\TRUCK\R-Serie Euro 6\Compressed air reserve system\APS Compressed air power supply(Scania protocol)	√	√	√	√			0003
Scania\Divided By Vehicle\TRUCK\R-Serie Euro 6\Compressed air reserve system\APS Compressed air power supply(Wabco protocol)	√	√	√	√			
Scania\Divided By Vehicle\TRUCK\R-Serie Euro 6\Diesel injection\EMS Engine management system S8(8 Cylindes)	√	√	√	√		√	0001
Scania\Divided By Vehicle\TRUCK\R-Serie Euro 6\Diesel injection\EMS Engine management system DC13(6 Cylindes)	√	√	√	√		√	
Scania\Divided By Vehicle\TRUCK\R-Serie Euro 6\Distance control\DAS Adaptive Cruise Control	√	√	√				
Scania\Divided By Vehicle\TRUCK\R-Serie Euro 6\Distance control\DIS Adaptive Cruise Control	√	√	√				
Scania\Divided By Vehicle\TRUCK\R-Serie Euro 6\EBS\BMS Brake management system 5.0 (4x2)	√	√	√	√		√	0004
Scania\Divided By Vehicle\TRUCK\R-Serie Euro 6\EBS\BMS Brake management system 5.0 (6x2 - 6x4)	√	√	√	√		√	0004
Scania\Divided By Vehicle\TRUCK\R-Serie Euro 6\EBS\BMS Brake management system 5.0 (8x2)	√	√	√	√		√	0004
Scania\Divided By Vehicle\TRUCK\R-Serie Euro 6\ECU external light\VIS Visibility system	√	√	√	√		√	
Scania\Divided By Vehicle\TRUCK\R-Serie Euro 6\Engine-vehicle adjustment\COO Coordinator module	√	√	√	√		√	
Scania\Divided By Vehicle\TRUCK\R-Serie Euro 6\Engine-vehicle adjustment\COO7 (Coordinator)	√	√	√	√		√	
Scania\Divided By Vehicle\TRUCK\R-Serie Euro 6\Four-wheel drive\AWD ALL-Wheel Drive	√	√	√				
Scania\Divided By Vehicle\TRUCK\R-Serie Euro 6\Instrument panel\NCL Instrument Panel 1	√	√	√	√		√	
Scania\Divided By Vehicle\TRUCK\R-Serie Euro 6\Instrument panel\NCL Instrument Panel 2	√	√	√	√		√	
Scania\Divided By Vehicle\TRUCK\R-Serie Euro 6\Radio\AUS Audio system	√	√	√				
Scania\Divided By Vehicle\TRUCK\R-Serie Euro 6\Retarder\RET Retarder	√	√	√	√		√	
Scania\Divided By Vehicle\TRUCK\R-Serie Euro 6\Suspensions\SMS Suspension management system	√	√	√	√			0006, 0007, 0014
Scania\Divided By Vehicle\TRUCK\R-Serie Euro 6\Tachograph\DTCO Tachograph	√	√	√				
Scania\Divided By Vehicle\TRUCK\R-Serie Euro 6\Tachograph\MTCO Tachograph	√	√	√				
Scania\Divided By Vehicle\TRUCK\R-Serie Euro 6\Tire pressure\TPM - Tires Pressure Monitoring System	√	√	√				
Scania\Divided By Vehicle\TRUCK\R-Serie Euro 6\Transmission\GMS - Gear management system A4	√	√	√			√	
Scania\Divided By Vehicle\TRUCK\R-Serie Euro 6\Transmission\GMS - Gear management system OPC	√	√	√	√		√	0005
Scania\Divided By Vehicle\TRUCK\R-Serie Euro 6\Transmission\GMS - Gear management system Opticruise 5	√	√	√	√		√	0009, 0011, 0018

Scania\Divided By Vehicle\TRUCK\R-Serie Euro 6\Transmission\GMS - GMS Opticruise 5	√	√	√	√		√	0009, 0011, 0018
Scania\Divided By Vehicle\TRUCK\R-Serie Euro 6\Transport information system\RTI - Road Transport Informatics	√	√	√				
Scania\Divided By Vehicle\BUS&Coach\K series\K 113\Bus DCS 11 [---91>---98]\Transmission\Ecomat 1	√	√	√				
Scania\Divided By Vehicle\BUS&Coach\K series\K124\Bus DC 12 [---98>]\DIESEL INJECTION\Bosch PDE EDC MS 6.2	√	√	√	√		√	
Scania\Divided By Vehicle\BUS&Coach\K series\K124\Bus DC 12 [---98>]\DIESEL INJECTION\Bosch EDC MS 5	√	√	√	√			
Scania\Divided By Vehicle\BUS&Coach\K series\K124\Bus DC 12 [---98>]\DIESEL INJECTION\Bosch HPI EDC S 6	√	√	√	√			
Scania\Divided By Vehicle\BUS&Coach\K series\K124\Bus DC 12 HPI [---98>]\Transmission\Ecomat 2	√	√	√	√		√	
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 230\TRUCK DC 9 [---04>---08]\ABS\BMS Brake management system-ABS E	√	√	√	√		√	
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 230\TRUCK DC 9 [---04>---08]\Aid for keeping lane\LDW Monitor traffic lane	√	√	√				
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 230\TRUCK DC 9 [---04>---08]\Air conditioner\CCS Climate control system	√	√	√	√		√	
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 230\TRUCK DC 9 [---04>---08]\Airbag\CSS Climate safety system	√	√	√				
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 230\TRUCK DC 9 [---04>---08]\Alarm\LAS Locking and alarm system	√	√	√				
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 230\TRUCK DC 9 [---04>---08]\Auxiliary heating\ATA Auxiliary heating system air-to-air	√	√	√	√			
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 230\TRUCK DC 9 [---04>---08]\Auxiliary heating\WTA Auxiliary heating system water-to-air	√	√	√				
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 230\TRUCK DC 9 [---04>---08]\Chassis equipment and design\BWS Preparation system	√	√	√				
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 230\TRUCK DC 9 [---04>---08]\Comfort system\CTS Clock and Time System	√	√	√				
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 230\TRUCK DC 9 [---04>---08]\Compressed air reserve system\APS Compressed air power supply(Scania protocol)	√	√	√	√			0003
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 230\TRUCK DC 9 [---04>---08]\Compressed air reserve system\APS Compressed air power supply(Wabco protocol)	√	√	√	√			
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 230\TRUCK DC 9 [---04>---08]\Diesel injection\EEC-Exhaust gas treatment	√	√	√	√		√	
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 230\TRUCK DC 9 [---04>---08]\Diesel injection\EMS Engine management system S6-S7	√	√	√	√		√	0002, 0015, 0017
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 230\TRUCK DC 9 [---04>---08]\Diesel injection\EMS Engine management system S8(8 Cylindes)	√	√	√	√		√	0001
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 230\TRUCK DC 9 [---04>---08]\Diesel injection\EMS Engine management system DC13(6 Cylindes)	√	√	√	√		√	
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 230\TRUCK DC 9 [---04>---08]\Distance control\DAS Adaptive Cruise Control	√	√	√				
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 230\TRUCK DC 9 [---04>---08]\Distance control\DIS Adaptive Cruise Control	√	√	√				
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 230\TRUCK DC 9 [---04>---08]\EBS\BMS Brake management system 5.0 (4x2)	√	√	√	√		√	0004
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 230\TRUCK DC 9 [---04>---08]\EBS\BMS Brake management system 5.0 (6x2 - 6x4)	√	√	√	√		√	0004
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 230\TRUCK DC 9 [---04>---08]\EBS\BMS Brake management system 5.0 (8x2)	√	√	√	√		√	0004
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 230\TRUCK DC 9 [---04>---08]\ECU external light\VIS Visibility system	√	√	√	√		√	
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 230\TRUCK DC 9 [---04>---08]\Engine-vehicle adjustment\COO Coordinator module	√	√	√	√		√	
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 230\TRUCK DC 9 [---04>---08]\Engine-vehicle adjustment\COO7 (Coordinator)	√	√	√	√		√	
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 230\TRUCK DC 9 [---04>---08]\Four-wheel drive\AWD ALL-Wheel Drive	√	√	√				
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 230\TRUCK DC 9 [---04>---08]\Instrument panel\NCL Instrument Panel 1	√	√	√	√		√	
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 230\TRUCK DC 9 [---04>---08]\Instrument panel\NCL Instrument Panel 2	√	√	√	√		√	
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 230\TRUCK DC 9 [---04>---08]\Radio\AUS Audio system	√	√	√				
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 230\TRUCK DC 9 [---04>---08]\Retarder\RET Retarder	√	√	√	√		√	

Scania\Divided By Vehicle\BUS&Coach\K series\Engine 230\TRUCK DC 9 [--04>---08]\Suspensions\SMS Suspension management system	√	√	√	√			0006, 0007, 0014
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 230\TRUCK DC 9 [--04>---08]\Tachograph\DTCO Tachograph	√	√	√				
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 230\TRUCK DC 9 [--04>---08]\Tachograph\MTCO Tachograph	√	√	√				
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 230\TRUCK DC 9 [--04>---08]\Tire pressure\TPM - Tires Pressure Monitoring System	√	√	√				
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 230\TRUCK DC 9 [--04>---08]\Transmission\GMS - Gear management system A4	√	√	√			√	
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 230\TRUCK DC 9 [--04>---08]\Transmission\GMS - Gear management system OPC	√	√	√	√		√	0005
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 230\TRUCK DC 9 [--04>---08]\Transmission\GMS - Gear management system Opticruise 5	√	√	√	√		√	0009, 0011, 0018
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 230\TRUCK DC 9 [--04>---08]\Transmission\GMS - GMS Opticruise 5	√	√	√	√		√	0009, 0011, 0018
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 230\TRUCK DC 9 [--04>---08]\Transport information system\RTI - Road Transport Informatics	√	√	√				
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 270\TRUCK DC 9 [--04>---08]\ABS\BMS Brake management system-ABS E	√	√	√	√		√	
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 270\TRUCK DC 9 [--04>---08]\Aid for keeping lane\LDW Monitor traffic lane	√	√	√				
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 270\TRUCK DC 9 [--04>---08]\Air conditioner\CCS Climate control system	√	√	√	√		√	
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 270\TRUCK DC 9 [--04>---08]\Airbag\CSS Climate safety system	√	√	√				
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 270\TRUCK DC 9 [--04>---08]\Alarm\LAS Locking and alarm system	√	√	√				
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 270\TRUCK DC 9 [--04>---08]\Auxiliary heating\ATA Auxiliary heating system air-to-air	√	√	√	√			
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 270\TRUCK DC 9 [--04>---08]\Auxiliary heating\WTA Auxiliary heating system water-to-air	√	√	√				
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 270\TRUCK DC 9 [--04>---08]\Chassis equipment and design\BWS Preparation system	√	√	√				
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 270\TRUCK DC 9 [--04>---08]\Comfort system\CTS Clock and Time System	√	√	√				
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 270\TRUCK DC 9 [--04>---08]\Compressed air reserve system\APS Compressed air power supply(Scania protocol)	√	√	√	√			0003
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 270\TRUCK DC 9 [--04>---08]\Compressed air reserve system\APS Compressed air power supply(Wabco protocol)	√	√	√	√			
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 270\TRUCK DC 9 [--04>---08]\Diesel injection\EEC-Exhaust gas treatment	√	√	√	√		√	
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 270\TRUCK DC 9 [--04>---08]\Diesel injection\EMS Engine management system S6-S7	√	√	√	√		√	0002, 0015, 0017
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 270\TRUCK DC 9 [--04>---08]\Diesel injection\EMS Engine management system S8(8 Cylindes)	√	√	√	√		√	0001
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 270\TRUCK DC 9 [--04>---08]\Diesel injection\EMS Engine management system DC13(6 Cylindes)	√	√	√	√		√	
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 270\TRUCK DC 9 [--04>---08]\Distance control\DAS Adaptive Cruise Control	√	√	√				
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 270\TRUCK DC 9 [--04>---08]\Distance control\DIS Adaptive Cruise Control	√	√	√				
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 270\TRUCK DC 9 [--04>---08]\EBS\BMS Brake management system 5.0 (4x2)	√	√	√	√		√	0004
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 270\TRUCK DC 9 [--04>---08]\EBS\BMS Brake management system 5.0 (6x2 - 6x4)	√	√	√	√		√	0004
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 270\TRUCK DC 9 [--04>---08]\EBS\BMS Brake management system 5.0 (8x2)	√	√	√	√		√	0004
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 270\TRUCK DC 9 [--04>---08]\ECU external light\VIS Visibility system	√	√	√	√		√	
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 270\TRUCK DC 9 [--04>---08]\Engine-vehicle adjustment\COO Coordinator module	√	√	√	√		√	
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 270\TRUCK DC 9 [--04>---08]\Engine-vehicle adjustment\COO7 (Coordinator)	√	√	√	√		√	
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 270\TRUCK DC 9 [--04>---08]\Four-wheel drive\AWD ALL-Wheel Drive	√	√	√				
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 270\TRUCK DC 9 [--04>---08]\Instrument panel\NCL Instrument Panel 1	√	√	√	√		√	
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 270\TRUCK DC 9 [--04>---08]\Instrument panel\NCL Instrument Panel 2	√	√	√	√		√	

Scania\Divided By Vehicle\BUS&Coach\K series\Engine 270\TRUCK DC 9 [---04>---08]\Radio\AUS Audio system	√	√	√				
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 270\TRUCK DC 9 [---04>---08]\Retarder\RET Retarder	√	√	√	√		√	
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 270\TRUCK DC 9 [---04>---08]\Suspensions\SMS Supension management system	√	√	√	√			0006, 0007, 0014
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 270\TRUCK DC 9 [---04>---08]\Tachograph\DTCO Tachograph	√	√	√				
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 270\TRUCK DC 9 [---04>---08]\Tachograph\MTCO Tachograph	√	√	√				
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 270\TRUCK DC 9 [---04>---08]\Tire pressure\TPM - Tires Pressure Monitoring System	√	√	√				
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 270\TRUCK DC 9 [---04>---08]\Transmission\GMS - Gear management system A4	√	√	√			√	
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 270\TRUCK DC 9 [---04>---08]\Transmission\GMS - Gear management system OPC	√	√	√	√		√	0005
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 270\TRUCK DC 9 [---04>---08]\Transmission\GMS - Gear management system Opticruise 5	√	√	√	√		√	0009, 0011, 0018
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 270\TRUCK DC 9 [---04>---08]\Transmission\GMS - GMS Opticruise 5	√	√	√	√		√	0009, 0011, 0018
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 270\TRUCK DC 9 [---04>---08]\Transport information system\RTI - Road Transport Informatics	√	√	√				
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 280\TRUCK DC 9 [---08>---13]\ABS\BMS Brake management system-ABS E	√	√	√	√		√	
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 280\TRUCK DC 9 [---08>---13]\Aid for keeping lane\LDW Monitor traffic lane	√	√	√				
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 280\TRUCK DC 9 [---08>---13]\Air conditioner\CCS Climate control system	√	√	√	√		√	
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 280\TRUCK DC 9 [---08>---13]\Airbag\CSS Climate safety system	√	√	√				
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 280\TRUCK DC 9 [---08>---13]\Alarm\LAS Locking and alarm system	√	√	√				
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 280\TRUCK DC 9 [---08>---13]\Auxiliary heating\ATA Auxiliary heating system air-to-air	√	√	√	√			
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 280\TRUCK DC 9 [---08>---13]\Auxiliary heating\WTA Auxiliary heating system water-to-air	√	√	√				
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 280\TRUCK DC 9 [---08>---13]\Chassis equipment and design\BWS Preparation system	√	√	√				
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 280\TRUCK DC 9 [---08>---13]\Comfort system\CTS Clock and Time System	√	√	√				
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 280\TRUCK DC 9 [---08>---13]\Compressed air reserve system\APS Compressed air power supply(Scania protocol)	√	√	√	√			0003
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 280\TRUCK DC 9 [---08>---13]\Compressed air reserve system\APS Compressed air power supply(Wabco protocol)	√	√	√	√			
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 280\TRUCK DC 9 [---08>---13]\Diesel injection\EEC-Exhaust gas treatment	√	√	√	√		√	
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 280\TRUCK DC 9 [---08>---13]\Diesel injection\EMS Engine management system S6-S7	√	√	√	√		√	0002, 0015, 0017
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 280\TRUCK DC 9 [---08>---13]\Diesel injection\EMS Engine management system S8(8 Cylindes)	√	√	√	√		√	0001
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 280\TRUCK DC 9 [---08>---13]\Diesel injection\EMS Engine management system DC13(6 Cylindes)	√	√	√	√		√	
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 280\TRUCK DC 9 [---08>---13]\Distance control\DAS Adaptive Cruise Control	√	√	√				
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 280\TRUCK DC 9 [---08>---13]\Distance control\DIS Adaptive Cruise Control	√	√	√				
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 280\TRUCK DC 9 [---08>---13]\EBS\BMS Brake management system 5.0 (4x2)	√	√	√	√		√	0004
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 280\TRUCK DC 9 [---08>---13]\EBS\BMS Brake management system 5.0 (6x2 - 6x4)	√	√	√	√		√	0004
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 280\TRUCK DC 9 [---08>---13]\EBS\BMS Brake management system 5.0 (8x2)	√	√	√	√		√	0004
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 280\TRUCK DC 9 [---08>---13]\ECU external light\VIS Visibility system	√	√	√	√		√	
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 280\TRUCK DC 9 [---08>---13]\Engine-vehicle adjustment\COO Coordinator module	√	√	√	√		√	
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 280\TRUCK DC 9 [---08>---13]\Engine-vehicle adjustment\COO7 (Coordinator)	√	√	√	√		√	
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 280\TRUCK DC 9 [---08>---13]\Four-wheel drive\AWD ALL-Wheel Drive	√	√	√				

Scania\Divided By Vehicle\BUS&Coach\K series\Engine 280\TRUCK DC 9 [---08>---13]\Instrument panel\NCL Instrument Panel 1	√	√	√	√		√	
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 280\TRUCK DC 9 [---08>---13]\Instrument panel\NCL Instrument Panel 2	√	√	√	√		√	
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 280\TRUCK DC 9 [---08>---13]\Radio\AUS Audio system	√	√	√				
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 280\TRUCK DC 9 [---08>---13]\Retarder\RET Retarder	√	√	√	√		√	
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 280\TRUCK DC 9 [---08>---13]\Suspensions\SMS Suspension management system	√	√	√	√			0006, 0007, 0014
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 280\TRUCK DC 9 [---08>---13]\Tachograph\DTCO Tachograph	√	√	√				
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 280\TRUCK DC 9 [---08>---13]\Tachograph\MTCO Tachograph	√	√	√				
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 280\TRUCK DC 9 [---08>---13]\Tire pressure\TPM - Tires Pressure Monitoring System	√	√	√				
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 280\TRUCK DC 9 [---08>---13]\Transmission\GMS - Gear management system A4	√	√	√			√	
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 280\TRUCK DC 9 [---08>---13]\Transmission\GMS - Gear management system OPC	√	√	√	√		√	0005
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 280\TRUCK DC 9 [---08>---13]\Transmission\GMS - Gear management system Opticruise 5	√	√	√	√		√	0009, 0011, 0018
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 280\TRUCK DC 9 [---08>---13]\Transmission\GMS - GMS Opticruise 5	√	√	√	√		√	0009, 0011, 0018
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 280\TRUCK DC 9 [---08>---13]\Transport information system\RTI - Road Transport Informatics	√	√	√				
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 310\TRUCK DC 9 [---04>---13]\ABS\BMS Brake management system-ABS E	√	√	√	√		√	
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 310\TRUCK DC 9 [---04>---13]\Aid for keeping lane\LDW Monitor traffic lane	√	√	√				
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 310\TRUCK DC 9 [---04>---13]\Air conditioner\CCS Climate control system	√	√	√	√		√	
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 310\TRUCK DC 9 [---04>---13]\Airbag\CSS Climate safety system	√	√	√				
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 310\TRUCK DC 9 [---04>---13]\Alarm\LAS Locking and alarm system	√	√	√				
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 310\TRUCK DC 9 [---04>---13]\Auxiliary heating\ATA Auxiliary heating system air-to-air	√	√	√	√			
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 310\TRUCK DC 9 [---04>---13]\Auxiliary heating\WTA Auxiliary heating system water-to-air	√	√	√				
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 310\TRUCK DC 9 [---04>---13]\Chassis equipment and design\BWS Preparation system	√	√	√				
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 310\TRUCK DC 9 [---04>---13]\Comfort system\CTS Clock and Time System	√	√	√				
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 310\TRUCK DC 9 [---04>---13]\Compressed air reserve system\APS Compressed air power supply(Scania protocol)	√	√	√	√			0003
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 310\TRUCK DC 9 [---04>---13]\Compressed air reserve system\APS Compressed air power supply(Wabco protocol)	√	√	√	√			
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 310\TRUCK DC 9 [---04>---13]\Diesel injection\EEC-Exhaust gas treatment	√	√	√	√		√	
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 310\TRUCK DC 9 [---04>---13]\Diesel injection\EMS Engine management system S6-S7	√	√	√	√		√	0002, 0015, 0017
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 310\TRUCK DC 9 [---04>---13]\Diesel injection\EMS Engine management system S8(8 Cylindes)	√	√	√	√		√	0001
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 310\TRUCK DC 9 [---04>---13]\Diesel injection\EMS Engine management system DC13(6 Cylindes)	√	√	√	√		√	
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 310\TRUCK DC 9 [---04>---13]\Distance control\DAS Adaptive Cruise Control	√	√	√				
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 310\TRUCK DC 9 [---04>---13]\Distance control\DIS Adaptive Cruise Control	√	√	√				
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 310\TRUCK DC 9 [---04>---13]\EBS\BMS Brake management system 5.0 (4x2)	√	√	√	√		√	0004
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 310\TRUCK DC 9 [---04>---13]\EBS\BMS Brake management system 5.0 (6x2 - 6x4)	√	√	√	√		√	0004
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 310\TRUCK DC 9 [---04>---13]\EBS\BMS Brake management system 5.0 (8x2)	√	√	√	√		√	0004
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 310\TRUCK DC 9 [---04>---13]\ECU external light\VIS Visibility system	√	√	√	√		√	
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 310\TRUCK DC 9 [---04>---13]\Engine-vehicle adjustment\COO Coordinator module	√	√	√	√		√	

Scania\Divided By Vehicle\BUS&Coach\K series\Engine 310\TRUCK DC 9 [---04>---13]\Engine-vehicle adjustment\COO7 (Coordinator)	√	√	√	√		√	
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 310\TRUCK DC 9 [---04>---13]\Four-wheel drive\AWD ALL-Wheel Drive	√	√	√				
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 310\TRUCK DC 9 [---04>---13]\Instrument panel\NCL Instrument Panel 1	√	√	√	√		√	
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 310\TRUCK DC 9 [---04>---13]\Instrument panel\NCL Instrument Panel 2	√	√	√	√		√	
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 310\TRUCK DC 9 [---04>---13]\Radio\AUS Audio system	√	√	√				
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 310\TRUCK DC 9 [---04>---13]\Retarder\RET Retarder	√	√	√	√		√	
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 310\TRUCK DC 9 [---04>---13]\Suspensions\SMS Suspension management system	√	√	√	√			0006, 0007, 0014
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 310\TRUCK DC 9 [---04>---13]\Tachograph\DTCO Tachograph	√	√	√				
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 310\TRUCK DC 9 [---04>---13]\Tachograph\MTCO Tachograph	√	√	√				
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 310\TRUCK DC 9 [---04>---13]\Tire pressure\TPM - Tires Pressure Monitoring System	√	√	√				
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 310\TRUCK DC 9 [---04>---13]\Transmission\GMS - Gear management system A4	√	√	√			√	
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 310\TRUCK DC 9 [---04>---13]\Transmission\GMS - Gear management system OPC	√	√	√	√		√	0005
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 310\TRUCK DC 9 [---04>---13]\Transmission\GMS - Gear management system Opticruise 5	√	√	√	√		√	0009, 0011, 0018
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 310\TRUCK DC 9 [---04>---13]\Transmission\GMS - GMS Opticruise 5	√	√	√	√		√	0009, 0011, 0018
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 310\TRUCK DC 9 [---04>---13]\Transport information system\RTI - Road Transport Informatics	√	√	√				
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 320\TRUCK DC 9 XPI EU5 [---08>---13]\ABS\BMS Brake management system-ABS E	√	√	√	√		√	
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 320\TRUCK DC 9 XPI EU5 [---08>---13]\Aid for keeping lane\LDW Monitor traffic lane	√	√	√				
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 320\TRUCK DC 9 XPI EU5 [---08>---13]\Air conditioner\CCS Climate control system	√	√	√	√		√	
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 320\TRUCK DC 9 XPI EU5 [---08>---13]\Airbag\CSS Climate safety system	√	√	√				
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 320\TRUCK DC 9 XPI EU5 [---08>---13]\Alarm\LAS Locking and alarm system	√	√	√				
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 320\TRUCK DC 9 XPI EU5 [---08>---13]\Auxiliary heating\ATA Auxiliary heating system air-to-air	√	√	√	√			
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 320\TRUCK DC 9 XPI EU5 [---08>---13]\Auxiliary heating\WTA Auxiliary heating system water-to-air	√	√	√				
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 320\TRUCK DC 9 XPI EU5 [---08>---13]\Chassis equipment and design\BWS Preparation system	√	√	√				
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 320\TRUCK DC 9 XPI EU5 [---08>---13]\Comfort system\CTS Clock and Time System	√	√	√				
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 320\TRUCK DC 9 XPI EU5 [---08>---13]\Compressed air reserve system\APS Compressed air power supply(Scania protocol)	√	√	√	√			0003
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 320\TRUCK DC 9 XPI EU5 [---08>---13]\Compressed air reserve system\APS Compressed air power supply(Wabco protocol)	√	√	√	√			
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 320\TRUCK DC 9 XPI EU5 [---08>---13]\Diesel injection\EEC-Exhaust gas treatment	√	√	√	√		√	
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 320\TRUCK DC 9 XPI EU5 [---08>---13]\Diesel injection\EMS Engine management system S6-S7	√	√	√	√		√	0002, 0015, 0017
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 320\TRUCK DC 9 XPI EU5 [---08>---13]\Diesel injection\EMS Engine management system S8(8 Cylindes)	√	√	√	√		√	0001
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 320\TRUCK DC 9 XPI EU5 [---08>---13]\Diesel injection\EMS Engine management system DC13(6 Cylindes)	√	√	√	√		√	
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 320\TRUCK DC 9 XPI EU5 [---08>---13]\Distance control\DAS Adaptive Cruise Control	√	√	√				
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 320\TRUCK DC 9 XPI EU5 [---08>---13]\Distance control\DIS Adaptive Cruise Control	√	√	√				
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 320\TRUCK DC 9 XPI EU5 [---08>---13]\EBS\BMS Brake management system 5.0 (4x2)	√	√	√	√		√	0004
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 320\TRUCK DC 9 XPI EU5 [---08>---13]\EBS\BMS Brake management system 5.0 (6x2 - 6x4)	√	√	√	√		√	0004
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 320\TRUCK DC 9 XPI EU5 [---08>---13]\EBS\BMS Brake management system 5.0 (8x2)	√	√	√	√		√	0004

Scania\Divided By Vehicle\BUS&Coach\K series\Engine 320\TRUCK DC 9 XPI EU5 [---08>---13]\ECU external light\VIS Visibility system	√	√	√	√		√	
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 320\TRUCK DC 9 XPI EU5 [---08>---13]\Engine-vehicle adjustment\COO Coordinator module	√	√	√	√		√	
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 320\TRUCK DC 9 XPI EU5 [---08>---13]\Engine-vehicle adjustment\COO7 (Coordinator)	√	√	√	√		√	
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 320\TRUCK DC 9 XPI EU5 [---08>---13]\Four-wheel drive\AWD ALL-Wheel Drive	√	√	√				
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 320\TRUCK DC 9 XPI EU5 [---08>---13]\Instrument pane\NCL Instrument Panel 1	√	√	√	√		√	
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 320\TRUCK DC 9 XPI EU5 [---08>---13]\Instrument pane\NCL Instrument Panel 2	√	√	√	√		√	
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 320\TRUCK DC 9 XPI EU5 [---08>---13]\Radio\AUS Audio system	√	√	√				
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 320\TRUCK DC 9 XPI EU5 [---08>---13]\Retarder\RET Retarder	√	√	√	√		√	
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 320\TRUCK DC 9 XPI EU5 [---08>---13]\Suspensions\SMS Suspension management system	√	√	√	√			0006, 0007, 0014
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 320\TRUCK DC 9 XPI EU5 [---08>---13]\Tachograph\DTCO Tachograph	√	√	√				
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 320\TRUCK DC 9 XPI EU5 [---08>---13]\Tachograph\WTCO Tachograph	√	√	√				
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 320\TRUCK DC 9 XPI EU5 [---08>---13]\Tire pressure\TPM - Tires Pressure Monitoring System	√	√	√				
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 320\TRUCK DC 9 XPI EU5 [---08>---13]\Transmission\GMS - Gear management system A4	√	√	√			√	
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 320\TRUCK DC 9 XPI EU5 [---08>---13]\Transmission\GMS - Gear management system OPC	√	√	√	√		√	0005
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 320\TRUCK DC 9 XPI EU5 [---08>---13]\Transmission\GMS - Gear management system Opticruise 5	√	√	√	√		√	0009, 0011, 0018
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 320\TRUCK DC 9 XPI EU5 [---08>---13]\Transmission\GMS - GMS Opticruise 5	√	√	√	√		√	0009, 0011, 0018
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 320\TRUCK DC 9 XPI EU5 [---08>---13]\Transport information system\RTI - Road Transport Informatics	√	√	√				
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 340\TRUCK DC 11 [---05>---08]\ABS\BMS Brake management system-ABS E	√	√	√	√		√	
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 340\TRUCK DC 11 [---05>---08]\Aid for keeping lane\LDW Monitor traffic lane	√	√	√				
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 340\TRUCK DC 11 [---05>---08]\Air conditioner\CCS Climate control system	√	√	√	√		√	
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 340\TRUCK DC 11 [---05>---08]\Airbag\CSS Climate safety system	√	√	√				
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 340\TRUCK DC 11 [---05>---08]\Alarm\LAS Locking and alarm system	√	√	√				
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 340\TRUCK DC 11 [---05>---08]\Auxiliary heating\ATA Auxiliary heating system air-to-air	√	√	√	√			
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 340\TRUCK DC 11 [---05>---08]\Auxiliary heating\WTA Auxiliary heating system water-to-air	√	√	√				
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 340\TRUCK DC 11 [---05>---08]\Chassis equipment and design\BWS Preparation system	√	√	√				
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 340\TRUCK DC 11 [---05>---08]\Comfort system\CTS Clock and Time System	√	√	√				
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 340\TRUCK DC 11 [---05>---08]\Compressed air reserve system\APS Compressed air power supply(Scania protocol)	√	√	√	√			0003
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 340\TRUCK DC 11 [---05>---08]\Compressed air reserve system\APS Compressed air power supply(Wabco protocol)	√	√	√	√			
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 340\TRUCK DC 11 [---05>---08]\Diesel injection\EEC-Exhaust gas treatment	√	√	√	√		√	
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 340\TRUCK DC 11 [---05>---08]\Diesel injection\EMS Engine management system S6-S7	√	√	√	√		√	0002, 0015, 0017
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 340\TRUCK DC 11 [---05>---08]\Diesel injection\EMS Engine management system S8(8 Cylindes)	√	√	√	√		√	0001
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 340\TRUCK DC 11 [---05>---08]\Diesel injection\EMS Engine management system DC13(6 Cylindes)	√	√	√	√		√	
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 340\TRUCK DC 11 [---05>---08]\Distance control\DAS Adaptive Cruise Control	√	√	√				
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 340\TRUCK DC 11 [---05>---08]\Distance control\DIS Adaptive Cruise Control	√	√	√				
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 340\TRUCK DC 11 [---05>---08]\EBS\BMS Brake management system 5.0 (4x2)	√	√	√	√		√	0004

Scania\Divided By Vehicle\BUS&Coach\K series\Engine 340\TRUCK DC 11 [---05>---08]\EBS\BMS Brake management system 5.0 (6x2 - 6x4)	√	√	√	√		√	0004
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 340\TRUCK DC 11 [---05>---08]\EBS\BMS Brake management system 5.0 (8x2)	√	√	√	√		√	0004
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 340\TRUCK DC 11 [---05>---08]\ECU external light\VIS Visibility system	√	√	√	√		√	
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 340\TRUCK DC 11 [---05>---08]\Engine-vehicle adjustment\COO Coordinator module	√	√	√	√		√	
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 340\TRUCK DC 11 [---05>---08]\Engine-vehicle adjustment\COO7 (Coordinator)	√	√	√	√		√	
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 340\TRUCK DC 11 [---05>---08]\Four-wheel drive\AWD ALL-Wheel Drive	√	√	√				
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 340\TRUCK DC 11 [---05>---08]\Instrument panel\NCL Instrument Panel 1	√	√	√	√		√	
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 340\TRUCK DC 11 [---05>---08]\Instrument panel\NCL Instrument Panel 2	√	√	√	√		√	
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 340\TRUCK DC 11 [---05>---08]\Radio\AUS Audio system	√	√	√				
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 340\TRUCK DC 11 [---05>---08]\Retarder\RET Retarder	√	√	√	√		√	
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 340\TRUCK DC 11 [---05>---08]\Suspensions\SMS Supension management system	√	√	√	√			0006, 0007, 0014
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 340\TRUCK DC 11 [---05>---08]\Tachograph\DTCO Tachograph	√	√	√				
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 340\TRUCK DC 11 [---05>---08]\Tachograph\MTCO Tachograph	√	√	√				
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 340\TRUCK DC 11 [---05>---08]\Tire pressure\TPM - Tires Pressure Monitoring System	√	√	√				
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 340\TRUCK DC 11 [---05>---08]\Transmission\GMS - Gear management system A4	√	√	√			√	
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 340\TRUCK DC 11 [---05>---08]\Transmission\GMS - Gear management system OPC	√	√	√	√		√	0005
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 340\TRUCK DC 11 [---05>---08]\Transmission\GMS - Gear management system Opticruise 5	√	√	√	√		√	0009, 0011, 0018
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 340\TRUCK DC 11 [---05>---08]\Transmission\GMS - GMS Opticruise 5	√	√	√	√		√	0009, 0011, 0018
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 340\TRUCK DC 11 [---05>---08]\Transport information system\RTI - Road Transport Informatics	√	√	√				
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 340\TRUCK DC 12 HPI [---05>---08]\ABS\BMS Brake management system-ABS E	√	√	√	√		√	
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 340\TRUCK DC 12 HPI [---05>---08]\Aid for keeping lane\LDW Monitor traffic lane	√	√	√				
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 340\TRUCK DC 12 HPI [---05>---08]\Air conditioner\CCS Climate control system	√	√	√	√		√	
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 340\TRUCK DC 12 HPI [---05>---08]\Airbag\CSS Climate safety system	√	√	√				
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 340\TRUCK DC 12 HPI [---05>---08]\Alarm\LAS Locking and alarm system	√	√	√				
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 340\TRUCK DC 12 HPI [---05>---08]\Auxiliary heating\ATA Auxiliary heating system air-to-air	√	√	√	√			
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 340\TRUCK DC 12 HPI [---05>---08]\Auxiliary heating\WTA Auxiliary heating system water-to-air	√	√	√				
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 340\TRUCK DC 12 HPI [---05>---08]\Chassis equipment and design\BWS Preparation system	√	√	√				
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 340\TRUCK DC 12 HPI [---05>---08]\Comfort system\CTS Clock and Time System	√	√	√				
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 340\TRUCK DC 12 HPI [---05>---08]\Compressed air reserve system\APS Compressed air power supply(Scania protocol)	√	√	√	√			0003
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 340\TRUCK DC 12 HPI [---05>---08]\Compressed air reserve system\APS Compressed air power supply(Wabco protocol)	√	√	√	√			
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 340\TRUCK DC 12 HPI [---05>---08]\Diesel injection\EEC-Exhaust gas treatment	√	√	√	√		√	
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 340\TRUCK DC 12 HPI [---05>---08]\Diesel injection\EMS Engine management system S6-S7	√	√	√	√		√	0002, 0015, 0017
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 340\TRUCK DC 12 HPI [---05>---08]\Diesel injection\EMS Engine management system S8(8 Cylindes)	√	√	√	√		√	0001
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 340\TRUCK DC 12 HPI [---05>---08]\Diesel injection\EMS Engine management system DC13(6 Cylindes)	√	√	√	√		√	
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 340\TRUCK DC 12 HPI [---05>---08]\Distance control\DAS Adaptive Cruise Control	√	√	√				

Scania\Divided By Vehicle\BUS&Coach\K series\Engine 340\TRUCK DC 12 HPI [---05>---08]\Distance control\DIS Adaptive Cruise Control	√	√	√				
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 340\TRUCK DC 12 HPI [---05>---08]\EBS\BMS Brake management system 5.0 (4x2)	√	√	√	√		√	0004
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 340\TRUCK DC 12 HPI [---05>---08]\EBS\BMS Brake management system 5.0 (6x2 - 6x4)	√	√	√	√		√	0004
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 340\TRUCK DC 12 HPI [---05>---08]\EBS\BMS Brake management system 5.0 (8x2)	√	√	√	√		√	0004
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 340\TRUCK DC 12 HPI [---05>---08]\ECU external light\VIS Visibility system	√	√	√	√		√	
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 340\TRUCK DC 12 HPI [---05>---08]\Engine-vehicle adjustment\COO Coordinator module	√	√	√	√		√	
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 340\TRUCK DC 12 HPI [---05>---08]\Engine-vehicle adjustment\COO7 (Coordinator)	√	√	√	√		√	
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 340\TRUCK DC 12 HPI [---05>---08]\Four-wheel drive\AWD ALL-Wheel Drive	√	√	√				
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 340\TRUCK DC 12 HPI [---05>---08]\Instrument panel\NCL Instrument Panel 1	√	√	√	√		√	
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 340\TRUCK DC 12 HPI [---05>---08]\Instrument panel\NCL Instrument Panel 2	√	√	√	√		√	
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 340\TRUCK DC 12 HPI [---05>---08]\Radio\AUS Audio system	√	√	√				
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 340\TRUCK DC 12 HPI [---05>---08]\Retarder\RET Retarder	√	√	√	√		√	
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 340\TRUCK DC 12 HPI [---05>---08]\Suspensions\SMS Suspension management system	√	√	√	√			0006, 0007, 0014
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 340\TRUCK DC 12 HPI [---05>---08]\Tachograph\DTCO Tachograph	√	√	√				
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 340\TRUCK DC 12 HPI [---05>---08]\Tachograph\MTCO Tachograph	√	√	√				
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 340\TRUCK DC 12 HPI [---05>---08]\Tire pressure\TPM - Tires Pressure Monitoring System	√	√	√				
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 340\TRUCK DC 12 HPI [---05>---08]\Transmission\GMS - Gear management system A4	√	√	√			√	
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 340\TRUCK DC 12 HPI [---05>---08]\Transmission\GMS - Gear management system OPC	√	√	√	√		√	0005
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 340\TRUCK DC 12 HPI [---05>---08]\Transmission\GMS - Gear management system Opticruise 5	√	√	√	√		√	0009, 0011, 0018
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 340\TRUCK DC 12 HPI [---05>---08]\Transmission\GMS - GMS Opticruise 5	√	√	√	√		√	0009, 0011, 0018
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 340\TRUCK DC 12 HPI [---05>---08]\Transport information system\RTI - Road Transport Informatics	√	√	√				
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 360\TRUCK DC 13 XPI EU5 [---08>---13]\ABS\BMS Brake management system-ABS E	√	√	√	√		√	
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 360\TRUCK DC 13 XPI EU5 [---08>---13]\Aid for keeping lane\LDW Monitor traffic lane	√	√	√				
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 360\TRUCK DC 13 XPI EU5 [---08>---13]\Air conditioner\CCS Climate control system	√	√	√	√		√	
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 360\TRUCK DC 13 XPI EU5 [---08>---13]\Airbag\CSS Climate safety system	√	√	√				
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 360\TRUCK DC 13 XPI EU5 [---08>---13]\Alarm\LAS Locking and alarm system	√	√	√				
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 360\TRUCK DC 13 XPI EU5 [---08>---13]\Auxiliary heating\ATA Auxiliary heating system air-to-air	√	√	√	√			
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 360\TRUCK DC 13 XPI EU5 [---08>---13]\Auxiliary heating\WTA Auxiliary heating system water-to-air	√	√	√				
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 360\TRUCK DC 13 XPI EU5 [---08>---13]\Chassis equipment and design\BWS Preparation system	√	√	√				
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 360\TRUCK DC 13 XPI EU5 [---08>---13]\Comfort system\CTS Clock and Time System	√	√	√				
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 360\TRUCK DC 13 XPI EU5 [---08>---13]\Compressed air reserve system\APS Compressed air power supply(Scania protocol)	√	√	√	√			0003
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 360\TRUCK DC 13 XPI EU5 [---08>---13]\Compressed air reserve system\APS Compressed air power supply(Wabco protocol)	√	√	√	√			
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 360\TRUCK DC 13 XPI EU5 [---08>---13]\Diesel injection\EEC-Exhaust gas treatment	√	√	√	√		√	
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 360\TRUCK DC 13 XPI EU5 [---08>---13]\Diesel injection\EMS Engine management system S6-S7	√	√	√	√		√	0002, 0015, 0017
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 360\TRUCK DC 13 XPI EU5 [---08>---13]\Diesel injection\EMS Engine management system S8(8 Cylindres)	√	√	√	√		√	0001

Scania\Divided By Vehicle\BUS&Coach\K series\Engine 360\TRUCK DC 13 XPI EU5 [---08>---13]\Diesel injection\EMS Engine management system DC13(6 Cylindres)	√	√	√	√		√	
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 360\TRUCK DC 13 XPI EU5 [---08>---13]\Distance control\DAS Adaptive Cruise Control	√	√	√				
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 360\TRUCK DC 13 XPI EU5 [---08>---13]\Distance control\DIS Adaptive Cruise Control	√	√	√				
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 360\TRUCK DC 13 XPI EU5 [---08>---13]\EBS\BMS Brake management system 5.0 (4x2)	√	√	√	√		√	0004
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 360\TRUCK DC 13 XPI EU5 [---08>---13]\EBS\BMS Brake management system 5.0 (6x2 - 6x4)	√	√	√	√		√	0004
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 360\TRUCK DC 13 XPI EU5 [---08>---13]\EBS\BMS Brake management system 5.0 (8x2)	√	√	√	√		√	0004
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 360\TRUCK DC 13 XPI EU5 [---08>---13]\ECU external light\VIS Visibility system	√	√	√	√		√	
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 360\TRUCK DC 13 XPI EU5 [---08>---13]\Engine-vehicle adjustment\COO Coordinator module	√	√	√	√		√	
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 360\TRUCK DC 13 XPI EU5 [---08>---13]\Engine-vehicle adjustment\COO7 (Coordinator)	√	√	√	√		√	
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 360\TRUCK DC 13 XPI EU5 [---08>---13]\Four-wheel drive\AWD ALL-Wheel Drive	√	√	√				
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 360\TRUCK DC 13 XPI EU5 [---08>---13]\Instrument panel\NCL Instrument Panel 1	√	√	√	√		√	
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 360\TRUCK DC 13 XPI EU5 [---08>---13]\Instrument panel\NCL Instrument Panel 2	√	√	√	√		√	
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 360\TRUCK DC 13 XPI EU5 [---08>---13]\Radio\AUS Audio system	√	√	√				
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 360\TRUCK DC 13 XPI EU5 [---08>---13]\Retarder\RET Retarder	√	√	√	√		√	
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 360\TRUCK DC 13 XPI EU5 [---08>---13]\Suspensions\SMS Suspension management system	√	√	√	√			0006, 0007, 0014
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 360\TRUCK DC 13 XPI EU5 [---08>---13]\Tachograph\DTCO Tachograph	√	√	√				
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 360\TRUCK DC 13 XPI EU5 [---08>---13]\Tachograph\MTCO Tachograph	√	√	√				
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 360\TRUCK DC 13 XPI EU5 [---08>---13]\Tire pressure\TPM - Tires Pressure Monitoring System	√	√	√				
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 360\TRUCK DC 13 XPI EU5 [---08>---13]\Transmission\GMS - Gear management system A4	√	√	√			√	
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 360\TRUCK DC 13 XPI EU5 [---08>---13]\Transmission\GMS - Gear management system OPC	√	√	√	√		√	0005
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 360\TRUCK DC 13 XPI EU5 [---08>---13]\Transmission\GMS - Gear management system Opticruise 5	√	√	√	√		√	0009, 0011, 0018
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 360\TRUCK DC 13 XPI EU5 [---08>---13]\Transmission\GMS - GMS Opticruise 5	√	√	√	√		√	0009, 0011, 0018
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 360\TRUCK DC 13 XPI EU5 [---08>---13]\Transport information system\RTI - Road Transport Informatics	√	√	√				
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 380\TRUCK DC 11 [---04>---08]\ABS\BMS Brake management system-ABS E	√	√	√	√		√	
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 380\TRUCK DC 11 [---04>---08]\Aid for keeping lane\LDW Monitor traffic lane	√	√	√				
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 380\TRUCK DC 11 [---04>---08]\Air conditioner\CCS Climate control system	√	√	√	√		√	
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 380\TRUCK DC 11 [---04>---08]\Airbag\CSS Climate safety system	√	√	√				
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 380\TRUCK DC 11 [---04>---08]\Alarm\LAS Locking and alarm system	√	√	√				
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 380\TRUCK DC 11 [---04>---08]\Auxiliary heating\ATA Auxiliary heating system air-to-air	√	√	√	√			
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 380\TRUCK DC 11 [---04>---08]\Auxiliary heating\WTA Auxiliary heating system water-to-air	√	√	√				
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 380\TRUCK DC 11 [---04>---08]\Chassis equipment and design\BWS Preparation system	√	√	√				
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 380\TRUCK DC 11 [---04>---08]\Comfort system\CTS Clock and Time System	√	√	√				
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 380\TRUCK DC 11 [---04>---08]\Compressed air reserve system\APS Compressed air power supply(Scania protocol)	√	√	√	√			0003
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 380\TRUCK DC 11 [---04>---08]\Compressed air reserve system\APS Compressed air power supply(Wabco protocol)	√	√	√	√			
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 380\TRUCK DC 11 [---04>---08]\Diesel injection\EEC-Exhaust gas treatment	√	√	√	√		√	

Scania\Divided By Vehicle\BUS&Coach\K series\Engine 380\TRUCK DC 11 [---04>---08]\Diesel injection\EMS Engine management system S6-S7	√	√	√	√		√	0002, 0015, 0017
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 380\TRUCK DC 11 [---04>---08]\Diesel injection\EMS Engine management system S8(8 Cylindes)	√	√	√	√		√	0001
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 380\TRUCK DC 11 [---04>---08]\Diesel injection\EMS Engine management system DC13(6 Cylindes)	√	√	√	√		√	
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 380\TRUCK DC 11 [---04>---08]\Distance control\DAS Adaptive Cruise Control	√	√	√				
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 380\TRUCK DC 11 [---04>---08]\Distance control\DIS Adaptive Cruise Control	√	√	√				
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 380\TRUCK DC 11 [---04>---08]\EBS\BMS Brake management system 5.0 (4x2)	√	√	√	√		√	0004
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 380\TRUCK DC 11 [---04>---08]\EBS\BMS Brake management system 5.0 (6x2 - 6x4)	√	√	√	√		√	0004
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 380\TRUCK DC 11 [---04>---08]\EBS\BMS Brake management system 5.0 (8x2)	√	√	√	√		√	0004
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 380\TRUCK DC 11 [---04>---08]\ECU external light\VIS Visibility system	√	√	√	√		√	
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 380\TRUCK DC 11 [---04>---08]\Engine-vehicle adjustment\COO Coordinator module	√	√	√	√		√	
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 380\TRUCK DC 11 [---04>---08]\Engine-vehicle adjustment\COO7 (Coordinator)	√	√	√	√		√	
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 380\TRUCK DC 11 [---04>---08]\Four-wheel drive\AWD ALL-Wheel Drive	√	√	√				
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 380\TRUCK DC 11 [---04>---08]\Instrument panel\NCL Instrument Panel 1	√	√	√	√		√	
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 380\TRUCK DC 11 [---04>---08]\Instrument panel\NCL Instrument Panel 2	√	√	√	√		√	
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 380\TRUCK DC 11 [---04>---08]\Radio\AUS Audio system	√	√	√				
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 380\TRUCK DC 11 [---04>---08]\Retarder\RET Retarder	√	√	√	√		√	
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 380\TRUCK DC 11 [---04>---08]\Suspensions\SMS Supension management system	√	√	√	√			0006, 0007, 0014
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 380\TRUCK DC 11 [---04>---08]\Tachograph\DTCO Tachograph	√	√	√				
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 380\TRUCK DC 11 [---04>---08]\Tachograph\MTCO Tachograph	√	√	√				
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 380\TRUCK DC 11 [---04>---08]\Tire pressure\TPM - Tires Pressure Monitoring System	√	√	√				
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 380\TRUCK DC 11 [---04>---08]\Transmission\GMS - Gear management system A4	√	√	√			√	
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 380\TRUCK DC 11 [---04>---08]\Transmission\GMS - Gear management system OPC	√	√	√	√		√	0005
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 380\TRUCK DC 11 [---04>---08]\Transmission\GMS - Gear management system Opticruise 5	√	√	√	√		√	0009, 0011, 0018
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 380\TRUCK DC 11 [---04>---08]\Transmission\GMS - GMS Opticruise 5	√	√	√	√		√	0009, 0011, 0018
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 380\TRUCK DC 11 [---04>---08]\Transport information system\RTI - Road Transport Informatics	√	√	√				
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 380\TRUCK DC 12 HPI EU5 [---08>---13]\ABS\BMS Brake management system-ABS E	√	√	√	√		√	
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 380\TRUCK DC 12 HPI EU5 [---08>---13]\Aid for keeping lane\LDW Monitor traffic lane	√	√	√				
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 380\TRUCK DC 12 HPI EU5 [---08>---13]\Air conditioner\CCS Climate control system	√	√	√	√		√	
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 380\TRUCK DC 12 HPI EU5 [---08>---13]\Airbag\CSS Climate safety system	√	√	√				
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 380\TRUCK DC 12 HPI EU5 [---08>---13]\Alarm\LAS Locking and alarm system	√	√	√				
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 380\TRUCK DC 12 HPI EU5 [---08>---13]\Auxiliary heating\ATA Auxiliary heating system air-to-air	√	√	√	√			
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 380\TRUCK DC 12 HPI EU5 [---08>---13]\Auxiliary heating\WTA Auxiliary heating system water-to-air	√	√	√				
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 380\TRUCK DC 12 HPI EU5 [---08>---13]\Chassis equipment and design\BWS Preparation system	√	√	√				
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 380\TRUCK DC 12 HPI EU5 [---08>---13]\Comfort system\CTS Clock and Time System	√	√	√				
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 380\TRUCK DC 12 HPI EU5 [---08>---13]\Compressed air reserve system\APS Compressed air power supply(Scania protocol)	√	√	√	√			0003

Scania\Divided By Vehicle\BUS&Coach\K series\Engine 380\TRUCK DC 12 HPI EU5 [---08>---13]\Compressed air reserve system\APS Compressed air power supply(Wabco protocol)	√	√	√	√			
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 380\TRUCK DC 12 HPI EU5 [---08>---13]\Diesel injection\EEC-Exhaust gas treatment	√	√	√	√		√	
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 380\TRUCK DC 12 HPI EU5 [---08>---13]\Diesel injection\EMS Engine management system S6-S7	√	√	√	√		√	0002, 0015, 0017
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 380\TRUCK DC 12 HPI EU5 [---08>---13]\Diesel injection\EMS Engine management system S8(8 Cylindres)	√	√	√	√		√	0001
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 380\TRUCK DC 12 HPI EU5 [---08>---13]\Diesel injection\EMS Engine management system DC13(6 Cylindres)	√	√	√	√		√	
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 380\TRUCK DC 12 HPI EU5 [---08>---13]\Distance control\DAS Adaptive Cruise Control	√	√	√				
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 380\TRUCK DC 12 HPI EU5 [---08>---13]\Distance control\DIS Adaptive Cruise Control	√	√	√				
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 380\TRUCK DC 12 HPI EU5 [---08>---13]\EBS\BMS Brake management system 5.0 (4x2)	√	√	√	√		√	0004
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 380\TRUCK DC 12 HPI EU5 [---08>---13]\EBS\BMS Brake management system 5.0 (6x2 - 6x4)	√	√	√	√		√	0004
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 380\TRUCK DC 12 HPI EU5 [---08>---13]\EBS\BMS Brake management system 5.0 (8x2)	√	√	√	√		√	0004
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 380\TRUCK DC 12 HPI EU5 [---08>---13]\ECU external light\VIS Visibility system	√	√	√	√		√	
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 380\TRUCK DC 12 HPI EU5 [---08>---13]\Engine-vehicle adjustment\COO Coordinator module	√	√	√	√		√	
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 380\TRUCK DC 12 HPI EU5 [---08>---13]\Engine-vehicle adjustment\COO7 (Coordinator)	√	√	√	√		√	
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 380\TRUCK DC 12 HPI EU5 [---08>---13]\Four-wheel drive\AWD ALL-Wheel Drive	√	√	√				
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 380\TRUCK DC 12 HPI EU5 [---08>---13]\Instrument panel\NCL Instrument Panel 1	√	√	√	√		√	
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 380\TRUCK DC 12 HPI EU5 [---08>---13]\Instrument panel\NCL Instrument Panel 2	√	√	√	√		√	
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 380\TRUCK DC 12 HPI EU5 [---08>---13]\Radio\AUS Audio system	√	√	√				
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 380\TRUCK DC 12 HPI EU5 [---08>---13]\Retarder\RET Retarder	√	√	√	√		√	
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 380\TRUCK DC 12 HPI EU5 [---08>---13]\Suspensions\SMS Supension management system	√	√	√	√			0006, 0007, 0014
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 380\TRUCK DC 12 HPI EU5 [---08>---13]\Tachograph\DTCO Tachograph	√	√	√				
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 380\TRUCK DC 12 HPI EU5 [---08>---13]\Tachograph\MTCO Tachograph	√	√	√				
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 380\TRUCK DC 12 HPI EU5 [---08>---13]\Tire pressure\TPM - Tires Pressure Monitoring System	√	√	√				
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 380\TRUCK DC 12 HPI EU5 [---08>---13]\Transmission\GMS - Gear management system A4	√	√	√			√	
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 380\TRUCK DC 12 HPI EU5 [---08>---13]\Transmission\GMS - Gear management system OPC	√	√	√	√		√	0005
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 380\TRUCK DC 12 HPI EU5 [---08>---13]\Transmission\GMS - Gear management system Opticruise 5	√	√	√	√		√	0009, 0011, 0018
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 380\TRUCK DC 12 HPI EU5 [---08>---13]\Transmission\GMS - GMS Opticruise 5	√	√	√	√		√	0009, 0011, 0018
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 380\TRUCK DC 12 HPI EU5 [---08>---13]\Transport information system\RTI - Road Transport Informatics	√	√	√				
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 380\TRUCK DC 12 HPI [---04>---08]\ABS\BMS Brake management system-ABS E	√	√	√	√		√	
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 380\TRUCK DC 12 HPI [---04>---08]\Aid for keeping lane\LDW Monitor traffic lane	√	√	√				
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 380\TRUCK DC 12 HPI [---04>---08]\Air conditioner\CCS Climate control system	√	√	√	√		√	
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 380\TRUCK DC 12 HPI [---04>---08]\Airbag\CSS Climate safety system	√	√	√				
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 380\TRUCK DC 12 HPI [---04>---08]\Alarm\LAS Locking and alarm system	√	√	√				
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 380\TRUCK DC 12 HPI [---04>---08]\Auxiliary heating\ATA Auxiliary heating system air-to-air	√	√	√	√			
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 380\TRUCK DC 12 HPI [---04>---08]\Auxiliary heating\WTA Auxiliary heating system water-to-air	√	√	√				
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 380\TRUCK DC 12 HPI [---04>---08]\Chassis equipment and design\BWS Preparation system	√	√	√				

Scania\Divided By Vehicle\BUS&Coach\K series\Engine 380\TRUCK DC 12 HPI [---04>---08]\Comfort system\CTS Clock and Time System	√	√	√				
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 380\TRUCK DC 12 HPI [---04>---08]\Compressed air reserve system\APS Compressed air power supply(Scania protocol)	√	√	√	√			0003
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 380\TRUCK DC 12 HPI [---04>---08]\Compressed air reserve system\APS Compressed air power supply(Wabco protocol)	√	√	√	√			
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 380\TRUCK DC 12 HPI [---04>---08]\Diesel injection\EEC-Exhaust gas treatment	√	√	√	√		√	
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 380\TRUCK DC 12 HPI [---04>---08]\Diesel injection\EMS Engine management system S6-S7	√	√	√	√		√	0002, 0015, 0017
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 380\TRUCK DC 12 HPI [---04>---08]\Diesel injection\EMS Engine management system S8(8 Cylindes)	√	√	√	√		√	0001
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 380\TRUCK DC 12 HPI [---04>---08]\Diesel injection\EMS Engine management system DC13(6 Cylindes)	√	√	√	√		√	
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 380\TRUCK DC 12 HPI [---04>---08]\Distance control\DAS Adaptive Cruise Control	√	√	√				
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 380\TRUCK DC 12 HPI [---04>---08]\Distance control\DIS Adaptive Cruise Control	√	√	√				
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 380\TRUCK DC 12 HPI [---04>---08]\EBS\BMS Brake management system 5.0 (4x2)	√	√	√	√		√	0004
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 380\TRUCK DC 12 HPI [---04>---08]\EBS\BMS Brake management system 5.0 (6x2 - 6x4)	√	√	√	√		√	0004
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 380\TRUCK DC 12 HPI [---04>---08]\EBS\BMS Brake management system 5.0 (8x2)	√	√	√	√		√	0004
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 380\TRUCK DC 12 HPI [---04>---08]\ECU external light\VIS Visibility system	√	√	√	√		√	
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 380\TRUCK DC 12 HPI [---04>---08]\Engine-vehicle adjustment\COO Coordinator module	√	√	√	√		√	
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 380\TRUCK DC 12 HPI [---04>---08]\Engine-vehicle adjustment\COO7 (Coordinator)	√	√	√	√		√	
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 380\TRUCK DC 12 HPI [---04>---08]\Four-wheel drive\AWD ALL-Wheel Drive	√	√	√				
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 380\TRUCK DC 12 HPI [---04>---08]\Instrument panel\NCL Instrument Panel 1	√	√	√	√		√	
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 380\TRUCK DC 12 HPI [---04>---08]\Instrument panel\NCL Instrument Panel 2	√	√	√	√		√	
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 380\TRUCK DC 12 HPI [---04>---08]\Radio\AUS Audio system	√	√	√				
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 380\TRUCK DC 12 HPI [---04>---08]\Retarder\RET Retarder	√	√	√	√		√	
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 380\TRUCK DC 12 HPI [---04>---08]\Suspensions\SMS Supension management system	√	√	√	√			0006, 0007, 0014
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 380\TRUCK DC 12 HPI [---04>---08]\Tachograph\DTCO Tachograph	√	√	√				
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 380\TRUCK DC 12 HPI [---04>---08]\Tachograph\MTCO Tachograph	√	√	√				
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 380\TRUCK DC 12 HPI [---04>---08]\Tire pressure\TPM - Tires Pressure Monitoring System	√	√	√				
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 380\TRUCK DC 12 HPI [---04>---08]\Transmission\GMS - Gear management system A4	√	√	√			√	
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 380\TRUCK DC 12 HPI [---04>---08]\Transmission\GMS - Gear management system OPC	√	√	√	√		√	0005
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 380\TRUCK DC 12 HPI [---04>---08]\Transmission\GMS - Gear management system Opticruise 5	√	√	√	√		√	0009, 0011, 0018
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 380\TRUCK DC 12 HPI [---04>---08]\Transmission\GMS - GMS Opticruise 5	√	√	√	√		√	0009, 0011, 0018
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 380\TRUCK DC 12 HPI [---04>---08]\Transport information system\RTI - Road Transport Informatics	√	√	√				
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 400\TRUCK DC 13 XPI EU5 [---08>---13]\ABS\BMS Brake management system-ABS E	√	√	√	√		√	
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 400\TRUCK DC 13 XPI EU5 [---08>---13]\Aid for keeping lane\LDW Monitor traffic lane	√	√	√				
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 400\TRUCK DC 13 XPI EU5 [---08>---13]\Air conditioner\CCS Climate control system	√	√	√	√		√	
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 400\TRUCK DC 13 XPI EU5 [---08>---13]\Airbag\CSS Climate safety system	√	√	√				
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 400\TRUCK DC 13 XPI EU5 [---08>---13]\Alarm\LAS Locking and alarm system	√	√	√				
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 400\TRUCK DC 13 XPI EU5 [---08>---13]\Auxiliary heating\ATA Auxiliary heating system air-to-air	√	√	√	√			

Scania\Divided By Vehicle\BUS&Coach\K series\Engine 400\TRUCK DC 13 XPI EU5 [---08>---13]\Auxiliary heating\WTA Auxiliary heating system water-to-air	√	√	√				
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 400\TRUCK DC 13 XPI EU5 [---08>---13]\Chassis equipment and design\BWS Preparation system	√	√	√				
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 400\TRUCK DC 13 XPI EU5 [---08>---13]\Comfort system\CTS Clock and Time System	√	√	√				
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 400\TRUCK DC 13 XPI EU5 [---08>---13]\Compressed air reserve system\APS Compressed air power supply(Scania protocol)	√	√	√	√			0003
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 400\TRUCK DC 13 XPI EU5 [---08>---13]\Compressed air reserve system\APS Compressed air power supply(Wabco protocol)	√	√	√	√			
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 400\TRUCK DC 13 XPI EU5 [---08>---13]\Diesel injection\EEC-Exhaust gas treatment	√	√	√	√		√	
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 400\TRUCK DC 13 XPI EU5 [---08>---13]\Diesel injection\EMS Engine management system S6-S7	√	√	√	√		√	0002, 0015, 0017
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 400\TRUCK DC 13 XPI EU5 [---08>---13]\Diesel injection\EMS Engine management system S8(8 Cylindes)	√	√	√	√		√	0001
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 400\TRUCK DC 13 XPI EU5 [---08>---13]\Diesel injection\EMS Engine management system DC13(6 Cylindes)	√	√	√	√		√	
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 400\TRUCK DC 13 XPI EU5 [---08>---13]\Distance control\DAS Adaptive Cruise Control	√	√	√				
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 400\TRUCK DC 13 XPI EU5 [---08>---13]\Distance control\DIS Adaptive Cruise Control	√	√	√				
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 400\TRUCK DC 13 XPI EU5 [---08>---13]\EBS\BMS Brake management system 5.0 (4x2)	√	√	√	√		√	0004
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 400\TRUCK DC 13 XPI EU5 [---08>---13]\EBS\BMS Brake management system 5.0 (6x2 - 6x4)	√	√	√	√		√	0004
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 400\TRUCK DC 13 XPI EU5 [---08>---13]\EBS\BMS Brake management system 5.0 (8x2)	√	√	√	√		√	0004
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 400\TRUCK DC 13 XPI EU5 [---08>---13]\ECU external light\VIS Visibility system	√	√	√	√		√	
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 400\TRUCK DC 13 XPI EU5 [---08>---13]\Engine-vehicle adjustment\COO Coordinator module	√	√	√	√		√	
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 400\TRUCK DC 13 XPI EU5 [---08>---13]\Engine-vehicle adjustment\COO7 (Coordinator)	√	√	√	√		√	
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 400\TRUCK DC 13 XPI EU5 [---08>---13]\Four-wheel drive\AWD ALL-Wheel Drive	√	√	√				
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 400\TRUCK DC 13 XPI EU5 [---08>---13]\Instrument panel\NCL Instrument Panel 1	√	√	√	√		√	
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 400\TRUCK DC 13 XPI EU5 [---08>---13]\Instrument panel\NCL Instrument Panel 2	√	√	√	√		√	
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 400\TRUCK DC 13 XPI EU5 [---08>---13]\Radio\AUS Audio system	√	√	√				
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 400\TRUCK DC 13 XPI EU5 [---08>---13]\Retarder\RET Retarder	√	√	√	√		√	
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 400\TRUCK DC 13 XPI EU5 [---08>---13]\Suspensions\SMS Supension management system	√	√	√	√			0006, 0007, 0014
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 400\TRUCK DC 13 XPI EU5 [---08>---13]\Tachograph\DTCO Tachograph	√	√	√				
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 400\TRUCK DC 13 XPI EU5 [---08>---13]\Tachograph\MTCO Tachograph	√	√	√				
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 400\TRUCK DC 13 XPI EU5 [---08>---13]\Tire pressure\TPM - Tires Pressure Monitoring System	√	√	√				
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 400\TRUCK DC 13 XPI EU5 [---08>---13]\Transmission\GMS - Gear management system A4	√	√	√			√	
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 400\TRUCK DC 13 XPI EU5 [---08>---13]\Transmission\GMS - Gear management system OPC	√	√	√	√		√	0005
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 400\TRUCK DC 13 XPI EU5 [---08>---13]\Transmission\GMS - Gear management system Opticruise 5	√	√	√	√		√	0009, 0011, 0018
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 400\TRUCK DC 13 XPI EU5 [---08>---13]\Transmission\GMS - GMS Opticruise 5	√	√	√	√		√	0009, 0011, 0018
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 400\TRUCK DC 13 XPI EU5 [---08>---13]\Transport information system\RTI - Road Transport Informatics	√	√	√				
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 420\TRUCK DC 12 HPI [---04>---08]\ABS\BMS Brake management system-ABS E	√	√	√	√		√	
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 420\TRUCK DC 12 HPI [---04>---08]\Aid for keeping lane\LDW Monitor traffic lane	√	√	√				
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 420\TRUCK DC 12 HPI [---04>---08]\Air conditioner\CCS Climate control system	√	√	√	√		√	
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 420\TRUCK DC 12 HPI [---04>---08]\Airbag\CSS Climate safety system	√	√	√				

Scania\Divided By Vehicle\BUS&Coach\K series\Engine 420\TRUCK DC 12 HPI [---04>---08]\Alarm\LAS Locking and alarm system	√	√	√				
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 420\TRUCK DC 12 HPI [---04>---08]\Auxiliary heating\ATA Auxiliary heating system air-to-air	√	√	√	√			
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 420\TRUCK DC 12 HPI [---04>---08]\Auxiliary heating\WTA Auxiliary heating system water-to-air	√	√	√				
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 420\TRUCK DC 12 HPI [---04>---08]\Chassis equipment and design\BWS Preparation system	√	√	√				
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 420\TRUCK DC 12 HPI [---04>---08]\Comfort system\CTS Clock and Time System	√	√	√				
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 420\TRUCK DC 12 HPI [---04>---08]\Compressed air reserve system\APS Compressed air power supply(Scania protocol)	√	√	√	√			0003
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 420\TRUCK DC 12 HPI [---04>---08]\Compressed air reserve system\APS Compressed air power supply(Wabco protocol)	√	√	√	√			
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 420\TRUCK DC 12 HPI [---04>---08]\Diesel injection\EEC-Exhaust gas treatment	√	√	√	√		√	
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 420\TRUCK DC 12 HPI [---04>---08]\Diesel injection\EMS Engine management system S6-S7	√	√	√	√		√	0002, 0015, 0017
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 420\TRUCK DC 12 HPI [---04>---08]\Diesel injection\EMS Engine management system S8(8 Cylindes)	√	√	√	√		√	0001
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 420\TRUCK DC 12 HPI [---04>---08]\Diesel injection\EMS Engine management system DC13(6 Cylindes)	√	√	√	√		√	
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 420\TRUCK DC 12 HPI [---04>---08]\Distance control\DAS Adaptive Cruise Control	√	√	√				
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 420\TRUCK DC 12 HPI [---04>---08]\Distance control\DIS Adaptive Cruise Control	√	√	√				
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 420\TRUCK DC 12 HPI [---04>---08]\EBS\BMS Brake management system 5.0 (4x2)	√	√	√	√		√	0004
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 420\TRUCK DC 12 HPI [---04>---08]\EBS\BMS Brake management system 5.0 (6x2 - 6x4)	√	√	√	√		√	0004
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 420\TRUCK DC 12 HPI [---04>---08]\EBS\BMS Brake management system 5.0 (8x2)	√	√	√	√		√	0004
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 420\TRUCK DC 12 HPI [---04>---08]\ECU external light\VIS Visibility system	√	√	√	√		√	
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 420\TRUCK DC 12 HPI [---04>---08]\Engine-vehicle adjustment\COO Coordinator module	√	√	√	√		√	
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 420\TRUCK DC 12 HPI [---04>---08]\Engine-vehicle adjustment\COO7 (Coordinator)	√	√	√	√		√	
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 420\TRUCK DC 12 HPI [---04>---08]\Four-wheel drive\AWD ALL-Wheel Drive	√	√	√				
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 420\TRUCK DC 12 HPI [---04>---08]\Instrument panel\NCL Instrument Panel 1	√	√	√	√		√	
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 420\TRUCK DC 12 HPI [---04>---08]\Instrument panel\NCL Instrument Panel 2	√	√	√	√		√	
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 420\TRUCK DC 12 HPI [---04>---08]\Radio\AUS Audio system	√	√	√				
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 420\TRUCK DC 12 HPI [---04>---08]\Retarder\RET Retarder	√	√	√	√		√	
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 420\TRUCK DC 12 HPI [---04>---08]\Suspensions\SMS Suspension management system	√	√	√	√			0006, 0007, 0014
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 420\TRUCK DC 12 HPI [---04>---08]\Tachograph\DTCO Tachograph	√	√	√				
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 420\TRUCK DC 12 HPI [---04>---08]\Tachograph\MTCO Tachograph	√	√	√				
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 420\TRUCK DC 12 HPI [---04>---08]\Tire pressure\TPM - Tires Pressure Monitoring System	√	√	√				
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 420\TRUCK DC 12 HPI [---04>---08]\Transmission\GMS - Gear management system A4	√	√	√			√	
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 420\TRUCK DC 12 HPI [---04>---08]\Transmission\GMS - Gear management system OPC	√	√	√	√		√	0005
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 420\TRUCK DC 12 HPI [---04>---08]\Transmission\GMS - Gear management system Opticruise 5	√	√	√	√		√	0009, 0011, 0018
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 420\TRUCK DC 12 HPI [---04>---08]\Transmission\GMS - GMS Opticruise 5	√	√	√	√		√	0009, 0011, 0018
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 420\TRUCK DC 12 HPI [---04>---08]\Transport information system\RTI - Road Transport Informatics	√	√	√				
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 420\TRUCK DC 13 XPI EU5 [---08>---13]\ABS\BMS Brake management system-ABS E	√	√	√	√		√	
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 420\TRUCK DC 13 XPI EU5 [---08>---13]\Aid for keeping lane\LDW Monitor traffic lane	√	√	√				

Scania\Divided By Vehicle\BUS&Coach\K series\Engine 420\TRUCK DC 13 XPI EU5 [---08>---13]\Air conditioner\CCS Climate control system	√	√	√	√		√	
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 420\TRUCK DC 13 XPI EU5 [---08>---13]\Airbag\CSS Climate safety system	√	√	√				
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 420\TRUCK DC 13 XPI EU5 [---08>---13]\Alarm\LAS Locking and alarm system	√	√	√				
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 420\TRUCK DC 13 XPI EU5 [---08>---13]\Auxiliary heating\ATA Auxiliary heating system air-to-air	√	√	√	√			
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 420\TRUCK DC 13 XPI EU5 [---08>---13]\Auxiliary heating\WTA Auxiliary heating system water-to-air	√	√	√				
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 420\TRUCK DC 13 XPI EU5 [---08>---13]\Chassis equipment and design\BWS Preparation system	√	√	√				
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 420\TRUCK DC 13 XPI EU5 [---08>---13]\Comfort system\CTS Clock and Time System	√	√	√				
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 420\TRUCK DC 13 XPI EU5 [---08>---13]\Compressed air reserve system\APS Compressed air power supply(Scania protocol)	√	√	√	√			0003
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 420\TRUCK DC 13 XPI EU5 [---08>---13]\Compressed air reserve system\APS Compressed air power supply(Wabco protocol)	√	√	√	√			
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 420\TRUCK DC 13 XPI EU5 [---08>---13]\Diesel injection\EEC-Exhaust gas treatment	√	√	√	√		√	
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 420\TRUCK DC 13 XPI EU5 [---08>---13]\Diesel injection\EMS Engine management system S6-S7	√	√	√	√		√	0002, 0015, 0017
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 420\TRUCK DC 13 XPI EU5 [---08>---13]\Diesel injection\EMS Engine management system S8(8 Cylindes)	√	√	√	√		√	0001
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 420\TRUCK DC 13 XPI EU5 [---08>---13]\Diesel injection\EMS Engine management system DC13(6 Cylindes)	√	√	√	√		√	
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 420\TRUCK DC 13 XPI EU5 [---08>---13]\Distance control\DAS Adaptive Cruise Control	√	√	√				
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 420\TRUCK DC 13 XPI EU5 [---08>---13]\Distance control\DIS Adaptive Cruise Control	√	√	√				
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 420\TRUCK DC 13 XPI EU5 [---08>---13]\EBS\BMS Brake management system 5.0 (4x2)	√	√	√	√		√	0004
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 420\TRUCK DC 13 XPI EU5 [---08>---13]\EBS\BMS Brake management system 5.0 (6x2 - 6x4)	√	√	√	√		√	0004
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 420\TRUCK DC 13 XPI EU5 [---08>---13]\EBS\BMS Brake management system 5.0 (8x2)	√	√	√	√		√	0004
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 420\TRUCK DC 13 XPI EU5 [---08>---13]\ECU external light\VIS Visibility system	√	√	√	√		√	
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 420\TRUCK DC 13 XPI EU5 [---08>---13]\Engine-vehicle adjustment\COO Coordinator module	√	√	√	√		√	
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 420\TRUCK DC 13 XPI EU5 [---08>---13]\Engine-vehicle adjustment\COO7 (Coordinator)	√	√	√	√		√	
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 420\TRUCK DC 13 XPI EU5 [---08>---13]\Four-wheel drive\AWD ALL-Wheel Drive	√	√	√				
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 420\TRUCK DC 13 XPI EU5 [---08>---13]\Instrument panel\NCL Instrument Panel 1	√	√	√	√		√	
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 420\TRUCK DC 13 XPI EU5 [---08>---13]\Instrument panel\NCL Instrument Panel 2	√	√	√	√		√	
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 420\TRUCK DC 13 XPI EU5 [---08>---13]\Radio\AUS Audio system	√	√	√				
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 420\TRUCK DC 13 XPI EU5 [---08>---13]\Retarder\RET Retarder	√	√	√	√		√	
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 420\TRUCK DC 13 XPI EU5 [---08>---13]\Suspensions\SMS Supension management system	√	√	√	√			0006, 0007, 0014
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 420\TRUCK DC 13 XPI EU5 [---08>---13]\Tachograph\DTCO Tachograph	√	√	√				
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 420\TRUCK DC 13 XPI EU5 [---08>---13]\Tachograph\MTCO Tachograph	√	√	√				
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 420\TRUCK DC 13 XPI EU5 [---08>---13]\Tire pressure\TPM - Tires Pressure Monitoring System	√	√	√				
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 420\TRUCK DC 13 XPI EU5 [---08>---13]\Transmission\GMS - Gear management system A4	√	√	√			√	
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 420\TRUCK DC 13 XPI EU5 [---08>---13]\Transmission\GMS - Gear management system OPC	√	√	√	√		√	0005
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 420\TRUCK DC 13 XPI EU5 [---08>---13]\Transmission\GMS - Gear management system Opticruise 5	√	√	√	√		√	0009, 0011, 0018
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 420\TRUCK DC 13 XPI EU5 [---08>---13]\Transmission\GMS - GMS Opticruise 5	√	√	√	√		√	0009, 0011, 0018
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 420\TRUCK DC 13 XPI EU5 [---08>---13]\Transport information system\RTI - Road Transport Informatics	√	√	√				

Scania\Divided By Vehicle\BUS&Coach\K series\Engine 420\TRUCK DT 12 HPI [---04>---08]\ABS\BMS Brake management system-ABS E	√	√	√	√		√	
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 420\TRUCK DT 12 HPI [---04>---08]\Aid for keeping lane\LDW Monitor traffic lane	√	√	√				
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 420\TRUCK DT 12 HPI [---04>---08]\Air conditioner\CCS Climate control system	√	√	√	√		√	
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 420\TRUCK DT 12 HPI [---04>---08]\Airbag\CSS Climate safety system	√	√	√				
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 420\TRUCK DT 12 HPI [---04>---08]\Alarm\LAS Locking and alarm system	√	√	√				
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 420\TRUCK DT 12 HPI [---04>---08]\Auxiliary heating\ATA Auxiliary heating system air-to-air	√	√	√	√			
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 420\TRUCK DT 12 HPI [---04>---08]\Auxiliary heating\WTA Auxiliary heating system water-to-air	√	√	√				
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 420\TRUCK DT 12 HPI [---04>---08]\Chassis equipment and design\BWS Preparation system	√	√	√				
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 420\TRUCK DT 12 HPI [---04>---08]\Comfort system\CTS Clock and Time System	√	√	√				
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 420\TRUCK DT 12 HPI [---04>---08]\Compressed air reserve system\APS Compressed air power supply(Scania protocol)	√	√	√	√			0003
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 420\TRUCK DT 12 HPI [---04>---08]\Compressed air reserve system\APS Compressed air power supply(Wabco protocol)	√	√	√	√			
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 420\TRUCK DT 12 HPI [---04>---08]\Diesel injection\EEC-Exhaust gas treatment	√	√	√	√		√	
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 420\TRUCK DT 12 HPI [---04>---08]\Diesel injection\EMS Engine management system S6-S7	√	√	√	√		√	0002, 0015, 0017
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 420\TRUCK DT 12 HPI [---04>---08]\Diesel injection\EMS Engine management system S8(8 Cylindes)	√	√	√	√		√	0001
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 420\TRUCK DT 12 HPI [---04>---08]\Diesel injection\EMS Engine management system DC13(6 Cylindes)	√	√	√	√		√	
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 420\TRUCK DT 12 HPI [---04>---08]\Distance control\DAS Adaptive Cruise Control	√	√	√				
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 420\TRUCK DT 12 HPI [---04>---08]\Distance control\DIS Adaptive Cruise Control	√	√	√				
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 420\TRUCK DT 12 HPI [---04>---08]\EBS\BMS Brake management system 5.0 (4x2)	√	√	√	√		√	0004
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 420\TRUCK DT 12 HPI [---04>---08]\EBS\BMS Brake management system 5.0 (6x2 - 6x4)	√	√	√	√		√	0004
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 420\TRUCK DT 12 HPI [---04>---08]\EBS\BMS Brake management system 5.0 (8x2)	√	√	√	√		√	0004
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 420\TRUCK DT 12 HPI [---04>---08]\ECU external light\VIS Visibility system	√	√	√	√		√	
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 420\TRUCK DT 12 HPI [---04>---08]\Engine-vehicle adjustment\COO Coordinator module	√	√	√	√		√	
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 420\TRUCK DT 12 HPI [---04>---08]\Engine-vehicle adjustment\COO7 (Coordinator)	√	√	√	√		√	
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 420\TRUCK DT 12 HPI [---04>---08]\Four-wheel drive\AWD ALL-Wheel Drive	√	√	√				
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 420\TRUCK DT 12 HPI [---04>---08]\Instrument panel\NCL Instrument Panel 1	√	√	√	√		√	
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 420\TRUCK DT 12 HPI [---04>---08]\Instrument panel\NCL Instrument Panel 2	√	√	√	√		√	
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 420\TRUCK DT 12 HPI [---04>---08]\Radio\AUS Audio system	√	√	√				
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 420\TRUCK DT 12 HPI [---04>---08]\Retarder\RET Retarder	√	√	√	√		√	
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 420\TRUCK DT 12 HPI [---04>---08]\Suspensions\SMS Suspension management system	√	√	√	√			0006, 0007, 0014
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 420\TRUCK DT 12 HPI [---04>---08]\Tachograph\DTCO Tachograph	√	√	√				
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 420\TRUCK DT 12 HPI [---04>---08]\Tachograph\MTCO Tachograph	√	√	√				
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 420\TRUCK DT 12 HPI [---04>---08]\Tire pressure\TPM - Tires Pressure Monitoring System	√	√	√				
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 420\TRUCK DT 12 HPI [---04>---08]\Transmission\GMS - Gear management system A4	√	√	√			√	
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 420\TRUCK DT 12 HPI [---04>---08]\Transmission\GMS - Gear management system OPC	√	√	√	√		√	0005
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 420\TRUCK DT 12 HPI [---04>---08]\Transmission\GMS - Gear management system Opticruise 5	√	√	√	√		√	0009, 0011, 0018

Scania\Divided By Vehicle\BUS&Coach\K series\Engine 420\TRUCK DT 12 HPI [---04>---08]\Transmission\GMS - GMS Opticruise 5	√	√	√	√		√	0009, 0011, 0018
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 420\TRUCK DT 12 HPI [---04>---08]\Transport information system\RTI - Road Transport Informatics	√	√	√				
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 440\TRUCK DC 13 XPI EU5 [---08>---13]\ABS\BMS Brake management system-ABS E	√	√	√	√		√	
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 440\TRUCK DC 13 XPI EU5 [---08>---13]\Aid for keeping lane\LDW Monitor traffic lane	√	√	√				
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 440\TRUCK DC 13 XPI EU5 [---08>---13]\Air conditioner\CCS Climate control system	√	√	√	√		√	
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 440\TRUCK DC 13 XPI EU5 [---08>---13]\Airbag\CSS Climate safety system	√	√	√				
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 440\TRUCK DC 13 XPI EU5 [---08>---13]\Alarm\LAS Locking and alarm system	√	√	√				
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 440\TRUCK DC 13 XPI EU5 [---08>---13]\Auxiliary heating\ATA Auxiliary heating system air-to-air	√	√	√	√			
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 440\TRUCK DC 13 XPI EU5 [---08>---13]\Auxiliary heating\WTA Auxiliary heating system water-to-air	√	√	√				
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 440\TRUCK DC 13 XPI EU5 [---08>---13]\Chassis equipment and design\BWS Preparation system	√	√	√				
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 440\TRUCK DC 13 XPI EU5 [---08>---13]\Comfort system\CTS Clock and Time System	√	√	√				
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 440\TRUCK DC 13 XPI EU5 [---08>---13]\Compressed air reserve system\APS Compressed air power supply(Scania protocol)	√	√	√	√			0003
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 440\TRUCK DC 13 XPI EU5 [---08>---13]\Compressed air reserve system\APS Compressed air power supply(Wabco protocol)	√	√	√	√			
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 440\TRUCK DC 13 XPI EU5 [---08>---13]\Diesel injection\EEC-Exhaust gas treatment	√	√	√	√		√	
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 440\TRUCK DC 13 XPI EU5 [---08>---13]\Diesel injection\EMS Engine management system S6-S7	√	√	√	√		√	0002, 0015, 0017
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 440\TRUCK DC 13 XPI EU5 [---08>---13]\Diesel injection\EMS Engine management system S8(8 Cylindes)	√	√	√	√		√	0001
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 440\TRUCK DC 13 XPI EU5 [---08>---13]\Diesel injection\EMS Engine management system DC13(6 Cylindes)	√	√	√	√		√	
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 440\TRUCK DC 13 XPI EU5 [---08>---13]\Distance control\DAS Adaptive Cruise Control	√	√	√				
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 440\TRUCK DC 13 XPI EU5 [---08>---13]\Distance control\DIS Adaptive Cruise Control	√	√	√				
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 440\TRUCK DC 13 XPI EU5 [---08>---13]\EBS\BMS Brake management system 5.0 (4x2)	√	√	√	√		√	0004
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 440\TRUCK DC 13 XPI EU5 [---08>---13]\EBS\BMS Brake management system 5.0 (6x2 - 6x4)	√	√	√	√		√	0004
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 440\TRUCK DC 13 XPI EU5 [---08>---13]\EBS\BMS Brake management system 5.0 (8x2)	√	√	√	√		√	0004
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 440\TRUCK DC 13 XPI EU5 [---08>---13]\ECU external light\VIS Visibility system	√	√	√	√		√	
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 440\TRUCK DC 13 XPI EU5 [---08>---13]\Engine-vehicle adjustment\COO Coordinator module	√	√	√	√		√	
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 440\TRUCK DC 13 XPI EU5 [---08>---13]\Engine-vehicle adjustment\COO7 (Coordinator)	√	√	√	√		√	
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 440\TRUCK DC 13 XPI EU5 [---08>---13]\Four-wheel drive\AWD ALL-Wheel Drive	√	√	√				
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 440\TRUCK DC 13 XPI EU5 [---08>---13]\Instrument panel\ICL Instrument Panel 1	√	√	√	√		√	
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 440\TRUCK DC 13 XPI EU5 [---08>---13]\Instrument panel\ICL Instrument Panel 2	√	√	√	√		√	
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 440\TRUCK DC 13 XPI EU5 [---08>---13]\Radio\AUS Audio system	√	√	√				
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 440\TRUCK DC 13 XPI EU5 [---08>---13]\Retarder\RET Retarder	√	√	√	√		√	
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 440\TRUCK DC 13 XPI EU5 [---08>---13]\Suspensions\SMS Supension management system	√	√	√	√			0006, 0007, 0014
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 440\TRUCK DC 13 XPI EU5 [---08>---13]\Tachograph\DTCO Tachograph	√	√	√				
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 440\TRUCK DC 13 XPI EU5 [---08>---13]\Tachograph\MTCO Tachograph	√	√	√				
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 440\TRUCK DC 13 XPI EU5 [---08>---13]\Tire pressure\TPM - Tires Pressure Monitoring System	√	√	√				
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 440\TRUCK DC 13 XPI EU5 [---08>---13]\Transmission\GMS - Gear management system A4	√	√	√			√	

Scania\Divided By Vehicle\BUS&Coach\K series\Engine 440\TRUCK DC 13 XPI EU5 [---08>---13]\Transmission\GMS - Gear management system OPC	√	√	√	√		√	0005
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 440\TRUCK DC 13 XPI EU5 [---08>---13]\Transmission\GMS - Gear management system Opticruise 5	√	√	√	√		√	0009, 0011, 0018
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 440\TRUCK DC 13 XPI EU5 [---08>---13]\Transmission\GMS - GMS Opticruise 5	√	√	√	√		√	0009, 0011, 0018
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 440\TRUCK DC 13 XPI EU5 [---08>---13]\Transport information system\RTI - Road Transport Informatics	√	√	√				
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 470\TRUCK DT 12 HPI [---04>---08]\ABS\BMS Brake management system-ABS E	√	√	√	√		√	
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 470\TRUCK DT 12 HPI [---04>---08]\Aid for keeping lane\LDW Monitor traffic lane	√	√	√				
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 470\TRUCK DT 12 HPI [---04>---08]\Air conditioner\CCS Climate control system	√	√	√	√		√	
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 470\TRUCK DT 12 HPI [---04>---08]\Airbag\CSS Climate safety system	√	√	√				
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 470\TRUCK DT 12 HPI [---04>---08]\Alarm\LAS Locking and alarm system	√	√	√				
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 470\TRUCK DT 12 HPI [---04>---08]\Auxiliary heating\ATA Auxiliary heating system air-to-air	√	√	√	√			
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 470\TRUCK DT 12 HPI [---04>---08]\Auxiliary heating\WTA Auxiliary heating system water-to-air	√	√	√				
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 470\TRUCK DT 12 HPI [---04>---08]\Chassis equipment and design\BWS Preparation system	√	√	√				
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 470\TRUCK DT 12 HPI [---04>---08]\Comfort system\CTS Clock and Time System	√	√	√				
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 470\TRUCK DT 12 HPI [---04>---08]\Compressed air reserve system\APS Compressed air power supply(Scania protocol)	√	√	√	√			0003
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 470\TRUCK DT 12 HPI [---04>---08]\Compressed air reserve system\APS Compressed air power supply(Wabco protocol)	√	√	√	√			
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 470\TRUCK DT 12 HPI [---04>---08]\Diesel injection\EEC-Exhaust gas treatment	√	√	√	√		√	
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 470\TRUCK DT 12 HPI [---04>---08]\Diesel injection\EMS Engine management system S6-S7	√	√	√	√		√	0002, 0015, 0017
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 470\TRUCK DT 12 HPI [---04>---08]\Diesel injection\EMS Engine management system S8(8 Cylindes)	√	√	√	√		√	0001
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 470\TRUCK DT 12 HPI [---04>---08]\Diesel injection\EMS Engine management system DC13(6 Cylindes)	√	√	√	√		√	
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 470\TRUCK DT 12 HPI [---04>---08]\Distance control\DAS Adaptive Cruise Control	√	√	√				
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 470\TRUCK DT 12 HPI [---04>---08]\Distance control\DIS Adaptive Cruise Control	√	√	√				
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 470\TRUCK DT 12 HPI [---04>---08]\EBS\BMS Brake management system 5.0 (4x2)	√	√	√	√		√	0004
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 470\TRUCK DT 12 HPI [---04>---08]\EBS\BMS Brake management system 5.0 (6x2 - 6x4)	√	√	√	√		√	0004
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 470\TRUCK DT 12 HPI [---04>---08]\EBS\BMS Brake management system 5.0 (8x2)	√	√	√	√		√	0004
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 470\TRUCK DT 12 HPI [---04>---08]\ECU external light\VIS Visibility system	√	√	√	√		√	
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 470\TRUCK DT 12 HPI [---04>---08]\Engine-vehicle adjustment\COO Coordinator module	√	√	√	√		√	
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 470\TRUCK DT 12 HPI [---04>---08]\Engine-vehicle adjustment\COO7 (Coordinator)	√	√	√	√		√	
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 470\TRUCK DT 12 HPI [---04>---08]\Four-wheel drive\AWD ALL-Wheel Drive	√	√	√				
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 470\TRUCK DT 12 HPI [---04>---08]\Instrument panel\ICL Instrument Panel 1	√	√	√	√		√	
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 470\TRUCK DT 12 HPI [---04>---08]\Instrument panel\ICL Instrument Panel 2	√	√	√	√		√	
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 470\TRUCK DT 12 HPI [---04>---08]\Radio\AUS Audio system	√	√	√				
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 470\TRUCK DT 12 HPI [---04>---08]\Retarder\RET Retarder	√	√	√	√		√	
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 470\TRUCK DT 12 HPI [---04>---08]\Suspensions\SMS Suspension management system	√	√	√	√			0006, 0007, 0014
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 470\TRUCK DT 12 HPI [---04>---08]\Tachograph\DTCO Tachograph	√	√	√				
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 470\TRUCK DT 12 HPI [---04>---08]\Tachograph\MTCO Tachograph	√	√	√				

Scania\Divided By Vehicle\BUS&Coach\K series\Engine 470\TRUCK DT 12 HPI [---04>---08]\Tire pressure\TPM - Tires Pressure Monitoring System	√	√	√				
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 470\TRUCK DT 12 HPI [---04>---08]\Transmission\GMS - Gear management system A4	√	√	√			√	
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 470\TRUCK DT 12 HPI [---04>---08]\Transmission\GMS - Gear management system OPC	√	√	√	√		√	0005
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 470\TRUCK DT 12 HPI [---04>---08]\Transmission\GMS - Gear management system Opticruise 5	√	√	√	√		√	0009, 0011, 0018
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 470\TRUCK DT 12 HPI [---04>---08]\Transmission\GMS - GMS Opticruise 5	√	√	√	√		√	0009, 0011, 0018
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 470\TRUCK DT 12 HPI [---04>---08]\Transport information system\RTI - Road Transport Informatics	√	√	√				
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 480\TRUCK DC 13 XPI EU5 [---08>---13]\ABS\BMS Brake management system-ABS E	√	√	√	√		√	
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 480\TRUCK DC 13 XPI EU5 [---08>---13]\Aid for keeping lane\LDW Monitor traffic lane	√	√	√				
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 480\TRUCK DC 13 XPI EU5 [---08>---13]\Air conditioner\CCS Climate control system	√	√	√	√		√	
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 480\TRUCK DC 13 XPI EU5 [---08>---13]\Airbag\CSS Climate safety system	√	√	√				
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 480\TRUCK DC 13 XPI EU5 [---08>---13]\Alarm\LAS Locking and alarm system	√	√	√				
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 480\TRUCK DC 13 XPI EU5 [---08>---13]\Auxiliary heating\ATA Auxiliary heating system air-to-air	√	√	√	√			
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 480\TRUCK DC 13 XPI EU5 [---08>---13]\Auxiliary heating\WTA Auxiliary heating system water-to-air	√	√	√				
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 480\TRUCK DC 13 XPI EU5 [---08>---13]\Chassis equipment and design\BWS Preparation system	√	√	√				
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 480\TRUCK DC 13 XPI EU5 [---08>---13]\Comfort system\CTS Clock and Time System	√	√	√				
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 480\TRUCK DC 13 XPI EU5 [---08>---13]\Compressed air reserve system\APS Compressed air power supply(Scania protocol)	√	√	√	√			0003
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 480\TRUCK DC 13 XPI EU5 [---08>---13]\Compressed air reserve system\APS Compressed air power supply(Wabco protocol)	√	√	√	√			
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 480\TRUCK DC 13 XPI EU5 [---08>---13]\Diesel injection\EEC-Exhaust gas treatment	√	√	√	√		√	
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 480\TRUCK DC 13 XPI EU5 [---08>---13]\Diesel injection\EMS Engine management system S6-S7	√	√	√	√		√	0002, 0015, 0017
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 480\TRUCK DC 13 XPI EU5 [---08>---13]\Diesel injection\EMS Engine management system S8(8 Cylindes)	√	√	√	√		√	0001
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 480\TRUCK DC 13 XPI EU5 [---08>---13]\Diesel injection\EMS Engine management system DC13(6 Cylindes)	√	√	√	√		√	
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 480\TRUCK DC 13 XPI EU5 [---08>---13]\Distance control\DAS Adaptive Cruise Control	√	√	√				
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 480\TRUCK DC 13 XPI EU5 [---08>---13]\Distance control\DIS Adaptive Cruise Control	√	√	√				
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 480\TRUCK DC 13 XPI EU5 [---08>---13]\EBS\BMS Brake management system 5.0 (4x2)	√	√	√	√		√	0004
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 480\TRUCK DC 13 XPI EU5 [---08>---13]\EBS\BMS Brake management system 5.0 (6x2 - 6x4)	√	√	√	√		√	0004
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 480\TRUCK DC 13 XPI EU5 [---08>---13]\EBS\BMS Brake management system 5.0 (8x2)	√	√	√	√		√	0004
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 480\TRUCK DC 13 XPI EU5 [---08>---13]\ECU external light\VIS Visibility system	√	√	√	√		√	
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 480\TRUCK DC 13 XPI EU5 [---08>---13]\Engine-vehicle adjustment\COO Coordinator module	√	√	√	√		√	
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 480\TRUCK DC 13 XPI EU5 [---08>---13]\Engine-vehicle adjustment\COO7 (Coordinator)	√	√	√	√		√	
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 480\TRUCK DC 13 XPI EU5 [---08>---13]\Four-wheel drive\AWD ALL-Wheel Drive	√	√	√				
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 480\TRUCK DC 13 XPI EU5 [---08>---13]\Instrument panel\ICL Instrument Panel 1	√	√	√	√		√	
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 480\TRUCK DC 13 XPI EU5 [---08>---13]\Instrument panel\ICL Instrument Panel 2	√	√	√	√		√	
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 480\TRUCK DC 13 XPI EU5 [---08>---13]\Radio\AUS Audio system	√	√	√				
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 480\TRUCK DC 13 XPI EU5 [---08>---13]\Retarder\RET Retarder	√	√	√	√		√	
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 480\TRUCK DC 13 XPI EU5 [---08>---13]\Suspensions\SMS Supension management system	√	√	√	√			0006, 0007, 0014

Scania\Divided By Vehicle\BUS&Coach\K series\Engine 480\TRUCK DC 13 XPI EU5 [---08>---13]\Tachograph\DTCO Tachograph	√	√	√				
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 480\TRUCK DC 13 XPI EU5 [---08>---13]\Tachograph\MTCO Tachograph	√	√	√				
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 480\TRUCK DC 13 XPI EU5 [---08>---13]\Tire pressure\TPM - Tires Pressure Monitoring System	√	√	√				
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 480\TRUCK DC 13 XPI EU5 [---08>---13]\Transmission\GMS - Gear management system A4	√	√	√			√	
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 480\TRUCK DC 13 XPI EU5 [---08>---13]\Transmission\GMS - Gear management system OPC	√	√	√	√		√	0005
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 480\TRUCK DC 13 XPI EU5 [---08>---13]\Transmission\GMS - Gear management system Opticruise 5	√	√	√	√		√	0009, 0011, 0018
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 480\TRUCK DC 13 XPI EU5 [---08>---13]\Transmission\GMS - GMS Opticruise 5	√	√	√	√		√	0009, 0011, 0018
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 480\TRUCK DC 13 XPI EU5 [---08>---13]\Transport information system\RTI - Road Transport Informatics	√	√	√				
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 480\TRUCK DC 13 [---04>---08]\ABS\BMS Brake management system-ABS E	√	√	√	√		√	
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 480\TRUCK DC 13 [---04>---08]\Aid for keeping lane\LDW Monitor traffic lane	√	√	√				
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 480\TRUCK DC 13 [---04>---08]\Air conditioner\CCS Climate control system	√	√	√	√		√	
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 480\TRUCK DC 13 [---04>---08]\Airbag\CSS Climate safety system	√	√	√				
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 480\TRUCK DC 13 [---04>---08]\Alarm\LAS Locking and alarm system	√	√	√				
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 480\TRUCK DC 13 [---04>---08]\Auxiliary heating\ATA Auxiliary heating system air-to-air	√	√	√	√			
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 480\TRUCK DC 13 [---04>---08]\Auxiliary heating\WTA Auxiliary heating system water-to-air	√	√	√				
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 480\TRUCK DC 13 [---04>---08]\Chassis equipment and design\BWS Preparation system	√	√	√				
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 480\TRUCK DC 13 [---04>---08]\Comfort system\CTS Clock and Time System	√	√	√				
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 480\TRUCK DC 13 [---04>---08]\Compressed air reserve system\APS Compressed air power supply(Scania protocol)	√	√	√	√			0003
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 480\TRUCK DC 13 [---04>---08]\Compressed air reserve system\APS Compressed air power supply(Wabco protocol)	√	√	√	√			
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 480\TRUCK DC 13 [---04>---08]\Diesel injection\EEC-Exhaust gas treatment	√	√	√	√		√	
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 480\TRUCK DC 13 [---04>---08]\Diesel injection\EMS Engine management system S6-S7	√	√	√	√		√	0002, 0015, 0017
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 480\TRUCK DC 13 [---04>---08]\Diesel injection\EMS Engine management system S8(8 Cylindres)	√	√	√	√		√	0001
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 480\TRUCK DC 13 [---04>---08]\Diesel injection\EMS Engine management system DC13(6 Cylindres)	√	√	√	√		√	
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 480\TRUCK DC 13 [---04>---08]\Distance control\DAS Adaptive Cruise Control	√	√	√				
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 480\TRUCK DC 13 [---04>---08]\Distance control\DIS Adaptive Cruise Control	√	√	√				
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 480\TRUCK DC 13 [---04>---08]\EBS\BMS Brake management system 5.0 (4x2)	√	√	√	√		√	0004
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 480\TRUCK DC 13 [---04>---08]\EBS\BMS Brake management system 5.0 (6x2 - 6x4)	√	√	√	√		√	0004
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 480\TRUCK DC 13 [---04>---08]\EBS\BMS Brake management system 5.0 (8x2)	√	√	√	√		√	0004
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 480\TRUCK DC 13 [---04>---08]\ECU external light\VIS Visibility system	√	√	√	√		√	
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 480\TRUCK DC 13 [---04>---08]\Engine-vehicle adjustment\COO Coordinator module	√	√	√	√		√	
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 480\TRUCK DC 13 [---04>---08]\Engine-vehicle adjustment\COO7 (Coordinator)	√	√	√	√		√	
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 480\TRUCK DC 13 [---04>---08]\Four-wheel drive\AWD ALL-Wheel Drive	√	√	√				
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 480\TRUCK DC 13 [---04>---08]\Instrument panel\NCL Instrument Panel 1	√	√	√	√		√	
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 480\TRUCK DC 13 [---04>---08]\Instrument panel\NCL Instrument Panel 2	√	√	√	√		√	
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 480\TRUCK DC 13 [---04>---08]\Radio\AUS Audio system	√	√	√				

Scania\Divided By Vehicle\BUS&Coach\K series\Engine 480\TRUCK DC 13 [---04>---08]\Retarder\RET Retarder	√	√	√	√		√	
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 480\TRUCK DC 13 [---04>---08]\Suspensions\SMS Supension management system	√	√	√	√			0006, 0007, 0014
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 480\TRUCK DC 13 [---04>---08]\Tachograph\DTCO Tachograph	√	√	√				
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 480\TRUCK DC 13 [---04>---08]\Tachograph\MTCO Tachograph	√	√	√				
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 480\TRUCK DC 13 [---04>---08]\Tire pressure\TPM - Tires Pressure Monitoring System	√	√	√				
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 480\TRUCK DC 13 [---04>---08]\Transmission\GMS - Gear management system A4	√	√	√			√	
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 480\TRUCK DC 13 [---04>---08]\Transmission\GMS - Gear management system OPC	√	√	√	√		√	0005
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 480\TRUCK DC 13 [---04>---08]\Transmission\GMS - Gear management system Opticruise 5	√	√	√	√		√	0009, 0011, 0018
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 480\TRUCK DC 13 [---04>---08]\Transmission\GMS - GMS Opticruise 5	√	√	√	√		√	0009, 0011, 0018
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 480\TRUCK DC 13 [---04>---08]\Transport information system\RTI - Road Transport Informatics	√	√	√				
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 480\TRUCK DT 12 HPI [---04>---08]\ABS\BMS Brake management system-ABS E	√	√	√	√		√	
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 480\TRUCK DT 12 HPI [---04>---08]\Aid for keeping lane\LDW Monitor traffic lane	√	√	√				
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 480\TRUCK DT 12 HPI [---04>---08]\Air conditioner\CCS Climate control system	√	√	√	√		√	
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 480\TRUCK DT 12 HPI [---04>---08]\Airbag\CSS Climate safety system	√	√	√				
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 480\TRUCK DT 12 HPI [---04>---08]\Alarm\LAS Locking and alarm system	√	√	√				
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 480\TRUCK DT 12 HPI [---04>---08]\Auxiliary heating\ATA Auxiliary heating system air-to-air	√	√	√	√			
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 480\TRUCK DT 12 HPI [---04>---08]\Auxiliary heating\WTA Auxiliary heating system water-to-air	√	√	√				
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 480\TRUCK DT 12 HPI [---04>---08]\Chassis equipment and design\BWS Preparation system	√	√	√				
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 480\TRUCK DT 12 HPI [---04>---08]\Comfort system\CTS Clock and Time System	√	√	√				
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 480\TRUCK DT 12 HPI [---04>---08]\Compressed air reserve system\APS Compressed air power supply(Scania protocol)	√	√	√	√			0003
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 480\TRUCK DT 12 HPI [---04>---08]\Compressed air reserve system\APS Compressed air power supply(Wabco protocol)	√	√	√	√			
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 480\TRUCK DT 12 HPI [---04>---08]\Diesel injection\EEC-Exhaust gas treatment	√	√	√	√		√	
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 480\TRUCK DT 12 HPI [---04>---08]\Diesel injection\EMS Engine management system S6-S7	√	√	√	√		√	0002, 0015, 0017
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 480\TRUCK DT 12 HPI [---04>---08]\Diesel injection\EMS Engine management system S8(8 Cylindes)	√	√	√	√		√	0001
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 480\TRUCK DT 12 HPI [---04>---08]\Diesel injection\EMS Engine management system DC13(6 Cylindes)	√	√	√	√		√	
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 480\TRUCK DT 12 HPI [---04>---08]\Distance control\DAS Adaptive Cruise Control	√	√	√				
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 480\TRUCK DT 12 HPI [---04>---08]\Distance control\DIS Adaptive Cruise Control	√	√	√				
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 480\TRUCK DT 12 HPI [---04>---08]\EBS\BMS Brake management system 5.0 (4x2)	√	√	√	√		√	0004
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 480\TRUCK DT 12 HPI [---04>---08]\EBS\BMS Brake management system 5.0 (6x2 - 6x4)	√	√	√	√		√	0004
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 480\TRUCK DT 12 HPI [---04>---08]\EBS\BMS Brake management system 5.0 (8x2)	√	√	√	√		√	0004
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 480\TRUCK DT 12 HPI [---04>---08]\ECU external light\VIS Visibility system	√	√	√	√		√	
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 480\TRUCK DT 12 HPI [---04>---08]\Engine-vehicle adjustment\COO Coordinator module	√	√	√	√		√	
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 480\TRUCK DT 12 HPI [---04>---08]\Engine-vehicle adjustment\COO7 (Coordinator)	√	√	√	√		√	
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 480\TRUCK DT 12 HPI [---04>---08]\Four-wheel drive\AWD ALL-Wheel Drive	√	√	√				
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 480\TRUCK DT 12 HPI [---04>---08]\Instrument panel\NCL Instrument Panel 1	√	√	√	√		√	

Scania\Divided By Vehicle\BUS&Coach\K series\Engine 480\TRUCK DT 12 HPI [---04>---08]\Instrument panel\NCL Instrument Panel 2	√	√	√	√		√	
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 480\TRUCK DT 12 HPI [---04>---08]\Radio\AUS Audio system	√	√	√				
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 480\TRUCK DT 12 HPI [---04>---08]\Retarder\RET Retarder	√	√	√	√		√	
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 480\TRUCK DT 12 HPI [---04>---08]\Suspensions\SMS Supension management system	√	√	√	√			0006, 0007, 0014
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 480\TRUCK DT 12 HPI [---04>---08]\Tachograph\DTCO Tachograph	√	√	√				
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 480\TRUCK DT 12 HPI [---04>---08]\Tachograph\MTCO Tachograph	√	√	√				
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 480\TRUCK DT 12 HPI [---04>---08]\Tire pressure\TPM - Tires Pressure Monitoring System	√	√	√				
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 480\TRUCK DT 12 HPI [---04>---08]\Transmission\GMS - Gear management system A4	√	√	√			√	
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 480\TRUCK DT 12 HPI [---04>---08]\Transmission\GMS - Gear management system OPC	√	√	√	√		√	0005
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 480\TRUCK DT 12 HPI [---04>---08]\Transmission\GMS - Gear management system Opticruise 5	√	√	√	√		√	0009, 0011, 0018
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 480\TRUCK DT 12 HPI [---04>---08]\Transmission\GMS - GMS Opticruise 5	√	√	√	√		√	0009, 0011, 0018
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 480\TRUCK DT 12 HPI [---04>---08]\Transport information system\RTI - Road Transport Informatics	√	√	√				
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 500\TRUCK DC 16 EU5 [---08>---13]\ABS\BMS Brake management system-ABS E	√	√	√	√		√	
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 500\TRUCK DC 16 EU5 [---08>---13]\Aid for keeping lane\LDW Monitor traffic lane	√	√	√				
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 500\TRUCK DC 16 EU5 [---08>---13]\Air conditioner\CCS Climate control system	√	√	√	√		√	
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 500\TRUCK DC 16 EU5 [---08>---13]\Airbag\CSS Climate safety system	√	√	√				
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 500\TRUCK DC 16 EU5 [---08>---13]\Alarm\LAS Locking and alarm system	√	√	√				
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 500\TRUCK DC 16 EU5 [---08>---13]\Auxiliary heating\ATA Auxiliary heating system air-to-air	√	√	√	√			
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 500\TRUCK DC 16 EU5 [---08>---13]\Auxiliary heating\WTA Auxiliary heating system water-to-air	√	√	√				
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 500\TRUCK DC 16 EU5 [---08>---13]\Chassis equipment and design\BWS Preparation system	√	√	√				
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 500\TRUCK DC 16 EU5 [---08>---13]\Comfort system\CTS Clock and Time System	√	√	√				
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 500\TRUCK DC 16 EU5 [---08>---13]\Compressed air reserve system\APS Compressed air power supply(Scania protocol)	√	√	√	√			0003
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 500\TRUCK DC 16 EU5 [---08>---13]\Compressed air reserve system\APS Compressed air power supply(Wabco protocol)	√	√	√	√			
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 500\TRUCK DC 16 EU5 [---08>---13]\Diesel injection\EEC-Exhaust gas treatment	√	√	√	√		√	
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 500\TRUCK DC 16 EU5 [---08>---13]\Diesel injection\EMS Engine management system S6-S7	√	√	√	√		√	0002, 0015, 0017
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 500\TRUCK DC 16 EU5 [---08>---13]\Diesel injection\EMS Engine management system S8(8 Cylindes)	√	√	√	√		√	0001
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 500\TRUCK DC 16 EU5 [---08>---13]\Diesel injection\EMS Engine management system DC13(6 Cylindes)	√	√	√	√		√	
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 500\TRUCK DC 16 EU5 [---08>---13]\Distance control\DAS Adaptive Cruise Control	√	√	√				
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 500\TRUCK DC 16 EU5 [---08>---13]\Distance control\DIS Adaptive Cruise Control	√	√	√				
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 500\TRUCK DC 16 EU5 [---08>---13]\EBS\BMS Brake management system 5.0 (4x2)	√	√	√	√		√	0004
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 500\TRUCK DC 16 EU5 [---08>---13]\EBS\BMS Brake management system 5.0 (6x2 - 6x4)	√	√	√	√		√	0004
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 500\TRUCK DC 16 EU5 [---08>---13]\EBS\BMS Brake management system 5.0 (8x2)	√	√	√	√		√	0004
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 500\TRUCK DC 16 EU5 [---08>---13]\ECU external light\VIS Visibility system	√	√	√	√		√	
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 500\TRUCK DC 16 EU5 [---08>---13]\Engine-vehicle adjustment\COO Coordinator module	√	√	√	√		√	
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 500\TRUCK DC 16 EU5 [---08>---13]\Engine-vehicle adjustment\COO7 (Coordinator)	√	√	√	√		√	

Scania\Divided By Vehicle\BUS&Coach\K series\Engine 500\TRUCK DC 16 EU5 [---08>---13]\Four-wheel drive\AWD ALL-Wheel Drive	√	√	√				
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 500\TRUCK DC 16 EU5 [---08>---13]\Instrument panel\NCL Instrument Panel 1	√	√	√	√		√	
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 500\TRUCK DC 16 EU5 [---08>---13]\Instrument panel\NCL Instrument Panel 2	√	√	√	√		√	
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 500\TRUCK DC 16 EU5 [---08>---13]\Radio\AUS Audio system	√	√	√				
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 500\TRUCK DC 16 EU5 [---08>---13]\Retarder\RET Retarder	√	√	√	√		√	
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 500\TRUCK DC 16 EU5 [---08>---13]\Suspensions\SMS Supension management system	√	√	√	√			0006, 0007, 0014
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 500\TRUCK DC 16 EU5 [---08>---13]\Tachograph\DTCO Tachograph	√	√	√				
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 500\TRUCK DC 16 EU5 [---08>---13]\Tachograph\MTCO Tachograph	√	√	√				
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 500\TRUCK DC 16 EU5 [---08>---13]\Tire pressure\TPM - Tires Pressure Monitoring System	√	√	√				
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 500\TRUCK DC 16 EU5 [---08>---13]\Transmission\GMS - Gear management system A4	√	√	√			√	
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 500\TRUCK DC 16 EU5 [---08>---13]\Transmission\GMS - Gear management system OPC	√	√	√	√		√	0005
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 500\TRUCK DC 16 EU5 [---08>---13]\Transmission\GMS - Gear management system Opticruise 5	√	√	√	√		√	0009, 0011, 0018
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 500\TRUCK DC 16 EU5 [---08>---13]\Transmission\GMS - GMS Opticruise 5	√	√	√	√		√	0009, 0011, 0018
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 500\TRUCK DC 16 EU5 [---08>---13]\Transport information system\RTI - Road Transport Informatics	√	√	√				
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 500\TRUCK DC 16 [---04>---13]\ABS\BMS Brake management system-ABS E	√	√	√	√		√	
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 500\TRUCK DC 16 [---04>---13]\Aid for keeping lane\LDW Monitor traffic lane	√	√	√				
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 500\TRUCK DC 16 [---04>---13]\Air conditioner\CCS Climate control system	√	√	√	√		√	
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 500\TRUCK DC 16 [---04>---13]\Airbag\CSS Climate safety system	√	√	√				
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 500\TRUCK DC 16 [---04>---13]\Alarm\LAS Locking and alarm system	√	√	√				
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 500\TRUCK DC 16 [---04>---13]\Auxiliary heating\ATA Auxiliary heating system air-to-air	√	√	√	√			
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 500\TRUCK DC 16 [---04>---13]\Auxiliary heating\WTA Auxiliary heating system water-to-air	√	√	√				
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 500\TRUCK DC 16 [---04>---13]\Chassis equipment and design\BWS Preparation system	√	√	√				
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 500\TRUCK DC 16 [---04>---13]\Comfort system\CTS Clock and Time System	√	√	√				
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 500\TRUCK DC 16 [---04>---13]\Compressed air reserve system\APS Compressed air power supply(Scania protocol)	√	√	√	√			0003
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 500\TRUCK DC 16 [---04>---13]\Compressed air reserve system\APS Compressed air power supply(Wabco protocol)	√	√	√	√			
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 500\TRUCK DC 16 [---04>---13]\Diesel injection\EEC-Exhaust gas treatment	√	√	√	√		√	
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 500\TRUCK DC 16 [---04>---13]\Diesel injection\EMS Engine management system S6-S7	√	√	√	√		√	0002, 0015, 0017
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 500\TRUCK DC 16 [---04>---13]\Diesel injection\EMS Engine management system S8(8 Cylindes)	√	√	√	√		√	0001
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 500\TRUCK DC 16 [---04>---13]\Diesel injection\EMS Engine management system DC13(6 Cylindes)	√	√	√	√		√	
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 500\TRUCK DC 16 [---04>---13]\Distance control\DAS Adaptive Cruise Control	√	√	√				
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 500\TRUCK DC 16 [---04>---13]\Distance control\DIS Adaptive Cruise Control	√	√	√				
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 500\TRUCK DC 16 [---04>---13]\EBS\BMS Brake management system 5.0 (4x2)	√	√	√	√		√	0004
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 500\TRUCK DC 16 [---04>---13]\EBS\BMS Brake management system 5.0 (6x2 - 6x4)	√	√	√	√		√	0004
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 500\TRUCK DC 16 [---04>---13]\EBS\BMS Brake management system 5.0 (8x2)	√	√	√	√		√	0004
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 500\TRUCK DC 16 [---04>---13]\ECU external light\VIS Visibility system	√	√	√	√		√	

Scania\Divided By Vehicle\BUS&Coach\K series\Engine 500\TRUCK DC 16 [---04>---13]\Engine-vehicle adjustment\COO Coordinator module	√	√	√	√		√	
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 500\TRUCK DC 16 [---04>---13]\Engine-vehicle adjustment\COO7 (Coordinator)	√	√	√	√		√	
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 500\TRUCK DC 16 [---04>---13]\Four-wheel drive\AWD ALL-Wheel Drive	√	√	√				
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 500\TRUCK DC 16 [---04>---13]\Instrument pane\NCL Instrument Panel 1	√	√	√	√		√	
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 500\TRUCK DC 16 [---04>---13]\Instrument pane\NCL Instrument Panel 2	√	√	√	√		√	
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 500\TRUCK DC 16 [---04>---13]\Radio\AUS Audio system	√	√	√				
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 500\TRUCK DC 16 [---04>---13]\Retarder\RET Retarder	√	√	√	√		√	
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 500\TRUCK DC 16 [---04>---13]\Suspensions\SMS Supension management system	√	√	√	√			0006, 0007, 0014
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 500\TRUCK DC 16 [---04>---13]\Tachograph\DTCO Tachograph	√	√	√				
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 500\TRUCK DC 16 [---04>---13]\Tachograph\MTCO Tachograph	√	√	√				
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 500\TRUCK DC 16 [---04>---13]\Tire pressure\TPM - Tires Pressure Monitoring System	√	√	√				
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 500\TRUCK DC 16 [---04>---13]\Transmission\GMS - Gear management system A4	√	√	√			√	
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 500\TRUCK DC 16 [---04>---13]\Transmission\GMS - Gear management system OPC	√	√	√	√		√	0005
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 500\TRUCK DC 16 [---04>---13]\Transmission\GMS - Gear management system Opticruise 5	√	√	√	√		√	0009, 0011, 0018
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 500\TRUCK DC 16 [---04>---13]\Transmission\GMS - GMS Opticruise 5	√	√	√	√		√	0009, 0011, 0018
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 500\TRUCK DC 16 [---04>---13]\Transport information system\RTI - Road Transport Informatics	√	√	√				
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 530\TRUCK DSC 14 [---04>---13]\ABS\BMS Brake management system-ABS E	√	√	√	√		√	
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 530\TRUCK DSC 14 [---04>---13]\Aid for keeping lane\LDW Monitor traffic lane	√	√	√				
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 530\TRUCK DSC 14 [---04>---13]\Air conditioner\CCS Climate control system	√	√	√	√		√	
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 530\TRUCK DSC 14 [---04>---13]\Airbag\CSS Climate safety system	√	√	√				
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 530\TRUCK DSC 14 [---04>---13]\Alarm\LAS Locking and alarm system	√	√	√				
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 530\TRUCK DSC 14 [---04>---13]\Auxiliary heating\ATA Auxiliary heating system air-to-air	√	√	√	√			
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 530\TRUCK DSC 14 [---04>---13]\Auxiliary heating\WTA Auxiliary heating system water-to-air	√	√	√				
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 530\TRUCK DSC 14 [---04>---13]\Chassis equipment and design\BWS Preparation system	√	√	√				
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 530\TRUCK DSC 14 [---04>---13]\Comfort system\CTS Clock and Time System	√	√	√				
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 530\TRUCK DSC 14 [---04>---13]\Compressed air reserve system\APS Compressed air power supply(Scania protocol)	√	√	√	√			0003
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 530\TRUCK DSC 14 [---04>---13]\Compressed air reserve system\APS Compressed air power supply(Wabco protocol)	√	√	√	√			
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 530\TRUCK DSC 14 [---04>---13]\Diesel injection\EEC-Exhaust gas treatment	√	√	√	√		√	
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 530\TRUCK DSC 14 [---04>---13]\Diesel injection\EMS Engine management system S6-S7	√	√	√	√		√	0002, 0015, 0017
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 530\TRUCK DSC 14 [---04>---13]\Diesel injection\EMS Engine management system S8(8 Cylindes)	√	√	√	√		√	0001
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 530\TRUCK DSC 14 [---04>---13]\Diesel injection\EMS Engine management system DC13(6 Cylindes)	√	√	√	√		√	
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 530\TRUCK DSC 14 [---04>---13]\Distance control\DAS Adaptive Cruise Control	√	√	√				
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 530\TRUCK DSC 14 [---04>---13]\Distance control\DIS Adaptive Cruise Control	√	√	√				
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 530\TRUCK DSC 14 [---04>---13]\EBS\BMS Brake management system 5.0 (4x2)	√	√	√	√		√	0004
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 530\TRUCK DSC 14 [---04>---13]\EBS\BMS Brake management system 5.0 (6x2 - 6x4)	√	√	√	√		√	0004

Scania\Divided By Vehicle\BUS&Coach\K series\Engine 530\TRUCK DSC 14 [---04>---13\EBS\BMS Brake management system 5.0 (8x2)	√	√	√	√		√	0004
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 530\TRUCK DSC 14 [---04>---13\ECU external light\VIS Visibility system	√	√	√	√		√	
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 530\TRUCK DSC 14 [---04>---13\Engine-vehicle adjustment\COO Coordinator module	√	√	√	√		√	
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 530\TRUCK DSC 14 [---04>---13\Engine-vehicle adjustment\COO7 (Coordinator)	√	√	√	√		√	
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 530\TRUCK DSC 14 [---04>---13\Four-wheel drive\AWD ALL-Wheel Drive	√	√	√				
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 530\TRUCK DSC 14 [---04>---13\Instrument panel\ICL Instrument Panel 1	√	√	√	√		√	
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 530\TRUCK DSC 14 [---04>---13\Instrument panel\ICL Instrument Panel 2	√	√	√	√		√	
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 530\TRUCK DSC 14 [---04>---13\Radio\AUS Audio system	√	√	√				
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 530\TRUCK DSC 14 [---04>---13\Retarder\RET Retarder	√	√	√	√		√	
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 530\TRUCK DSC 14 [---04>---13\Suspensions\SMS Suspension management system	√	√	√	√			0006, 0007, 0014
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 530\TRUCK DSC 14 [---04>---13\Tachograph\DTCO Tachograph	√	√	√				
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 530\TRUCK DSC 14 [---04>---13\Tachograph\MTCO Tachograph	√	√	√				
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 530\TRUCK DSC 14 [---04>---13\Tire pressure\TPM - Tires Pressure Monitoring System	√	√	√				
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 530\TRUCK DSC 14 [---04>---13\Transmission\GMS - Gear management system A4	√	√	√			√	
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 530\TRUCK DSC 14 [---04>---13\Transmission\GMS - Gear management system OPC	√	√	√	√		√	0005
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 530\TRUCK DSC 14 [---04>---13\Transmission\GMS - Gear management system Opticruise 5	√	√	√	√		√	0009, 0011, 0018
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 530\TRUCK DSC 14 [---04>---13\Transmission\GMS - GMS Opticruise 5	√	√	√	√		√	0009, 0011, 0018
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 530\TRUCK DSC 14 [---04>---13\Transport information system\RTI - Road Transport Informatics	√	√	√				
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 560\TRUCK DC 16 EU5 [---08>---13\ABS\BMS Brake management system-ABS E	√	√	√	√		√	
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 560\TRUCK DC 16 EU5 [---08>---13\Aid for keeping lane\LDW Monitor traffic lane	√	√	√				
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 560\TRUCK DC 16 EU5 [---08>---13\Air conditioner\CCS Climate control system	√	√	√	√		√	
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 560\TRUCK DC 16 EU5 [---08>---13\Airbag\CSS Climate safety system	√	√	√				
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 560\TRUCK DC 16 EU5 [---08>---13\Alarm\LAS Locking and alarm system	√	√	√				
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 560\TRUCK DC 16 EU5 [---08>---13\Auxiliary heating\ATA Auxiliary heating system air-to-air	√	√	√	√			
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 560\TRUCK DC 16 EU5 [---08>---13\Auxiliary heating\WTA Auxiliary heating system water-to-air	√	√	√				
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 560\TRUCK DC 16 EU5 [---08>---13\Chassis equipment and design\BWS Preparation system	√	√	√				
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 560\TRUCK DC 16 EU5 [---08>---13\Comfort system\CTS Clock and Time System	√	√	√				
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 560\TRUCK DC 16 EU5 [---08>---13\Compressed air reserve system\APS Compressed air power supply(Scania protocol)	√	√	√	√			0003
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 560\TRUCK DC 16 EU5 [---08>---13\Compressed air reserve system\APS Compressed air power supply(Wabco protocol)	√	√	√	√			
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 560\TRUCK DC 16 EU5 [---08>---13\Diesel injection\EEC-Exhaust gas treatment	√	√	√	√		√	
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 560\TRUCK DC 16 EU5 [---08>---13\Diesel injection\EMS Engine management system S6-S7	√	√	√	√		√	0002, 0015, 0017
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 560\TRUCK DC 16 EU5 [---08>---13\Diesel injection\EMS Engine management system S8(8 Cylindes)	√	√	√	√		√	0001
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 560\TRUCK DC 16 EU5 [---08>---13\Diesel injection\EMS Engine management system DC13(6 Cylindes)	√	√	√	√		√	
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 560\TRUCK DC 16 EU5 [---08>---13\Distance control\DAS Adaptive Cruise Control	√	√	√				
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 560\TRUCK DC 16 EU5 [---08>---13\Distance control\DIS Adaptive Cruise Control	√	√	√				

Scania\Divided By Vehicle\BUS&Coach\K series\Engine 560\TRUCK DC 16 EU5 [---08>---13]\EBS\BMS Brake management system 5.0 (4x2)	√	√	√	√		√	0004
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 560\TRUCK DC 16 EU5 [---08>---13]\EBS\BMS Brake management system 5.0 (6x2 - 6x4)	√	√	√	√		√	0004
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 560\TRUCK DC 16 EU5 [---08>---13]\EBS\BMS Brake management system 5.0 (8x2)	√	√	√	√		√	0004
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 560\TRUCK DC 16 EU5 [---08>---13]\ECU external light\VIS Visibility system	√	√	√	√		√	
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 560\TRUCK DC 16 EU5 [---08>---13]\Engine-vehicle adjustment\COO Coordinator module	√	√	√	√		√	
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 560\TRUCK DC 16 EU5 [---08>---13]\Engine-vehicle adjustment\COO7 (Coordinator)	√	√	√	√		√	
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 560\TRUCK DC 16 EU5 [---08>---13]\Four-wheel drive\AWD ALL-Wheel Drive	√	√	√				
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 560\TRUCK DC 16 EU5 [---08>---13]\Instrument panel\NCL Instrument Panel 1	√	√	√	√		√	
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 560\TRUCK DC 16 EU5 [---08>---13]\Instrument panel\NCL Instrument Panel 2	√	√	√	√		√	
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 560\TRUCK DC 16 EU5 [---08>---13]\Radio\AUS Audio system	√	√	√				
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 560\TRUCK DC 16 EU5 [---08>---13]\Retarder\RET Retarder	√	√	√	√		√	
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 560\TRUCK DC 16 EU5 [---08>---13]\Suspensions\SMS Supension management system	√	√	√	√			0006, 0007, 0014
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 560\TRUCK DC 16 EU5 [---08>---13]\Tachograph\DTCO Tachograph	√	√	√				
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 560\TRUCK DC 16 EU5 [---08>---13]\Tachograph\MTCO Tachograph	√	√	√				
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 560\TRUCK DC 16 EU5 [---08>---13]\Tire pressure\TPM - Tires Pressure Monitoring System	√	√	√				
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 560\TRUCK DC 16 EU5 [---08>---13]\Transmission\GMS - Gear management system A4	√	√	√			√	
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 560\TRUCK DC 16 EU5 [---08>---13]\Transmission\GMS - Gear management system OPC	√	√	√	√		√	0005
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 560\TRUCK DC 16 EU5 [---08>---13]\Transmission\GMS - Gear management system Opticruise 5	√	√	√	√		√	0009, 0011, 0018
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 560\TRUCK DC 16 EU5 [---08>---13]\Transmission\GMS - GMS Opticruise 5	√	√	√	√		√	0009, 0011, 0018
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 560\TRUCK DC 16 EU5 [---08>---13]\Transport information system\RTI - Road Transport Informatics	√	√	√				
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 560\TRUCK DC 16 [---06>---13]\ABS\BMS Brake management system-ABS E	√	√	√	√		√	
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 560\TRUCK DC 16 [---06>---13]\Aid for keeping lane\LDW Monitor traffic lane	√	√	√				
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 560\TRUCK DC 16 [---06>---13]\Air conditioner\CCS Climate control system	√	√	√	√		√	
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 560\TRUCK DC 16 [---06>---13]\Airbag\CSS Climate safety system	√	√	√				
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 560\TRUCK DC 16 [---06>---13]\Alarm\LAS Locking and alarm system	√	√	√				
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 560\TRUCK DC 16 [---06>---13]\Auxiliary heating\ATA Auxiliary heating system air-to-air	√	√	√	√			
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 560\TRUCK DC 16 [---06>---13]\Auxiliary heating\WTA Auxiliary heating system water-to-air	√	√	√				
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 560\TRUCK DC 16 [---06>---13]\Chassis equipment and design\BWS Preparation system	√	√	√				
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 560\TRUCK DC 16 [---06>---13]\Comfort system\CTS Clock and Time System	√	√	√				
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 560\TRUCK DC 16 [---06>---13]\Compressed air reserve system\APS Compressed air power supply(Scania protocol)	√	√	√	√			0003
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 560\TRUCK DC 16 [---06>---13]\Compressed air reserve system\APS Compressed air power supply(Wabco protocol)	√	√	√	√			
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 560\TRUCK DC 16 [---06>---13]\Diesel injection\EEC-Exhaust gas treatment	√	√	√	√		√	
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 560\TRUCK DC 16 [---06>---13]\Diesel injection\EMS Engine management system S6-S7	√	√	√	√		√	0002, 0015, 0017
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 560\TRUCK DC 16 [---06>---13]\Diesel injection\EMS Engine management system S8(8 Cylindres)	√	√	√	√		√	0001
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 560\TRUCK DC 16 [---06>---13]\Diesel injection\EMS Engine management system DC13(6 Cylindres)	√	√	√	√		√	

Scania\Divided By Vehicle\BUS&Coach\K series\Engine 560\TRUCK DC 16 [---06>---13]\Distance control\DAS Adaptive Cruise Control	√	√	√				
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 560\TRUCK DC 16 [---06>---13]\Distance control\DIS Adaptive Cruise Control	√	√	√				
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 560\TRUCK DC 16 [---06>---13]\EBS\BMS Brake management system 5.0 (4x2)	√	√	√	√		√	0004
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 560\TRUCK DC 16 [---06>---13]\EBS\BMS Brake management system 5.0 (6x2 - 6x4)	√	√	√	√		√	0004
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 560\TRUCK DC 16 [---06>---13]\EBS\BMS Brake management system 5.0 (8x2)	√	√	√	√		√	0004
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 560\TRUCK DC 16 [---06>---13]\ECU external light\VIS Visibility system	√	√	√	√		√	
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 560\TRUCK DC 16 [---06>---13]\Engine-vehicle adjustment\COO Coordinator module	√	√	√	√		√	
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 560\TRUCK DC 16 [---06>---13]\Engine-vehicle adjustment\COO7 (Coordinator)	√	√	√	√		√	
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 560\TRUCK DC 16 [---06>---13]\Four-wheel drive\AWD ALL-Wheel Drive	√	√	√				
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 560\TRUCK DC 16 [---06>---13]\Instrument panel\NCL Instrument Panel 1	√	√	√	√		√	
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 560\TRUCK DC 16 [---06>---13]\Instrument panel\NCL Instrument Panel 2	√	√	√	√		√	
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 560\TRUCK DC 16 [---06>---13]\Radio\AUS Audio system	√	√	√				
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 560\TRUCK DC 16 [---06>---13]\Retarder\RET Retarder	√	√	√	√		√	
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 560\TRUCK DC 16 [---06>---13]\Suspensions\SMS Supension management system	√	√	√	√			0006, 0007, 0014
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 560\TRUCK DC 16 [---06>---13]\Tachograph\DTCO Tachograph	√	√	√				
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 560\TRUCK DC 16 [---06>---13]\Tachograph\MTCO Tachograph	√	√	√				
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 560\TRUCK DC 16 [---06>---13]\Tire pressure\TPM - Tires Pressure Monitoring System	√	√	√				
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 560\TRUCK DC 16 [---06>---13]\Transmission\GMS - Gear management system A4	√	√	√			√	
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 560\TRUCK DC 16 [---06>---13]\Transmission\GMS - Gear management system OPC	√	√	√	√		√	0005
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 560\TRUCK DC 16 [---06>---13]\Transmission\GMS - Gear management system Opticruise 5	√	√	√	√		√	0009, 0011, 0018
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 560\TRUCK DC 16 [---06>---13]\Transmission\GMS - GMS Opticruise 5	√	√	√	√		√	0009, 0011, 0018
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 560\TRUCK DC 16 [---06>---13]\Transport information system\RTI - Road Transport Informatics	√	√	√				
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 580\TRUCK DC 16 [---06>---13]\ABS\BMS Brake management system-ABS E	√	√	√	√		√	
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 580\TRUCK DC 16 [---06>---13]\Aid for keeping lane\LDW Monitor traffic lane	√	√	√				
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 580\TRUCK DC 16 [---06>---13]\Air conditioner\CCS Climate control system	√	√	√	√		√	
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 580\TRUCK DC 16 [---06>---13]\Airbag\CSS Climate safety system	√	√	√				
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 580\TRUCK DC 16 [---06>---13]\Alarm\LAS Locking and alarm system	√	√	√				
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 580\TRUCK DC 16 [---06>---13]\Auxiliary heating\ATA Auxiliary heating system air-to-air	√	√	√	√			
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 580\TRUCK DC 16 [---06>---13]\Auxiliary heating\WTA Auxiliary heating system water-to-air	√	√	√				
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 580\TRUCK DC 16 [---06>---13]\Chassis equipment and design\BWS Preparation system	√	√	√				
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 580\TRUCK DC 16 [---06>---13]\Comfort system\CTS Clock and Time System	√	√	√				
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 580\TRUCK DC 16 [---06>---13]\Compressed air reserve system\APS Compressed air power supply(Scania protocol)	√	√	√	√			0003
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 580\TRUCK DC 16 [---06>---13]\Compressed air reserve system\APS Compressed air power supply(Wabco protocol)	√	√	√	√			
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 580\TRUCK DC 16 [---06>---13]\Diesel injection\EEC-Exhaust gas treatment	√	√	√	√		√	
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 580\TRUCK DC 16 [---06>---13]\Diesel injection\EMS Engine management system S6-S7	√	√	√	√		√	0002, 0015, 0017

Scania\Divided By Vehicle\BUS&Coach\K series\Engine 580\TRUCK DC 16 [---06>---13]\Diesel injection\EMS Engine management system S8(8 Cylindes)	√	√	√	√		√	0001
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 580\TRUCK DC 16 [---06>---13]\Diesel injection\EMS Engine management system DC13(6 Cylindes)	√	√	√	√		√	
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 580\TRUCK DC 16 [---06>---13]\Distance control\DAS Adaptive Cruise Control	√	√	√				
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 580\TRUCK DC 16 [---06>---13]\Distance control\DIS Adaptive Cruise Control	√	√	√				
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 580\TRUCK DC 16 [---06>---13]\EBS\BMS Brake management system 5.0 (4x2)	√	√	√	√		√	0004
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 580\TRUCK DC 16 [---06>---13]\EBS\BMS Brake management system 5.0 (6x2 - 6x4)	√	√	√	√		√	0004
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 580\TRUCK DC 16 [---06>---13]\EBS\BMS Brake management system 5.0 (8x2)	√	√	√	√		√	0004
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 580\TRUCK DC 16 [---06>---13]\ECU external light\VIS Visibility system	√	√	√	√		√	
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 580\TRUCK DC 16 [---06>---13]\Engine-vehicle adjustment\COO Coordinator module	√	√	√	√		√	
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 580\TRUCK DC 16 [---06>---13]\Engine-vehicle adjustment\COO7 (Coordinator)	√	√	√	√		√	
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 580\TRUCK DC 16 [---06>---13]\Four-wheel drive\AWD ALL-Wheel Drive	√	√	√				
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 580\TRUCK DC 16 [---06>---13]\Instrument panel\NCL Instrument Panel 1	√	√	√	√		√	
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 580\TRUCK DC 16 [---06>---13]\Instrument panel\NCL Instrument Panel 2	√	√	√	√		√	
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 580\TRUCK DC 16 [---06>---13]\Radio\AUS Audio system	√	√	√				
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 580\TRUCK DC 16 [---06>---13]\Retarder\RET Retarder	√	√	√	√		√	
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 580\TRUCK DC 16 [---06>---13]\Suspensions\SMS Supension management system	√	√	√	√			0006, 0007, 0014
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 580\TRUCK DC 16 [---06>---13]\Tachograph\DTCO Tachograph	√	√	√				
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 580\TRUCK DC 16 [---06>---13]\Tachograph\MTCO Tachograph	√	√	√				
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 580\TRUCK DC 16 [---06>---13]\Tire pressure\TPM - Tires Pressure Monitoring System	√	√	√				
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 580\TRUCK DC 16 [---06>---13]\Transmission\GMS - Gear management system A4	√	√	√			√	
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 580\TRUCK DC 16 [---06>---13]\Transmission\GMS - Gear management system OPC	√	√	√	√		√	0005
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 580\TRUCK DC 16 [---06>---13]\Transmission\GMS - Gear management system Opticruise 5	√	√	√	√		√	0009, 0011, 0018
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 580\TRUCK DC 16 [---06>---13]\Transmission\GMS - GMS Opticruise 5	√	√	√	√		√	0009, 0011, 0018
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 580\TRUCK DC 16 [---06>---13]\Transport information system\RTI - Road Transport Informatics	√	√	√				
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 620\TRUCK DC 16 EU5 [---08>---13]\ABS\BMS Brake management system-ABS E	√	√	√	√		√	
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 620\TRUCK DC 16 EU5 [---08>---13]\Aid for keeping lane\LDW Monitor traffic lane	√	√	√				
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 620\TRUCK DC 16 EU5 [---08>---13]\Air conditioner\CCS Climate control system	√	√	√	√		√	
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 620\TRUCK DC 16 EU5 [---08>---13]\Airbag\CSS Climate safety system	√	√	√				
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 620\TRUCK DC 16 EU5 [---08>---13]\Alarm\LAS Locking and alarm system	√	√	√				
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 620\TRUCK DC 16 EU5 [---08>---13]\Auxiliary heating\ATA Auxiliary heating system air-to-air	√	√	√	√			
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 620\TRUCK DC 16 EU5 [---08>---13]\Auxiliary heating\WTA Auxiliary heating system water-to-air	√	√	√				
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 620\TRUCK DC 16 EU5 [---08>---13]\Chassis equipment and design\BWS Preparation system	√	√	√				
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 620\TRUCK DC 16 EU5 [---08>---13]\Comfort system\CTS Clock and Time System	√	√	√				
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 620\TRUCK DC 16 EU5 [---08>---13]\Compressed air reserve system\APS Compressed air power supply(Scania protocol)	√	√	√	√			0003
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 620\TRUCK DC 16 EU5 [---08>---13]\Compressed air reserve system\APS Compressed air power supply(Wabco protocol)	√	√	√	√			

Scania\Divided By Vehicle\BUS&Coach\K series\Engine 620\TRUCK DC 16 EU5 [---08>---13]\Diesel injection\EEC-Exhaust gas treatment	√	√	√	√		√	
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 620\TRUCK DC 16 EU5 [---08>---13]\Diesel injection\EMS Engine management system S6-S7	√	√	√	√		√	0002, 0015, 0017
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 620\TRUCK DC 16 EU5 [---08>---13]\Diesel injection\EMS Engine management system S8(8 Cylindres)	√	√	√	√		√	0001
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 620\TRUCK DC 16 EU5 [---08>---13]\Diesel injection\EMS Engine management system DC13(6 Cylindres)	√	√	√	√		√	
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 620\TRUCK DC 16 EU5 [---08>---13]\Distance control\DAS Adaptive Cruise Control	√	√	√				
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 620\TRUCK DC 16 EU5 [---08>---13]\Distance control\DIS Adaptive Cruise Control	√	√	√				
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 620\TRUCK DC 16 EU5 [---08>---13]\EBS\BMS Brake management system 5.0 (4x2)	√	√	√	√		√	0004
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 620\TRUCK DC 16 EU5 [---08>---13]\EBS\BMS Brake management system 5.0 (6x2 - 6x4)	√	√	√	√		√	0004
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 620\TRUCK DC 16 EU5 [---08>---13]\EBS\BMS Brake management system 5.0 (8x2)	√	√	√	√		√	0004
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 620\TRUCK DC 16 EU5 [---08>---13]\ECU external light\VIS Visibility system	√	√	√	√		√	
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 620\TRUCK DC 16 EU5 [---08>---13]\Engine-vehicle adjustment\COO Coordinator module	√	√	√	√		√	
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 620\TRUCK DC 16 EU5 [---08>---13]\Engine-vehicle adjustment\COO7 (Coordinator)	√	√	√	√		√	
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 620\TRUCK DC 16 EU5 [---08>---13]\Four-wheel drive\AWD ALL-Wheel Drive	√	√	√				
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 620\TRUCK DC 16 EU5 [---08>---13]\Instrument panel\NCL Instrument Panel 1	√	√	√	√		√	
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 620\TRUCK DC 16 EU5 [---08>---13]\Instrument panel\NCL Instrument Panel 2	√	√	√	√		√	
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 620\TRUCK DC 16 EU5 [---08>---13]\Radio\AUS Audio system	√	√	√				
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 620\TRUCK DC 16 EU5 [---08>---13]\Retarder\RET Retarder	√	√	√	√		√	
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 620\TRUCK DC 16 EU5 [---08>---13]\Suspensions\SMS Supension management system	√	√	√	√			0006, 0007, 0014
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 620\TRUCK DC 16 EU5 [---08>---13]\Tachograph\DTCO Tachograph	√	√	√				
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 620\TRUCK DC 16 EU5 [---08>---13]\Tachograph\MTCO Tachograph	√	√	√				
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 620\TRUCK DC 16 EU5 [---08>---13]\Tire pressure\TPM - Tires Pressure Monitoring System	√	√	√				
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 620\TRUCK DC 16 EU5 [---08>---13]\Transmission\GMS - Gear management system A4	√	√	√			√	
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 620\TRUCK DC 16 EU5 [---08>---13]\Transmission\GMS - Gear management system OPC	√	√	√	√		√	0005
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 620\TRUCK DC 16 EU5 [---08>---13]\Transmission\GMS - Gear management system Opticruise 5	√	√	√	√		√	0009, 0011, 0018
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 620\TRUCK DC 16 EU5 [---08>---13]\Transmission\GMS - GMS Opticruise 5	√	√	√	√		√	0009, 0011, 0018
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 620\TRUCK DC 16 EU5 [---08>---13]\Transport information system\RTI - Road Transport Informatics	√	√	√				
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 620\TRUCK DC 16 [---06>---13]\ABS\BMS Brake management system-ABS E	√	√	√	√		√	
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 620\TRUCK DC 16 [---06>---13]\Aid for keeping lane\LDW Monitor traffic lane	√	√	√				
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 620\TRUCK DC 16 [---06>---13]\Air conditioner\CCS Climate control system	√	√	√	√		√	
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 620\TRUCK DC 16 [---06>---13]\Airbag\CSS Climate safety system	√	√	√				
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 620\TRUCK DC 16 [---06>---13]\Alarm\LAS Locking and alarm system	√	√	√				
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 620\TRUCK DC 16 [---06>---13]\Auxiliary heating\ATA Auxiliary heating system air-to-air	√	√	√	√			
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 620\TRUCK DC 16 [---06>---13]\Auxiliary heating\WTA Auxiliary heating system water-to-air	√	√	√				
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 620\TRUCK DC 16 [---06>---13]\Chassis equipment and design\BWS Preparation system	√	√	√				
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 620\TRUCK DC 16 [---06>---13]\Comfort system\CTS Clock and Time System	√	√	√				

Scania\Divided By Vehicle\BUS&Coach\K series\Engine 620\TRUCK DC 16 [---06>---13]\Compressed air reserve system\APS Compressed air power supply(Scania protocol)	√	√	√	√			0003
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 620\TRUCK DC 16 [---06>---13]\Compressed air reserve system\APS Compressed air power supply(Wabco protocol)	√	√	√	√			
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 620\TRUCK DC 16 [---06>---13]\Diesel injection\EEC-Exhaust gas treatment	√	√	√	√		√	
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 620\TRUCK DC 16 [---06>---13]\Diesel injection\EMS Engine management system S6-S7	√	√	√	√		√	0002, 0015, 0017
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 620\TRUCK DC 16 [---06>---13]\Diesel injection\EMS Engine management system S8(8 Cylindes)	√	√	√	√		√	0001
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 620\TRUCK DC 16 [---06>---13]\Diesel injection\EMS Engine management system DC13(6 Cylindes)	√	√	√	√		√	
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 620\TRUCK DC 16 [---06>---13]\Distance control\DAS Adaptive Cruise Control	√	√	√				
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 620\TRUCK DC 16 [---06>---13]\Distance control\DIS Adaptive Cruise Control	√	√	√				
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 620\TRUCK DC 16 [---06>---13]\EBS\BMS Brake management system 5.0 (4x2)	√	√	√	√		√	0004
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 620\TRUCK DC 16 [---06>---13]\EBS\BMS Brake management system 5.0 (6x2 - 6x4)	√	√	√	√		√	0004
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 620\TRUCK DC 16 [---06>---13]\EBS\BMS Brake management system 5.0 (8x2)	√	√	√	√		√	0004
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 620\TRUCK DC 16 [---06>---13]\ECU external light\VIS Visibility system	√	√	√	√		√	
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 620\TRUCK DC 16 [---06>---13]\Engine-vehicle adjustment\COO Coordinator module	√	√	√	√		√	
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 620\TRUCK DC 16 [---06>---13]\Engine-vehicle adjustment\COO7 (Coordinator)	√	√	√	√		√	
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 620\TRUCK DC 16 [---06>---13]\Four-wheel drive\AWD ALL-Wheel Drive	√	√	√				
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 620\TRUCK DC 16 [---06>---13]\Instrument pane\NCL Instrument Panel 1	√	√	√	√		√	
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 620\TRUCK DC 16 [---06>---13]\Instrument pane\NCL Instrument Panel 2	√	√	√	√		√	
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 620\TRUCK DC 16 [---06>---13]\Radio\AUS Audio system	√	√	√				
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 620\TRUCK DC 16 [---06>---13]\Retarder\RET Retarder	√	√	√	√		√	
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 620\TRUCK DC 16 [---06>---13]\Suspensions\SMS Supension management system	√	√	√	√			0006, 0007, 0014
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 620\TRUCK DC 16 [---06>---13]\Tachograph\DTCO Tachograph	√	√	√				
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 620\TRUCK DC 16 [---06>---13]\Tachograph\MTCO Tachograph	√	√	√				
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 620\TRUCK DC 16 [---06>---13]\Tire pressure\TPM - Tires Pressure Monitoring System	√	√	√				
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 620\TRUCK DC 16 [---06>---13]\Transmission\GMS - Gear management system A4	√	√	√			√	
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 620\TRUCK DC 16 [---06>---13]\Transmission\GMS - Gear management system OPC	√	√	√	√		√	0005
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 620\TRUCK DC 16 [---06>---13]\Transmission\GMS - Gear management system Opticruise 5	√	√	√	√		√	0009, 0011, 0018
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 620\TRUCK DC 16 [---06>---13]\Transmission\GMS - GMS Opticruise 5	√	√	√	√		√	0009, 0011, 0018
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 620\TRUCK DC 16 [---06>---13]\Transport information system\RTI - Road Transport Informatics	√	√	√				
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 730\TRUCK DC 16 [---10>---13]\ABS\BMS Brake management system-ABS E	√	√	√	√		√	
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 730\TRUCK DC 16 [---10>---13]\Aid for keeping lane\LDW Monitor traffic lane	√	√	√				
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 730\TRUCK DC 16 [---10>---13]\Air conditioner\CCS Climate control system	√	√	√	√		√	
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 730\TRUCK DC 16 [---10>---13]\Airbag\CSS Climate safety system	√	√	√				
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 730\TRUCK DC 16 [---10>---13]\Alarm\LAS Locking and alarm system	√	√	√				
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 730\TRUCK DC 16 [---10>---13]\Auxiliary heating\ATA Auxiliary heating system air-to-air	√	√	√	√			
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 730\TRUCK DC 16 [---10>---13]\Auxiliary heating\WTA Auxiliary heating system water-to-air	√	√	√				

Scania\Divided By Vehicle\BUS&Coach\K series\Engine 730\TRUCK DC 16 [---10>---13]\Chassis equipment and design\BWS Preparation system	√	√	√				
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 730\TRUCK DC 16 [---10>---13]\Comfort system\CTS Clock and Time System	√	√	√				
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 730\TRUCK DC 16 [---10>---13]\Compressed air reserve system\APS Compressed air power supply(Scania protocol)	√	√	√	√			0003
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 730\TRUCK DC 16 [---10>---13]\Compressed air reserve system\APS Compressed air power supply(Wabco protocol)	√	√	√	√			
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 730\TRUCK DC 16 [---10>---13]\Diesel injection\EEC-Exhaust gas treatment	√	√	√	√		√	
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 730\TRUCK DC 16 [---10>---13]\Diesel injection\EMS Engine management system S6-S7	√	√	√	√		√	0002, 0015, 0017
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 730\TRUCK DC 16 [---10>---13]\Diesel injection\EMS Engine management system S8(8 Cylindes)	√	√	√	√		√	0001
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 730\TRUCK DC 16 [---10>---13]\Diesel injection\EMS Engine management system DC13(6 Cylindes)	√	√	√	√		√	
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 730\TRUCK DC 16 [---10>---13]\Distance control\DAS Adaptive Cruise Control	√	√	√				
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 730\TRUCK DC 16 [---10>---13]\Distance control\DIS Adaptive Cruise Control	√	√	√				
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 730\TRUCK DC 16 [---10>---13]\EBS\BMS Brake management system 5.0 (4x2)	√	√	√	√		√	0004
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 730\TRUCK DC 16 [---10>---13]\EBS\BMS Brake management system 5.0 (6x2 - 6x4)	√	√	√	√		√	0004
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 730\TRUCK DC 16 [---10>---13]\EBS\BMS Brake management system 5.0 (8x2)	√	√	√	√		√	0004
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 730\TRUCK DC 16 [---10>---13]\ECU external light\VIS Visibility system	√	√	√	√		√	
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 730\TRUCK DC 16 [---10>---13]\Engine-vehicle adjustment\COO Coordinator module	√	√	√	√		√	
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 730\TRUCK DC 16 [---10>---13]\Engine-vehicle adjustment\COO7 (Coordinator)	√	√	√	√		√	
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 730\TRUCK DC 16 [---10>---13]\Four-wheel drive\AWD ALL-Wheel Drive	√	√	√				
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 730\TRUCK DC 16 [---10>---13]\Instrument pane\NCL Instrument Panel 1	√	√	√	√		√	
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 730\TRUCK DC 16 [---10>---13]\Instrument pane\NCL Instrument Panel 2	√	√	√	√		√	
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 730\TRUCK DC 16 [---10>---13]\Radio\AUS Audio system	√	√	√				
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 730\TRUCK DC 16 [---10>---13]\Retarder\RET Retarder	√	√	√	√		√	
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 730\TRUCK DC 16 [---10>---13]\Suspensions\SMS Supension management system	√	√	√	√			0006, 0007, 0014
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 730\TRUCK DC 16 [---10>---13]\Tachograph\DTCO Tachograph	√	√	√				
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 730\TRUCK DC 16 [---10>---13]\Tachograph\MTCO Tachograph	√	√	√				
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 730\TRUCK DC 16 [---10>---13]\Tire pressure\TPM - Tires Pressure Monitoring System	√	√	√				
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 730\TRUCK DC 16 [---10>---13]\Transmission\GMS - Gear management system A4	√	√	√			√	
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 730\TRUCK DC 16 [---10>---13]\Transmission\GMS - Gear management system OPC	√	√	√	√		√	0005
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 730\TRUCK DC 16 [---10>---13]\Transmission\GMS - Gear management system Opticruise 5	√	√	√	√		√	0009, 0011, 0018
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 730\TRUCK DC 16 [---10>---13]\Transmission\GMS - GMS Opticruise 5	√	√	√	√		√	0009, 0011, 0018
Scania\Divided By Vehicle\BUS&Coach\K series\Engine 730\TRUCK DC 16 [---10>---13]\Transport information system\RTI - Road Transport Informatics	√	√	√				
Scania\Divided By Vehicle\BUS&Coach\S series\Series K\250\Bus DC 9 [-----]\ABS\BMS(Brake management syatem ABS E)	√	√	√	√		√	0004
Scania\Divided By Vehicle\BUS&Coach\S series\Series K\250\Bus DC 9 [-----]\Articulation management\ACS(Articulation control system)	√	√	√				
Scania\Divided By Vehicle\BUS&Coach\S series\Series K\250\Bus DC 9 [-----]\Chassis equipment and design\BWS(Preparation system)	√	√	√				
Scania\Divided By Vehicle\BUS&Coach\S series\Series K\250\Bus DC 9 [-----]\Compressed air reserve system\APS Compressed air power supply(Scania protocol)	√	√	√	√			0003
Scania\Divided By Vehicle\BUS&Coach\S series\Series K\250\Bus DC 9 [-----]\Compressed air reserve system\APS Compressed air power supply(Wabco protocol)	√	√	√	√		√	

Scania\Divided By Vehicle\BUS&Coach\S series\Series K\250\Bus DC 9 [-----]\Diesel injection\EEC-Exhaust gas treatment	√	√	√	√			
Scania\Divided By Vehicle\BUS&Coach\S series\Series K\250\Bus DC 9 [-----]\Diesel injection\EMS S6-S7(Engine Management System)	√	√	√	√		√	0001, 0002, 0008, 0013
Scania\Divided By Vehicle\BUS&Coach\S series\Series K\250\Bus DC 9 [-----]\Diesel injection\EMS S8(Engine Management System)	√	√	√	√			
Scania\Divided By Vehicle\BUS&Coach\S series\Series K\250\Bus DC 9 [-----]\Diesel injection\EMS Engine management system DC13(6 Cylindes)	√	√	√	√		√	
Scania\Divided By Vehicle\BUS&Coach\S series\Series K\250\Bus DC 9 [-----]\Distance control\DAS(Adaptive Cruise Control)	√	√	√				
Scania\Divided By Vehicle\BUS&Coach\S series\Series K\250\Bus DC 9 [-----]\Distance control\DIS(Adaptive Cruise Control)	√	√	√				
Scania\Divided By Vehicle\BUS&Coach\S series\Series K\250\Bus DC 9 [-----]\EBS\BMS(Brake Management System)	√	√	√	√		√	0004
Scania\Divided By Vehicle\BUS&Coach\S series\Series K\250\Bus DC 9 [-----]\Engine-vehicle adjustment\COO(Coordinator module)	√	√	√	√		√	
Scania\Divided By Vehicle\BUS&Coach\S series\Series K\250\Bus DC 9 [-----]\Instrument panel\ICL1(Instrument Cluster)	√	√	√	√		√	
Scania\Divided By Vehicle\BUS&Coach\S series\Series K\250\Bus DC 9 [-----]\Instrument panel\ICL2(Instrument Cluster)	√	√	√	√		√	
Scania\Divided By Vehicle\BUS&Coach\S series\Series K\250\Bus DC 9 [-----]\Network system\BCS(Bus chassis system)	√	√	√	√			
Scania\Divided By Vehicle\BUS&Coach\S series\Series K\250\Bus DC 9 [-----]\Suspensions\SMS(Suspension management system)	√	√	√	√			0019
Scania\Divided By Vehicle\BUS&Coach\S series\Series K\250\Bus DC 9 [-----]\Transmission\Ecomat 2	√	√	√	√		√	
Scania\Divided By Vehicle\BUS&Coach\S series\Series K\250\Bus DC 9 [-----]\Transmission\Ecomat 4	√	√	√	√		√	
Scania\Divided By Vehicle\BUS&Coach\S series\Series K\270\Bus DC 9 [-----]\ABS\BMS(Brake management syatem ABS E)	√	√	√	√		√	0004
Scania\Divided By Vehicle\BUS&Coach\S series\Series K\270\Bus DC 9 [-----]\Articulation management\ACS(Articulation control system)	√	√	√				
Scania\Divided By Vehicle\BUS&Coach\S series\Series K\270\Bus DC 9 [-----]\Chassis equipment and design\BWS(Preparation system)	√	√	√				
Scania\Divided By Vehicle\BUS&Coach\S series\Series K\270\Bus DC 9 [-----]\Compressed air reserve system\APS Compressed air power supply(Scania protocol)	√	√	√	√			0003
Scania\Divided By Vehicle\BUS&Coach\S series\Series K\270\Bus DC 9 [-----]\Compressed air reserve system\APS Compressed air power supply(Wabco protocol)	√	√	√	√			
Scania\Divided By Vehicle\BUS&Coach\S series\Series K\270\Bus DC 9 [-----]\Diesel injection\EEC-Exhaust gas treatment	√	√	√	√			
Scania\Divided By Vehicle\BUS&Coach\S series\Series K\270\Bus DC 9 [-----]\Diesel injection\EMS S6-S7(Engine Management System)	√	√	√	√		√	0001, 0002, 0008, 0013
Scania\Divided By Vehicle\BUS&Coach\S series\Series K\270\Bus DC 9 [-----]\Diesel injection\EMS S8(Engine Management System)	√	√	√	√			
Scania\Divided By Vehicle\BUS&Coach\S series\Series K\270\Bus DC 9 [-----]\Diesel injection\EMS Engine management system DC13(6 Cylindes)	√	√	√	√		√	
Scania\Divided By Vehicle\BUS&Coach\S series\Series K\270\Bus DC 9 [-----]\Distance control\DAS(Adaptive Cruise Control)	√	√	√				
Scania\Divided By Vehicle\BUS&Coach\S series\Series K\270\Bus DC 9 [-----]\Distance control\DIS(Adaptive Cruise Control)	√	√	√				
Scania\Divided By Vehicle\BUS&Coach\S series\Series K\270\Bus DC 9 [-----]\EBS\BMS(Brake Management System)	√	√	√	√		√	0004
Scania\Divided By Vehicle\BUS&Coach\S series\Series K\270\Bus DC 9 [-----]\Engine-vehicle adjustment\COO(Coordinator module)	√	√	√	√		√	
Scania\Divided By Vehicle\BUS&Coach\S series\Series K\270\Bus DC 9 [-----]\Instrument panel\ICL1(Instrument Cluster)	√	√	√	√		√	
Scania\Divided By Vehicle\BUS&Coach\S series\Series K\270\Bus DC 9 [-----]\Instrument panel\ICL2(Instrument Cluster)	√	√	√	√		√	
Scania\Divided By Vehicle\BUS&Coach\S series\Series K\270\Bus DC 9 [-----]\Network system\BCS(Bus chassis system)	√	√	√	√			
Scania\Divided By Vehicle\BUS&Coach\S series\Series K\270\Bus DC 9 [-----]\Suspensions\SMS(Suspension management system)	√	√	√	√			0019
Scania\Divided By Vehicle\BUS&Coach\S series\Series K\270\Bus DC 9 [-----]\Transmission\Ecomat 2	√	√	√	√		√	
Scania\Divided By Vehicle\BUS&Coach\S series\Series K\270\Bus DC 9 [-----]\Transmission\Ecomat 4	√	√	√	√		√	
Scania\Divided By Vehicle\BUS&Coach\S series\Series K\310\Bus DC 9 [-----]\ABS\BMS(Brake management syatem ABS E)	√	√	√	√		√	0004
Scania\Divided By Vehicle\BUS&Coach\S series\Series K\310\Bus DC 9 [-----]\Articulation management\ACS(Articulation control system)	√	√	√				

Scania\Divided By Vehicle\BUS&Coach\S series\Series K\310\Bus DC 9 [-----]\Chassis equipment and design\BWS(Preparation system)	√	√	√				
Scania\Divided By Vehicle\BUS&Coach\S series\Series K\310\Bus DC 9 [-----]\Compressed air reserve system\APS Compressed air power supply(Scania protocol)	√	√	√	√			0003
Scania\Divided By Vehicle\BUS&Coach\S series\Series K\310\Bus DC 9 [-----]\Compressed air reserve system\APS Compressed air power supply(Wabco protocol)	√	√	√	√			
Scania\Divided By Vehicle\BUS&Coach\S series\Series K\310\Bus DC 9 [-----]\Diesel injection\EEC-Exhaust gas treatment	√	√	√	√			
Scania\Divided By Vehicle\BUS&Coach\S series\Series K\310\Bus DC 9 [-----]\Diesel injection\EMS S6-S7(Engine Management System)	√	√	√	√		√	0001, 0002, 0008, 0013
Scania\Divided By Vehicle\BUS&Coach\S series\Series K\310\Bus DC 9 [-----]\Diesel injection\EMS S8(Engine Management System)	√	√	√	√			
Scania\Divided By Vehicle\BUS&Coach\S series\Series K\310\Bus DC 9 [-----]\Diesel injection\EMS Engine management system DC13(6 Cylindes)	√	√	√	√		√	
Scania\Divided By Vehicle\BUS&Coach\S series\Series K\310\Bus DC 9 [-----]\Distance control\DAS(Adaptive Cruise Control)	√	√	√				
Scania\Divided By Vehicle\BUS&Coach\S series\Series K\310\Bus DC 9 [-----]\Distance control\DIS(Adaptive Cruise Control)	√	√	√				
Scania\Divided By Vehicle\BUS&Coach\S series\Series K\310\Bus DC 9 [-----]\EBS\BMS(Brake Management System)	√	√	√	√		√	0004
Scania\Divided By Vehicle\BUS&Coach\S series\Series K\310\Bus DC 9 [-----]\Engine-vehicle adjustment\COO(Coordinator module)	√	√	√	√		√	
Scania\Divided By Vehicle\BUS&Coach\S series\Series K\310\Bus DC 9 [-----]\Instrument panel\NCL1(Instrument Cluster)	√	√	√	√		√	
Scania\Divided By Vehicle\BUS&Coach\S series\Series K\310\Bus DC 9 [-----]\Instrument panel\NCL2(Instrument Cluster)	√	√	√	√		√	
Scania\Divided By Vehicle\BUS&Coach\S series\Series K\310\Bus DC 9 [-----]\Network system\BCS(Bus chassis system)	√	√	√	√			
Scania\Divided By Vehicle\BUS&Coach\S series\Series K\310\Bus DC 9 [-----]\Suspensions\SMS(Suspension management system)	√	√	√	√			0019
Scania\Divided By Vehicle\BUS&Coach\S series\Series K\310\Bus DC 9 [-----]\Transmission\Ecomat 2	√	√	√	√		√	
Scania\Divided By Vehicle\BUS&Coach\S series\Series K\310\Bus DC 9 [-----]\Transmission\Ecomat 4	√	√	√	√		√	
Scania\Divided By Vehicle\BUS&Coach\S series\Series K\360\Bus DC 9 [-----]\ABS\BMS(Brake management syatem ABS E)	√	√	√	√		√	0004
Scania\Divided By Vehicle\BUS&Coach\S series\Series K\360\Bus DC 9 [-----]\Articulation management\ACS(Articulation control system)	√	√	√				
Scania\Divided By Vehicle\BUS&Coach\S series\Series K\360\Bus DC 9 [-----]\Chassis equipment and design\BWS(Preparation system)	√	√	√				
Scania\Divided By Vehicle\BUS&Coach\S series\Series K\360\Bus DC 9 [-----]\Compressed air reserve system\APS Compressed air power supply(Scania protocol)	√	√	√	√			0003
Scania\Divided By Vehicle\BUS&Coach\S series\Series K\360\Bus DC 9 [-----]\Compressed air reserve system\APS Compressed air power supply(Wabco protocol)	√	√	√	√			
Scania\Divided By Vehicle\BUS&Coach\S series\Series K\360\Bus DC 9 [-----]\Diesel injection\EEC-Exhaust gas treatment	√	√	√	√			
Scania\Divided By Vehicle\BUS&Coach\S series\Series K\360\Bus DC 9 [-----]\Diesel injection\EMS S6-S7(Engine Management System)	√	√	√	√		√	0001, 0002, 0008, 0013
Scania\Divided By Vehicle\BUS&Coach\S series\Series K\360\Bus DC 9 [-----]\Diesel injection\EMS S8(Engine Management System)	√	√	√	√			
Scania\Divided By Vehicle\BUS&Coach\S series\Series K\360\Bus DC 9 [-----]\Diesel injection\EMS Engine management system DC13(6 Cylindes)	√	√	√	√		√	
Scania\Divided By Vehicle\BUS&Coach\S series\Series K\360\Bus DC 9 [-----]\Distance control\DAS(Adaptive Cruise Control)	√	√	√				
Scania\Divided By Vehicle\BUS&Coach\S series\Series K\360\Bus DC 9 [-----]\Distance control\DIS(Adaptive Cruise Control)	√	√	√				
Scania\Divided By Vehicle\BUS&Coach\S series\Series K\360\Bus DC 9 [-----]\EBS\BMS(Brake Management System)	√	√	√	√		√	0004
Scania\Divided By Vehicle\BUS&Coach\S series\Series K\360\Bus DC 9 [-----]\Engine-vehicle adjustment\COO(Coordinator module)	√	√	√	√		√	
Scania\Divided By Vehicle\BUS&Coach\S series\Series K\360\Bus DC 9 [-----]\Instrument panel\NCL1(Instrument Cluster)	√	√	√	√		√	
Scania\Divided By Vehicle\BUS&Coach\S series\Series K\360\Bus DC 9 [-----]\Instrument panel\NCL2(Instrument Cluster)	√	√	√	√		√	
Scania\Divided By Vehicle\BUS&Coach\S series\Series K\360\Bus DC 9 [-----]\Network system\BCS(Bus chassis system)	√	√	√	√			
Scania\Divided By Vehicle\BUS&Coach\S series\Series K\360\Bus DC 9 [-----]\Suspensions\SMS(Suspension management system)	√	√	√	√			0019
Scania\Divided By Vehicle\BUS&Coach\S series\Series K\360\Bus DC 9 [-----]\Transmission\Ecomat 2	√	√	√	√		√	

Scania\Divided By Vehicle\BUS&Coach\S series\Series K\360\Bus DC 9 [-----]\Transmission\Ecomat 4	√	√	√	√		√	
Scania\Divided By Vehicle\BUS&Coach\S series\Series K\400\Bus DC 9 [-----]\ABS\BMS(Brake management syatem ABS E)	√	√	√	√		√	0004
Scania\Divided By Vehicle\BUS&Coach\S series\Series K\400\Bus DC 9 [-----]\Articulation management\ACS(Articulation control system)	√	√	√				
Scania\Divided By Vehicle\BUS&Coach\S series\Series K\400\Bus DC 9 [-----]\Chassis equipment and design\BWS(Preparation system)	√	√	√				
Scania\Divided By Vehicle\BUS&Coach\S series\Series K\400\Bus DC 9 [-----]\Compressed air reserve system\APS Compressed air power supply(Scania protocol)	√	√	√	√			0003
Scania\Divided By Vehicle\BUS&Coach\S series\Series K\400\Bus DC 9 [-----]\Compressed air reserve system\APS Compressed air power supply(Wabco protocol)	√	√	√	√			
Scania\Divided By Vehicle\BUS&Coach\S series\Series K\400\Bus DC 9 [-----]\Diesel injection\EEC-Exhaust gas treatment	√	√	√	√			
Scania\Divided By Vehicle\BUS&Coach\S series\Series K\400\Bus DC 9 [-----]\Diesel injection\EMS S6-S7(Engine Management System)	√	√	√	√		√	0001, 0002, 0008, 0013
Scania\Divided By Vehicle\BUS&Coach\S series\Series K\400\Bus DC 9 [-----]\Diesel injection\EMS S8(Engine Management System)	√	√	√	√			
Scania\Divided By Vehicle\BUS&Coach\S series\Series K\400\Bus DC 9 [-----]\Diesel injection\EMS Engine management system DC13(6 Cylindes)	√	√	√	√		√	
Scania\Divided By Vehicle\BUS&Coach\S series\Series K\400\Bus DC 9 [-----]\Distance control\DAS(Adaptive Cruise Control)	√	√	√				
Scania\Divided By Vehicle\BUS&Coach\S series\Series K\400\Bus DC 9 [-----]\Distance control\DIS(Adaptive Cruise Control)	√	√	√				
Scania\Divided By Vehicle\BUS&Coach\S series\Series K\400\Bus DC 9 [-----]\EBS\BMS(Brake Management System)	√	√	√	√		√	0004
Scania\Divided By Vehicle\BUS&Coach\S series\Series K\400\Bus DC 9 [-----]\Engine-vehicle adjustment\COO(Coordinator module)	√	√	√	√		√	
Scania\Divided By Vehicle\BUS&Coach\S series\Series K\400\Bus DC 9 [-----]\Instrument panel\NCL1(Instrument Cluster)	√	√	√	√		√	
Scania\Divided By Vehicle\BUS&Coach\S series\Series K\400\Bus DC 9 [-----]\Instrument panel\NCL2(Instrument Cluster)	√	√	√	√		√	
Scania\Divided By Vehicle\BUS&Coach\S series\Series K\400\Bus DC 9 [-----]\Network system\BCS(Bus chassis system)	√	√	√	√			
Scania\Divided By Vehicle\BUS&Coach\S series\Series K\400\Bus DC 9 [-----]\Suspensions\SMS(Suspension management system)	√	√	√	√			0019
Scania\Divided By Vehicle\BUS&Coach\S series\Series K\400\Bus DC 9 [-----]\Transmission\Ecomat 2	√	√	√	√		√	
Scania\Divided By Vehicle\BUS&Coach\S series\Series K\400\Bus DC 9 [-----]\Transmission\Ecomat 4	√	√	√	√		√	
Scania\Divided By Vehicle\BUS&Coach\S series\Series K\440\Bus DC 9 [-----]\ABS\BMS(Brake management syatem ABS E)	√	√	√	√		√	0004
Scania\Divided By Vehicle\BUS&Coach\S series\Series K\440\Bus DC 9 [-----]\Articulation management\ACS(Articulation control system)	√	√	√				
Scania\Divided By Vehicle\BUS&Coach\S series\Series K\440\Bus DC 9 [-----]\Chassis equipment and design\BWS(Preparation system)	√	√	√				
Scania\Divided By Vehicle\BUS&Coach\S series\Series K\440\Bus DC 9 [-----]\Compressed air reserve system\APS Compressed air power supply(Scania protocol)	√	√	√	√			0003
Scania\Divided By Vehicle\BUS&Coach\S series\Series K\440\Bus DC 9 [-----]\Compressed air reserve system\APS Compressed air power supply(Wabco protocol)	√	√	√	√			
Scania\Divided By Vehicle\BUS&Coach\S series\Series K\440\Bus DC 9 [-----]\Diesel injection\EEC-Exhaust gas treatment	√	√	√	√			
Scania\Divided By Vehicle\BUS&Coach\S series\Series K\440\Bus DC 9 [-----]\Diesel injection\EMS S6-S7(Engine Management System)	√	√	√	√		√	0001, 0002, 0008, 0013
Scania\Divided By Vehicle\BUS&Coach\S series\Series K\440\Bus DC 9 [-----]\Diesel injection\EMS S8(Engine Management System)	√	√	√	√			
Scania\Divided By Vehicle\BUS&Coach\S series\Series K\440\Bus DC 9 [-----]\Diesel injection\EMS Engine management system DC13(6 Cylindes)	√	√	√	√		√	
Scania\Divided By Vehicle\BUS&Coach\S series\Series K\440\Bus DC 9 [-----]\Distance control\DAS(Adaptive Cruise Control)	√	√	√				
Scania\Divided By Vehicle\BUS&Coach\S series\Series K\440\Bus DC 9 [-----]\Distance control\DIS(Adaptive Cruise Control)	√	√	√				
Scania\Divided By Vehicle\BUS&Coach\S series\Series K\440\Bus DC 9 [-----]\EBS\BMS(Brake Management System)	√	√	√	√		√	0004
Scania\Divided By Vehicle\BUS&Coach\S series\Series K\440\Bus DC 9 [-----]\Engine-vehicle adjustment\COO(Coordinator module)	√	√	√	√		√	
Scania\Divided By Vehicle\BUS&Coach\S series\Series K\440\Bus DC 9 [-----]\Instrument panel\NCL1(Instrument Cluster)	√	√	√	√		√	
Scania\Divided By Vehicle\BUS&Coach\S series\Series K\440\Bus DC 9 [-----]\Instrument panel\NCL2(Instrument Cluster)	√	√	√	√		√	

Scania\Divided By Vehicle\BUS&Coach\S series\Series K\440\Bus DC 9 [-----]\Network system\BCS(Bus chassis system)	√	√	√	√			
Scania\Divided By Vehicle\BUS&Coach\S series\Series K\440\Bus DC 9 [-----]\Suspensions\SMS(Suspension management system)	√	√	√	√			0019
Scania\Divided By Vehicle\BUS&Coach\S series\Series K\440\Bus DC 9 [-----]\Transmission\Ecomat 2	√	√	√	√		√	
Scania\Divided By Vehicle\BUS&Coach\S series\Series K\440\Bus DC 9 [-----]\Transmission\Ecomat 4	√	√	√	√		√	
Scania\Divided By Vehicle\BUS&Coach\S series\Series F\Engine 250\Bus DC 9 [-----]\ABS\BMS Brake management system-ABS E	√	√	√	√		√	0004
Scania\Divided By Vehicle\BUS&Coach\S series\Series F\Engine 250\Bus DC 9 [-----]\Articulation management\Articulation control system(ACS)	√	√	√				
Scania\Divided By Vehicle\BUS&Coach\S series\Series F\Engine 250\Bus DC 9 [-----]\Chassis equipment and design\BWS Preparation system	√	√	√				
Scania\Divided By Vehicle\BUS&Coach\S series\Series F\Engine 250\Bus DC 9 [-----]\Compressed air reserve system\APS Compressed air power supply(Scania protocol)	√	√	√	√			0003
Scania\Divided By Vehicle\BUS&Coach\S series\Series F\Engine 250\Bus DC 9 [-----]\Compressed air reserve system\APS Compressed air power supply(Wabco protocol)	√	√	√	√			
Scania\Divided By Vehicle\BUS&Coach\S series\Series F\Engine 250\Bus DC 9 [-----]\Diesel injection\EEC-Exhaust gas treatment	√	√	√	√			
Scania\Divided By Vehicle\BUS&Coach\S series\Series F\Engine 250\Bus DC 9 [-----]\Diesel injection\EMS Engine management system S6-S7	√	√	√	√		√	0001, 0002, 0008, 0013
Scania\Divided By Vehicle\BUS&Coach\S series\Series F\Engine 250\Bus DC 9 [-----]\Diesel injection\EMS Engine management system S8(8 Cylindes)	√	√	√	√			
Scania\Divided By Vehicle\BUS&Coach\S series\Series F\Engine 250\Bus DC 9 [-----]\Diesel injection\EMS Engine management system DC13(6 Cylindes)	√	√	√	√		√	
Scania\Divided By Vehicle\BUS&Coach\S series\Series F\Engine 250\Bus DC 9 [-----]\Distance control\DAS Adaptive Cruise Control	√	√	√				
Scania\Divided By Vehicle\BUS&Coach\S series\Series F\Engine 250\Bus DC 9 [-----]\Distance control\DIS Adaptive Cruise Control	√	√	√				
Scania\Divided By Vehicle\BUS&Coach\S series\Series F\Engine 250\Bus DC 9 [-----]\EBS\BMS Brake management system 5.0	√	√	√	√		√	0004
Scania\Divided By Vehicle\BUS&Coach\S series\Series F\Engine 250\Bus DC 9 [-----]\Engine-vehicle adjustment\COO Coordinator module	√	√	√	√		√	
Scania\Divided By Vehicle\BUS&Coach\S series\Series F\Engine 250\Bus DC 9 [-----]\Instrument panel\NCL Instrument Panel 1	√	√	√	√		√	
Scania\Divided By Vehicle\BUS&Coach\S series\Series F\Engine 250\Bus DC 9 [-----]\Instrument panel\NCL Instrument Panel 2	√	√	√	√		√	
Scania\Divided By Vehicle\BUS&Coach\S series\Series F\Engine 250\Bus DC 9 [-----]\Network system\BCS Bus chassis system	√	√	√	√			
Scania\Divided By Vehicle\BUS&Coach\S series\Series F\Engine 250\Bus DC 9 [-----]\Suspensions\SMS Suspension management system	√	√	√	√			0019
Scania\Divided By Vehicle\BUS&Coach\S series\Series F\Engine 250\Bus DC 9 [-----]\Transmission\Ecomat 2	√	√	√	√		√	
Scania\Divided By Vehicle\BUS&Coach\S series\Series F\Engine 250\Bus DC 9 [-----]\Transmission\Ecomat 4	√	√	√	√		√	
Scania\Divided By Vehicle\BUS&Coach\S series\Series F\Engine 310\Bus DC 9 [-----]\ABS\BMS Brake management system-ABS E	√	√	√	√		√	0004
Scania\Divided By Vehicle\BUS&Coach\S series\Series F\Engine 310\Bus DC 9 [-----]\Articulation management\Articulation control system(ACS)	√	√	√				
Scania\Divided By Vehicle\BUS&Coach\S series\Series F\Engine 310\Bus DC 9 [-----]\Chassis equipment and design\BWS Preparation system	√	√	√				
Scania\Divided By Vehicle\BUS&Coach\S series\Series F\Engine 310\Bus DC 9 [-----]\Compressed air reserve system\APS Compressed air power supply(Scania protocol)	√	√	√	√			0003
Scania\Divided By Vehicle\BUS&Coach\S series\Series F\Engine 310\Bus DC 9 [-----]\Compressed air reserve system\APS Compressed air power supply(Wabco protocol)	√	√	√	√			
Scania\Divided By Vehicle\BUS&Coach\S series\Series F\Engine 310\Bus DC 9 [-----]\Diesel injection\EEC-Exhaust gas treatment	√	√	√	√			
Scania\Divided By Vehicle\BUS&Coach\S series\Series F\Engine 310\Bus DC 9 [-----]\Diesel injection\EMS Engine management system S6-S7	√	√	√	√		√	0001, 0002, 0008, 0013
Scania\Divided By Vehicle\BUS&Coach\S series\Series F\Engine 310\Bus DC 9 [-----]\Diesel injection\EMS Engine management system S8(8 Cylindes)	√	√	√	√			
Scania\Divided By Vehicle\BUS&Coach\S series\Series F\Engine 310\Bus DC 9 [-----]\Diesel injection\EMS Engine management system DC13(6 Cylindes)	√	√	√	√		√	
Scania\Divided By Vehicle\BUS&Coach\S series\Series F\Engine 310\Bus DC 9 [-----]\Distance control\DAS Adaptive Cruise Control	√	√	√				
Scania\Divided By Vehicle\BUS&Coach\S series\Series F\Engine 310\Bus DC 9 [-----]\Distance control\DIS Adaptive Cruise Control	√	√	√				
Scania\Divided By Vehicle\BUS&Coach\S series\Series F\Engine 310\Bus DC 9 [-----]\EBS\BMS Brake management system 5.0	√	√	√	√		√	0004

Scania\Divided By Vehicle\BUS&Coach\S series\Series F\Engine 310\Bus DC 9 [-----]\Engine-vehicle adjustment\COO Coordinator module	√	√	√	√		√	
Scania\Divided By Vehicle\BUS&Coach\S series\Series F\Engine 310\Bus DC 9 [-----]\Instrument panel\NCL Instrument Panel 1	√	√	√	√		√	
Scania\Divided By Vehicle\BUS&Coach\S series\Series F\Engine 310\Bus DC 9 [-----]\Instrument panel\NCL Instrument Panel 2	√	√	√	√		√	
Scania\Divided By Vehicle\BUS&Coach\S series\Series F\Engine 310\Bus DC 9 [-----]\Network system\BCS Bus chassis system	√	√	√	√			
Scania\Divided By Vehicle\BUS&Coach\S series\Series F\Engine 310\Bus DC 9 [-----]\Suspensions\SMS Suspension management system	√	√	√	√			0019
Scania\Divided By Vehicle\BUS&Coach\S series\Series F\Engine 310\Bus DC 9 [-----]\Transmission\Ecomat 2	√	√	√	√		√	
Scania\Divided By Vehicle\BUS&Coach\S series\Series F\Engine 310\Bus DC 9 [-----]\Transmission\Ecomat 4	√	√	√	√		√	
Scania\Divided By Vehicle\BUS&Coach\T Series\Touring Euro 4-Euro 5-EEV\Bus DCS 9 [----->]\ABS\BMS(Brake management syatem ABS E)	√	√	√	√		√	0004
Scania\Divided By Vehicle\BUS&Coach\T Series\Touring Euro 4-Euro 5-EEV\Bus DCS 9 [----->]\Articulation management\ACS(Articulation control system)	√	√	√				
Scania\Divided By Vehicle\BUS&Coach\T Series\Touring Euro 4-Euro 5-EEV\Bus DCS 9 [----->]\Chassis equipment and design\BWS(Preparation system)	√	√	√				
Scania\Divided By Vehicle\BUS&Coach\T Series\Touring Euro 4-Euro 5-EEV\Bus DCS 9 [----->]\Compressed air reserve system\APS Compressed air power supply(Scania protocol)	√	√	√	√			0003
Scania\Divided By Vehicle\BUS&Coach\T Series\Touring Euro 4-Euro 5-EEV\Bus DCS 9 [----->]\Compressed air reserve system\APS Compressed air power supply(Wabco protocol)\EEC-Exhaust gas treatment	√	√	√	√			
Scania\Divided By Vehicle\BUS&Coach\T Series\Touring Euro 4-Euro 5-EEV\Bus DCS 9 [----->]\Diesel injection\EMS S6-S7(Engine Management System)	√	√	√	√		√	0001, 0002, 0008, 0013
Scania\Divided By Vehicle\BUS&Coach\T Series\Touring Euro 4-Euro 5-EEV\Bus DCS 9 [----->]\Diesel injection\EMS S8(Engine Management System)	√	√	√	√			
Scania\Divided By Vehicle\BUS&Coach\T Series\Touring Euro 4-Euro 5-EEV\Bus DCS 9 [----->]\Diesel injection\EMS Engine management system DC13(6 Cylindes)	√	√	√	√		√	
Scania\Divided By Vehicle\BUS&Coach\T Series\Touring Euro 4-Euro 5-EEV\Bus DCS 9 [----->]\Distance control\DAS(Adaptive Cruise Control)	√	√	√				
Scania\Divided By Vehicle\BUS&Coach\T Series\Touring Euro 4-Euro 5-EEV\Bus DCS 9 [----->]\Distance control\DIS(Adaptive Cruise Control)	√	√	√				
Scania\Divided By Vehicle\BUS&Coach\T Series\Touring Euro 4-Euro 5-EEV\Bus DCS 9 [----->]\EBS\BMS(Brake Management System)	√	√	√	√		√	0004
Scania\Divided By Vehicle\BUS&Coach\T Series\Touring Euro 4-Euro 5-EEV\Bus DCS 9 [----->]\ECU external light\VIS Visbility system	√	√	√	√		√	
Scania\Divided By Vehicle\BUS&Coach\T Series\Touring Euro 4-Euro 5-EEV\Bus DCS 9 [----->]\Engine-vehicle adjustment\COO(Coordinator module)	√	√	√	√		√	
Scania\Divided By Vehicle\BUS&Coach\T Series\Touring Euro 4-Euro 5-EEV\Bus DCS 9 [----->]\Instrument panel\NCL1(Instrument Cluster)	√	√	√	√		√	
Scania\Divided By Vehicle\BUS&Coach\T Series\Touring Euro 4-Euro 5-EEV\Bus DCS 9 [----->]\Instrument panel\NCL2(Instrument Cluster)	√	√	√	√		√	
Scania\Divided By Vehicle\BUS&Coach\T Series\Touring Euro 4-Euro 5-EEV\Bus DCS 9 [----->]\Network system\BCS(Bus chassis system)	√	√	√	√			
Scania\Divided By Vehicle\BUS&Coach\T Series\Touring Euro 4-Euro 5-EEV\Bus DCS 9 [----->]\Suspensions\SMS(Suspension management system)	√	√	√	√			0019
Scania\Divided By Vehicle\BUS&Coach\T Series\Touring Euro 4-Euro 5-EEV\Bus DCS 9 [----->]\Transmission\Ecomat 2	√	√	√	√		√	
Scania\Divided By Vehicle\BUS&Coach\O Series\Omnicity Euro 3\Bus DCS 9 [----->]\Transmission\Ecomat 2	√	√	√	√		√	
Scania\Divided By Vehicle\BUS&Coach\O Series\Omnicity Euro 4-Euro 5-EEV\Bus --- [----->]\ABS\BMS(Brake management syatem ABS E)	√	√	√	√		√	0004
Scania\Divided By Vehicle\BUS&Coach\O Series\Omnicity Euro 4-Euro 5-EEV\Bus --- [----->]\Articulation management\ACS(Articulation control system)	√	√	√				
Scania\Divided By Vehicle\BUS&Coach\O Series\Omnicity Euro 4-Euro 5-EEV\Bus --- [----->]\Chassis equipment and design\BWS(Preparation system)	√	√	√				
Scania\Divided By Vehicle\BUS&Coach\O Series\Omnicity Euro 4-Euro 5-EEV\Bus --- [----->]\Compressed air reserve system\APS Compressed air power supply(Scania protocol)	√	√	√	√			0003
Scania\Divided By Vehicle\BUS&Coach\O Series\Omnicity Euro 4-Euro 5-EEV\Bus --- [----->]\Compressed air reserve system\APS Compressed air power supply(Wabco protocol)\EEC-Exhaust gas treatment	√	√	√	√			
Scania\Divided By Vehicle\BUS&Coach\O Series\Omnicity Euro 4-Euro 5-EEV\Bus --- [----->]\Diesel injection\EMS S6-S7(Engine Management System)	√	√	√	√		√	0001, 0002, 0008, 0013
Scania\Divided By Vehicle\BUS&Coach\O Series\Omnicity Euro 4-Euro 5-EEV\Bus --- [----->]\Diesel injection\EMS S8(Engine Management System)	√	√	√	√			
Scania\Divided By Vehicle\BUS&Coach\O Series\Omnicity Euro 4-Euro 5-EEV\Bus --- [----->]\Diesel injection\EMS Engine management system DC13(6 Cylindes)	√	√	√	√		√	
Scania\Divided By Vehicle\BUS&Coach\O Series\Omnicity Euro 4-Euro 5-EEV\Bus --- [----->]\Distance control\DAS(Adaptive Cruise Control)	√	√	√				

Scania\Divided By Vehicle\BUS&Coach\O Series\Omnicity Euro 4-Euro 5-EEV\Bus --- [----->]\Distance control\DIS(Adaptive Cruise Control)	√	√	√				
Scania\Divided By Vehicle\BUS&Coach\O Series\Omnicity Euro 4-Euro 5-EEV\Bus --- [----->]\EBS\BMS(Brake Management System)	√	√	√	√		√	0004
Scania\Divided By Vehicle\BUS&Coach\O Series\Omnicity Euro 4-Euro 5-EEV\Bus --- [----->]\ECU external light\VIS Visibility system	√	√	√	√		√	
Scania\Divided By Vehicle\BUS&Coach\O Series\Omnicity Euro 4-Euro 5-EEV\Bus --- [----->]\Engine-vehicle adjustment\COO(Coordinator module)	√	√	√	√		√	
Scania\Divided By Vehicle\BUS&Coach\O Series\Omnicity Euro 4-Euro 5-EEV\Bus --- [----->]\Instrument panel\NCL1(Instrument Cluster)	√	√	√	√		√	
Scania\Divided By Vehicle\BUS&Coach\O Series\Omnicity Euro 4-Euro 5-EEV\Bus --- [----->]\Instrument panel\NCL2(Instrument Cluster)	√	√	√	√		√	
Scania\Divided By Vehicle\BUS&Coach\O Series\Omnicity Euro 4-Euro 5-EEV\Bus --- [----->]\Network system\BCS(Bus chassis system)	√	√	√	√			
Scania\Divided By Vehicle\BUS&Coach\O Series\Omnicity Euro 4-Euro 5-EEV\Bus --- [----->]\Suspensions\SMS(Suspension management system)	√	√	√	√			0019
Scania\Divided By Vehicle\BUS&Coach\O Series\Omnicity Euro 4-Euro 5-EEV\Bus --- [----->]\Transmission\Ecomat 2	√	√	√	√		√	
Scania\Divided By Vehicle\BUS&Coach\O Series\OmniExpress Euro 4-Euro 5-EEV\Bus DC 13 [----->]\ABS\BMS(Brake management syatem ABS E)	√	√	√	√		√	0004
Scania\Divided By Vehicle\BUS&Coach\O Series\OmniExpress Euro 4-Euro 5-EEV\Bus DC 13 [----->]\Articulation management\ACS(Articulation control system)	√	√	√				
Scania\Divided By Vehicle\BUS&Coach\O Series\OmniExpress Euro 4-Euro 5-EEV\Bus DC 13 [----->]\Chassis equipment and design\BWS(Preparation system)	√	√	√				
Scania\Divided By Vehicle\BUS&Coach\O Series\OmniExpress Euro 4-Euro 5-EEV\Bus DC 13 [----->]\Compressed air reserve system\APS Compressed air power supply(Scania protocol)	√	√	√	√			0003
Scania\Divided By Vehicle\BUS&Coach\O Series\OmniExpress Euro 4-Euro 5-EEV\Bus DC 13 [----->]\Compressed air reserve system\APS Compressed air power supply(Wabco protocol)\EEC-Exhaust gas treatment	√	√	√	√			
Scania\Divided By Vehicle\BUS&Coach\O Series\OmniExpress Euro 4-Euro 5-EEV\Bus DC 13 [----->]\Diesel injection\EMS S6-S7(Engine Management System)	√	√	√	√		√	0001, 0002, 0008, 0013
Scania\Divided By Vehicle\BUS&Coach\O Series\OmniExpress Euro 4-Euro 5-EEV\Bus DC 13 [----->]\Diesel injection\EMS S8(Engine Management System)	√	√	√	√			
Scania\Divided By Vehicle\BUS&Coach\O Series\OmniExpress Euro 4-Euro 5-EEV\Bus DC 13 [----->]\Diesel injection\EMS Engine management system DC13(6 Cylindes)	√	√	√	√		√	
Scania\Divided By Vehicle\BUS&Coach\O Series\OmniExpress Euro 4-Euro 5-EEV\Bus DC 13 [----->]\Distance control\DAS(Adaptive Cruise Control)	√	√	√				
Scania\Divided By Vehicle\BUS&Coach\O Series\OmniExpress Euro 4-Euro 5-EEV\Bus DC 13 [----->]\Distance control\DIS(Adaptive Cruise Control)	√	√	√				
Scania\Divided By Vehicle\BUS&Coach\O Series\OmniExpress Euro 4-Euro 5-EEV\Bus DC 13 [----->]\EBS\BMS(Brake Management System)	√	√	√	√		√	0004
Scania\Divided By Vehicle\BUS&Coach\O Series\OmniExpress Euro 4-Euro 5-EEV\Bus DC 13 [----->]\ECU external light\VIS Visibility system	√	√	√	√		√	
Scania\Divided By Vehicle\BUS&Coach\O Series\OmniExpress Euro 4-Euro 5-EEV\Bus DC 13 [----->]\Engine-vehicle adjustment\COO(Coordinator module)	√	√	√	√		√	
Scania\Divided By Vehicle\BUS&Coach\O Series\OmniExpress Euro 4-Euro 5-EEV\Bus DC 13 [----->]\Instrument panel\NCL1(Instrument Cluster)	√	√	√	√		√	
Scania\Divided By Vehicle\BUS&Coach\O Series\OmniExpress Euro 4-Euro 5-EEV\Bus DC 13 [----->]\Instrument panel\NCL2(Instrument Cluster)	√	√	√	√		√	
Scania\Divided By Vehicle\BUS&Coach\O Series\OmniExpress Euro 4-Euro 5-EEV\Bus DC 13 [----->]\Network system\BCS(Bus chassis system)	√	√	√	√			
Scania\Divided By Vehicle\BUS&Coach\O Series\OmniExpress Euro 4-Euro 5-EEV\Bus DC 13 [----->]\Suspensions\SMS(Suspension management system)	√	√	√	√			0019
Scania\Divided By Vehicle\BUS&Coach\O Series\OmniExpress Euro 4-Euro 5-EEV\Bus DC 13 [----->]\Transmission\Ecomat 2	√	√	√	√		√	
Scania\Divided By Vehicle\BUS&Coach\O Series\OmniExpress Euro 4-Euro 5-EEV\Bus DC 9 [----->]\ABS\BMS(Brake management syatem ABS E)	√	√	√	√		√	0004
Scania\Divided By Vehicle\BUS&Coach\O Series\OmniExpress Euro 4-Euro 5-EEV\Bus DC 9 [----->]\Articulation management\ACS(Articulation control system)	√	√	√				
Scania\Divided By Vehicle\BUS&Coach\O Series\OmniExpress Euro 4-Euro 5-EEV\Bus DC 9 [----->]\Chassis equipment and design\BWS(Preparation system)	√	√	√				
Scania\Divided By Vehicle\BUS&Coach\O Series\OmniExpress Euro 4-Euro 5-EEV\Bus DC 9 [----->]\Compressed air reserve system\APS Compressed air power supply(Scania protocol)	√	√	√	√			0003
Scania\Divided By Vehicle\BUS&Coach\O Series\OmniExpress Euro 4-Euro 5-EEV\Bus DC 9 [----->]\Compressed air reserve system\APS Compressed air power supply(Wabco protocol)\EEC-Exhaust gas treatment	√	√	√	√			
Scania\Divided By Vehicle\BUS&Coach\O Series\OmniExpress Euro 4-Euro 5-EEV\Bus DC 9 [----->]\Diesel injection\EMS S6-S7(Engine Management System)	√	√	√	√		√	0001, 0002, 0008, 0013
Scania\Divided By Vehicle\BUS&Coach\O Series\OmniExpress Euro 4-Euro 5-EEV\Bus DC 9 [----->]\Diesel injection\EMS S8(Engine Management System)	√	√	√	√			
Scania\Divided By Vehicle\BUS&Coach\O Series\OmniExpress Euro 4-Euro 5-EEV\Bus DC 9 [----->]\Diesel injection\EMS Engine management system DC13(6 Cylindes)	√	√	√	√		√	

Scania\Divided By Vehicle\BUS&Coach\O Series\OmniExpress Euro 4-Euro 5-EEV\Bus DC 9 [----->]\Distance control\DAS(Adaptive Cruise Control)	√	√	√				
Scania\Divided By Vehicle\BUS&Coach\O Series\OmniExpress Euro 4-Euro 5-EEV\Bus DC 9 [----->]\Distance control\DIS(Adaptive Cruise Control)	√	√	√				
Scania\Divided By Vehicle\BUS&Coach\O Series\OmniExpress Euro 4-Euro 5-EEV\Bus DC 9 [----->]\EBS\BMS(Brake Management System)	√	√	√	√		√	0004
Scania\Divided By Vehicle\BUS&Coach\O Series\OmniExpress Euro 4-Euro 5-EEV\Bus DC 9 [----->]\ECU external light\VIS Visibility system	√	√	√	√		√	
Scania\Divided By Vehicle\BUS&Coach\O Series\OmniExpress Euro 4-Euro 5-EEV\Bus DC 9 [----->]\Engine-vehicle adjustment\COO(Coordinator module)	√	√	√	√		√	
Scania\Divided By Vehicle\BUS&Coach\O Series\OmniExpress Euro 4-Euro 5-EEV\Bus DC 9 [----->]\Instrument panel\ICL1(Instrument Cluster)	√	√	√	√		√	
Scania\Divided By Vehicle\BUS&Coach\O Series\OmniExpress Euro 4-Euro 5-EEV\Bus DC 9 [----->]\Instrument panel\ICL2(Instrument Cluster)	√	√	√	√		√	
Scania\Divided By Vehicle\BUS&Coach\O Series\OmniExpress Euro 4-Euro 5-EEV\Bus DC 9 [----->]\Network system\BCS(Bus chassis system)	√	√	√	√			
Scania\Divided By Vehicle\BUS&Coach\O Series\OmniExpress Euro 4-Euro 5-EEV\Bus DC 9 [----->]\Suspensions\SMS(Suspension management system)	√	√	√	√			0019
Scania\Divided By Vehicle\BUS&Coach\O Series\OmniExpress Euro 4-Euro 5-EEV\Bus DC 9 [----->]\Transmission\Ecomat 2	√	√	√	√		√	
Scania\Divided By Vehicle\BUS&Coach\O Series\Omniline Euro 3\Bus DC 9 [----->]\Transmission\Ecomat 2	√	√	√	√		√	
Scania\Divided By Vehicle\BUS&Coach\O Series\Omniline Euro 4-Euro 5-EEV\Bus DC 9 [----->]\ABS\BMS(Brake management system ABS E)	√	√	√	√		√	0004
Scania\Divided By Vehicle\BUS&Coach\O Series\Omniline Euro 4-Euro 5-EEV\Bus DC 9 [----->]\Articulation management\ACS(Articulation control system)	√	√	√				
Scania\Divided By Vehicle\BUS&Coach\O Series\Omniline Euro 4-Euro 5-EEV\Bus DC 9 [----->]\Chassis equipment and design\BWS(Preparation system)	√	√	√				
Scania\Divided By Vehicle\BUS&Coach\O Series\Omniline Euro 4-Euro 5-EEV\Bus DC 9 [----->]\Compressed air reserve system\APS Compressed air power supply(Scania protocol)	√	√	√	√			0003
Scania\Divided By Vehicle\BUS&Coach\O Series\Omniline Euro 4-Euro 5-EEV\Bus DC 9 [----->]\Compressed air reserve system\APS Compressed air power supply(Wabco protocol)\EEC-Exhaust gas treatment	√	√	√	√			
Scania\Divided By Vehicle\BUS&Coach\O Series\Omniline Euro 4-Euro 5-EEV\Bus DC 9 [----->]\Diesel injection\EMS S6-S7(Engine Management System)	√	√	√	√		√	0001, 0002, 0008, 0013
Scania\Divided By Vehicle\BUS&Coach\O Series\Omniline Euro 4-Euro 5-EEV\Bus DC 9 [----->]\Diesel injection\EMS S8(Engine Management System)	√	√	√	√			
Scania\Divided By Vehicle\BUS&Coach\O Series\Omniline Euro 4-Euro 5-EEV\Bus DC 9 [----->]\Diesel injection\EMS Engine management system DC13(6 Cylindes)	√	√	√	√		√	
Scania\Divided By Vehicle\BUS&Coach\O Series\Omniline Euro 4-Euro 5-EEV\Bus DC 9 [----->]\Distance control\DAS(Adaptive Cruise Control)	√	√	√				
Scania\Divided By Vehicle\BUS&Coach\O Series\Omniline Euro 4-Euro 5-EEV\Bus DC 9 [----->]\Distance control\DIS(Adaptive Cruise Control)	√	√	√				
Scania\Divided By Vehicle\BUS&Coach\O Series\Omniline Euro 4-Euro 5-EEV\Bus DC 9 [----->]\EBS\BMS(Brake Management System)	√	√	√	√		√	0004
Scania\Divided By Vehicle\BUS&Coach\O Series\Omniline Euro 4-Euro 5-EEV\Bus DC 9 [----->]\ECU external light\VIS Visibility system	√	√	√	√		√	
Scania\Divided By Vehicle\BUS&Coach\O Series\Omniline Euro 4-Euro 5-EEV\Bus DC 9 [----->]\Engine-vehicle adjustment\COO(Coordinator module)	√	√	√	√		√	
Scania\Divided By Vehicle\BUS&Coach\O Series\Omniline Euro 4-Euro 5-EEV\Bus DC 9 [----->]\Instrument panel\ICL1(Instrument Cluster)	√	√	√	√		√	
Scania\Divided By Vehicle\BUS&Coach\O Series\Omniline Euro 4-Euro 5-EEV\Bus DC 9 [----->]\Instrument panel\ICL2(Instrument Cluster)	√	√	√	√		√	
Scania\Divided By Vehicle\BUS&Coach\O Series\Omniline Euro 4-Euro 5-EEV\Bus DC 9 [----->]\Network system\BCS(Bus chassis system)	√	√	√	√			
Scania\Divided By Vehicle\BUS&Coach\O Series\Omniline Euro 4-Euro 5-EEV\Bus DC 9 [----->]\Suspensions\SMS(Suspension management system)	√	√	√	√			0019
Scania\Divided By Vehicle\BUS&Coach\O Series\Omniline Euro 4-Euro 5-EEV\Bus DC 9 [----->]\Transmission\Ecomat 2	√	√	√	√		√	
Scania\Divided By Vehicle\BUS&Coach\O Series\Omnilink Euro 4-Euro 5-EEV\Bus DC 9 [----->]\ABS\BMS(Brake management system ABS E)	√	√	√	√		√	0004
Scania\Divided By Vehicle\BUS&Coach\O Series\Omnilink Euro 4-Euro 5-EEV\Bus DC 9 [----->]\Articulation management\ACS(Articulation control system)	√	√	√				
Scania\Divided By Vehicle\BUS&Coach\O Series\Omnilink Euro 4-Euro 5-EEV\Bus DC 9 [----->]\Chassis equipment and design\BWS(Preparation system)	√	√	√				
Scania\Divided By Vehicle\BUS&Coach\O Series\Omnilink Euro 4-Euro 5-EEV\Bus DC 9 [----->]\Compressed air reserve system\APS Compressed air power supply(Scania protocol)	√	√	√	√			0003
Scania\Divided By Vehicle\BUS&Coach\O Series\Omnilink Euro 4-Euro 5-EEV\Bus DC 9 [----->]\Compressed air reserve system\APS Compressed air power supply(Wabco protocol)\EEC-Exhaust gas treatment	√	√	√	√			
Scania\Divided By Vehicle\BUS&Coach\O Series\Omnilink Euro 4-Euro 5-EEV\Bus DC 9 [----->]\Diesel injection\EMS S6-S7(Engine Management System)	√	√	√	√		√	0001, 0002, 0008, 0013

Scania\Divided By Vehicle\BUS&Coach\O Series\Omnalink Euro 4-Euro 5-EEV\Bus DC 9 [----->]\Diesel injection\EMS S8(Engine Management System)	√	√	√	√			
Scania\Divided By Vehicle\BUS&Coach\O Series\Omnalink Euro 4-Euro 5-EEV\Bus DC 9 [----->]\Diesel injection\EMS Engine management system DC13(6 Cylindes)	√	√	√	√		√	
Scania\Divided By Vehicle\BUS&Coach\O Series\Omnalink Euro 4-Euro 5-EEV\Bus DC 9 [----->]\Distance control\DAS(Adaptive Cruise Control)	√	√	√				
Scania\Divided By Vehicle\BUS&Coach\O Series\Omnalink Euro 4-Euro 5-EEV\Bus DC 9 [----->]\Distance control\DIS(Adaptive Cruise Control)	√	√	√				
Scania\Divided By Vehicle\BUS&Coach\O Series\Omnalink Euro 4-Euro 5-EEV\Bus DC 9 [----->]\EBS\BMS(Brake Management System)	√	√	√	√		√	0004
Scania\Divided By Vehicle\BUS&Coach\O Series\Omnalink Euro 4-Euro 5-EEV\Bus DC 9 [----->]\ECU external light\VIS Visibilty system	√	√	√	√		√	
Scania\Divided By Vehicle\BUS&Coach\O Series\Omnalink Euro 4-Euro 5-EEV\Bus DC 9 [----->]\Engine-vehicle adjustment\COO(Coordinator module)	√	√	√	√		√	
Scania\Divided By Vehicle\BUS&Coach\O Series\Omnalink Euro 4-Euro 5-EEV\Bus DC 9 [----->]\Instrument panel\ICL1(Instrument Cluster)	√	√	√	√		√	
Scania\Divided By Vehicle\BUS&Coach\O Series\Omnalink Euro 4-Euro 5-EEV\Bus DC 9 [----->]\Instrument panel\ICL2(Instrument Cluster)	√	√	√	√		√	
Scania\Divided By Vehicle\BUS&Coach\O Series\Omnalink Euro 4-Euro 5-EEV\Bus DC 9 [----->]\Network system\BCS(Bus chassis system)	√	√	√	√			
Scania\Divided By Vehicle\BUS&Coach\O Series\Omnalink Euro 4-Euro 5-EEV\Bus DC 9 [----->]\Suspensions\SMS(Suspension management system)	√	√	√	√			0019
Scania\Divided By Vehicle\BUS&Coach\O Series\Omnalink Euro 4-Euro 5-EEV\Bus DC 9 [----->]\Transmission\Ecomat 2	√	√	√	√		√	
Scania\Divided By Connector\16 Pin Square\APS (compressed air supply)		√	√			√	
Scania\Divided By Connector\16 Pin Square\BMS (brake management system)	√	√	√	√		√	0016
Scania\Divided By Connector\16 Pin Square\CCS (Smart climate control system)	√	√	√	√			
Scania\Divided By Connector\16 Pin Square\COO (Coordinator)\COO (Coordinator)	√	√	√	√			
Scania\Divided By Connector\16 Pin Square\COO (Coordinator)\COO7 (Coordinator)	√	√	√	√			
Scania\Divided By Connector\16 Pin Square\EMS (Engine Management System)\EEC-Exhaust gas treatment	√	√	√	√		√	
Scania\Divided By Connector\16 Pin Square\EMS (Engine Management System)\EMS Engine management system S6-S7	√	√	√	√		√	0002, 0015, 0017
Scania\Divided By Connector\16 Pin Square\EMS (Engine Management System)\EMS Engine management system S8(8 Cylindes)	√	√	√	√		√	0001
Scania\Divided By Connector\16 Pin Square\EMS (Engine Management System)\EMS Engine management system DC13(6 Cylindes)	√	√	√	√		√	
Scania\Divided By Connector\16 Pin Square\ICL (instrument panel)	√	√	√	√		√	
Scania\Divided By Connector\16 Pin Square\SMS (Suspension Control System)	√	√	√	√			0019
Scania\Divided By Connector\16 Pin Square\VIS (lighting system)	√	√	√	√			
Scania\Divided By Connector\16 Pin Square\BCS (bus chassis system)	√	√	√	√			
Scania\Divided By Connector\16 Pin Square\TCO (mileage recorder)	√	√	√				
Scania\Divided By Connector\16 Pin Square\GMS (transmission control system)	√	√	√				
Scania\Divided By Connector\16 Pin Square\GMS - Gear management system Opticruise 5	√	√	√	√		√	0009, 0011, 0018
Scania\Divided By Connector\16 Pin Square\GMS - GMS Opticruise 5	√	√	√	√		√	0009, 0011, 0018
Scania\Divided By Connector\16 Pin Square\LAS (locking and alarm system)	√	√	√				
Scania\Divided By Connector\16 Pin Round\3 Series(models end with 3, e.g.93,113,143)\Truck 3 series\Engine\Bosch PDE EDC MS 6.2	√	√	√	√	√	√	
Scania\Divided By Connector\16 Pin Round\3 Series(models end with 3, e.g.93,113,143)\Truck 3 series\Engine\Bosch PDE EDC MS 6.2	√	√	√	√		√	
Scania\Divided By Connector\16 Pin Round\3 Series(models end with 3, e.g.93,113,143)\Truck 3 series\Engine\Bosch EDC MS 5	√	√	√	√			
Scania\Divided By Connector\16 Pin Round\3 Series(models end with 3, e.g.93,113,143)\Truck 3 series\Engine\EDC MS5 DSC14 Version1		√	√	√		√	
Scania\Divided By Connector\16 Pin Round\3 Series(models end with 3, e.g.93,113,143)\Truck 3 series\Engine\EDC MS5 DSC14 Version2		√	√	√			

[illegible]

Scania\Divided By Connector\16 Pin Round\4 Series(models end with 4, e.g.94,114,124)\Bus 4 series\Bus\Engine\EDC MS5 DSC14 Version1		√	√	√		√	
Scania\Divided By Connector\16 Pin Round\4 Series(models end with 4, e.g.94,114,124)\Bus 4 series\Bus\Engine\EDC MS5 DSC14 Version2		√	√	√			
Scania\Divided By Connector\16 Pin Round\4 Series(models end with 4, e.g.94,114,124)\Bus 4 series\Bus\Brake\ABS		√	√	√		√	
Scania\Divided By Connector\16 Pin Round\4 Series(models end with 4, e.g.94,114,124)\Bus 4 series\Bus\Brake\EBS		√	√	√		√	
Scania\Divided By Connector\16 Pin Round\4 Series(models end with 4, e.g.94,114,124)\Bus 4 series\Bus\Brake\Knorr EBS 2.2		√	√	√		√	
Scania\Divided By Connector\16 Pin Round\4 Series(models end with 4, e.g.94,114,124)\Bus 4 series\Bus\Brake\Knorr EBS 2.2		√	√				
Scania\Divided By Connector\16 Pin Round\4 Series(models end with 4, e.g.94,114,124)\Bus 4 series\Bus\Coordinator	√	√	√	√		√	0010, 0012
Scania\Divided By Connector\16 Pin Round\4 Series(models end with 4, e.g.94,114,124)\Bus 4 series\Bus\Auxiliary brake		√	√	√			

Special Function Table

0001	Activating fuel supply solenoid valves
0002	Adjustment
0003	Air measuring device reset
0004	Auto-adaptive parameters reset
0005	Basic transmission parameters' reset
0006	Calibrating of all levels
0007	Calibrating the drive level
0008	Checking fuel supply pressure
0009	Clutch Adaption
0010	Display of status
0011	Fluid replace and bleeding the clutch actuator
0012	Fuel supply
0013	Measuring fuel pressure
0014	Pressure sensors, Calibration
0015	Reset EGR data
0016	Reset self-learned parameters
0017	SCR warning light reset
0018	Setting total clutch disk thickness
0019	Suspension calibration