

Man V14.0 Function List

Note:

✓ Functions marked with ✓ is fully supported.

System	ECU Info	Read Fault Code	Clear Fault Code	Live Data	Active Test	Special Func
Automatic control unit detection from vehicle	✓	✓	✓	✓	Automatic scanning function	
Divided by the System\Brake\Sustained-action brakes\EBS\EBS 2.2/2.3, KNORR\EBS/ESP commercial vehicle	✓	✓	✓	✓		
Divided by the System\Brake\Sustained-action brakes\EBS\EBS 2.2/2.3, KNORR\EBS bus	✓	✓	✓	✓		
Divided by the System\Brake\Sustained-action brakes\EBS\EBS 5, KNORR	✓	✓	✓	✓	A0001, A0002	S0001, S0002, S0003, S0004
Divided by the System\Brake\Sustained-action brakes\EBS\EBS 2, WABCO	✓	✓	✓	✓	A0001, A0002, A0003	S0005
Divided by the System\Brake\Sustained-action brakes\ECAM\Haldex ECAM	✓	✓	✓			
Divided by the System\Brake\Sustained-action brakes\Sustained-action brakes\ZF Intarder	✓	✓	✓	✓		
Divided by the System\Brake\Sustained-action brakes\Sustained-action brakes\Retarder R115E/R120-3/R133-2 Voith	✓	✓	✓	✓		
Divided by the System\Brake\Sustained-action brakes\Sustained-action brakes\PriTarder (Voith water pump retarder)	✓	✓	✓	✓		
Divided by the System\Brake\Sustained-action brakes\Sustained-action brakes\Intarder3	✓	✓	✓	✓		
Divided by the System\Running gear\Steering\ECAS\ECAS/EFR	✓	✓	✓			
Divided by the System\Running gear\Steering\ECAS\ECAS2 Wabco	✓	✓	✓	✓	A0004, A0005, A0006, A0007, A0008, A0009	S0006
Divided by the System\Running gear\Steering\ECAS\ECAS2 CDC Wabco	✓	✓	✓	✓		
Divided by the System\Running gear\Steering\Rear axle steering\RAS-EC1 steering system, rear axle, ZF	✓	✓	✓	✓		
Divided by the System\Running gear\Steering\Rear axle steering\Steering system(EHLA/ALA) Mobil Elektronik	✓	✓	✓	✓		
Divided by the System\Engine / Exhaust post-treatment\EDC\EDC MS 6.1 BOSCH	✓	✓	✓	✓		
Divided by the System\Engine / Exhaust post-treatment\EDC\EDC 7 BOSCH	✓	✓	✓	✓		
Divided by the System\Engine / Exhaust post-treatment\EDC\EDC 7C32, Bosch	✓	✓	✓	✓	A0010	S0007, S0008, S0009
Divided by the System\Engine / Exhaust post-treatment\EDC\EDC MS 6.4, Bosch	✓	✓	✓	✓		
Divided by the System\Engine / Exhaust post-treatment\EDC\EDC 7 master, Bosch	✓	✓	✓	✓		
Divided by the System\Engine / Exhaust post-treatment\EDC\EDC 7 slave, Bosch	✓	✓	✓	✓		
Divided by the System\Engine / Exhaust post-treatment\EDC\EDC 7C32 Master, Bosch	✓	✓	✓	✓		
Divided by the System\Engine / Exhaust post-treatment\EDC\EDC 7C32 Slave, Bosch	✓	✓	✓	✓		
Divided by the System\Engine / Exhaust post-treatment\CNG gas engine control\Gas ME 7, Bosch	✓	✓	✓	✓		
Divided by the System\Engine / Exhaust post-treatment\CRT (self-cleaning particle filter)MAN\CRT (self-cleaning particle filter)MAN	✓	✓	✓	✓		
Divided by the System\Engine / Exhaust post-treatment\CRT (self-cleaning particle filter)MAN\EDC17	✓	✓	✓	✓		
Divided by the System\Engine / Exhaust post-treatment\CRT (self-cleaning particle filter)MAN\EGC4	✓	✓	✓	✓		
Divided by the System\Engine / Exhaust post-treatment\AdBlue system\DENOX AdBlue System, Bosch	✓	✓	✓	✓		
Divided by the System\Engine / Exhaust post-treatment\AdBlue system\NONOX AdBlue System, Emitec	✓	✓	✓	✓		
Divided by the System\Engine / Exhaust post-treatment\MAN Engine\D2866LOH23\BOSCH EDC MS5 Euro II	✓	✓	✓	✓		
Divided by the System\Engine / Exhaust post-treatment\MAN Engine\D2866LOH25\BOSCH EDC MS5 Euro II	✓	✓	✓	✓		
Divided by the System\Engine / Exhaust post-treatment\MAN Engine\D2866LOH27\BOSCH EDC MS5 Euro III	✓	✓	✓	✓		
Divided by the System\Engine / Exhaust post-treatment\MAN Engine\D2866LOH28\BOSCH EDC MS5 Euro III	✓	✓	✓	✓		

Divided by the System\Engine / Exhaust post-treatment\MAN Engine\D2866L0H29\BOSCH EDC MS5 Euro III	✓	✓	✓	✓		
Divided by the System\Engine / Exhaust post-treatment\MAN Engine\D2876L0H01\BOSCH EDC MS5 Euro II	✓	✓	✓	✓		
Divided by the System\Engine / Exhaust post-treatment\MAN Engine\BOSCH EDC MS5/M(S)5	✓	✓	✓	✓		
Divided by the System\Gearbox\Powertrain\Gearbox\ASTRONIC ZF	✓	✓	✓	✓		
Divided by the System\Gearbox\Powertrain\Gearbox\ASTRONICmid ZF	✓	✓	✓	✓		
Divided by the System\Gearbox\Powertrain\Gearbox\6AS 850 ASTRONIC lite ZF	✓	✓	✓	✓		
Divided by the System\Gearbox\Powertrain\Gearbox\Ecomat 2/4 ZF	✓	✓	✓			
Divided by the System\Gearbox\Powertrain\Gearbox\DIWA.5Voith Turbo	✓	✓	✓	✓		
Divided by the System\Gearbox\Powertrain\Gearbox\EcoLife, ZF	✓	✓	✓	✓		
Divided by the System\Gearbox\Powertrain\Hydro Drive MAN	✓	✓	✓	✓		
Divided by the System\Gearbox\Powertrain\WSK\Torque converter and clutch system TC2ZF	✓	✓	✓			
Divided by the System\Gearbox\Powertrain\VSM\VSM SVD0	✓	✓	✓	✓		
Divided by the System\Gearbox\Powertrain\VSM\TIPMATIC 3	✓	✓	✓			
Divided by the System\Climate control\auxiliary heaters\Air-conditioning\auxiliary air-conditioning/heating\Behr/GKB air-conditioning control	✓	✓	✓	✓		
Divided by the System\Climate control\auxiliary heaters\Air-conditioning\auxiliary air-conditioning/heating\Airconditioning system KR 49x Bader	✓	✓	✓			
Divided by the System\Climate control\auxiliary heaters\Air-conditioning\auxiliary air-conditioning/heating\Heating\air conditioning\auxiliary air conditioning BHTC, Behr	✓	✓	✓	✓	A0011, A0012, A0013, A0014, A0015, A0016, A0017	S0010
Divided by the System\Climate control\auxiliary heaters\Air-conditioning\auxiliary air-conditioning/heating\Independent air-conditioning control unit	✓	✓	✓	✓		
Divided by the System\Climate control\auxiliary heaters\Air-conditioning\auxiliary air-conditioning/heating\Independent air-conditioning control	✓	✓	✓	✓		
Divided by the System\Climate control\auxiliary heaters\Additional heaters air or water\D1LC- / D3LC Compact, Eberspacher	✓	✓	✓	✓		
Divided by the System\Climate control\auxiliary heaters\Additional heaters air or water\Airtronic D2/D4, Eberspacher	✓	✓	✓			
Divided by the System\Climate control\auxiliary heaters\Additional heaters air or water\Air Top 3500 ST, Webasto	✓	✓	✓	✓		
Divided by the System\Climate control\auxiliary heaters\Additional heaters air or water\Air Top 3500, Webasto SG 11580		✓	✓			
Divided by the System\Climate control\auxiliary heaters\Additional heaters air or water\Hydronic D5W, Eberspacher	✓	✓	✓	✓		
Divided by the System\Climate control\auxiliary heaters\Additional heaters air or water\Thermo 50, Webasto	✓	✓	✓	✓		
Divided by the System\Climate control\auxiliary heaters\Additional heaters air or water\Hydronic 24/30/35, Eberspacher	✓	✓	✓	✓		
Divided by the System\Climate control\auxiliary heaters\Additional heaters air or water\Air Top 3500, Webasto SG 11580 old	✓	✓	✓	✓		
Divided by the System\Climate control\auxiliary heaters\Additional heaters air or water\D1LC-/D3LC Compact (9A), Eberspacher		✓	✓			
Divided by the System\Climate control\auxiliary heaters\Additional heaters air or water\Thermo S, Spheros	✓	✓	✓	✓		
Divided by the System\Climate control\auxiliary heaters\Additional heaters air or water\Air Top 2000 OEM, Webasto		✓	✓	✓	A0018, A0019, A0020	S0011
Divided by the System\Central computer\instrumentation\Instrumentation\VD0Kienzle instrumentation	✓	✓	✓	✓		
Divided by the System\Central computer\instrumentation\Instrumentation\Instrumentation\Stoneridge Electronics	✓	✓	✓	✓		
Divided by the System\Central computer\instrumentation\FFR\PTM\MFR\VD0 FFR	✓	✓	✓			
Divided by the System\Central computer\instrumentation\ZBR(central on board computer)\CBR II Wabco up to version E5	✓	✓	✓	✓		
Divided by the System\Central computer\instrumentation\ZBR(central on board computer)\CBR II Wabco from version E6 onwards	✓	✓	✓	✓		
Divided by the System\Central computer\instrumentation\ZBRO\ZBRO control unit software status 'ZR_103' or earlier		✓	✓			
Divided by the System\Central computer\instrumentation\ZBRO\ZBRO control unit software status 'ZR_104' or earlier		✓	✓			

Divided by the System\Central computer/instrumentation\ZBR0\ZBR032	✓	✓	✓			
Divided by the System\Central computer/instrumentation\Customer's special module\VDO KSM	✓	✓	✓	✓		
Divided by the System\Central computer/instrumentation\ZFR\ZFR MAN	✓	✓	✓	✓		
Divided by the System\Central computer/instrumentation\ZFR\PTM		✓	✓			
Divided by the System\Central computer/instrumentation\ZFR\Engine management computer (MFR)	✓	✓	✓	✓		
Divided by the System\Central computer/instrumentation\FFR Step 12	✓	✓	✓	✓		
Divided by the System\Central computer/instrumentation\Wabco ZBR II\Wabco ZBR II (Version 1)	✓	✓	✓	✓	A0021, A0022	S0012
Divided by the System\Central computer/instrumentation\Wabco ZBR II\Wabco ZBR II (Version 2)	✓	✓	✓	✓	A0021, A0022	S0013
Divided by the System\Comfort/assistance/safety systems\ACC MAN		✓	✓			
Divided by the System\Comfort/assistance/safety systems\LGS (Lane Guard System)\LGS ITERIS	✓	✓	✓	✓		
Divided by the System\Comfort/assistance/safety systems\Tire Pressure Monitor (TPM) Wabco	✓	✓	✓	✓		
Divided by the System\Comfort/assistance/safety systems\Telematik Boardmodul (TBM) OHB	✓	✓	✓			
Divided by the System\Comfort/assistance/safety systems\Door module\Berifors door module	✓	✓	✓	✓		
Divided by the System\Comfort/assistance/safety systems\Door module\Door module TRW	✓	✓	✓	✓		
Divided by the System\Comfort/assistance/safety systems\Universal mobile phone preparation (UHV)\FWD	✓			✓		
Divided by the System\Comfort/assistance/safety systems\Radars sensor	✓	✓	✓	✓		
Divided by the System\Comfort/assistance/safety systems\Airbag\BOSCH airbag	✓	✓	✓			
Divided by the System\Central computer,marine and auxiliary engines\Ship vehicle management computer (SFFR)	✓	✓	✓			
Divided by the System\Central computer,marine and auxiliary engines\MAN Marine Diagnostic System (MMDS)	✓	✓	✓	✓		
Divided by the System\Central computer,marine and auxiliary engines\EDC\EDC MS 6.1 BOSCH	✓	✓	✓	✓		
Divided by the System\Central computer,marine and auxiliary engines\EDC\EDC 7 BOSCH	✓	✓	✓	✓		
Divided by the System\Central computer,marine and auxiliary engines\EDC\EDC 7C32, Bosch	✓	✓	✓	✓	A0010	S0007, S0008, S0009
Divided by the System\Central computer,marine and auxiliary engines\EDC\EDC MS 6.4, Bosch	✓	✓	✓	✓		
Divided by the System\Central computer,marine and auxiliary engines\EDC\EDC 7 master, Bosch	✓	✓	✓	✓		
Divided by the System\Central computer,marine and auxiliary engines\EDC\EDC 7 slave, Bosch	✓	✓	✓	✓		
Divided by the System\Central computer,marine and auxiliary engines\EDC\EDC 7C32 Master, Bosch	✓	✓	✓	✓		
Divided by the System\Central computer,marine and auxiliary engines\EDC\EDC 7C32 Slave, Bosch	✓	✓	✓	✓		
Divided by the System\Central computer,marine and auxiliary engines\CNG gas engine control\Gas ME 7, Bosch	✓	✓	✓	✓		
Divided by the System\Central computer,marine and auxiliary engines\FFR\PTM\MFR\VDO FFR	✓	✓	✓	✓		
Divided by the System\Central computer,marine and auxiliary engines\FFR\PTM\MFR\PTM		✓	✓			
Divided by the System\Central computer,marine and auxiliary engines\FFR\PTM\MFR\Engine management computer (MFR)	✓	✓	✓	✓		
Divided by the System\Hybrid components\EMU Energy Managment Unit	✓	✓	✓	✓		
Divided by the System\Hybrid components\Vehicle electrical system power converter	✓	✓	✓	✓		
Divided by the System\Hybrid components\MT-Gateway	✓					
Divided by the System\Hybrid components\UCM Ultracap-Management	✓	✓	✓	✓		
Divided by the System\Hybrid components\Wechselrichter 1	✓	✓	✓	✓		

Divided by the System\Hybrid components\DICO Siemens	✓	✓	✓	✓		
Divided by the System\Man engine (Latin America)\EDC Engine						
Divided by the Vehicle\TG-A\Computer\Wabco Car PC		✓	✓			
Divided by the Vehicle\TG-A\Diesel injection system\280\D 0836 LF41\Bosch EDC 7	✓	✓	✓	✓		
Divided by the Vehicle\TG-A\Diesel injection system\310\D 2066 LF04\Bosch EDC 7	✓	✓	✓	✓		
Divided by the Vehicle\TG-A\Diesel injection system\310\D 2866 LF26\Bosch EDC 7	✓	✓	✓	✓		
Divided by the Vehicle\TG-A\Diesel injection system\310\D 2866 LF26\Bosch EDC MS 6.1	✓	✓	✓	✓		
Divided by the Vehicle\TG-A\Diesel injection system\310\D 2866 LF27\Bosch EDC 7	✓	✓	✓	✓		
Divided by the Vehicle\TG-A\Diesel injection system\310\D 2866 LF27\Bosch EDC MS 6.1	✓	✓	✓	✓		
Divided by the Vehicle\TG-A\Diesel injection system\310\D 2866 LF36\Bosch EDC 7	✓	✓	✓	✓		
Divided by the Vehicle\TG-A\Diesel injection system\310\D 2866 LF36\Bosch EDC MS 6.1	✓	✓	✓	✓		
Divided by the Vehicle\TG-A\Diesel injection system\330\D 0836 LF44\Bosch EDC 7	✓	✓	✓	✓		
Divided by the Vehicle\TG-A\Diesel injection system\350\D 2066 LF03\Bosch EDC 7	✓	✓	✓	✓		
Divided by the Vehicle\TG-A\Diesel injection system\350\D 2066 LF04\Bosch EDC 7	✓	✓	✓	✓		
Divided by the Vehicle\TG-A\Diesel injection system\360\D 2866 LF26\Bosch EDC 7	✓	✓	✓	✓		
Divided by the Vehicle\TG-A\Diesel injection system\360\D 2866 LF26\Bosch EDC MS 6.1	✓	✓	✓	✓		
Divided by the Vehicle\TG-A\Diesel injection system\360\D 2866 LF27\Bosch EDC 7	✓	✓	✓	✓		
Divided by the Vehicle\TG-A\Diesel injection system\360\D 2866 LF27\Bosch EDC MS 6.1	✓	✓	✓	✓		
Divided by the Vehicle\TG-A\Diesel injection system\360\D 2866 LF37\Bosch EDC 7	✓	✓	✓	✓		
Divided by the Vehicle\TG-A\Diesel injection system\360\D 2866 LF37\Bosch EDC MS 6.1	✓	✓	✓	✓		
Divided by the Vehicle\TG-A\Diesel injection system\390\D 2066 LF02\Bosch EDC 7	✓	✓	✓	✓		
Divided by the Vehicle\TG-A\Diesel injection system\410\D 2866 LF28\Bosch EDC 7	✓	✓	✓	✓		
Divided by the Vehicle\TG-A\Diesel injection system\410\D 2866 LF28\Bosch EDC MS 6.1	✓	✓	✓	✓		
Divided by the Vehicle\TG-A\Diesel injection system\410\D 2866 LF32\Bosch EDC 7	✓	✓	✓	✓		
Divided by the Vehicle\TG-A\Diesel injection system\410\D 2866 LF32\Bosch EDC MS 6.1	✓	✓	✓	✓		
Divided by the Vehicle\TG-A\Diesel injection system\430\D 2066 LF04\Bosch EDC 7	✓	✓	✓	✓		
Divided by the Vehicle\TG-A\Diesel injection system\440\D 2066 LF21\Bosch EDC 7	✓	✓	✓	✓		
Divided by the Vehicle\TG-A\Diesel injection system\460\D 2876 LF04\Bosch EDC 7	✓	✓	✓	✓		
Divided by the Vehicle\TG-A\Diesel injection system\460\D 2876 LF04\Bosch EDC MS 6.1	✓	✓	✓	✓		
Divided by the Vehicle\TG-A\Diesel injection system\460\D 2876 LF07\Bosch EDC 7	✓	✓	✓	✓		
Divided by the Vehicle\TG-A\Diesel injection system\460\D 2876 LF07\Bosch EDC MS 6.1	✓	✓	✓	✓		
Divided by the Vehicle\TG-A\Diesel injection system\480\D 2876 LF12\Bosch EDC 7	✓	✓	✓	✓		
Divided by the Vehicle\TG-A\Diesel injection system\510\D 2876 LF05\Bosch EDC 7	✓	✓	✓	✓		
Divided by the Vehicle\TG-A\Diesel injection system\510\D 2876 LF05\Bosch EDC MS 6.1	✓	✓	✓	✓		
Divided by the Vehicle\TG-A\Diesel injection system\530\D 2876 LF13\Bosch EDC 7	✓	✓	✓	✓		
Divided by the Vehicle\TG-A\Diesel injection system\660\D 2840 LF25\Bosch EDC 7	✓	✓	✓	✓		

Divided by the Vehicle\TG-A\EBS\Knorr EBS 4x2		✓	✓	✓		
Divided by the Vehicle\TG-A\EBS\Knorr EBS 6 × 2 (Third Intermediate axle)		✓	✓	✓		
Divided by the Vehicle\TG-A\EBS\Knorr EBS 6 × 2 (the third dragging axle)		✓	✓	✓		
Divided by the Vehicle\TG-A\EBS\Knorr EBS 6x4		✓	✓	✓		
Divided by the Vehicle\TG-A\EBS\Knorr EBS 8x4		✓	✓	✓		
Divided by the Vehicle\TG-A\EBS\Knorr EBS Auto H88		✓	✓	✓		
Divided by the Vehicle\TG-A\EBS\Knorr EBS Auto H95		✓	✓	✓		
Divided by the Vehicle\TG-A\Engine - Auto adjustment\VDO FFR auto - engine (navigator)		✓	✓	✓		
Divided by the Vehicle\TG-A\EBS 2.3,KNORR\EBS/ESP commerical vehicle	✓	✓	✓	✓		
Divided by the Vehicle\TG-A\EBS 2.3,KNORR\EBS bus	✓	✓	✓	✓		
Divided by the Vehicle\TG-A\ECAS2 Wabco	✓	✓	✓	✓	A0004, A0005, A0006, A0007, A0008, A0009	S0006
Divided by the Vehicle\TG-A\EDC 7 BOSCH	✓	✓	✓	✓		
Divided by the Vehicle\TG-A\FFR Step 10 VDO	✓	✓	✓	✓		
Divided by the Vehicle\TG-A\Wabco ZBR II	✓	✓	✓	✓	A0021, A0022	S0012
Divided by the Vehicle\TG-A\Berifors door module	✓	✓	✓	✓		
Divided by the Vehicle\TG-A\Behr/GKR air-conditioning control	✓	✓	✓	✓		
Divided by the Vehicle\TG-A\Stoneridge Electronics Highline instrumentation	✓	✓	✓	✓		
Divided by the Vehicle\TG-M\EBS 2, WABCO	✓	✓	✓	✓	A0001, A0002, A0003	S0005
Divided by the Vehicle\TG-M\ECAS2 Wabco	✓	✓	✓	✓	A0004, A0005, A0006, A0007, A0008, A0009	S0006
Divided by the Vehicle\TG-M\ASTRONIC mid ZF	✓	✓	✓	✓		
Divided by the Vehicle\TG-M\EDC 7 BOSCH	✓	✓	✓	✓		S0014, S0015, S0016
Divided by the Vehicle\TG-M\EDC7C32 V44,BOSCH	✓	✓	✓	✓	A0010	S0007, S0008, S0009
Divided by the Vehicle\TG-M\FFR Step 12	✓	✓	✓	✓		
Divided by the Vehicle\TG-M\Wabco ZBR II	✓	✓	✓	✓	A0021, A0022	S0012
Divided by the Vehicle\TG-M\Berifors door module	✓	✓	✓	✓		
Divided by the Vehicle\TG-M\Behr/GKR air-conditioning control	✓	✓	✓	✓		
Divided by the Vehicle\TG-M\Instrumentation Stoneridge Electronics	✓	✓	✓	✓		
Divided by the Vehicle\TG-E						
Divided by the Vehicle\TG-S\PTM	✓	✓	✓	✓		
Divided by the Vehicle\TG-S\ECAS2 Wabco	✓	✓	✓	✓	A0004, A0005, A0006, A0007, A0008, A0009	S0006, S0017
Divided by the Vehicle\TG-S\DENOX AdBlue system V28 SOP, Bosch	✓	✓	✓	✓		S0018, S0019, S0020, S0021, S0022
Divided by the Vehicle\TG-S\EDC 7 BOSCH	✓	✓	✓	✓	A0023	S0014, S0015, S0023
Divided by the Vehicle\TG-S\EDC 7C32 V35.BOSCH	✓	✓	✓	✓	A0010	S0023, S0007, S0008, S0024
Divided by the Vehicle\TG-S\Wabco ZBR II	✓	✓	✓	✓	A0021, A0022	S0012
Divided by the Vehicle\TG-S\Door module TRW	✓	✓	✓	✓		
Divided by the Vehicle\TG-S\EBS 5,KNORR	✓	✓	✓	✓	A0001, A0002	S0001, S0002, S0003, S0004

Divided by the Vehicle\TG-S\ASTRONIC ZF	✓	✓	✓	✓		
Divided by the Vehicle\TG-S\Instrumentation Stoneridge Electronics	✓	✓	✓	✓		
Divided by the Vehicle\TG-S\Heating / air conditioning / auxiliary air conditioning BHTC, Behr	✓	✓	✓	✓	A0024, A0025, A0026, A0027, A0028, A0029, A0030, A0031, A0032, A0033, A0034, A0035, A0036, A0015, A0011, A0012, A0013, A0014, A0017, A0037, A0011,	S0010
Divided by the Vehicle\TG-S\Universal mobile phone preparation (UHV) FWD	✓			✓		
Divided by the Vehicle\TG-X\EBS 5, KNORR	✓	✓	✓	✓	A0001, A0002	S0001, S0002, S0003, S0004
Divided by the Vehicle\TG-X\ECAS2 Wabco	✓	✓	✓	✓	A0004, A0005, A0006, A0007, A0008, A0009	S0006
Divided by the Vehicle\TG-X\DENOX AdBlue system V28 SOP, Bosch	✓	✓	✓	✓		S0018, S0019, S0020, S0021, S0022
Divided by the Vehicle\TG-X\PTM	✓	✓	✓	✓		
Divided by the Vehicle\TG-X\ASTRONIC ZF	✓	✓	✓	✓		
Divided by the Vehicle\TG-X\EDC 7C32 V35.BOSCH	✓	✓	✓	✓	A0010	S0023, S0007, S0008, S0024
Divided by the Vehicle\TG-X\Heating / air conditioning / auxiliary air conditioning BHTC, Behr	✓	✓	✓	✓	A0024, A0025, A0026, A0027, A0028, A0029, A0030, A0031, A0032, A0033, A0034, A0035, A0036, A0015, A0011, A0012, A0013, A0014, A0017, A0037, A0011,	S0010
Divided by the Vehicle\TG-X\Instrumentation Stoneridge Electronics	✓	✓	✓	✓		
Divided by the Vehicle\TG-X\Wabco ZBR II	✓	✓	✓	✓	A0021, A0022	S0012
Divided by the Vehicle\TG-X\Universal mobile phone preparation (UHV) FWD	✓			✓		
Divided by the Vehicle\TG-X\Door module TRW	✓	✓	✓	✓		
Divided by the Vehicle\TG-X\Multi Media System	✓	✓	✓	✓		
Divided by the Vehicle\TG-X\FFR/MFR						
Divided by the Vehicle\TG-L\Diesel injection system\150\D 0834 LFL40\Bosch EDC 7	✓	✓	✓	✓		
Divided by the Vehicle\TG-L\Diesel injection system\180\D 0834 LFL41\Bosch EDC 7	✓	✓	✓	✓		
Divided by the Vehicle\TG-L\Diesel injection system\210\D 0834 LFL42\Bosch EDC 7	✓	✓	✓	✓		
Divided by the Vehicle\TG-L\Diesel injection system\240\D 0836 LFL40\Bosch EDC 7	✓	✓	✓	✓		
Divided by the Vehicle\TG-L\Engine - Auto adjustment\VDO FFR Vehicle-Engine(Navigator)		✓	✓	✓		
Divided by the Vehicle\E 2000\Braking force support\Voith VERA R115E	✓	✓	✓	✓		
Divided by the Vehicle\E 2000\Diesel injection system\BOSCH EDC MS 5	✓	✓	✓	✓		
Divided by the Vehicle\E 2000 Evolution\Braking force support\Voith VERA R115E	✓	✓	✓	✓		
Divided by the Vehicle\E 2000 Evolution\Diesel injection system\310\D 2866 LF23\BOSCH EDC MS 5	✓	✓	✓	✓		
Divided by the Vehicle\E 2000 Evolution\Diesel injection system\310\D 2866 LF23\BOSCH EDC MS 6.1	✓	✓	✓	✓		
Divided by the Vehicle\E 2000 Evolution\Diesel injection system\360\D 2866 LF24\BOSCH EDC MS 5	✓	✓	✓	✓		
Divided by the Vehicle\E 2000 Evolution\Diesel injection system\360\D 2866 LF24\BOSCH EDC MS 6.1	✓	✓	✓	✓		
Divided by the Vehicle\E 2000 Evolution\Diesel injection system\410\D 2866 LF 25\BOSCH EDC MS 5	✓	✓	✓	✓		
Divided by the Vehicle\E 2000 Evolution\Diesel injection system\410\D 2866 LF 25\BOSCH EDC MS 6.1	✓	✓	✓	✓		
Divided by the Vehicle\E 2000 Evolution\Diesel injection system\414\D 2876 LF03\BOSCH EDC MS 5	✓	✓	✓	✓		
Divided by the Vehicle\E 2000 Evolution\Diesel injection system\414\D 2876 LF03\BOSCH EDC MS 6.1	✓	✓	✓	✓		
Divided by the Vehicle\F 2000\Braking force support\Voith VERA R115E	✓	✓	✓	✓		
Divided by the Vehicle\F 2000\Diesel injection system\BOSCH EDC MS 5	✓	✓	✓	✓		
Divided by the Vehicle\F 2000 Evolution\Braking force support\Voith VERA R115E	✓	✓	✓	✓		

Divided by the Vehicle\F 2000 Evolution\Diesel injection system\310\D 2866 LF 23\BOSCH EDC MS 5	✓	✓	✓	✓		
Divided by the Vehicle\F 2000 Evolution\Diesel injection system\310\D 2866 LF 23\BOSCH EDC MS 6.1	✓	✓	✓	✓		
Divided by the Vehicle\F 2000 Evolution\Diesel injection system\360\D 2866 LF24\BOSCH EDC MS 5	✓	✓	✓	✓		
Divided by the Vehicle\F 2000 Evolution\Diesel injection system\360\D 2866 LF24\BOSCH EDC MS 6.1	✓	✓	✓	✓		
Divided by the Vehicle\F 2000 Evolution\Diesel injection system\410\D 2866 LF25\BOSCH EDC MS 5	✓	✓	✓	✓		
Divided by the Vehicle\F 2000 Evolution\Diesel injection system\410\D 2866 LF25\BOSCH EDC MS 6.1	✓	✓	✓	✓		
Divided by the Vehicle\F 2000 Evolution\Diesel injection system\414\D 2876 LF 03\BOSCH EDC MS 5	✓	✓	✓	✓		
Divided by the Vehicle\F 2000 Evolution\Diesel injection system\414\D 2876 LF 03\BOSCH EDC MS 6.1	✓	✓	✓	✓		
Divided by the Vehicle\F 90\Braking force support\Voith VERA R115E	✓	✓	✓	✓		
Divided by the Vehicle\L 2000\Diesel injection system\264\D 0826 LFL09\Bosch EDC MS 5	✓	✓	✓	✓		
Divided by the Vehicle\LE 2000\DIESEL INJECTION\140\D 0834 LFL02\BOSCH EDC MS 5	✓	✓	✓	✓		
Divided by the Vehicle\LE 2000\DIESEL INJECTION\140\D 0834 LFL02\BOSCH EDC MS 6.4	✓	✓	✓	✓		
Divided by the Vehicle\LE 2000\DIESEL INJECTION\180\D 0834 LFL03\BOSCH EDC MS 5	✓	✓	✓	✓		
Divided by the Vehicle\LE 2000\DIESEL INJECTION\180\D 0834 LFL03\BOSCH EDC MS 6.4	✓	✓	✓	✓		
Divided by the Vehicle\LE 2000\DIESEL INJECTION\225\BOSCH EDC MS 5	✓	✓	✓	✓		
Divided by the Vehicle\LE 2000\DIESEL INJECTION\225\BOSCH EDC MS 6.4	✓	✓	✓	✓		
Divided by the Vehicle\LE 2000\DIESEL INJECTION\250\BOSCH EDC MS 5	✓	✓	✓	✓		
Divided by the Vehicle\LE 2000\DIESEL INJECTION\250\BOSCH EDC MS 6.4	✓	✓	✓	✓		
Divided by the Vehicle\LE 2000\DIESEL INJECTION\255\BOSCH EDC MS 5	✓	✓	✓	✓		
Divided by the Vehicle\LE 2000\DIESEL INJECTION\255\BOSCH EDC MS 6.4	✓	✓	✓	✓		
Divided by the Vehicle\LE 2000\DIESEL INJECTION\280\BOSCH EDC MS 5	✓	✓	✓	✓		
Divided by the Vehicle\LE 2000\DIESEL INJECTION\280\BOSCH EDC MS 6.4	✓	✓	✓	✓		
Divided by the Vehicle\LE 2000\DIESEL INJECTION\285\BOSCH EDC MS 5	✓	✓	✓	✓		
Divided by the Vehicle\LE 2000\DIESEL INJECTION\285\BOSCH EDC MS 6.4	✓	✓	✓	✓		
Divided by the Vehicle\M 2000\BRAKE POWER SUPPORT\Voith Retarder VERA 1 R115E	✓	✓	✓	✓		
Divided by the Vehicle\M 2000\DIESEL INJECTION\264\D 0826 LF17\BOSCH EDC MS 5	✓	✓	✓	✓		
Divided by the Vehicle\M 2000 L\BRAKE POWER SUPPORT\Voith Retarder VERA 1 R115E	✓	✓	✓	✓		
Divided by the Vehicle\M 2000 L\DIESEL INJECTION\264\D 0826 LF17\BOSCH EDC MS 5	✓	✓	✓	✓		
Divided by the Vehicle\M 2000 L Evolution\BRAKE POWER SUPPORT\Voith Retarder VERA 1 R115E	✓	✓	✓	✓		
Divided by the Vehicle\M 2000 L Evolution\DIESEL INJECTION\264\D 0826 LF17\BOSCH EDC MS 5	✓	✓	✓	✓		
Divided by the Vehicle\M 2000 M\BRAKE POWER SUPPORT\Voith Retarder VERA 1 R115E	✓	✓	✓	✓		
Divided by the Vehicle\M 2000 M\DIESEL INJECTION\264\D 0826 LF17\BOSCH EDC MS 5	✓	✓	✓	✓		
Divided by the Vehicle\M 2000 M Evolution\BRAKE POWER SUPPORT\Voith Retarder VERA 1 R115E	✓	✓	✓	✓		
Divided by the Vehicle\M 2000 M Evolution\DIESEL INJECTION\264\D 0826 LF17\BOSCH EDC MS 5	✓	✓	✓	✓		
Divided by the Vehicle\M 90\BRAKE POWER SUPPORT\Voith Retarder VERA 1 R115E	✓	✓	✓	✓		
Divided by the Vehicle\ME 2000\DIESEL INJECTION\250\BOSCH EDC MS 5	✓	✓	✓	✓		

Divided by the Vehicle\ME 2000\DIESEL INJECTION\250\BOSCH EDC MS 6.4	✓	✓	✓	✓		
Divided by the Vehicle\ME 2000\DIESEL INJECTION\280\BOSCH EDC MS 5	✓	✓	✓	✓		
Divided by the Vehicle\ME 2000\DIESEL INJECTION\280\BOSCH EDC MS 6.4	✓	✓	✓	✓		
Divided by the Vehicle\MEXICO VOLKS-BUS\EDC ENGINE(Automatic detection)						
Divided by the Vehicle\MEXICO VOLKS-BUS\Central computer, marine and auxiliary engines\Ship vehicle management computer (SFFR)	✓	✓	✓			
Divided by the Vehicle\MEXICO VOLKS-BUS\Central computer, marine and auxiliary engines\MAN Marine Diagnostic System(MMDS)	✓	✓	✓	✓		
Divided by the Vehicle\MEXICO VOLKS-BUS\Central computer, marine and auxiliary engines\EDC\EDC MS 6.1 BOSCH	✓	✓	✓	✓		
Divided by the Vehicle\MEXICO VOLKS-BUS\Central computer, marine and auxiliary engines\EDC\EDC 7 BOSCH	✓	✓	✓	✓		
Divided by the Vehicle\MEXICO VOLKS-BUS\Central computer, marine and auxiliary engines\EDC\EDC 7C32, Bosch	✓	✓	✓	✓	A0010	S0007, S0008, S0009
Divided by the Vehicle\MEXICO VOLKS-BUS\Central computer, marine and auxiliary engines\EDC\EDC MS 6.4, Bosch	✓	✓	✓	✓		
Divided by the Vehicle\MEXICO VOLKS-BUS\Central computer, marine and auxiliary engines\EDC\EDC 7 master, Bosch	✓	✓	✓	✓		
Divided by the Vehicle\MEXICO VOLKS-BUS\Central computer, marine and auxiliary engines\EDC\EDC 7 slave, Bosch	✓	✓	✓	✓		
Divided by the Vehicle\MEXICO VOLKS-BUS\Central computer, marine and auxiliary engines\EDC\EDC 7C32 Master, Bosch	✓	✓	✓	✓		
Divided by the Vehicle\MEXICO VOLKS-BUS\Central computer, marine and auxiliary engines\EDC\EDC 7C32 Slave, Bosch	✓	✓	✓	✓		
Divided by the Vehicle\MEXICO VOLKS-BUS\Central computer, marine and auxiliary engines\CNG gas engine control\Gas ME 7, Bosch	✓	✓	✓	✓		
Divided by the Vehicle\MEXICO VOLKS-BUS\Central computer, marine and auxiliary engines\FFR/PTM/MFR\VDO FFR	✓	✓	✓	✓		
Divided by the Vehicle\MEXICO VOLKS-BUS\Central computer, marine and auxiliary engines\FFR/PTM/MFR/PTM		✓	✓			
Divided by the Vehicle\MEXICO VOLKS-BUS\Central computer, marine and auxiliary engines\FFR/PTM/MFR\Engine management computer (MFR)	✓	✓	✓	✓		
Divided by the Vehicle\MEXICO VOLKS-BUS\PTM	✓	✓	✓	✓		S0013
Divided by the Vehicle\VW vehicle with Man engine	✓	✓	✓	✓		
Hot functions\Steering angle sensor						S0027
Hot functions\Service Light Reset (SLR)\Service Reset						S0025, S0026
Hot functions\Service Light Reset (SLR)\Service Reset (PTM)						S0025, S0026
Hot functions\Throttle matching						S0028
Hot functions\Diesel particulate filter						S0029

Special Function Table	
S0001	check the pressure control module arrangment
S0002	Check wheel sensor arrangement
S0003	dynamometer test rig
S0004	ESP sensor calibration
S0005	Parameter
S0006	Calibration ride height
S0007	Cylinder shut-off test
S0008	High-pressure test
S0009	Pressure-limiting valve (DBV) open test
S0010	Stepper motor calibration
S0011	Fill fuel line
S0012	Automatic headlight beam regulation(for vehicles with leaf-air suspension only)
S0013	Calibration
S0014	Compression test
S0015	Rev-up test
S0016	Cylinder shut-off
S0017	Calibration pressure sensors
S0018	Initial startup
S0019	Adblue metering module test
S0020	Checking the air lines(8 bar)
S0021	Maximum supply module quantity
S0022	Empty AdBlue circuit
S0023	Evaluation
S0024	Reset torque limiting and flashing MIL
S0025	Read service parameters

S0026	Reset service
S0027	Steering angle sensor
S0028	Throttle matching
S0029	Diesel particulate filter

Active Test Table

A0001	Pressure-control modules
A0002	Check lamps and display messages
A0003	Redundancy test
A0004	Solenoid valve rear axle left
A0005	Solenoid valve rear axle right
A0006	Solenoid valve reservoir
A0007	Solenoid valve lifting axle left
A0008	Solenoid valve lifting axle right
A0009	Solenoid valve lifting axle bellows
A0010	Exhaust gas recirculation activation
A0011	Stepper motor side nozzle
A0012	Stepper motor recirculated air
A0013	Stepper motor air distribution
A0014	Stepper motor bypass
A0015	Blower voltage
A0016	Stepper motor butterfly valve
A0017	Compressor
A0018	Glow element test
A0019	Blower motor test (0%-100%)
A0020	Metering pump test
A0021	Lighting
A0022	Miscellaneous
A0023	Exhaust gas recirculation
A0024	Blower
A0025	Flaps
A0026	Valves
A0027	Entrance and side wall heater
A0028	Other outputs
A0029	functions refrigerant circuit without engine
A0030	Compressor clutch ON/OFF
A0031	Compressor clutch does not disengage
A0032	Solenoid valve ON/OFF
A0033	Solenoid valve does not disengage
A0034	Solenoid valve does not engage
A0035	Recirculation ventilation flap
A0036	Bypass flap
A0037	Solenoid valve
A0038	Stepper motor valve B
A0039	Stepper motor valve C
A0040	Main pump
A0041	Recirculating pump